

ZEBRA SETTING	166
ZEBRA LEVEL	166
AUDIO SETTING	167
MIC/REMOTE RELEASE	168
TIME CODE SETTING	169
TALLY LIGHT	171
MOVIE SILENT CONTROL	172

7 Playback and the Playback Menu 173

The Playback Display	174
The DISP/BACK Button	175
Viewing Pictures	177
Playback Zoom	178
Multi-Frame Playback	178
The Playback Menu	179
RAW CONVERSION	179
ERASE	182
CROP	184
RESIZE	185
PROTECT	186
IMAGE ROTATE	187
RED EYE REMOVAL	188
VOICE MEMO SETTING	189
RATING	190
IMAGE TRANSFER ORDER	191
WIRELESS COMMUNICATION	192
SLIDE SHOW	192
PHOTOBOOK ASSIST	193
PC AUTO SAVE	194
PRINT ORDER (DPOF)	195
instax PRINTER PRINT	196
DISP ASPECT	197

8 The Setup Menus 199

USER SETTING	200
FORMAT	200
DATE/TIME	201
TIME DIFFERENCE	201