


Setup Menu

Adjust basic camera settings.

 See page 331 for details.

	USER SETTING			SOUND SETTING	
1½	FORMAT	332	1½	AF BEEP VOL.	338
	AREA SETTING	333		SELF-TIMER BEEP VOL.	338
	DATE/TIME	333		OPERATION VOL.	339
	TIME DIFFERENCE	334		REC START/STOP VOLUME	339
	言語/LANG.	335		MS EF ELECTRONIC SHUTTER VOLUME	339
	MY MENU SETTING	335		MS EF ELECTRONIC SHUTTER SOUND	340
	MY MENU SETTING	335		ES ELECTRONIC SHUTTER VOLUME	340
2½	SENSOR CLEANING	336	2½	ES ELECTRONIC SHUTTER SOUND	340
	BATTERY AGE	336		PLAYBACK VOLUME	341
	RESET	337		4ch AUDIO PLAYBACK	341
	REGULATORY	337			