

## FUNCTION (Fn) SETTING

Choose the roles played by the function buttons (📖 385).

## COMMAND DIAL SETTING

Choose the roles played by the command dials.

Option	Description
<b>FRONT COMMAND DIAL 1</b>	Assign shutter speed ( <b>S.S. (PROGRAM SHIFT)</b> ) or aperture ( <b>APERTURE</b> )* to <b>FRONT COMMAND DIAL 1</b> .
<b>FRONT COMMAND DIAL 2</b>	Assign shutter speed ( <b>S.S. (PROGRAM SHIFT)</b> ), aperture ( <b>APERTURE</b> )*, exposure compensation ( <b>EXPOSURE COMPENSATION</b> ), sensitivity ( <b>ISO</b> ), or no role ( <b>NONE</b> ) to <b>FRONT COMMAND DIAL 2</b> or <b>FRONT COMMAND DIAL 3</b> .
<b>FRONT COMMAND DIAL 3</b>	
<b>REAR COMMAND DIAL</b>	Assign shutter speed ( <b>S.S. (PROGRAM SHIFT)</b> ), aperture ( <b>APERTURE</b> )*, exposure compensation ( <b>EXPOSURE COMPENSATION</b> ), sensitivity ( <b>ISO</b> ), or no role ( <b>NONE</b> ) to the rear command dial.
<b>EXP. COMPENSATION ASSIGNMENT</b>	Exposure compensation can be adjusted using either or both of the front and rear command dials while the function button assigned to exposure compensation is pressed.

\* Aperture ring rotated to **A** or **C** in mode **A** (aperture-priority AE) or **M** (manual).



- **COMMAND DIAL SETTING** can also be accessed by pressing and holding the center of the front command dial.
- You can also press the center of the front command dial to cycle through settings in the order **FRONT COMMAND DIAL 1**, **FRONT COMMAND DIAL 2**, and **FRONT COMMAND DIAL 3**.