


## REC START/STOP VOLUME


Choose the volume at the start and end of movie recording.

### Options

 (high)

 (medium)

 (low)

 OFF (mute)

## MS ELECTRONIC SHUTTER VOLUME

Adjust the volume of the sounds produced by the mechanical shutter.

### Options

 (high)

 (medium)

 (low)

 OFF (mute)

## MS ELECTRONIC SHUTTER SOUND

Choose the sound made by the mechanical shutter.

### Options

 1 SOUND 1

 2 SOUND 2

 3 SOUND 3