

The Q (Quick Menu) Button.....	247
The Quick Menu Display	247
Viewing and Changing Settings.....	248
Editing the Quick Menu.....	249
The Fn (Function) Buttons	250
Assigning Roles to the Function Buttons.....	252
10 Peripherals and Optional Accessories	255
Optional Accessories	256
The AR-X100 Adapter Ring	256
The LH-X100 Lens Hood	257
PRF-49 and PRF-49S Protective Filters.....	257
Conversion Lenses	258
External Flash Units	260
Flash Settings	261
SYNC TERMINAL	262
SHOE MOUNT FLASH	263
MASTER(OPTICAL)	266
11 Connections	271
HDMI Output	272
Connecting to HDMI Devices	272
Shooting.....	273
Playback.....	273
Wireless Connections (Bluetooth®, Wireless LAN/Wi-Fi)	274
Smartphones and Tablets: FUJIFILM Camera Remote.....	274
Copying Pictures to a Computer: PC AutoSave	276
Connecting via USB.....	277
Connecting to Computers	277
Copying Pictures to a Computer	280
Connecting to Smartphones.....	281
Converting RAW Images: FUJIFILM X RAW STUDIO	284
Backing up and Restoring Camera Settings (FUJIFILM X Acquire).....	284
instax SHARE Printers	285
Establishing a Connection	285
Printing Pictures.....	286