





Sensitivity

Adjust the camera's sensitivity to light.

Set sensitivity using  **SHOOTING SETTING > ISO**.

Option	Description
AUTO1 AUTO2 AUTO3	Sensitivity is automatically adjusted in response to shooting conditions. Different values for DEFAULT SENSITIVITY , MAX. SENSITIVITY , and MIN. SHUTTER SPEED can be chosen for each of AUTO1 , AUTO2 , and AUTO3 (83).
160–12800	Adjust sensitivity manually. Selected value is shown in display.
L (80) L (100) L (125) H (25600) H (51200)	Choose for special situations. Note that mottling may appear in pictures taken at H , while L reduces dynamic range.

-  Sensitivity is not reset when the camera is turned off.
- A  **MOVIE SETTING > ISO** option is available in the movie shooting menu when  (movie) is selected for drive mode.
- Sensitivity can be assigned to the front command dial using  **BUTTON/DIAL SETTING > COMMAND DIAL SETTING** (226).

Adjusting Sensitivity

High values can be used to reduce blur when lighting is poor, while lower values allow slower shutter speeds or wider apertures in bright light; note, however, that mottling may appear in pictures taken at high sensitivities.