


EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu.

- 1 Select  **BUTTON/DIAL SETTING > EDIT/SAVE QUICK MENU** in the  (**SET UP**) tab.
- 2 Choose the number of items displayed in the quick menu. Quick menu save/edit options will be displayed.
- 3 Highlight the item you wish to change and press **MENU/OK**. The following can be assigned to the quick menu.
 - IMAGE SIZE
 - IMAGE QUALITY
 - FILM SIMULATION
 - GRAIN EFFECT
 - COLOR CHROME EFFECT
 - COLOR CHROME FX BLUE
 - DYNAMIC RANGE
 - D RANGE PRIORITY
 - WHITE BALANCE
 - HIGHLIGHT TONE
 - SHADOW TONE
 - COLOR
 - SHARPNESS
 - CLARITY
 - NOISE REDUCTION
 - SELECT CUSTOM SETTING
 - AF MODE (MOVIE AF MODE)
 - AF-C CUSTOM SETTINGS
 - FACE/EYE DETECTION SETTING
 - MF ASSIST
 - TOUCH SCREEN MODE
 - SELF-TIMER
 - PHOTOMETRY
 - SHUTTER TYPE
 - FLICKER REDUCTION
 - CONVERSION LENS
 - ND FILTER
 - FLASH FUNCTION SETTING
 - FLASH COMPENSATION
 - MOVIE MODE
 - FULL HD HIGH SPEED REC
 - INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
 - SOUND & FLASH
 - EVF/LCD BRIGHTNESS
 - EVF/LCD COLOR
 - NONE

-  • Select **NONE** to assign no option to the selected position.
- When **SELECT CUSTOM SETTING** is selected, current settings are shown in the quick menu by the label **BASE**.