

Bit Rate

Choose the movie bit rate.

| Options | | | |
|---------|---------|---------|---------|
| 50Mbps | 100Mbps | 200Mbps | 360Mbps |



The options available for bit rate vary with the settings chosen for high-speed movie recording and compression. The actual bit rate may be slower than the selected value depending on the subject.

HDMI OUTPUT SETTING

Adjust settings for use when the shooting display is output to an HDMI device.

HDMI OUTPUT INFO DISPLAY

If **ON** is selected, HDMI devices to which the camera is connected will mirror the information in the camera display.

| Options | |
|---------|-----|
| ON | OFF |

HDMI REC CONTROL

Choose whether the camera sends movie start and stop signals to the HDMI device when the shutter button is pressed to start and stop movie recording.

| Options | |
|---------|-----|
| ON | OFF |