









AF MODE

Choose the AF mode for focus modes **S** and **C**.

Option	Description
 SINGLE POINT	<p>The camera focuses on the subject in the selected focus point. The number of focus points available can be selected using  AF/MF SETTING > NUMBER OF FOCUS POINTS. Use for pin-point focus on a selected subject.</p>
 ZONE	<p>The camera focuses on the subject in the selected focus zone. Focus zones include multiple focus points, making it easier to focus on subjects that are in motion.</p>
 WIDE/TRACKING	<ul style="list-style-type: none"> • In focus mode S, the camera automatically focuses on high-contrast subjects; the areas in focus are shown in the display. • In focus mode C, the camera tracks focus on the subject in the selected focus point while the shutter button is pressed halfway. <p>The camera may be unable to focus on small objects or subjects that are moving rapidly.</p>
 ALL	<p>Rotate the rear command dial in the focus-point selection display (📖 70, 71) to cycle through AF modes in the following order:  SINGLE POINT,  ZONE, and  WIDE/TRACKING.</p>