


Viewing and Changing Settings


- 1 Press **Q** to display the quick menu during shooting.



- 2 Use the focus stick (focus lever) to highlight items.




- 3 Rotate the front command dial to change.



 To jump to the **EDIT/SAVE CUSTOM SETTING** menu, press and hold the **Q** button when the quick menu is displayed.

- 4 Press **Q** to exit when settings are complete.

-  The quick menu can also be edited using touch controls.
- Using **2 BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING**, you can assign the **Q** button roles normally reserved for the function buttons or assign the **Q** button's default role to a function button (253).
- To disable the **Q** (quick menu) button, select **NONE** for **2 BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING > Q BUTTON SETTING**.