

Problem	Solution
The flash does not fire.	<ul style="list-style-type: none">• The flash is disabled: Adjust settings (📖 180).• The electronic shutter is enabled: Choose a SHUTTER TYPE that does not use the electronic shutter (📖 170).• The battery is exhausted: Charge the battery or insert a fully-charged spare battery (📖 42).• The camera is in bracketing or continuous mode: Select single frame mode (📖 6).
The flash does not fully light the subject.	<ul style="list-style-type: none">• The subject is not in range of the flash: Position the subject in range of the flash.• The flash window is obstructed: Hold the camera correctly.• Shutter speed is faster than the sync speed: Choose a slower shutter speed (📖 74, 80, 398).