






Problem	Solution
The battery runs down quickly.	<ul style="list-style-type: none"> • The battery is cold: Warm the battery by placing it in a pocket or other warm place and reinsert it in the camera immediately before taking a picture. • There is dirt on the battery terminals: Clean the terminals with a soft, dry cloth. • ON is selected for  AF/MF SETTING > PRE-AF: Turn PRE-AF off ( 149). • The battery has been charged many times: Select BATTERY AGE to view the battery age; if the battery is old, replace it with a new battery ( 276).
The camera turns off suddenly.	The battery is exhausted: Charge the battery or insert a fully-charged spare battery ( 42).
The camera does not turn off.	The camera may be busy. Check the indicator lamp ( 9).