



Table of Contents

Introduction	ii
For the Latest Information	ii
Menu List	iv
Shooting Menus	iv
The Playback Menu	viii
Setup Menus	ix
The Network/USB Settings Menu	xii
Supplied Accessories	xxvii
About This Manual	xxviii
Symbols and Conventions	xxviii
Terminology	xxviii

1 Before You Begin **1**

Parts of the Camera	2
The Serial Number Plate	6
The Memory Card Slot Cover (Detachable)	6
The Focus Stick (Focus Lever)	6
The Mode Dial	7
The STILL/MOVIE Mode Switch	8
The DRIVE Button	8
The Command Dials	9
The Indicator Lamp	10
The LCD Monitor	11
The Viewfinder	12
Attaching the Viewfinder	13
The Eye Cup	14
Focusing the Viewfinder	15
Camera Displays	16
The Electronic Viewfinder	16
The LCD Monitor	18
Choosing a Display Mode	20
Adjusting Display Brightness	22
Display Rotation	22
The DISP/BACK Button	22