

## TOUCH SCREEN SETTING

Enable or disable touch-screen controls.

### TOUCH SCREEN SETTING

| Option     | Description  |
|------------|--|
| <b>ON</b>  | The LCD monitor functions as a touch screen during shooting. |
| <b>OFF</b> | Touch controls disabled.                                     |

### DOUBLE TAP SETTING

| Option     | Description   |
|------------|---|
| <b>ON</b>  | Tap the LCD monitor twice to zoom in on your subject during shooting. |
| <b>OFF</b> | Touch zoom disabled.  |

### TOUCH FUNCTION

| Option     | Description                      |
|------------|----------------------------------|
| <b>ON</b>  | Enable touch-function gestures.  |
| <b>OFF</b> | Disable touch-function gestures. |

### TOUCH SCREEN SETTING

| Option     | Description  |
|------------|--|
| <b>ON</b>  | The LCD monitor functions as a touch screen during playback. |
| <b>OFF</b> | Touch controls disabled.                                     |