

Using an external SSD in place of a memory card

This camera can save still images and movies to an SSD. If an SSD is connected to the USB connector, an icon appears on the screen, and the recording destination is switched to the SSD automatically. To record to a memory card, turn off the camera, and then remove the SSD.



Even when an SSD is connected, you can select the SSD or a memory card for playback by **▢ PLAY BACK MENU > SWITCH SLOT.**