

Problem	Solution
No face is detected.	<ul style="list-style-type: none"> • The subject's face is obscured by sunglasses, a hat, long hair, or other objects: Remove the obstructions (📖 153). • The subject's face occupies only a small area of the frame: Change the composition so that the subject's face occupies a larger area of the frame (📖 153). • The subject's face is turned away from the camera: Ask the subject to face the camera (📖 153). • 👤 FACE/EYE DETECTION SETTING is off: Turn 👤 FACE/EYE DETECTION SETTING on (📖 153). • The camera is tilted: Keep the camera level. • The subject's face is poorly lit: Shoot in better light.
No subject is detected.	<ul style="list-style-type: none"> • The subject is partially hidden: Choose a vantage point where you can see as much of the subject as possible (📖 155). • The subject occupies only a small portion of the frame: Get closer to your subject so it occupies more of the frame (📖 155). • OFF is selected for SUBJECT DETECTION SETTING: Select SUBJECT DETECTION ON (📖 155). • The subject is poorly lit: Shoot in better light.
The flash does not fire.	<ul style="list-style-type: none"> • The flash is disabled: Adjust settings (📖 174). • The electronic shutter is enabled: Choose a SHUTTER TYPE that does not use the electronic shutter (📖 170). • The battery is exhausted: Charge the battery or insert a fully-charged spare battery (📖 50). • The camera is in bracketing or continuous mode: Select single frame mode (📖 8).