

AE/AF-LOCK MODE

This option determines the behavior of the button to which exposure and/or focus lock is assigned.

| Option | Description |
|-----------------------------------|---|
| AE&AF ON WHEN PRESSING | Exposure and/or focus will lock while the button is pressed. |
| AE&AF ON/OFF SWITCH | Exposure and/or focus will lock when the button is pressed and remain locked until it is pressed again. |

AWB-LOCK MODE

Choose the behavior of function buttons assigned auto white balance (AWB) lock. Auto white balance lock is used to lock white balance at the value metered by the camera when **AUTO** is selected for white balance.

| Option | Description |
|-----------------------------|---|
| AWB ON WHEN PRESSING | Auto white balance locks while the button is pressed. |
| AWB ON/OFF SWITCH | Press the button once to lock auto white balance and again to end the lock. |

APERTURE RING SETTING (A)

Choose whether the front command dial can be used to adjust aperture when aperture is set to **A** (auto).

| Option | Description |
|----------------|--|
| AUTO | The camera adjusts aperture automatically. |
| COMMAND | Aperture can be adjusted using the front command dial. |