


FLICKERLESS S.S. SETTING


Select **ON** to allow shutter speed to be fine-tuned to reduce flicker caused by LED lighting and the like.


| Options | |
|---------|-----|
| ON | OFF |

 This option takes effect only in modes **S** and **M**.

IS MODE

Turn image stabilization on or off.

| Option | Description |
|----------------------|--|
| CONTINUOUS | Image stabilization on. |
| SHOOTING ONLY | Image stabilization enabled only when the shutter button is pressed halfway (focus mode C) or the shutter is released. |
| OFF | Image stabilization off;  appears in the display. |

-  The setting selected with the lens image stabilization switch, if any, takes priority over the setting chosen with **IS MODE**.
- Note that vibration or camera sounds may be noticeable as image stabilization takes effect.