





Adjusting Movie Settings

Movie settings can be adjusted from the movie menus or using the  **MOVIE SETTING** item in the photo menus (📖 19).

- A simplified menu of movie settings can be accessed via the  **MOVIE SETTING** item in the photo menus (📖 152).
- The movie menus contain options for use when recording movies via the shutter button with **MOVIE** selected in the drive-mode menu (📖 155).

 Changes made using the  **MOVIE SETTING** item in the photo menus also apply to the movie menus. Changes made in one set of menus automatically apply in the other.

Depth of Field

To soften backgrounds, set aperture as wide as possible. Aperture can be adjusted directly in modes **A** (aperture-priority AE) and **M** (manual).