

home of **Locus**
ENERGY



skytron®

DiGi WR21/31 Modem Basics

06/03/2022

Table of Contents

Table of Contents.....	2
Outline	3
Lan Settings.....	3
How to arp -a (AKA LAN IP/MAC Table)	4
How to Ping	4
How to Create Port Forwards.....	5
Signal Strength/Quality	5
ICCID/IMEI.....	6
APN Settings	7

Outline

In this document you will find screenshots outlining how to find common settings and other information in a DiGi WR21/31 modem.

Lan Settings

DiGi TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Configuration - Network > Interfaces > Ethernet > ETH 0

1. Network in sidebar menu

2. Interfaces in breadcrumb

3. Ethernet in breadcrumb

4. ETH 0 in breadcrumb

5. Static IP settings (IP Address, Mask, Gateway, DNS Server, Secondary DNS Server)

6. Apply button

7. Configuration successfully applied. Click [here](#) to save configuration.

DiGi TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Configuration - Network > IP Routing/Forwarding > IP Port Forwarding/Static NAT Mappings

Save current configuration to Config 0 (power up)

Save

Save all configuration. This includes the following

- Save the current configuration to config 0
- Save the current firewall
- Save all registers on all ports to profile 0
- Save all PAD parameters on all PADs to profile 0

1. Save All button

How to arp -a (AKA LAN IP/MAC Table)



TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Home

Wizards

Configuration

Network

Alarms

System

Remote Management

Security

Telemetry

Applications

Basic

Python

Management

Network Status

Connections

Telemetry

Event Log

Analyser

Top Talkers

Administration

System Information

File Management

X.509 Certificate Management

Backup/Restore

Update Firmware

Factory Default Settings

Execute a command

Save configuration

Reboot

Administration - Execute a command

Command:

Execute

Command: arp -a

Command result

```

ARP Cache Size:100 entries, old entries reused:0 no arp matches:324
ETH 0:
IP Address      Physical Address  Expiry   Retries   State
192.168.2.51    00-1e-c6-05-0b-8e 251      3         found
nb of entries:1
nb of entries:0
nb of entries:0
nb of entries:0
nb of entries:0
nb of entries:0
nb of entries:0
nb of entries:0
nb of entries:0
nb of entries:0
OK

```

Copyright © Digi International Inc. All rights reserved.

How to Ping



TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Home

Wizards

Configuration

Network

Alarms

System

Remote Management

Security

Telemetry

Applications

Basic

Python

Management

Network Status

Connections

Telemetry

Event Log

Analyser

Top Talkers

Administration

System Information

File Management

X.509 Certificate Management

Backup/Restore

Update Firmware

Factory Default Settings

Execute a command

Save configuration

Reboot

Administration - Execute a command

Command:

Execute

Command: ping 192.168.2.51

Command result

```

Pinging Addr [192.168.2.51]
Sent PING # 1
PING receipt # 1 : response time 0.00 seconds
Iface: ETH 0
Ping Statistics
Sent      : 1
Received  : 1
Success   : 100 %
Average RTT : 0.00 seconds
OK

```

Copyright © Digi International Inc. All rights reserved.

How to Create Port Forwards



TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Home

Wizards

Configuration

Network

Alarms

System

Remote Management

Security

Telemetry

Applications

Basic

Python

Management

Network Status

Connections

Telemetry

Event Log

Analysers

Top Talkers

Administration

System Information

File Management

X.509 Certificate Management

Backup/Restore

Update Firmware

Factory Default Settings

Execute a command

Save configuration

Reboot

Configuration - Network > IP Routing/Forwarding > IP Port Forwarding/Static NAT Mappings

Interfaces

DHCP Server

Network Services

DNS Servers

Dynamic DNS

IP Routing/Forwarding

IP Routing

Static Routes

RIP

OSPF

BGP

IP Port Forwarding/Static NAT Mappings

Forward connections from external networks to the following internal devices.

In order to forward to an internal port, an interface must have its NAT configuration set to "IP address and Port".

(you may configure up to 30 forwarding rules):

External Min Port	External Max Port	Forward to Internal IP Address	Forward to Internal Port	
1021	1021	192.168.2.51	80	Delete
4361	4361	192.168.2.161	443	Delete
				Add

Apply

Configuration successfully applied. Click [here](#) to save configuration.

TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Home

Wizards

Configuration

Network

Alarms

System

Remote Management

Security

Telemetry

Configuration - Network > IP Routing/Forwarding > IP Port Forwarding/Static NAT Mappings

Save current configuration to Config 0 (power up)

Save

Save all configuration. This includes the following

- Save the current configuration to config 0
- Save the current firewall
- Save all registers on all ports to profile 0
- Save all PAD parameters on all PADS to profile 0

Save All

Signal Strength/Quality

TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Home

System

LEDs

Device Cloud

Interfaces

Cellular

GPIO

Model: Transport WR31

Part Number: WR31-LS2A-DE1-TB

Serial Number: 745647

Firmware Version: 7.0.3.5 (Mar 7 2019 06:58:57)

Image Number: 0

Boot Version: 7.65u

Uptime: 2 hours 38 minutes 26 seconds

System Time: 3 Jun 2022 15:37:59

CPU Utilization: 12% (Min: 1%, Max: 94%, Avg: 2%)

Temperature: 43°C (CPU), 36°C (internal)

Description:

Contact:

Location:

Power: ON

Service: ON

WWAN: ON

Signal 1: ON

Signal 2: ON

Signal 3: ON

Server: my.devicecloud.com

Status: Disabled

Device ID: 00000000-00000000-00042DFF-FF0860AF

Uptime: 0 seconds

Data Received: 0 Bytes

Data Sent: 0 Bytes

Ethernet 0: ON

Ethernet 1: ON

Cellular: ON

Module: MC7354

SIM: Detected (using SIM 1)

Signal Strength: Fair (-109 dBm)

Signal Quality: Excellent (-4 dB)

Uptime: 2 Hours 37 Minutes 41 Seconds

Temperature: 32°C

IP address: 10.0.3.187

DNS Server: 166.216.138.41

Data Received: 260.21 KB

Data Sent: 604.20 KB

Analog Mode: Current

Analog Value: 0.0231 mA

Analog Current Calibration Low: Uncalibrated

Analog Current Calibration High: Uncalibrated

Analog Voltage Calibration Low: Uncalibrated

Analog Voltage Calibration High: Uncalibrated

Digital 0 Input: HIGH (inactive)

Digital 0 Output: OFF

Digital 0 Pullup: ON

Digital 1 Input: HIGH (inactive)

Digital 1 Output: OFF

Digital 1 Pullup: ON

ALSOENERGY INC - 5400 AIRPORT BLVD STE 100 - BOULDER, CO 80301 - WWW.ALSOENERGY.COM - 866-303-5668 - v1

5

ICCID/IMEI



TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Home

Home

Wizards

Configuration

Network

Alarms

System

Remote Management

Security

Telemetry

Applications

Basic

Python

Management

Network Status

Connections

Telemetry

Event Log

Analysier

Top Talkers

Administration

System Information

File Management

X.509 Certificate Management

Backup/Restore

Update Firmware

Factory Default Settings

Execute a command

Save configuration

Reboot

Logout

System

LEDs

Device Cloud

Interfaces

Cellular

GPIO

Model: Transport WR31

Part Number: WR31-LED3-DE1-TB

Serial Number: 745647

FW Version: 7.0.3.5 (Mar 7 2019 06:58:57)

Image Number: 0

Boot Version: 7.86u

Uptime: 2 hours 34 minutes 17 seconds

System Time: 3 Jun 2022 15:33:50

CPU Utilization: 28% (Min: 1%, Max: 94%, Avg: 6%)

Temperature: 43°C (CPU), 36°C (Internal)

Description:

Contact:

Location:

Power: ●

Service: ●

WWAN: ●

Signal 1: ●

Signal 2: ●

Signal 3: ●

Server: my.devicecloud.com

Status: Disabled

Device ID: 00000000-00000000-000420FF-FF0B60AF

Uptime: 0 seconds

Data Received: 0 Bytes

Data Sent: 0 Bytes

Ethernet 0: ●

Ethernet 1: ●

Cellular: ●

Module: MC7354

SIM: Detected (using SIM 1)

Signal Strength: Fair (-109 dBm)

Signal Quality: Excellent (-8 dB)

Uptime: 2 Hours 33 Minutes 32 Seconds

Temperature: 32°C

IP Address: 10.0.3.187

DNS Server: 166.216.138.41

Data Received: 214.25 KB

Data Sent: 473.98 KB

Analog Mode: Current

Analog Value: 0.0231 mA

Analog Current Calibration Low: Uncalibrated

Analog Current Calibration High: Uncalibrated

Analog Voltage Calibration Low: Uncalibrated

Analog Voltage Calibration High: Uncalibrated

Digital 0 Input: HIGH (inactive)

Digital 0 Output: OFF

Digital 0 Pullup: ON

Digital 1 Input: HIGH (inactive)

Digital 1 Output: OFF

Digital 1 Pullup: ON



TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Management - Network Status > Interfaces > Mobile

Home

Wizards

Configuration

Network

Alarms

System

Remote Management

Security

Telemetry

Applications

Basic

Python

Management

Network Status

Connections

Telemetry

Event Log

Analysier

Top Talkers

Administration

System Information

File Management

X.509 Certificate Management

Backup/Restore

Update Firmware

Factory Default Settings

Execute a command

Save configuration

Reboot

Logout

Ethernet

Mobile

The following information and statistics can be used to manage and monitor your mobile connection. This information may also be helpful in troubleshooting problems with the mobile network.

Mobile Connection

Registration Status: Registered tac:9611 ci:05E05F16

Signal Strength: Fair (-109 dBm)

Signal Quality: Excellent (-8 dB)

Connection type: NDIS

Mobile Statistics

IP Address: 10.0.3.187

Primary DNS Address: 166.216.138.41

Secondary DNS Address: 166.216.138.42

Data Received: 233.89 KB

Data Sent: 513.56 KB

Mobile Information

Results of Last Module Status Poll at 3 Jun 2022 15:34:22

Outcome: Got modem status OK

SIM status: Ready (PIN checking disabled)

Signal strength: -80 dBm

Radio technology: LTE

Signal quality (LTE): RSSI -80 dBm, RSRP -109 dBm, RSRQ -8 dB, SINR 5.6 dB

Radio band: E-UTRA Operating Band 4

Channel: 2225

Manufacturer: Sierra Wireless, Incorporated

Model: MC7354

IMEI: 353968092052530

ESN: 8075E3CB

MEID: 35396809205253

IMSI: 310410170651382

MDN: 15334536375

ICCID: 89014104271706513824

ALSOENERGY INC - 5400 AIRPORT BLVD STE 100 - BOULDER, CO 80301 - WWW.ALSOENERGY.COM - 866-303-5668 - v1

6

APN Settings



TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Home

Wizards

Configuration

Network

Alarms

System

Remote Management

Security

Telemetry

Applications

Basic

Python

Management

Network Status

Connections

Telemetry

Event Log

Analysers

Top Talkers

Administration

System Information

File Management

X.509 Certificate Management

Backup/Restore

Update Firmware

Factory Default Settings

Execute a command

Save configuration

Reboot

Logout

Configuration - Network > Interfaces > Mobile

Interfaces

Ethernet

Mobile

Select a to configure from the list below

Settings on this page apply to the selected SIM

SIM: 1 (PPP 1)

IMSI: 310410170651382

Mobile Settings

Select the service plan and connection settings used in connecting to the mobile network.

Mobile Service Provider Settings

Service Plan / APN: 14112.mcs

☐ Select APN automatically
 ☐ Use backup APN

Retry the main APN after 0 minutes

SIM PIN: (Optional)

Confirm SIM PIN:

Username: (Optional)

Password: (Optional)

Confirm Password:

Mobile Connection Settings

☐ Re-establish connection when no data is received for a period of time

Mobile Network Settings

☒ Enable NAT on this interface

☒ IP address ☐ IP address and Port

☐ Enable IPsec on this interface

☐ Enable the firewall on this interface

Mobile Firmware (OTA) Update

SIM Selection

Advanced

SMS Settings

Apply

Configuration successfully applied. Click [here](#) to save configuration.



TRANSPORT WR31 (SN: 745647) CONFIGURATION AND MANAGEMENT

User : admin

Home

Wizards

Configuration

Network

Alarms

System

Remote Management

Security

Telemetry

Configuration - Network > IP Routing/Forwarding > IP Port Forwarding/Static NAT Mappings

Save current configuration to Config 0 (power up)

Save

Save all configuration. This includes the following

- Save the current configuration to config 0
- Save the current firewall
- Save all registers on all ports to profile 0
- Save all PAD parameters on all PADs to profile 0

Save All