



Display cluster connections

ONTAP 9

aherbin
April 27, 2021

Table of Contents

- Display cluster connections 1
 - Display active connections by client (cluster administrators only) 1
 - Display active connections by protocol (cluster administrators only) 2
 - Display active connections by service (cluster administrators only) 3
 - Display active connections by LIF on a node and SVM 4
 - Display active connections in a cluster 5
 - Display listening connections in a cluster 6

Display cluster connections

You can display all the active connections in the cluster or a count of active connections on the node by client, logical interface, protocol, or service. You can also display all the listening connections in the cluster.

Display active connections by client (cluster administrators only)

You can view the active connections by client to verify the node that a specific client is using and to view possible imbalances between client counts per node.

About this task

The count of active connections by client is useful in the following scenarios:

- Finding a busy or overloaded node.
- Determining why a particular client's access to a volume is slow.

You can view details about the node that the client is accessing and then compare it with the node on which the volume resides. If accessing the volume requires traversing the cluster network, clients might experience decreased performance because of the remote access to the volume on an oversubscribed remote node.

- Verifying that all nodes are being used equally for data access.
- Finding clients that have an unexpectedly high number of connections.
- Verifying whether certain clients have connections to a node.

Step

Display a count of the active connections by client on a node by using the `network connections active show-clients` command.

For more information about this command, see the man page: [ONTAP 9 commands](#)

```

network connections active show-clients
Node      Vserver Name      Client IP Address      Count
-----
node0     vs0                192.0.2.253            1
          vs0                192.0.2.252            2
          Cluster        192.10.2.124           5
node1     vs0                192.0.2.250            1
          vs0                192.0.2.252            3
          Cluster        192.10.2.123           4
node2     vs1                customer.example.com    1
          vs1                192.0.2.245            3
          Cluster        192.10.2.122           4
node3     vs1                customer.example.org    1
          vs1                customer.example.net    3
          Cluster        192.10.2.121           4

```

Display active connections by protocol (cluster administrators only)

You can display a count of the active connections by protocol (TCP or UDP) on a node to compare the usage of protocols within the cluster.

About this task

The count of active connections by protocol is useful in the following scenarios:

- Finding the UDP clients that are losing their connection.

If a node is near its connection limit, UDP clients are the first to be dropped.

- Verifying that no other protocols are being used.

Step

Display a count of the active connections by protocol on a node by using the `network connections active show-protocols` command.

For more information about this command, see the man page.

```

network connections active show-protocols
Node      Vserver Name  Protocol  Count
-----
node0
          vs0      UDP        19
          Cluster  TCP        11
node1
          vs0      UDP        17
          Cluster  TCP         8
node2
          vs1      UDP        14
          Cluster  TCP        10
node3
          vs1      UDP        18
          Cluster  TCP         4

```

Display active connections by service (cluster administrators only)

You can display a count of the active connections by service type (for example, by NFS, SMB, mount, and so on) for each node in a cluster. This is useful to compare the usage of services within the cluster, which helps to determine the primary workload of a node.

About this task

The count of active connections by service is useful in the following scenarios:

- Verifying that all nodes are being used for the appropriate services and that the load balancing for that service is working.
- Verifying that no other services are being used. Display a count of the active connections by service on a node by using the `network connections active show-services` command.

For more information about this command, see the man page: [ONTAP 9 commands](#)

```

network connections active show-services
Node      Vserver Name      Service      Count
-----
node0
      vs0          mount         3
      vs0          nfs           14
      vs0          nlm_v4        4
      vs0          cifs_srv      3
      vs0          port_map      18
      vs0          rclopcp       27
      Cluster      ctlopcp       60
node1
      vs0          cifs_srv      3
      vs0          rclopcp       16
      Cluster      ctlopcp       60
node2
      vs1          rclopcp       13
      Cluster      ctlopcp       60
node3
      vs1          cifs_srv      1
      vs1          rclopcp       17
      Cluster      ctlopcp       60

```

Display active connections by LIF on a node and SVM

You can display a count of active connections for each LIF, by node and storage virtual machine (SVM), to view connection imbalances between LIFs within the cluster.

About this task

The count of active connections by LIF is useful in the following scenarios:

- Finding an overloaded LIF by comparing the number of connections on each LIF.
- Verifying that DNS load balancing is working for all data LIFs.
- Comparing the number of connections to the various SVMs to find the SVMs that are used the most.

Step

Display a count of active connections for each LIF by SVM and node by using the `network connections active show-lifs` command.

For more information about this command, see the man page: [ONTAP 9 commands](#)

```

network connections active show-lifs
Node      Vserver Name  Interface Name  Count
-----
node0
    vs0        datalif1        3
    Cluster    node0_clus_1    6
    Cluster    node0_clus_2    5
node1
    vs0        datalif2        3
    Cluster    node1_clus_1    3
    Cluster    node1_clus_2    5
node2
    vs1        datalif2        1
    Cluster    node2_clus_1    5
    Cluster    node2_clus_2    3
node3
    vs1        datalif1        1
    Cluster    node3_clus_1    2
    Cluster    node3_clus_2    2

```

Display active connections in a cluster

You can display information about the active connections in a cluster to view the LIF, port, remote host, service, storage virtual machines (SVMs), and protocol used by individual connections.

About this task

Viewing the active connections in a cluster is useful in the following scenarios:

- Verifying that individual clients are using the correct protocol and service on the correct node.
- If a client is having trouble accessing data using a certain combination of node, protocol, and service, you can use this command to find a similar client for configuration or packet trace comparison.

Step

Display the active connections in a cluster by using the `network connections active show` command.

For more information about this command, see the man page: [ONTAP 9 commands](#)

The following command shows the active connections on the node node1:

```
network connections active show -node node1
```

| Vserver | Interface | Remote | |
|-------------|--------------------|--------------------|------------------|
| Name | Name:Local Port | Host:Port | Protocol/Service |
| ----- | ----- | ----- | ----- |
| Node: node1 | | | |
| Cluster | node1_clus_1:50297 | 192.0.2.253:7700 | TCP/ctlopcp |
| Cluster | node1_clus_1:13387 | 192.0.2.253:7700 | TCP/ctlopcp |
| Cluster | node1_clus_1:8340 | 192.0.2.252:7700 | TCP/ctlopcp |
| Cluster | node1_clus_1:42766 | 192.0.2.252:7700 | TCP/ctlopcp |
| Cluster | node1_clus_1:36119 | 192.0.2.250:7700 | TCP/ctlopcp |
| vs1 | data1:111 | host1.aa.com:10741 | UDP/port-map |
| vs3 | data2:111 | host1.aa.com:10741 | UDP/port-map |
| vs1 | data1:111 | host1.aa.com:12017 | UDP/port-map |
| vs3 | data2:111 | host1.aa.com:12017 | UDP/port-map |

The following command shows the active connections on SVM vs1:

```
network connections active show -vserver vs1
```

| Vserver | Interface | Remote | |
|-------------|-----------------|--------------------|------------------|
| Name | Name:Local Port | Host:Port | Protocol/Service |
| ----- | ----- | ----- | ----- |
| Node: node1 | | | |
| vs1 | data1:111 | host1.aa.com:10741 | UDP/port-map |
| vs1 | data1:111 | host1.aa.com:12017 | UDP/port-map |

Display listening connections in a cluster

You can display information about the listening connections in a cluster to view the LIFs and ports that are accepting connections for a given protocol and service.

About this task

Viewing the listening connections in a cluster is useful in the following scenarios:

- Verifying that the desired protocol or service is listening on a LIF if client connections to that LIF fail consistently.
- Verifying that a UDP/rclopcp listener is opened at each cluster LIF if remote data access to a volume on one node through a LIF on another node fails.
- Verifying that a UDP/rclopcp listener is opened at each cluster LIF if SnapMirror transfers between two nodes in the same cluster fail.
- Verifying that a TCP/ctlopcp listener is opened at each intercluster LIF if SnapMirror transfers between two nodes in different clusters fail.

Step

Display the listening connections per node by using the `network connections listening show` command.

network connections listening show

| Vserver Name | Interface Name:Local Port | Protocol/Service |
|--------------|---------------------------|------------------|
| ----- | ----- | ----- |
| Node: node0 | | |
| Cluster | node0_clus_1:7700 | TCP/ctlopcp |
| vs1 | data1:4049 | UDP/unknown |
| vs1 | data1:111 | TCP/port-map |
| vs1 | data1:111 | UDP/port-map |
| vs1 | data1:4046 | TCP/sm |
| vs1 | data1:4046 | UDP/sm |
| vs1 | data1:4045 | TCP/nlm-v4 |
| vs1 | data1:4045 | UDP/nlm-v4 |
| vs1 | data1:2049 | TCP/nfs |
| vs1 | data1:2049 | UDP/nfs |
| vs1 | data1:635 | TCP/mount |
| vs1 | data1:635 | UDP/mount |
| Cluster | node0_clus_2:7700 | TCP/ctlopcp |

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.