


## 2. INSTALLATION INSTRUCTIONS

### 2-1. HOW TO ADJUST LEVEL

**1**

#### Installation area


- Install the washer on a firm, flat surface.
- If the washer is installed on an unsuitable floor, it could make considerable noise and vibrate.




**3**

#### Checking level

- Open the lid, check if the washer is correctly leveled by looking down from the top. If the tub is not centered in the opening, then the washer is not level.



WRONG





RIGHT

**2**

#### Set Leveling feet


- Loosen the locknuts on 2 front leveling feet until you can turn the feet with the included wrench. Turn clockwise to raise the washer or counterclockwise to lower it.



**4**

#### Checking slope

- If installation surface is tilted, the washer will vibrate. Do not install on a sloping floor.



**No shims. It would be dangerous. If the floor is that far from being level, it is a floor problem and not a washer problem.**

### **⚠ CAUTION**

- The ventilating openings in the base area must not be obstructed by carpeting.
  - Install the washing machine on a level and firm surface. There should be no more than 1° of variation.
  - Wooden floors may need reinforcing to prevent the normal vibration which occurs with an unbalanced load.
  - Do not install the washer on an inclined floor.
- Improper installation of the washer may cause noise and malfunctioning.