

# STM32PRGFW-UTIL Firmware utility to manage One-Time Programmable (OTP) memories

---

## Table of Contents

---

- [Project overview](#)
- [Repository structure](#)
- [How to Use CP\\_Serial\\_Boot](#)
  - [Hardware prerequisites](#)
  - [STM32CubeProgrammer GUI interface](#)
  - [STM32CubeProgrammer CLI interface](#)
  - [OTP Programming](#)
  - [PMIC NVM Programming](#)
- [How to Use Console\\_SH](#)
  - [Hardware prerequisites](#)
  - [STM32CubeIDE Step by Step](#)
- [How to Use Console\\_Uart](#)
  - [Hardware prerequisites](#)
  - [STM32CubeIDE Step by Step](#)
- [Release note](#)
- [Troubleshooting](#)

## Warning

Please use **v1.0.2 tag and later** from now as an important fix done to avoid **bricking your device**.

## Project overview

**STM32PRGFW-UTIL** package provides embedded SW applications to manage the One-Time Programmable (OTP) memories on **STM32MP13xx, STM32MP15xx devices** as described in the following [wiki page](#)

It is **alternative** to the use of **U-Boot embedded SW package** described in article [How to fuse OTP](#) but of course U-Boot services are still available.

This Utility could be usefull during bring-up phase to modify OTP when ecosystem Software (U-Boot in particular) is not ready yet. Indeed, this STM32PRGFW-UTIL firmware is **DDR independant** ; thus it is ready to use in most of cases for your own design.

This package includes only source code required to support UART and USB DFU protocol and OTP programming without more complex software, i.e. easy to adapt and improve for your own needs.


This package contains several "Modes" (CP\_Serial\_Boot, Console\_SH..) that you can use with **Windows® or Linux® host PC**.

Please find below the more appropriated mode depending on your setup.

""How to"" for each mode is described below into this document.

Major Use cases / Setup	CP_Serial_boot (Preferred)	Console_SH	Console_UART	CP_Dev_Boot
* Board with USB DFU or UART serial if * <a href="#">STM32CubeProgrammer</a> PC tool installed (v2.15.0 minimum)	X			
* Board with Debug port * <a href="#">STM32CubeIDE</a> PC tool installed (v1.13.0 minimum)		X		
* Board with Debug port and 1 UART interface * Semihosting (Terminal I/O through debug port) NOT available on PC			X Note: need to modify UART instance in source code if different from ST boards	
* Need to debug your own tool based on this package				X

The functional chart of the project describing all applications mentioned above:




## Repository structure

The **STM32PRGFW-UTIL** repository consists of the following repositories:

- **Drivers:** It contains HAL/LL component per serie and CMSIS Device source code. You can notice there is no BSP as this package is board independent.
- **Middlewares:** It contains OpenBL and USB device library core source code modified for MPU protocols.
- **Projects:** Project directory. It contains 1 STM32CubeIDE project per serie and 1 common project containing source code common to the different projects.

The project structure is described as below:



## How to Use CP\_Serial\_Boot

In this section, you will use "Binary" directory containing a STM32PRGFW-UTIL binary and a tsv file used by STM32CubeProgrammer.

### Hardware prerequisites


- Set boot pins to b000 (BOOT0/1/2 to OFF) position to select **serial boot**

- If you want to use USB DFU interface
  - connect USB cable between PC and the board. PC should test USB DFU interface
- else if you want to use UART interface
  - connect UART cable between PC and the board
    - Note: could be STLink connector if Virtual COM port is connected on the board like ST DK boards
  - **!!! NOTE: USB cable should not be connected if you want to use UART !!! - ROM CODE will USB DFU if both interface are available!**


## STM32CubeProgrammer GUI interface

Please Read STM32CubeProgrammer user manual for further details if needed

- Select Port (USB or UART) depending on the choice you made
- Click on Connect button - STM32CubeProgrammer is now connected to ROM Code
- Select TSV <Your Directory Path>\Projects\<STM32 device>\Binary\FlashLayout\_STM32PRGFW\_UTIL.tsv
- Select Binary Path with Browse Button <Your Directory Path>\Projects\<STM32 device>\Binary\
- Click on Download - STM32CubeProgrammer is now connected to STM32PRGFW-UTIL firmware



- Click on OTP button to get OTP Panel



## STM32CubeProgrammer CLI interface

Please Read STM32CubeProgrammer user manual for further details if needed

- Go to the STM32CubeProgrammer binary directory (i.e. STM32CubeProgrammer-212\bin)
- Open command prompt inside this bin directory
- Run this command to load the STM32PRGFW-UTIL binary in the embedded ram:  
`$STM32_Programmer_CLI.exe -c port=COM <num> -w <Your Directory Path>\Projects\<STM32 device>\Binary\FlashLayout_STM32PRGFW_UTIL.tsv`
- Do not reset the board and execute command - Some command examples where UART interface (COM8) is used:  
`$STM32_Programmer_CLI.exe -c port=COM8 -otp displ`  
`$STM32_Programmer_CLI.exe -c port=COM8 -otp write word=10 value=0x1`

## PMIC NVM Programming

- PMIC NVM can be programmed in serial boot mode using USB DFU or UART.
  - Read the entire NVM partition by following command `$STM32_Programmer_CLI -c port=usb1 -rp 0xf4 0x0 <size of partition> <Your Directory Path>\PMIC_NVM_read.bin` here NVM data is written to PMIC\_NVM\_read.bin.
  - To read NVM using UART in serial boot mode replace usb1 with COM port appearing on the HOST. `$STM32_Programmer_CLI -c port=COM<num> -rp 0xf4 0x0 <size of partition> <Your Directory Path>\PMIC_NVM_read.bin`
  - Backup it by creating a copy PMIC\_NVM\_write.bin
  - using hex editor modify PMIC\_NVM\_write.bin.
  - Write the NVM partion using below command for USB DFU. `$STM32_Programmer_CLI -c port=usb1 -pmic "<Your Directory Path>\PMIC_NVM_write.bin"`

- To write NVM using UART in serial boot mode replace usb1 with COM port appearing on the HOST. \$STM32\_Programmer\_CLI -c port=COM<num> -pmic "<Your Directory Path>\PMIC\_NVM\_write.bin"

**Note: - For STPMIC1 size of partition is 8 Bytes.**

## How to Use Console\_SH

In this mode, you will use STM32CubeIDE and build config Console\_SH

### Hardware prerequisites

- Set boot pins to b100 (BOOT2 = ON, BOOT0/1=OFF) position to select **development boot** (or also called Engineering boot)
- Connect cable from Board/STLINK connector to the PC


### STM32CubeIDE Step by Step

- Build Project by selecting Console\_SH build configuration
- Setup Debug Configuration as below and in particular (in Startup tab):

```
monitor reset
monitor halt
mon arm semihosting enable
mon arm semihosting_redirect tcp 2323
```


IDE Debug Configurations

Create, manage, and run configurations




IDE Debug Configurations

Create, manage, and run configurations



- Run Debug configuration and Open TCP window with localhost and port number as described below (Window -> Show View -> Other -> TCP Console)
- Some command examples:

```
$help
$displ
$displ word=10
$write word=10 value=1
```



## How to Use Console\_Uart

In this mode, you will use STM32CubeIDE and build config Console\_UART

### Hardware prerequisites

- Set boot pins to b100 (BOOT2 = ON, BOOT0/1=OFF) position to select **development boot** (or also called Engineering boot)
- Connect cable from Board/STLINK connector to the PC

### STM32CubeIDE Step by Step



- Depending your own board, you should change UART instance and GPIO into otp\_interface\_cli\_util.h file
  - By default it is the instance used on ST board (UART4 PD6&PD8 for STM32MP13xx / UART4 PG11/PB2 for STM32MP15xx)
- Build Project by selecting Console\_UART build configuration
- Setup Debug Configuration and in particular (in Startup tab):

```
monitor reset
monitor halt
```

- Run Debug configuration
- Connect an hyperterminal and connect to COM port

```
===== OTP Serial Interface =====
Target: STM32MP13XX
Print 'help' to see OTP commands
User>displ

OTP GLOBAL STATE
| State      : Secure Open
| Hardware Key Set : N
| Encrypted data : N

OTP DATA
-----
ID | VALUE | STATUS
-----
00 | 0x00000017 | 0x30000000
| [28] Shadow write sticky lock
| [29] Shadow read sticky lock
01 | 0x00008800 | 0x50000000
| [28] Shadow write sticky lock
| [30] Permanent programming lock
02 | 0x000100010 | 0x18000000
```

## Release note

Details about the content of this release are available in the release note [Release\\_Notes.html](#).

## Troubleshooting

**Caution** : The issues are **strictly limited** to submit problems or suggestions related to the software delivered in this repository.

**For any other question** related to the product, the hardware performance or characteristics, the tools, the environment, you can submit it to the **ST Community** on the STM32 MPUs related [page](#).