

**Subject: RE: The files**

**Date:** Wed, 23 Jul 2003 14:33:42 -0400

**From:** "Earl" <support@tecmag.com>

**To:** "Gernot Laicher" <gernot@physics.utah.edu>

Dear Gernot,

It could be an issue with the receiver synthesizer. The synthesizer output should be around 1Vpp (0-4dbm) at all frequencies. What you should do is measure the output level of this board at 40 MHz, 11 MHz, and 5 MHz. The output of this board is CW and so all you will need to do is type in a frequency and hit return and you should see the frequency change to Obs. Freq + 12.5 MHz. The board should be in the slot labeled Synth7-RX. There are 4 smb connectors on this board. Three are inputs, one comes from the Clock, and the other two come from the DDS-RX board next to it. The output of this board goes to the RF-RX.

Sincerely,

Earl

-----  
Earl Emery  
Tecmag, Inc.  
713-667-8747(ph)  
support@tecmag.com  
-----

I've stopped 1,419 spam messages. You can too!

One month FREE spam protection at <http://www.cloudmark.com/spamnetsig/>

-----Original Message-----

From: Gernot Laicher [mailto:[gernot@physics.utah.edu](mailto:gernot@physics.utah.edu)]

Sent: Wednesday, July 23, 2003 2:06 PM

To: Earl Emery; Brian Saam; Steven Morgan; Gernot

Subject: The files

Dear Earl,

I forgot to attach the files obtained with the Apollo. Here they are.

Regards,

Gernot

typed in	measured	Amplitude Vpp
20 MHz $\Rightarrow$	32.5 MHz	432 mV pp (into 50 $\Omega$ ) 864 $\mu$ V (into 1 M $\Omega$ )
40 MHz $\Rightarrow$	52 $\pm$ 1 MHz	374 mV (50 $\Omega$ ) 567 $\mu$ V
11 MHz		350 $\mu$ V 552 $\mu$ V (1 M $\Omega$ )
5 MHz		596 $\mu$ V (50 $\Omega$ ) <del>596 <math>\mu</math>V</del> (1 M $\Omega$ ) 504 $\mu$ V (1 M $\Omega$ )



# Apollo Installation

## Introduction

Verify that the shipment is complete. See **Parts Lists**, below, and any shipping documents. Check for any notices or instructions attached to the units.

### Parts List \*

- Apollo console, including AC power cable and extra connectors
- PCI interface cables (two 50-pin, 6 ft ribbon cables)
- NTNMR software CD-ROM (required only for backup, re-installation, or installation on another computer)
- Computer system, including tower, power cord, keyboard, mouse, Tecmag PCI interface boards (factory-installed) and software (factory-installed). DISPLAY MONITOR NOT INCLUDED.

### Optional Parts List \*

- DAC-18 subsystem chassis, with serial data cables (RJ-45 connectors, 25 ft, similar to 10-base-T network cables) for imaging systems.

\* Note: Consult packing list for exact list of items in your shipment

## Installation Procedure

*Note: NTNMR is pre-installed on the spectrometer computer at the factory - you do not need to run the NTNMR Installer from the CD! The NTNMR CD contains additional material as well as an installer for re-installing NTNMR if necessary.*

All connections are on the rear of the Apollo console cabinet.

1. Find a convenient location for the console box and the computer. The two units must be within about 4 feet of each other due to the length of the interconnecting cables. Be sure to leave the air vents on the console (top, bottom and rear) unobstructed.
2. Check that the power switch is off (rear panel, adjacent to the mains cord socket). Connect AC mains power of proper voltage. (See Environment.doc for details).

3. Set up the computer following instructions supplied with it. Set up your monitor and connect it to the computer. **DO NOT MODIFY THE COMPUTER SYSTEM OR SOFTWARE** by installing other boards or software until you have verified correct operation of the Apollo console (see below).
4. Connect the two ribbon cables from the PCI boards in the computer to the Apollo box, observing the polarity (key slots on the side of each connector). Note that the two connectors are identical, so observe the labelling on the cables to match the correct cable and connector. Care must be taken that *PCI-SI* goes to the System Interface and *PCI-SA* goes to the Signal Averager. The cables may be connected and disconnected while AC power is applied, although this is not recommended since excessive force may cause components in the computer to move causing electrical short circuits. Also, the state of the Apollo outputs cannot be guaranteed when the cables are disconnected.
5. Connect the following signals to the appropriate points in the NMR system using 50 ohm coaxial cable and BNC connectors (not supplied):
  - **F1 or F1 TX out.** Approximately 1 V p-p modulated radiofrequency (RF) source for the F1 channel. Connect to the input of your RF amplifier. Use a fixed attenuator if required (not supplied).
  - **F2 TX out.** (If second channel was purchased). Approximately 1 V p-p modulated RF source for the F2 channel. Connect to the input of a second RF amplifier. Use a fixed attenuator if required (not supplied).
  - **RF in.** Low level RF signal from your RF preamplifier. A preamp with a gain of 20-30dB is recommended, depending on the application (not supplied). The internal amplifier has a gain of about 70dB, and the input may be damaged by excessive signal.
  - **10 MHz out.** 1 V p-p 10 MHz sine wave is available for synchronizing external devices (if required).
  - **Ext Trig in.** Apply a TTL (5v) pulse here to synchronize pulse sequences with external events (as required).
6. Signals are provided on the back panel of the Apollo system for amplifier blanking, scope trigger, etc. Consult the chart included for output assignments. For use of Spare LP lines, refer to NTNMR documentation or contact technical support. Note that Tecmag reserves the right to assign any one or more of these lines to specific purposes in future hardware/software releases.

## Optional Gradient Subsystem Installation Procedure.

1. Find a convenient location near the gradient amplifiers for the DAC-18 subsystem box.
2. Connect the subsystem to the console using three RJ-45 serial cables. Note that the outputs of the gradient board in the console are X, Y, and Z in order from bottom to top. One serial cable goes to each channel. If you have ordered a  $B_0$  compensation unit, you will need to install 3 additional cables for the X, Y, and Z components.
3. Connect the DAC-18 boards to their respective gradient amplifier inputs using short cables. BNC or Twin-ax connectors for these cables are supplied if ordered. If the  $B_0$  compensation unit is included, a 3-to-1 adapter cable is provided to connect the 3 DAC outputs to the  $B_0$  amplifier input.
4. Once the system has been tested, you may wish to mount the individual DAC-18 boards directly inside the respective gradient amplifiers, using the  $\pm 15V$  from the amplifier power supply to power them. This should significantly reduce any mains-frequency signal pickup by reducing ground loops.

## Preliminary Test - Loopback

Disconnect **F1 TX out**, **F2 TX out**, and **RX in** from the console. Connect **F1 TX out** to **RX in** via a 50 ohm coaxial cable and a 20dB attenuator.

Turn on the power. The red LED on the front panel should light up. Turn on and boot up the computer. Log in to Windows NT as "administrator", no password required. If there is a "READ ME" icon on the desktop, double-click it to read last-minute instructions.

Double-click the NTNMR icon on the desktop. NTNMR will start, and after a minute or so, you will hear a "beep" signifying that the console has been initialized. (For troubleshooting purposes, you may open the hinged rear panel of the console (two knurled screws at the top of each panel) and watch the LEDs during this process. After NTNMR has been launched, or after the reset button ("hammer") has been clicked, all of the LEDs will flicker briefly. When the process is complete, all RED LEDs should be extinguished except the one on the Signal Averager.)

Open the file Data\TX\_RX\_Loopback.tnt (may be located in Data\test\). Click the “ZG” button on the toolbar. A waveform should appear on the screen, consisting of a “sinc function” followed by a “ramp”.

If this test fails, contact Tecmag technical support immediately.

If this test passes, reconnect the cables to **F1 TX out**, **F2 TX out**, and **RX in**. You’re ready to do NMR!

## Additional Documentation

Other than the documentation in this folder (i.e. Installation Notes, last minute documentation changes, etc.), all documentation is online in either Adobe Acrobat format or in Microsoft HTML Help File format. The Adobe Acrobat Reader software package is pre-installed on the computer at Tecmag. HTML Help requires either Internet Explorer 4.01 or later, or the Microsoft HTML Help update (pre-installed on the computer at Tecmag).

The online documentation consists of:

- NTNMR Reference Manual
- NTNMR Online Help
- Hardware Reference Manual

Other items contained on the NTNMR CD include NTNMR File Format documentation, Visual Basic and Visual C++ automation examples.

## Contacting Tecmag

Tecmag, Inc.  
6006 Bellaire Blvd.  
Houston, TX 77081

Phone: 713-667-8747  
Fax: 713-667-3180

[www.tecmag.com](http://www.tecmag.com)  
Sales inquires: [info@tecmag.com](mailto:info@tecmag.com)  
Support inquires: [support@tecmag.com](mailto:support@tecmag.com)

*Acrobat® Reader Copyright ©1987-1996 Adobe Systems Incorporated. All rights reserved. Adobe and Acrobat are trademarks of Adobe Systems Incorporated which may be registered in certain jurisdictions. Windows NT is a registered trademark of Microsoft Corporation.*

Rev.80111

# Setting up the Optional Room Temperature Shim Control

This section describes the connections required for using the optional Tecmag 24DAC18 module for controlling a room temperature shim power supply. Information on using the shimming features of NTNMR can be found in the NTNMR Reference Manual (pre-installed on the computer and available on the supplied NTNMR CD).

*This section does NOT apply to other types of shim control DACs such as the Acromag PCI card.*

**General:** The Tecmag 24DAC18 board provides 18-bit digital-to-analog (DAC) voltage outputs for up to 24 channels for control of a shim power supply or similar device. The board is configured at the factory for either +/- 1 V output, or +/- 3 V output on each channel. The output voltages are present on a 25-pin connector (DB25) labeled **Shim** or **Shim Cont** on the back of the Apollo-Console Chassis.

The 24DAC18 obtains its power and control signals from the Tecmag Bus (Apollo Bus).

*Consult the system information document for the exact connector labeling on the Apollo-Console Chassis.*

**Hardware Connections:** The mapping of the coil term in the NTNMR shim panel to a particular output pin on the **Shim** connector is configurable in software. In most cases C1, C2, C3, ... C24 in the [coils] section of the default.shm file (see the next section) are assigned to pin 1, pin 2, pin 3, ... pin 24. Pin 25 of the **Shim** connector is always ground.

**Software Configuration:** Generally, the shim configuration in NTNMR will have been setup as per the users request. However, in some special situations you may wish to modify the software configuration for shim control.

The 24DAC18 is controlled via the NTNMR Console Window. Both the current shim settings, and the display format, are specified in the file C:\NTNMR\shims\Default.shm. There are three sections in this file: [Shims], [ShimTerms], and [Coils].

The first section, [Shims], has one entry for each defined shim term, and shows the current DAC values for each term. For a new installation, the DAC values can be entered as zeroes.

The second section, [ShimTerms], defines the layout in the Console Window. There are three subgroups of shims, A, B and C. Groups A and B are on the left in the window (one row each, of 5 terms each), and Group C is on the right (3 rows of 4, for

total 12 terms). Each group has an associated title text (Atext, Btext, and Ctext) which can be changed to suit the user. The shim terms are listed underneath. For example, in the sample, the first window in the second row on the left (Group B) is defined as "Z0". The shim terms are arbitrary text strings, so users can use either the Cartesian or Legendre notations, or anything else that suits. However, the terms must be named consistently between the three sections of the file!


The third section, [Coils], defines the relationship between the Console Window values and the DACs. Normally, there is a one-to-one correspondance between a shim term and a DAC (e.g. Z(X2-Y2) is assigned to coil C16 in the example). However, linear combinations of coils may also be defined for a single term (matrix shims). Contact the factory for details on this option. In this section, any term defined using special characters should be enclosed in square brackets ("[ ]"). (For example Z(X2-Y2).)

To modify the default.shm file follow these steps:


1. Open the file C:\NTNMR\shims\Default.shm using Windows **Notepad**.
2. Edit the file as necessary to match your shim power supply configuration.
3. Save the modified file with the same name.
4. Start NTNMR
5. Open the Console Window.
6. Click the **Shim** tab.
7. Verify the correct layout of the shim terms. Change one or more terms and observe the corresponding change in shim power supply output.



## Apollo Installation – Transcoupler Diagram



*Note: 1/4 wave cables are frequency/nuclei specific ( $\pm 20\%$ ). If provided by Tecmag 1/4 wave cables will be labeled by nuclei (i.e.  $^1\text{H}$ ,  $^{13}\text{C}$ , etc.) and/or by frequency. Depending on system configuration, some items might not be provided.*



# System Information

The table below lists configuration information about the system which may be system specific. This table should be used as a reference when reviewing system specifications and capabilities found in the "Hardware Reference Manual". *Consult the "Hardware Reference Manual" for all system specifications.*

General	
System	Apollo HF, 1 RF Channel, MRI
Ship Date	9/27/02
Hardware	
<b>F1 Channel</b>	
Freq Range	0.55 - 450 MHz
Phase Mod Type	G2
Amplitude Mod Type	G2
Freq Control Type	G1
<b>F2 Channel</b>	
Freq Range	N/A
Phase Mod Type	N/A
Amplitude Mod Type	N/A
Freq Control Type	N/A
<b>Gradients</b>	
Gradient Type	G2
Rotation Option	Yes

## Chassis Layout Diagram

PRF1	PRF2	P1	P2	P3	P4	P5	P6	P7	P8	P9	P10	P11	P12	P13	P14	P15	P16	P17
Synth 7-RX																		
Em-Phase-Rx-G2																		
DDDS-RX																		
EM-Freq -RX-G1																		
DRX utility																		
Signal Averager																		
Signal Averager																		
Digital Receiver																		
EM-Grad-S-G2																		
EM-Grad-P-G2																		
EM-Grad-R-G2																		
Rotation																		
Gradient Preemphasis																		
EM-BP1-G2																		
EM-Master- G2																		
Sys interface																		
Master Clock																		

Connector Label = BP1		
*TTL output lines		
DB-25pin	Signal	Assigned/Available to User*
1	LP00	N/A (RX_PhRst)
2	LP02	N/A (RX_DDDS_Ph_90)
3	LP04	
4	LP06	
5	LP08	
6	LP10	
7	LP12	
8	LP14	N/A (DRX_Trig_2)
9	LP16	N/A (DDDS_Trig)
10	LP18	
11	LP20	
12	LP22	
13	GND	Chassis ground
14	LP01	
15	LP03	N/A (RX_DDDS_Ph_180)
16	LP05	N/A (RX_LO)
17	LP07	
18	LP09	
19	LP11	
20	LP13	
21	LP15	N/A (DRX_Trig_1)
22	LP17	N/A (EM_Freq_RX)
23	LP19	Scope_Trig
24	LP21	
25	LP23	

\*Leave blank if available

\*Enter config.con name if assigned (i.e. F1\_UnBlank, etc.)

\*Enter N/A if unavailable

Connector Label = BP2		
*TTL output lines		
DB-25pin	Signal	Assigned/Available to User*
1	LP00	N/A (F1_PhRst)
2	LP02	
3	LP04	N/A (F1_Ph_90)
4	LP06	
5	LP08	
6	LP10	
7	LP12	N/A (F2_Ph_180)
8	LP14	
9	LP16	N/A (DDDS1_Trig)
10	LP18	
11	LP20	N/A (EM_Ph2_Trig)
12	LP22	N/A (EM_Ampl2_Trig)
13	GND	
14	LP01	N/A (Rcvr 1 Blank)
15	LP03	
16	LP05	N/A (F1_Ph_180)
17	LP07	N/A (F2_PhRst)
18	LP09	F2_UnBlank
19	LP11	N/A (F2_Ph_90)
20	LP13	F1_UnBlank
21	LP15	N/A (EM_Ph1_Trig)
22	LP17	N/A (EM_Ampl1_Trig)
23	LP19	
24	LP21	N/A (DDDS2_Trig)
25	LP23	

\*Leave blank if available

\*Enter config.con name if assigned (i.e. F1\_UnBlank, etc.)

\*Enter N/A if unavailable

# Reference Manuals Errata

## General Notes

Several new feature have recently been added to the Apollo system. In general the documentation is still correct, except that some new features are not yet fully documented. We are working hard on this and will send updated documentation as a soon as possible. Please note that there are additional read me files located in the 'man' directory that you should review.

## Hardware Reference Manual – ch 2 – p 17-19. (6 places)

the Gp lines are assigned to the hardware 'Y' channel, the Gp lines are assigned to the hardware 'Y' channel

*should read*

the Gp lines are assigned to the hardware 'Y' channel, and the Gs lines are assigned to the hardware 'Z' channel

## NTNMR Reference Manual – ch 8 – p 142.

This is the default mode for S.A. Dimension = 1.

*should read*

This is the default mode for S.A. Dimension = 0.

## NTNMR Reference Manual – ch 9 – p 196 and following.

*objectname.SetData array*

*should read*

*objectname.SetData numPoints, array*

Example:

Data.SetData myArray

*should read*

Example:

Data.SetData 512, myArray

Also note that the parameter *numPoints* is the total number of points to be passed, not the number of complex points.

**NTNMR Reference Manual – ch 9 – p 158 and following.**

SetData	yes	array	variant (array)	-
---------	-----	-------	--------------------	---

*should read*

SetData	yes	numPoints, array	long, variant (array)	-
---------	-----	------------------	-----------------------------	---

Also note that the parameter *numPoints* is the total number of points to be passed, not the number of complex points.



# Remote Control Setup

## Introduction

Using a third party software package called VNC (Virtual Network Computing) your system can be controlled remotely by other computers all over the world. Computer platforms supported for remote control clients are Windows, Linux, Macintosh, and various versions of UNIX. Tecmag is not the author of this software package and Tecmag does not assume any responsibility for the VNC software or any potential problems associated with its use. If you would like more information regarding the VNC software please see the VNC homepage at <http://www.uk.research.att.com/vnc/>.

You must perform the following steps to setup the computer for remote control.

- Assign a static IP address to the computer
- Connect the computer to the network with a permanent connection
- Install and activate the VNC software (see below)

*Tecmag will never connect to the spectrometer computer without prior consent and arrangement by an authorized end-user of the system. The VNC software provides password protection and the end-user has full control and responsibility of the remote control software, including password assignment and allowing/disallowing connections.*

## Basic Installation and Setup


Tecmag does not pre-install VNC; the end user must install the software on the spectrometer control computer. The latest release of the VNC software package for Windows and other platforms is included on the NTNMR CD in the "VNC" directory.

1. Insert the NTNMR CD and navigate to the VNC/Windows directory and double-click on "setup.exe" to run the VNC installer.

*You must have a permanent TCP/IP network connection (not a dial-up connection) and a static IP address to use VNC.*



2. Point to the Start menu and locate the VNC program group (located under 'Programs'). Select Run WinVNC (App Mode) to start the WinVNC server.



**Figure 1 – VNC Program Group Menu**

3. The first time the VNC server software is run the WinVNC properties panel should appear. (If the properties panel does not appear see “Opening the Properties Panel” below).
4. Setup the following items as shown below in Figure 2:
  - Check “Accept Socket Connections”
  - Check “Auto” next to Display number
  - Assign a password




Figure 2 – The VNC Properties Window

5. Click OK to save the settings. VNC is now ready to accept connections from the Internet. Note that a user assigned password is required to connect the computer. This password is not the same as the Windows password.

## Opening the Properties Panel

If the VNC properties panel does not open the first time the VNC server is started (as described above in Basic Installation and Setup) or if you need to change the properties later right click on the VNC icon in the Taskbar and select “Properties”.

If the VNC icon is not visible in the Taskbar this indicates that the VNC server is not running. VNC will not allow connections to the computer unless the VNC server is running.



Figure 3 – VNC Icon in taskbar



Figure 4 – VNC right-click menu

## Closing VNC

Normally the VNC server is run as an application (as described above). Connection are only allowed when the VNC server application is running as indicated by the presence of the VNC icon in the taskbar.

To close VNC right-click on the VNC icon in the taskbar and select Close VNC from the right click menu (Figure 4).

## Frequently Asked Questions

*Which TCP/IP port does the VNC server use?*

A VNC server listens on two ports. The exact port numbers depend on the VNC display number, because a single machine may run multiple servers. The most important one is 59xx, where xx is the display number. The VNC protocol itself runs over this port. So for most PC servers, the port will be 5900, because they use display 0 by default.

*My University/Institution/Company has a firewall, what can I do?*

In many cases your IT department will be able to create a very restricted hole in the firewall that you can use to allow connections. Contact your IT department for more information.

*We use a DHCP server to dynamically assign IP addresses. Will this cause VNC to fail?*

VNC uses the IP address assigned to the machine running the server. As long as you have some method for determining the IP address currently in use by the computer running VNC, there should not be any problems. Your IT department should be able to help you determine the current IP address.

*Where can I find more information about VNC?*

The VNC documentation is installed on the NTNMR CD in the VNC directory along with the VNC programs for various computer platforms. You can also connect to <http://www.uk.research.att.com/vnc/> for more information

# dBm - Voltage Chart

dBm	mV (p-p)	mWatts	dBm	V (p-p)	mWatts	dBm	V (p-p)	Watts
-30	20.0	0.0010	0	0.632	1.00	30	20.0	1.00
-29	22.4	0.0013	1	0.710	1.26	31	22.4	1.26
-28	25.2	0.0016	2	0.796	1.58	32	25.2	1.58
-27	28.3	0.0020	3	0.893	2.00	33	28.3	2.00
-26	31.7	0.0025	4	1.00	2.51	34	31.7	2.51
-25	35.6	0.0032	5	1.12	3.16	35	35.6	3.16
-24	39.9	0.0040	6	1.26	3.98	36	39.9	3.98
-23	44.8	0.0050	7	1.42	5.01	37	44.8	5.01
-22	50.2	0.0063	8	1.59	6.31	38	50.2	6.31
-21	56.4	0.0079	9	1.78	7.94	39	56.4	7.94
-20	63.2	0.0100	10	2.00	10	40	63.2	10.00
-19	71.0	0.0126	11	2.24	12.6	41	71.0	12.59
-18	79.6	0.0158	12	2.52	15.8	42	79.6	15.85
-17	89.3	0.0200	13	2.83	20.0	43	89.3	19.95
-16	100	0.0251	14	3.17	25.1	44	100	25.12
-15	112	0.0316	15	3.56	31.6	45	112	31.62
-14	126	0.0398	16	3.99	39.8	46	126	39.81
-13	142	0.0501	17	4.48	50.1	47	142	50.12
-12	159	0.0631	18	5.02	63.1	48	159	63.10
-11	178	0.0794	19	5.64	79.4	49	178	79.43
-10	200	0.100	20	6.32	100	50	200	100.0
-9	224	0.126	21	7.10	126	51	224	125.9
-8	252	0.158	22	7.96	158	52	252	158.5
-7	283	0.200	23	8.93	200	53	283	199.5
-6	317	0.251	24	10.02	25.1	54	317	251.2
-5	356	0.316	25	11.25	316	55	356	316.2
-4	399	0.398	26	12.62	398	56	399	398.1
-3	448	0.501	27	14.16	501	57	448	501.2
-2	502	0.631	28	15.89	631	58	502	631.0
-1	564	0.794	29	17.83	794	59	564	794.3
0	632	1.00	30	20.00	1000	60	632	1000
1	710	1.26	31	22.44	1259	61	710	1259
2	796	1.58	32	25.18	1585	62	796	1585
3	893	2.00	33	28.25	1995	63	893	1995

Prod. → Ext.

→ Config Folder

→ default.txt under \Setup\dashboard\

→ shims folder

AC power cable.

# dBm - volts - watts conversion

(50-ohm system)

dBm	V	P <sub>o</sub>	dBm	V	P <sub>o</sub>	dBm	mV	P <sub>o</sub>	dBm	μV	P <sub>o</sub>
+53	100.0	200W	0	.225	1.0 mW	-49	0.80		-98	2.9	
+50	70.7	100W	-1	.200	.80 mW	-50	0.71	.01 μW	-99	2.51	
+49	64.0	80W	-2	.180	.64 mW	-51	0.64		-100	2.25	.1 pW
+48	58.0	64W	-3	.160	.50 mW	-52	0.57		-101	2.0	
+47	50.0	50W	-4	.141	.40 mW	-53	0.50		-102	1.8	
+46	44.5	40W	-5	.125	.32 mW	-54	0.45		-103	1.6	
+45	40.0	32W	-6	.115	.25 mW	-55	0.40		-104	1.41	
+44	32.5	25W	-7	.100	.20 mW	-56	0.351		-105	1.27	
+43	32.0	20W	-8	.090	.16 mW	-57	0.32		-106	1.18	
+42	28.0	16W	-9	.080	.125 mW	-58	0.286				
+41	26.2	12.5W	-10	.071	.10 mW	-59	0.251				
+40	22.5	10W	-11	.064		-60	0.225	.001 μW	-107	1000	
+39	20.0	8W	-12	.058		-61	0.200		-108	900	
+38	18.0	6.4W	-13	.050		-62	0.180		-109	800	
+37	16.0	.5W	-14	.045		-63	0.160		-110	710	.01 pW
+36	14.1	4W	-13	.050		-64	0.141		-109	640	
+35	12.5	3.2W	-16	.0355					-112	580	
+34	11.5	2.5W									
+33	10.0	2W									
+32	9.0	1.6W									
+31	8.0	1.25W									
+30	7.10	1.0W									
+29	6.40	800 mW									
+28	5.80	640 mW									
+27	5.00	500 mW									
+26	4.45	400 mW									
+25	4.00	320 mW									
+24	3.55	250 mW									
+23	3.20	200 mW									
+22	2.80	160 mW									
+21	2.52	125 mW									
+20	2.25	100 mW									
+19	2.00	80 mW									
+18	1.80	64 mW									
+17	1.60	50 mW									
+16	1.41	40 mW									
+15	1.25	32 mW									
+14	1.15	25 mW									
+13	1.00	20 mW									
+12	.90	16 mW									
+11	.80	12.5 mW									
+10	.71	10 mW									
+9	.64	8 mW									
+8	.58	6.4 mW									
+7	.500	5 mW									
+6	.445	4 mW									
+5	.400	3.2 mW									
+4	.355	2.5 mW									
+3	.320	2.0 mW									
+2	.280	1.6 mW									
+1	.252	1.25 mW									



Distribution Centers NORTH AMERICA 800-654-7949 • 417 335-5935 • Fax 417-335-5945 • EUROPE 44-1252-832600 • Fax 44-1252-837010

ISO 9001 CERTIFIED

INTERNET <http://www.minicircuits.com>

P.O. Box 350166, Brooklyn, New York 11235-0003 (718) 934-4500 Fax (718) 332-4661