

Refilling the Strapper



STEP	ACTION
1	Hold release button to empty out left over strap in strapper
2	Remove old roll by twisting and pulling the nob on dispenser, and removing the side. Add on new roll with arrows facing in the direction that strap will spin. Put side of dispenser back on and make sure it has been tightened on completely
3	Press release button to get some slack of strap.
4	Feed the strap into strapper until you feel resistance.
5	Press the bottom lever up while feeding another 1-2 inches of the strap into the strapper.
6	Press start button