



E-stop should only be used when there is an emergency.



STEP	ACTION
1	E-stop location will be shown on HMI. Indicator will be blinking. Go to that location and reset that specific E-stop
2	<p>Go to HMI. Click the “Safety System” button in order to bring up the safety devices overview screen.</p> <p>If a critical fault has occurred that zone button should turn red and say “critical fault” in the status description.</p> <p>From the safety overview tab click on the affect Safety Zone button which will bring up the tab for that zone.</p>
3	Press the critical fault reset button in order to reset the fault.
4	<p>Reset any affected safety zones.</p> <p>Note: the critical fault must first be reset on the HMI as per step 2 in order to be able to reset the safety zone.</p>
5	Press Start All at the gate or HMI control panel.