



NOTE:

1. PB05 and PB06 can be used as normal IO modes in addition to debugging serial ports
2. TX and RX interfaces of UART1 are default after PB00 and PB01 are electrified, and the functions can be changed in the program
3. When using UART to burn, it is necessary to force the PB14 to be high. If the PB14 is low, the UART function can be used normally

Title		
LE5010_SOP16		
Size	Number	Revision
A4		v0.1
Date:	2020/4/9	Sheet of 1
File:	D:\work_file\...\SOP16_EN.SchDoc	Drawn By: xianwei