

## DTP – Dynamic Trunking Protocol

Dynamically negotiate the creation of trunks

Cisco proprietary protocol

	Dynamic Auto	Dynamic Desirable	Trunk	Access
Dynamic Auto	Access	Trunk	Trunk	Access
Dynamic Desirable	Trunk	Trunk	Trunk	Access
Trunk	Trunk	Trunk	Trunk	Limited Connectivity
Access	Access	Access	Limited Connectivity	Access

It is recommended that you not use DTP

Instead, set the trunks manually

And disable the use of DTP explicitly with the interface level command: `switchport nonegotiate`