



IT900

External Interface Connections

February 2011

IT900-AN-003-R1.1

Copyright © YITRAN Communications Ltd.

PRELIMINARY information concerns products in the formative or design phase of development. Characteristic data and other specifications are design goals. YITRAN Communications reserves the right to change or discontinue these products without notice.



Please be aware that an important notice concerning availability, standard warranty, and use in critical applications of YITRAN Communications semiconductor products and disclaimers thereto appears at the end of this document.

Table of Contents

1. INTRODUCTION	4
2. IT900 PINOUT	5
3. DIGITAL INTERFACES.....	6
3.1 DIGITAL INTERFACES SUMMARY	6
3.2 UART INTERFACE.....	6
3.3 RESET PIN	7
3.4 ACTIVITY PIN	8
3.5 SAFE MODE.....	9
3.6 IT900 EMULATOR INTERFACE	10
3.7 EEPROM.....	11
3.8 LEDS	12
4. ANALOG INTERFACES.....	13
4.1 ANALOG INTERFACES SUMMARY	13
4.2 PLC SIGNAL PINS	13
4.3 POWER SUPPLY AND GROUND PINS	13
4.4 CRYSTAL.....	14

Proprietary Information

Table of Figures

Figure 1: IT900 Pinout	5
Figure 2: IT900 UART Pins Connection to Host Controller	6
Figure 3: IT900 Reset PIN Connection to Host Controller	7
Figure 4: Activity Pin Connection.....	8
Figure 5: Safe Mode Pin Connection	9
Figure 6: IT900 Emulator Connector Pinout	10
Figure 7: IT900 Emulator Connector Dimensions	10
Figure 8: IT900 to EEPROM Connection	11

Table of Tables

Table 1: UART Interface Pins.....	6
Table 2: UART Interface Default Parameters.....	7
Table 3: Reset Pin	7
Table 4: Activity Monitoring Pin	8
Table 5: Safe Mode Pin	9
Table 6: IT900 Emulator PINs.....	10
Table 7: EEPROM Size Options	11
Table 8: LED Pins	12
Table 9: IT900 Analog Interfaces	13
Table 10: Input and Output Pins	13
Table 11: Connection to External Crystal.....	14

1. Introduction

The *IT900 External Interface Connections* Application Note is provided to allow developers a quick understanding of the IT900 Interfaces that need to be considered during the design phase in Protocol Controller Architecture. It should be noted that this document provides only basic details about each interface and it is required to refer to the *IT900 Data Sheet* for further details.

The IT900 provides Digital and Analog interface connections.

The functionalities of all digital interfaces described in this document are relevant for Protocol Controller Architecture developers as the I/O functionality is fixed in this mode; some of these interfaces are mandatory (i.e. UART, Reset, etc.) and others are optional.

The Analog interfaces described in this document are mandatory.

2. IT900 PINOUT

The following diagram shows the IT900 PINOUT:




Figure 1: IT900 Pinout

3. Digital Interfaces

3.1 Digital Interfaces Summary

The following table summarizes the IT900 digital interfaces. Each digital interface is marked as Mandatory (**M**), Optional (**O**) or Recommended (**R**). In addition, the table below separates NC (Network Concentrator) and RS (Remote Station) devices.

Interface	Protocol Controller		Section
	NC	RS	
<i>UART</i>	M	M	3.2
<i>Reset</i>	M	M	3.3
<i>Activity</i>	R	R	3.4
<i>Safe Mode</i>	R	R	3.5
<i>IT900 (JTAG) Programmer</i>	O	O	3.6
<i>Eeprom</i>	M	R	3.7
<i>Leds</i>	O	O	3.8

3.2 UART Interface

The following figure shows IT900 UART pins connection to Host controller. These connections are **mandatory when working in Protocol Controller mode**.




Figure 2: IT900 UART Pins Connection to Host Controller

The UART interface pins are listed in the table below:

Table 1: UART Interface Pins

Pin Name	IT900 Pin Number	Interface Function	Description
P6_3	67	TXD	UART data output (IT900 → Host)
P6_2	68	RXD	UART data input (Host → IT900)

Proprietary Information

The communication default parameters of the UART host interface are set to the values listed in the table below:

Table 2: UART Interface Default Parameters

Parameter	Value
Communication Rate [bps]	960000 or 38400
Data [bits]	8
Parity [bits]	0
Stop [bits]	1
Flow Control	Off

Fast/Slow UART baud rate select

uC which don't support fast UART baud rates may select slow baud rate mode. The selection between Fast and Slow rate is preformed using P6_0 (pin 70) as detailed below:

P6_0 = '1': Fast baud rate (default value is 960000)

P6_0 = '0': Slow baud rate (default value is 38400)

3.3 Reset PIN

The following diagram shows IT900 Reset pin connection to Host controller. This connection is **mandatory when working in Protocol Controller mode**.




Figure 3: IT900 Reset PIN Connection to Host Controller

The Reset pin is listed in the table below:

Table 3: Reset Pin

Pin Name	IT900 Pin Number	Interface Function	Description
RESET	10	RESET	RESET (active low)

3.4 Activity Pin

It is recommended to implement firmware activity monitoring logic by periodically polling the External Host Interface using NOP command, and verifying correct response from the IT900. If no response is received from the IT900, the Host should issue a reset sequence.

For devices that require very high reliability, the IT900 provides an “activity monitor” Pin (P1_0), that may be used by an external circuitry to monitor correct operation. This pin generates pulse (1 mS width - active high) every 0.8 ± 0.1 seconds for all bands, except for CA2 that generates pulse every 1.2 ± 0.1 seconds.

If the pulse is not generated for more than 1.7 sec, then the IC should get a reset sequence. The monitoring circuitry may be implemented by watchdog element.

The following diagram shows IT900 Activity pin connection to Host controller:




Figure 4: Activity Pin Connection

The following table details the IT900 Activity pin:

Table 4: Activity Monitoring Pin

Pin Name	IT900 Pin Number	Interface Function	Description
P1_0	78	Activity	Activity Monitor

3.5 Safe Mode

As part of the startup sequence after reset, IT900 loads parameters stored in the NVM (non-volatile memory). The host application may inadvertently set the values of the parameters therefore causing a bad startup sequence of IT900, which may result in repeated resets. Safe mode enables IT900 to startup using the default parameter values stored in the firmware, thus guaranteeing successful completion of the startup sequence. The Safe Mode startup sequence is set through P1_4. See the *IT900 Data Sheet* for more details about Safe Mode procedure.

The following diagram shows IT900 Safe Mode connection to Host controller:




Figure 5: Safe Mode Pin Connection

The following table details the IT900 Safe Mode pin:

Table 5: Safe Mode Pin

Pin Name	IT900 Pin Number	Interface Function	Description
P1_4	74	SM	Safe Mode (Active Low)

3.6 IT900 Emulator Interface

The IT900 Emulator allows FW download to the IT900.


The following table details the IT900 PINs used for Emulator connection:

Table 6: IT900 Emulator PINs

IT900 Pin Name	IT900 Pin Number	Emulator Interface Function	Description
P6_4	66	BUSY	Handshake
P6_5	65	SCLK	Serial Clock
P6_6	64	RXD	Serial Data Input
P6_7	63	TXD	Serial Data Output
CNVss	7	CNVss	Service signal
Reset	10	nRST	IT900 RESET (Active Low)

The IT900 Emulator uses a 10 PINs connector. The following figure shows the connector pinout (signal 'CE' is not used for IT900 programming):

Figure 6: IT900 Emulator Connector Pinout



The following figure shows the Emulator Connector dimensions:

Pin Header 2.54mm 2 Row H=1.5/1.7/2.5mm Straight Type




Figure 7: IT900 Emulator Connector Dimensions

3.7 EEPROM

The EEPROM is mandatory for IT900 NC and for any application that requires Remote Version Download support (firmware upgrade through power line).

For a RS or for any application which does not rely on IT900 Network Layer (NL Manager Disabled), the EEPROM is optional.

The required EEPROM connection to the IT900 is shown in the following figure:




Figure 8: IT900 to EEPROM Connection

The different EEPROM size options are detailed in the table below:

Table 7: EEPROM Size Options

EEPROM Size	Supports RS	Supports NC	Supports Remote Version Download
None	+		
256Kbit	+	+	
1Mbit	+	+	+

Note: The EEPROM is assembled by default as part of the IT900 PIM. Refer to the *IT900 PIM Reference Design* document for specific EEPROM selection.

3.8 LEDS

The IT900 provides 3 LED indications detailed in the table below:

Table 8: LED Pins

Pin Name	Pin Number	Interface Function	Description
P7_3	25	RX_LED	Receive LED (Active High)
TS	59	TX_LED	Transmit LED (Active High)
P7_2	26	LINK_LED	Network Layer Link LED (Active High)

Note: The LEDs are assembled by default as part of the IT900 PIM. Refer to the *IT900 PIM Reference Design* document for reference on connection between IT900 and LEDs.

4. Analog Interfaces

4.1 Analog Interfaces Summary

The following table summarizes the IT900 Analog interfaces. Each Analog interface is marked as Mandatory (**M**), Optional (**O**) or Recommended (**R**). In addition, the table separates between NC (Network Concentrator) and RS (Remote Station) devices.

Table 9: IT900 Analog Interfaces

Interface	Protocol Controller		Section
	NC	RS	
<i>PLC Signal</i>	M	M	4.2
<i>Power Supply and Ground</i>	M	M	4.3
<i>Crystal</i>	M	M	4.4

4.2 PLC Signal PINs

The IT900 PLC Signal Input and Output PINs are detailed in the table below:

Table 10: Input and Output Pins

Pin Name	Pin Number	Description
VINP	52	Positive Differential Input from power line coupler/filter
VINN	53	Negative Differential Input from power line coupler/filter
VOUTP	38,39,40	Positive Differential Line Driver Output to power line coupler
VOUTN	32,33,34	Negative Differential Line Driver Output to power line coupler

The IT900 PLC Signals are connected through an analog circuit to the line coupler. For more information regarding the connection between the IT900 PLC signals and line coupler, refer to the *IT900 PIM Reference Design* document.

4.3 Power Supply and Ground PINs

The IT900 Power Supply and Ground PINs are detailed in the *IT900 Data Sheet*.

For more information regarding the required connection of the IT900 Power and Ground Pins, refer to the *IT900 PIM Reference Design* document.

4.4 Crystal

The IT900 PINs used for connection to the external crystal are detailed below:

Table 11: Connection to External Crystal

Pin Name	Pin Number	Description
XOUT	11	External Oscillator Output
XIN	13	External Oscillator Input

For more information regarding the connection between the IT900 and external crystal, refer to the *IT900 PIM Reference Design* document.

Document Control

Revision	Date	Description
1.0	January, 2011	Creation
1.1	July, 2011	Table 8 corrected: EEPROM size option from 32Kbit to 256Kbit

Important Notice

YITRAN Communications (YITRAN) reserve the right to make changes to their products or to discontinue any product or service without notice, and advise customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete. All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgement, including those pertaining to warranty, patent infringement, and limitation of liability.

YITRAN warrants performance of its products to the specifications applicable at the time of sale in accordance with YITRAN'S standard warranty. Testing and other quality control techniques are utilized to the extent YITRAN deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

CERTAIN APPLICATIONS USING SEMICONDUCTOR PRODUCTS MAY INVOLVE POTENTIAL RISKS OF DEATH, PERSONAL INJURY, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE ("CRITICAL APPLICATIONS"). YITRAN'S PRODUCTS ARE NOT DESIGNED, AUTHORIZED, OR WARRANTED TO BE SUITABLE FOR USE IN LIFE-SUPPORT DEVICES OR SYSTEMS OR OTHER CRITICAL APPLICATIONS. INCLUSION OF YITRAN'S PRODUCTS IN SUCH APPLICATIONS IS UNDERSTOOD TO BE FULLY AT THE CUSTOMER'S RISK.

In order to minimize risks associated with the customer's applications, the customer to minimize inherent or procedural hazards must provide adequate design and operating safeguards.

YITRAN assumes no liability for applications assistance or customer product design. YITRAN does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of YITRAN covering or relating to any combination, machine, or process in which such semiconductor products or services might be or are used. YITRAN'S publication of information regarding any third party's products or services does not constitute YITRAN'S approval, warranty or endorsement thereof.