

IEC61850 Client

straton user guide Rev. 11

sales@straton-plc.com



straton



STRATON AUTOMATION, All Rights Reserved

The information contained in this document is the property of STRATON AUTOMATION. The distribution and/or reproduction of all or part of this document in any form whatsoever is authorized only with the written authorization of STRATON AUTOMATION. The technical data are used only for the description of the product and do not constitute a guarantee of quality in the legal sense of the term. We reserve the right to make technical changes.

Content

1. OVERVIEW.....	4
2. REQUIREMENT AND SETUP.....	4
3. CREATE AND CONFIGURE AN APPLICATION	4
3.1. Create a new project	4
3.2. Download the application	5
3.3. File transfer.....	6
3.4. Connection status bit.....	7
3.5. t-attribute	8
3.6. Quality bits	9
3.7. Write an IEC 61850 attribute	10
3.8. Commands (Control model).....	11
3.8.1. IEC61850_OPER (Oper or Select and Oper)	12
3.8.2. IEC 61850_OPER (Oper or Select and Oper).....	12
3.8.3. IEC 61850 CANCEL (Cancel)	12
3.8.4. Parameters	13
3.8.5. Status and Result	13
3.9. Report Control Block (RCB).....	14
3.9.1. Unbuffered Report Control Block (URBC)	15
3.9.2. Buffered Report Control Block (BRCB)	16
3.9.3. Trigger options	17
4. FREQUENTLY ASKED QUESTIONS.....	18

1. Overview

The aim of this document is to guide beginners in the configuration of an IEC61850 Client. Further information are available in the online help for advances users.

2. Requirement and setup


The required software is the IDE, for the configuration of the IEC61850 protocol, and some add-ons driver are required in order to support the IEC61850 Client protocol.


The application can be downloaded to any runtime that support the IEC61850 Client, please refer to the OEMs information for special device.


3. Create and configure an application

3.1. Create a new project


Open the IO Drivers window using the tool bar () or right click on the project > Insert Shortcut > Fieldbus configurations

Insert a new Fieldbus using tool bar () or menu Insert > Insert configuration and select the IEC61850 Client driver.


Insert a master using tool bar () or menu Insert > Insert Master/Port.



Using the right mouse button select *Read variable From SCL file* or *Read variable from server*, in this last case the Server must be running.



Select the variables to declare.



3.2. Download the application

Download the application to the runtime:

- ▶ Select the communication parameters in menu Tools/Communication Parameters
- ▶ Establish the connection through menu Project/Online

RESULT IS:



The download is successful and application starts correctly.



The runtime is not started or communication parameters are wrong.



The application is not yet downloaded or an error occurs during startup. More detail can be found in the output view.

The application is not yet downloaded or an error occurs during startup. More detail can be found in the output view.

3.3. File transfer

The IEC61850 server from COPADATA needs to be configured in order to support file transfer. In the IEC61850 server Fieldbus configuration the *File transfer directory* needs to be set, if used. Only file under the folder's name will be available for file transfer.

Name	Value
File transfer directory	User
Adapter identification	
Max. number of saved report...	1000
Max. number of simultaneous...	0

In the IEC61850 Client Fieldbus configuration, the destination folder needs to be set too.

Name	Value
Directory for file transfer	C:\Temp
Run communication from with...	<input type="checkbox"/>
Queue all value changes	<input type="checkbox"/>
Originator category (orCat)	Station-control

Write an IEC61131-3 program to upload the desired file, for example:

```

IF bUploadFile THEN
    bErrorReport := IEC61850_FTGET(ServerId,'File.txt');
    bUploadFile := FALSE;
END_IF;

```

ServerId is a DINT variable, defined in the Master/Port in the IEC61850 Client Fieldbus configuration (cf: paragraph 3.1 in this document).


NOTES:

The file transfer directory's name must be set according to the used OS, for example if the application is downloaded on a Windows runtime it can be "C:\Temp", if it uses VXWORKS the file transfer directory can be "/ROM/user

3.4. Connection status bit

It is possible to look after a variable containing status bits about the state connection with the server. To create this variable, open "Fieldbus configurations", right click on the 61850 server to watch, and choose "Create status variable".

A new variable appears in global variables with a name like: "servername_ConnectionState".



The different values it can take are:

For the first connection:

TCP_CONNECTING	0x04
TCP_CONNECTED	0x02
TCP_CONNECTFAILED	0x08
MMS_INITIALIZED	0x10000
MMS_RCBENABLEFAILED	0x20000

For the second connection:

TCP_CONNECTING	0x40
TCP_CONNECTED	0x20
TCP_CONNECTFAILED	0x80
MMS_INITIALIZED	0x1000000
MMS_RCBENABLEFAILED	0x2000000

The standard evolution for this value is:

TCP_CONNECTFAILED => TCP_CONNECTING => TCP_CONNECTFAILED

Or:

TCP_CONNECTFAILED => TCP_CONNECTING => TCP_CONNECTED => TCP_CONNECTED |
 MMS_INITIALIZED => (or if error while enabling RCB: TCP_CONNECTED | MMS_INITIALIZED |
 MMS_RCBENABLEFAILED)

3.5. t-attribute

The Quality Time can be set by the Server (cf: *IEC61850 Server tutorial*)

It can be retrieved by the Client using the status bits #21, #22 and #49 of any variable. Commands in the Client looks like:

```
__BitOk21 := VSIGETBIT( MyClient_MyIedLDevice_XCBR1_Beh_stVal_ST, 21 );__
```

Quality	Bit #21	Bit #22	Bit #49
OK	TRUE	FALSE	FALSE
ClockNotSynchronized	TRUE	FALSE	TRUE
ClockFailure	FALSE	TRUE	TRUE

NOTES:

The variable in the client must have a profile ( - profile for example)

Each bit's value is refreshed when the data changes.

3.6. Quality bits

The quality bits of IEC61850 common data attribute “q” are mapped according to the following table:

Attribute name		Attribute type Value/Value range	bit
Validity		CODED ENUM good invalid reserved questionable Bits 6 and 7 respectively 0 0 1 0 0 1 1 1	6,7
detailQual		PACKED LIST	
	Overflow	BOOLEAN DEFAULT FALSE	5
	Out Of Range	BOOLEAN DEFAULT FALSE	4
	Bad Reference	BOOLEAN DEFAULT FALSE	3
	Oscillatory	BOOLEAN DEFAULT FALSE	2
	Failure	BOOLEAN DEFAULT FALSE	1
	Old Data	BOOLEAN DEFAULT FALSE	0
	Inconsistent	BOOLEAN DEFAULT FALSE	15
	Inaccurate	BOOLEAN DEFAULT FALSE	14
Source		CODED ENUM process substituted	13
Test		BOOLEAN DEFAULT FALSE	11
Operator Blocked		BOOLEAN DEFAULT FALSE	12

NOTES:

The “detailQual” bits are linked with the “Validity” bits. For example, if the “detailQual” is *overflow* then the “Validity” shall be set to *invalid*.

More details are available in the standard, see IEC61850-7-3 and IEC61850-8-1.

3.7. Write an IEC 61850 attribute

A function block is available to write a variable through IEC61850/MMS protocol. The function required the ServerID and the path name.

Path Name is composed of the Logical Device Name plus the Path you can find in the client driver.

Name	Value
Name	MyVarName
Path	LLN0/Mod/stVal[ST]


```
// Set server ID
ServerId := 1;

if bWRITE then
    bWRITEstatus := IEC61850_WRITE(ServerId, 'LNB1/LLN0/Mod/stVal[ST]', 0);
    bWRITE := False;
end_if;
```

3.8. Commands (Control model)

The driver supports the command 'Direct Operate' and 'Select Before Operate' (SBO) in normal and in enhanced security. In IEC61850_OPER the driver automatically checks the actual Control Model and executes the command in the corresponding way.

For this, first the attribute `*/ctlModel[CF]` of the Data Object is read out. Depending on the value of this attribute, the corresponding command is executed using the respective Control model:

Value	Action
0	No action, execute command not possible (status only)
1	An 'Operate' service (direct control with normal security) is executed
2	'Select' and 'Operate' services (select before operate with normal security) are executed
3	An 'Operate' service (direct control with enhanced security) is executed
4	'SelectWithValue' and 'Operate' services (select before operate with enhanced security) are executed

OPERATE COMMAND:

The value is set directly to `*/Oper[CO]`.

Select commands are processed sequentially:

- ▶ Select command normal security: read from `*/SBO[CO]`, write to `*/Oper[CO]`.
- ▶ Select command enhanced security: write to `*/SBOw[CO]`, write to `*/Oper[CO]`.

The required command sequences are automatically performed in the right sequence by the driver. No further configuration steps are necessary.

Additionally, the driver supports manual Select and Cancel. The driver - according to the `ctlModel` of the Data Object - executes the Select (only when `ctlModel=2` or `4`). The values of `ctlModel=0`, `1` or `3` are treated as negative answer of Select.

When the IEC 61850 server responds the Select positive, the driver stores information about selected the Data Object and in the following command (in the following IEC61850_OPER) the driver only executes the Operate.

3.8.1. IEC61850_OPER (Oper or Select and Oper)

PARAMETERS:

```
VAR_INPUT
    ENABLE : BOOL;                (* Operate on a rising edge *)
    SERVERID : UDINT;             (* Id of the server set in the IEC61850 configuration *)
    PATH : STRING;                (* IedNameLogicalDeviceName/LnodeName/Pos/OperctlVal[CO] *)
    CHECK : USINT;
    VALUE : ANY;
END_VAR

VAR_OUTPUT
    STATUS : UDINT;
    RESULT : DINT;
END_VAR
```

3.8.2. IEC 61850_OPER (Oper or Select and Oper)

PARAMETERS:

```
VAR_INPUT
    ENABLE : BOOL;
    SERVERID : UDINT;
    PATH : STRING;
    CHECK : USINT;
    VALUE : ANY;
END_VAR

VAR_OUTPUT
    STATUS : UDINT;
    RESULT : DINT;
END_VAR
```

3.8.3. IEC 61850_CANCEL (Cancel)

PARAMETERS:

```
VAR_INPUT
    ENABLE : BOOL;
    SERVERID : UDINT;
    PATH : STRING;
END_VAR

VAR_OUTPUT
    STATUS : UDINT;
    RESULT : DINT;
END_VAR
```

3.8.4. Parameters

ENABLE: the trigger (edge) of the command. Note: the command will be started only when the last command is already done (compare STATUS).

SERVERID: Server ID

PATH: Path (without server name) e.g. 'GEDeviceF650/XCBR1/Pos/OperctlVal[CO]'

CHECK: IEC61850 Check attribute:

- ▶ 0: No check
- ▶ 1: Interlock check
- ▶ 2: Synchro check
- ▶ 3: Interlock and synchro check

VALUE: value of the command (any Data type)

3.8.5. Status and Result

STATUS: Status of last command:

- ▶ 0: BUSY
- ▶ 1: DONE
- ▶ 2: ERROR

RESULT:

when > 0 responds the IEC61850 AddCause

- ▶ < 0 internal error code:
- ▶ -1, VALUE wrong parameter
- ▶ -2, driver not loaded
- ▶ -3, write command cannot be given (e.g. not valid SERVERID)

3.9. Report Control Block (RCB)

The IEC61850 Client gets the data from the server by polling by default. The definition of RCB control block optimize the communication by using an event based communication.

RCB IS AN ABSTRACT FOR:

URCB (unbuffered report control blocks)

The unbuffered are sent to the client and destroyed immediately by the server after sending without any acknowledgment.

The server sends a block immediately after value or quality change.

BRCB (buffered report control blocks)

The buffered are sent to the client till the reception of the acknowledgment from the client.

They are resent as long as the client accepts them.

They are stored (up to the specified limit with the actual server) in case the communication between server and client fails.

The client asks for the buffered reports since a given number only if he detects a connection failure or (some) lost reports, otherwise the BRCBs act like URCBs and the server sends a block immediately after value or quality change.

3.9.1. Unbuffered Report Control Block (URBC)


The IEC61850 Client gets the data from the server by polling by default. The definition of RCB control block optimize the communication by using an event based communication.

RCB IS AN ABSTRACT FOR:

- ▶ URBC (unbuffered report control blocks)
 - The unbuffered are sent to the client and destroyed immediately by the server after sending without any acknowledgment.
 - The server sends a block immediately after value or quality change.
- ▶ BRCB (buffered report control blocks)
 - The buffered are sent to the client till the reception of the acknowledgment from the client.
 - They are resent as long as the client accepts them.
 - They are stored (up to the specified limit with the actual server) in case the communication between server and client fails.
 - The client asks for the buffered reports since a given number only if he detects a connection failure or (some) lost reports, otherwise the BRCBs act like URBCs and the server sends a block immediately after value or quality change.

3.9.2. Buffered Report Control Block (BRCB)

For Buffered RCB and statically assigned RCB, this is done by right click on the server and RCB Assignment.



In that case you can import it from a server or enter the name of the RCB: exampleLDevice/XCBR1/urcb[RP]

Where:

- ▶ "example" is the IED Name
- ▶ "LDevice" is the name of the logical device
- ▶ "XCBRxx" the class of the logical node and xx the instance number
- ▶ "urcb" the name of the report control block.

To receive the RCB correctly, one must enter the name of the client's machine, in capital letters. For example on a Mitsubishi Q24 (VXWORKS) the configuration can be:



3.9.3. Trigger options

In a RCB, the data are pushed by the server on a trigger. The trigger supports several options:

TrgOps data-change: Data value change

TrgOps quality-change: Quality change

TrgOps data-update: Timestamp change

TrgOps Integrity: Minimum every bufTm (bufTm is define in the RCB)

TrgOps general-interrogation: On request by the client (GI)

These options are set by the server if the "Use preconfigured TrgOps" is set.

Otherwise the defined value in the client configuration are used.

4. Frequently Asked Questions

CONNECTION BETWEEN CLIENT AND SERVER FAILS?

At least one variable needs to be linked in the client so that straton/zenon logic can establish the connection. For instance LLN0.Mod.stVal is always present in any server.

FILE TRANSFER FAILED?

When IEC61850 client upload a file it keep the folder/sub-folder architecture locally. These folders need to be present in the IEC61850 working directory defined in the configuration tool.