

Parking Manager demo

User's Guide

Intertraff Parking Manager demo User's Guide

Copyright Notice
© Intertraff 2005
All rights reserved.

The use and copying of this product is subject to a license agreement. Any other use is prohibited. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language in any form by any means without the prior written consent of Intertraff. Information in this manual is subject to change without notice and does not represent a commitment on the part of the vendor.

Italian copyright law permits you to make a backup of this software for archival purposes only. Any other duplication of this software, including copies offered through sale, loan, rental or gift is a violation of law, and subject to both criminal and civil penalties.

Notice to Intertraff Parking Manager demo Users

In some countries and states, it is illegal to store an image of a vehicle from which the driver may be identified without the express permission of the driver.

If the Parking Manager is being used in such a country or state then enabling the recording of the images may constitute a criminal offence. If in any doubt then legal advice should be sought.

Trademarks

Intertraff, the Intertraff logo, Parking Manager, BlackBox, BlackBox Unit, BlackBox Manager, are trademarks of Intertraff and its subsidiaries.

Intel is a trademark of Intel Corporation.

Microsoft, MS, MS-DOS, Word and Excel, are registered trademarks, and Windows is a trademark of Microsoft Corporation.

All other product names are trademarks of their respective owners.

EVALUATION LICENSE AGREEMENT FOR INTERTRAFF SOFTWARE

IPM Evaluation License

Intertraff Parking Manager® Copyright © 2005 by Intertraff srl. All rights reserved. This license applies to the evaluation version of Intertraff Parking Manager.

Your Agreement to this License

You should carefully read the following terms and conditions before using, installing, copying, distributing, or transmitting this software. By using, installing, copying, distributing, or transmitting Intertraff Parking Manager demo ("IPM demo"), you agree to all of the terms of this agreement ("License").

Please read the license terms below. If you do not agree to all of the terms of this License, then do not use, install, copy, distribute, or transmit IPM demo.

Scope of License

This is not free software. Subject to the terms below, you are hereby licensed by Intertraff srl to use one copy of IPM demo, on one (1) computer or workstation, for evaluation purposes without charge for a period of 15 days. If you use this software after the 15-day evaluation period, a license fee is required.

Use of IPM after the 15 days evaluation period without payment of the license fee is a breach of this License and a violation of Italian and international copyright laws.

Subject to all of the terms of this License, you may, without making any payment to Intertraff:

- give exact copies of this evaluation version of IPM demo personally to anyone;
- distribute exact copies of this evaluation version of IPM demo, if done exclusively through electronic channels; and
- make as many exact copies of this evaluation version of IPM demo as you wish, for purposes of distribution as described in (a) and (b) above.

You are specifically prohibited from charging, or requesting donations, for any copies, however made, and from distributing such copies with other products of any kind, commercial or otherwise, without prior written permission from Intertraff. Intertraff reserves the right to revoke the above distribution rights at any time, for any or no reason.

All rights of any kind in IPM demo which are not expressly granted in this License are entirely and exclusively reserved to and by Intertraff. IPM demo is protected by the Italian copyright laws and other applicable laws and treaties. You may not rent, lease, sublicense, modify, translate, reverse engineer, decompile, disassemble, or create derivative works based on, IPM demo, nor permit anyone else to do so. You may not make access to IPM demo available to others in connection with a service bureau, application service provider, or similar business, nor permit anyone else to do so.

Warranty Disclaimers and Liability Limitations

IPM demo, and any and all accompanying software, files, data and materials, are distributed and provided "AS IS" and with no warranties of any kind, whether express or implied, including, without limitation, any warranty of merchantability or fitness for a particular purpose. Intertraff does not warrant, guarantee, or make any representations regarding the use of, or the results of the use of, IPM demo. Intertraff does not warrant that the operation of IPM demo will be uninterrupted or error-free. You acknowledge that good data processing procedure dictates that any program, including IPM demo, must be thoroughly tested with non-critical data before there is any reliance on it, and you hereby assume the entire risk of all use of the copies of IPM demo covered by this License. **This disclaimer of warranty constitutes an essential part of this License.**

Except to the extent expressly prohibited by applicable statutes, Intertraff shall not be liable for any damage or financial loss arising out of the use of, or inability to use, IPM demo. Any liability of Intertraff will be limited exclusively to refund of the license fee paid to Intertraff. Except to the extent expressly prohibited by applicable statutes, in no event shall Intertraff, or its principals, shareholders, officers, employees, affiliates, contractors, subsidiaries, or parent organizations, be liable for any indirect, incidental, consequential, special, or punitive damages whatsoever relating to the use of IPM demo, or to your relationship with Intertraff, (including, without limitation, loss or disclosure of data or information, loss of profit, revenue, business opportunity or business advantage, or business interruption), whether based upon a claim or action of contract, warranty, negligence, strict liability, contribution, indemnity, or any other legal theory or cause of action, even if advised of the possibility of such damages.

In addition, in no event does Intertraff authorize you or anyone else to use IPM demo in applications or systems where IPM demo's failure to perform can reasonably be expected to result in a significant physical injury, or in loss of property, or in loss of life. Any such use is entirely at your own risk, and you agree to hold Intertraff harmless from any and all claims or losses relating to such unauthorized use.

Export Restrictions

IPM demo is subject to certain export restrictions of the Italian Government. If you are (a) in a country to which export from the Italy is restricted for anti-terrorism reasons, or a national of any such country, wherever located, (b) in a country to which Italy has embargoed or restricted the export of goods or services, or a national of any such country, wherever located, or (c) a person or entity who has been prohibited from participating in Italian export transactions by any agency of the Italian Government, then you may not install, download, access, use, or license IPM demo. By accepting this License, you warrant and represent to Intertraff that (1) you do not match the criteria set forth in (a), (b), or (c) above, (2) that you will not export or re-export IPM demo to any country, person, or entity subject to Italian export restrictions, including those persons and entities that match the criteria set forth in (a), (b), or (c) above.

General

This License is the complete statement of the agreement between the parties on the subject matter, and merges and supersedes all other or prior understandings, purchase orders, agreements, and arrangements. This License shall be governed by the Italian laws and regulations. Exclusive jurisdiction and venue for all matters relating to this License shall be in courts and fora located in Rome, and you consent to such jurisdiction and venue. There are no third-party beneficiaries of any promises, obligations, or representations made by Intertraff herein. Any waiver by Intertraff of any violation of this License by you shall not constitute, nor contribute to, a waiver by Intertraff of any other or future violation by you of the same provision, or any other provision, of this License. If any part of this License or the application thereof to any person or circumstance is for any reason held invalid or unenforceable, it shall be deemed severable, and the validity of the remainder of this License, or the applications of such provision to other persons or circumstances, shall not be affected thereby.

Contents

Preface

About This Guide	5
Assumptions	5
Documentation Feedback	5

Chapter 1

Introducing Intertraff Parking Manager	6
About the Parking Manager demo	6

Chapter 2

Installing Intertraff Parking Manager demo	7
Reviewing System Requirements	7
Before You Install Parking Manager demo	8
Parking Manager Hardware Installation	8

Chapter 3

Starting the Parking Manager demo Installation	9
Uninstalling Parking Manager	17

Chapter 4

Getting Started	18
User Interface	18
Option and Features	19

Chapter 5

File Menu	21
-----------------	----

Chapter 6

Options Menu	31
--------------------	----

Chapter 7

Plate Manage Menu	36
-------------------------	----

Chapter 8

Intertraff Parking Backstage	38
------------------------------------	----

Preface

About This Guide

This user's guide describes how to use the most popular features in Parking Manager 1.0, the Automatic Number Plate Recognition Software from Intertraff. This product runs under Microsoft Windows 2000 and Windows NT4.

This preface describes the conventions used in this guide. For an introduction to Parking Manager, see Chapter 1, "Introducing Parking Manager".

Assumptions

This guide assumes you are familiar with the version of Windows you are using. If you are not familiar with Windows terms such as "dialog", "icon", "option", or "drop-down list", see your MS Windows documentation.

Documentation Feedback

Intertraff is interested in your suggestions for improving both the print and the online documentation for the Parking Manager. We are interested in knowing what works and what needs improvement. Did you find errors, omissions, or confusing information? Tell us if you found information too difficult to find.

Tell us where you looked for information, and where you looked first.

Your feedback will help shape future versions of the documentation for the Parking Manager.

To forward your feedback, use one of the following methods:

Fax

Fax your comments to +39 06 69.19.03.82 to the attention of the
<Technical Publications Department>.

Postal letter

Send a letter to:

Intertraff srl

Technical Publications Department

via dei Mille, 40

00185 Rome – Italy

Email

info@intertraff.com

All feedback will be gathered and considered for future releases by our Technical Publications Department. Your feedback is valuable and really appreciated.

1

Introducing Parking Manager

This chapter introduces the Parking Manager demo, Automatic Number Plate Recognition for Windows XP SP2 and Windows 2000 SP4

About Parking Manager demo

Intertraff Parking Manager is an ANPR (automatic number plate recognition) system which allows you to keep track of vehicles entering and exiting your premises. Once installed and running you will have the ability to connect live video input to your system and carefully monitor it.

By the way, this demonstration software license:

- **reads number plates only from AVI files**
- **reads only Italian license plates**
- **reads number plates from 1 lane only. Lanes 2, 3 and 4 do not work;**
- **does not support Frame Grabber card and Barrier Interface Board installation**
- **does not record more than 50 records in the database**
- **works only for 15 days**

The IPM demo installation package contains 1 AVI file. If you are interested to get more AVI files to check better the software performance please visit our web site

Each vehicle's registration plate read is saved into the database along with the date and time of capture, lane entry/exit details, and options to store images to disk for retrieval at a later date. You are able to manipulate the database by searching for records using a wide range of search methods enabling searches to be made with only partial criteria.

Options are also available to set audible alert tones to your system – to inform you that a specific license plate was captured by the system.

2

Installing the Parking Manager demo

This chapter describes the IPM demo installation process. Topics in this chapter include:

- Reviewing system requirements
- Installing the Parking Manager
- Uninstalling

Before you install the Parking Manager demo, we recommend that you read the system requirements section to familiarize with the hardware and software requirements.

Reviewing System Requirements

The following table outlines both the minimum and the recommended system requirements for installing and running the Parking Manager under Windows 2000 and Windows NT4.

Equipment	Minimum	Recommended
Operating system	Windows XP SP2 or Windows 2000 SP4	Windows XP SP2
PC	Intel Celeron Processor 2.00 GHz or higher, a mouse, and an SVGA graphics display (1024x768 resolution)	Intel Pentium IV 2.00 GHz or higher, a mouse, and an SVGA graphics display (1024x768 resolution)
RAM	Windows 2000 – 256 MB Windows XP – 256 MB	Windows 2000 – 512 MB Windows NT4 – 512 MB
Hard disk space Required	500 MB	1 GB

Before You Install the Parking Manager demo

To ensure a smooth installation, we recommend you follow the procedure below before you install Parking Manager 1.0:

1. Exit all programs
2. Check for sufficient disk space. Your requirements will vary, depending on the type of installation you choose. See “Reviewing System Requirements”.

Parking Manager Hardware Installation

The Frame Grabber card and the Barrier Interface board are not supported in this demonstration software license. Please refer to the Intertraff Parking Manager non demonstration software license if you are interested to set up a real ANPR installation.


3

Starting the Parking Manager demo Installation


The Setup program guides you through the installation process by prompting you for information and automatically determining your system configuration and available disk space.

Note to Windows 2000 users: If you are installing IPM demo under Windows 2000, you must have *administrative* privileges.


To install the Parking Manager demo:
Double click on the SETUP.EXE file




Install Shield will connect to Intertraff web site to download the IPM Demo. Once the downloading will be completed installation file will be Install Shield will install IPM demo on your Computer. See picture below.




Please select <Next> to proceed




Please read carefully the License Agreement then press <Yes> if you want to proceed.




if you want to move to another destination folder please press the <Browse> button otherwise select <Next>



Click the type of Setup you prefer then click <Next>




Review setting then please select <Next> to proceed




Please select <Yes> to proceed. IPM demo will start installing Firebird.




Please select <Next> to proceed




Please mark <I accept the agreement> then select <Next> to proceed



Choose <Install> to proceed




Here, just press <OK>



Press <Next>



Now that Firebird was successfully install, please press <Finish>



By choosing again <Finish> the Intertraff Parking Manager demo installation will be completed.

Uninstalling Parking Manager

At some point, you may want to uninstall the Parking Manager. When uninstalling and reinstalling the Parking Manager, you can back up the Database folder which contains all pictures and data collected. The Database folder is located at the following path c:\\program files\\intertraff\\IPM

Note to Windows 2000 users:

To use the Uninstall feature, your Windows 2000 account must have *administrative* privileges.

To uninstall the Parking Manager choose Start, Control Panel, select the Installation icon then select IPM_Demo and press Remove.


4

Getting Started


Once you have installed the Parking Manager, you are ready to start exploring the program.

User Interface

When you run the Intertraff Parking Manager you will see an interface as the one shown below:



IPM demo installation package comes with 1 AVI file sample. More AVI files can be downloaded from Intertraff web site. To start running the AVI file please select File, Display Camera and press <OK>.




Operation & Features

As you can see from the picture above the Parking Manager has determined the registration plate of the vehicle, then searched the database to see if a match could be found. A match was not found within the records, therefore the details of this employee have been not displayed on screen.

At the top of the plate patch you will notice a comment entitled Action, this would display any message associated with this vehicle or driver, such as 'Stolen' if the vehicle has been reported stolen or 'Invalid Pass' if their site pass is out of date etc.

At the right side of the interface you will notice a list box named 'Plates', each vehicle's transmitted plate will be displayed within this list. You can double click with the mouse on any of these registrations and the Intertraff Parking Backstage will be maximised displaying the vehicle and details related to the registration that you double clicked on.

An example of the Backstage maximised and set on the item in the list box which was double clicked on is shown in the picture below:



This list box will remain updating (with a scrollbar on the right hand side when the list exceeds the viewing size) until the Parking Manager is closed, each time the application is closed these details will be cleared from the list box. They can still be stored to disk, along with the captured image and plate patch.

To the bottom of the user details you will see either a photo of the driver or the colour of the vehicle displayed in a box, this provides the user with an immediate reaction to observe the colour of the vehicle or the driver entering. If a colour has been specified within the database rather than a photo, then the name of the colour will appear in the section above the colour.


5

File Menu Options

The following shows the menu options available and their functions:

File

The file menu consists of the following options:



Display Camera

Selecting this option you will be able to choose the number of ANPR windows (up four) the Parking Manager will display contemporarily. Each window shall correspond to one camera.

Audit Trial

This will simply list any useful events, such as when the application was started and closed, when a user selected a registration plate to view further details, when an image was stored etc. The events that are stored here can be customised to specific user's requirements.

View Alarm Trial

The alarm trail is used in a similar way to the Audit Trail, but lists details of all vehicles where an alarm has been sounded.

Run Review

This option will maximise the Intertraff Parking Backstage, see Chapter 8 for further details.


Preferences

This menu is where all the setup changes are made, e.g. to add or remove a lane, add or remove cameras, setup ANPR Engine preferences etc. It's basically formed by two TAB:

1. Cameras
2. Recognition Engine

Cameras TAB

The options available within this section are shown below:



Name: This should contain a meaningful description of the lane, e.g. South Car Park Entry.

Video Source: The video source determines the video capture method being used. As said IPM demo supports only AVI file but, the IPM software license supports also video capture.

Advanced: If the video system is .AVI File, this shows the path of the avi file being used.

Barrier: These options enable you to setup and test a barrier to work in conjunction with the Parking Manager. This option does not work with this demo license,

Advanced: It allows you to setup and test relays to the system.

Lane: Each lane configured must have a unique identifier, which must be a numeric value, this number is used by Intertraff ANPR Engine to identify the lane being used.

Crop Region Settings: This option allows you to set an area to which the recognition engine will search for a plate, the active region is shown by an outlined shape, which can be dragged to position, as shown below:

Crop Region Enable: mark this option if you need to control the crop region settings.



New: Selecting this button will allow you to add a new lane to the configuration, you must set all the further settings on this page for the new lane before it can be used.

Remove: Selecting this option will remove the currently selected lane from the configuration. If you select this option accidentally, select the Cancel button to restore the original settings.

Recognition Engine TAB

The options available within this section are shown below:

Preferences

Cameras | **Recognition Engine**

Font configuration file:

Number plate Percentage in the frame
 Min Width (6 by default) Min Height (5 by default)
 Max Width (52 by default) Max Height (13 by default)

Number plate width to height Ratio
 Min (2.0 by default) Nominal (3.0 by default) Max (5.5 by default)

Restrictions of frame processing
 Timeout (ms) Max candidate polygons

Discarding of similar plate numbers
 Re-admit timeout (sec.)

Inter frame Optimization
 Frame buffers per camera Accumulation Pool size Idle Pool size
 Accumulation Interleave Ignorance Interleave Idle Interleave
 Min accumulation count Max accumulation count ☒ Lite Version model

Engine parameter's INI file:

Recognition Engine TAB is for Intertraff ANPR Engine advanced tuning. Operator must be familiar with recognition model implemented in IPM before changing any settings:

Font Configuration File: is used to define fonts' templates for symbol recognition. This file is distributed in bundle with IPM.

Number plate Percentage in the frame and **Number plate width to height Ratio** groups specify, the parameters range to the ANPR Engine for plate patch localization. If this option is

too high the Engine may not attempt to recognise valid plates and if the setting is too low, it may increase performance and drop unreliable plate patch cases. Please use default values.

Restrictions of frame processing group is used to protect Engine performance. Frame processing is stopped when **Timeout** is called or the **Maximum Number** of candidates is reached.

Discarding of similar plate numbers group. Default value is **Discard the same plate numbers**. This setting allows discarding any reading which is identical to the previous. **Re-Admit Timeout** specifies the number of seconds between allowing the same vehicle back into the premises. On the contrary **No Discarding** will enter into the database any reading. **Discarding one plate's symbol difference** discards similar plates but using fuzzy comparison. So in case two readings differs one each other for 1 character only, the latter will be discarded.

Inter frame Optimiztion group is for reliable and fast recognition. The idea is to merge several preliminary readings of the same number plate, all coming from different frames, into one reliable result. Second idea is that IPM does not need to recognize every frame. Regular user should not change these parameters.


Engine parameter's INI file is for camera specific. This option allows you to choose between an Infrared Camera (used in low light conditions), a PAL camera (standard colour camera) or a CCIR camera (standard monochrome camera). IPM demo does not support INI settings modification.

Set Default restores default values into Recognition Engine TAB.

Program Options

Property Page

The dialog shown below will appear:



Preliminary note: all these settings will only take effect once the application will be restarted.

Show Car Colours

Selecting this option will display the colours of each car which is matched to the database.

Show Plate List

Selecting this option will display the list of plates on the right hand side of the screen as they are transmitted.

Save camera windows positions on Exit


Selecting this option the Parking Manager will display the ANPR windows exactly in the same position and size they were before the application itself was close.

Automatic Login

Selecting this option the Parking Manager will not require the ANPR Operator to log in any time the application restarts.

Relay Control

The dialog shown below will appear:



Enable Relay Control Card

In the IPM this option should be selected if you wish to make use of your relay control card, e.g. for linking to one or more barriers.


In this IPM demo software license this option does not work.

Database settings

This dialog is particularly important in case IPM is running unattended. The sub tab Automatic deleting of obsolete records helps installer to keep in the hard disk only a set number of records after that the older ANPR readings and associated records will be overwritten with the newer.


To enter this setting please mark **Enable** checkbox and choose **By count** and in the field on the right enter the number or records you want to save on the Hard Disk. When this value will be reached IPM will start deleting the older file. In the **Timeout** enter the number of seconds after which you want the IPM to compare the total number of records present on the disk with the value entered in the by count field.

It's also possible to perform this control by setting a number of days after that the old records will be deleted. Mark the **Delete pictures in real time** if you need to go this way otherwise old pictures will be cancelled on IPM restart only. See the picture below for details.



Categories


The dialog shown below will appear:



This is where you set each category within the database.

Directories

The dialog shown below will appear:



History Path

This directs the application to the path where the history file is located (the history file contains all the data relating to captured plates)

Database Path

Path where the database file is located.

Colours Path

Path where the file containing all the colour details is located.

HISTORY

New History

This option enable you to generate a new History File (.bpz). The History file contains the full amount of data captured by the system. Before doing it please save the old history file through the History/Archive data option.

Pay attention. Generating a new history file, will delete the old one.

Archive data

This option enable you to save the History file which contains the full amount of data captured by the system.

Log On

Use this option to re-launch the password dialog box if you wish to logon as a different user.

Log Off

Use this option to log off as the current user to prevent other users using your level of privileges.

Save frame settings

This option enable you to save the ANPR windows position and size. If closes and then restarts the application will display the ANPR windows as they were displays before the application was closed.

Stop recognition

This option enable you to stop the ANPR Engine and any plates recognition.

Exit

This option will closedown the Intertraff Parking Manager.

6

Options

The Options menu contains the following options:

- Edit Database
- Edit Parking List
- Edit Access Controls
- Edit Colours
- Select Sounds
- Passwords
- Access Periods

Edit Database

The dialog that will be displayed is shown below:

Vehicle Database Details

Number	Name	Vehicle
<New Plate...>		

Buttons: Add New, Delete, Apply, Import, Export

Record Data

Car Information

Plate: <New Plate...>
Vehicle:
Colour:

Dirver Information

Title:
First name:
Last name:

Category: Barrier options:
Last Entry: Action:
Fuzzy logic distance:

OK Cancel

This option requires the user to log into the system and to have all the ANPR windows closed. It allows you to Add, Delete, Edit and Search for records held within your database files. Use this dialog to get the list records currently stored.


If you select a record within the list box at the top of the dialog then all the details stored relating to that person will be displayed in the edit boxes below. If you wish to make any changes to these details (assuming your password level allows you), you can edit directly into the edit boxes and then press the Apply button to update the changes you have made. The Import and Export buttons will allow you to use different database files for different locations if required.

Particularly important is the < Barrier options > drag and drop windows. For any record the ANPR manager decides if:

1. Use Category DEFAULT;
2. OPEN barrier;
3. Keep the barrier CLOSE;

Access Controls

This option will display the following dialog:



It allows you to setup Access Control preferences.

Categories

You would first select a Category then decide which type of access they are allowed using the Access Type.

Access Type

There are two options here:


- Automatic Access – this would raise the barrier to all
- Manual Access – this would prevent the barrier from being raised to any one automatically, it would have to be done manually

Unknown Cars Get Access

This option would give access to any vehicle which is not in the database (this could be used if a database was held only for suspect vehicles and not staff). Or in case the checking should be applied only on exit.

Edit colours

If you select this option you will see the dialog shown below:



As shown above there is a list box on the left side of the dialog, listing all the currently entered colours.

Add New

Selecting this option allows you to select and add a new colour to the table.

Delete


This option allows you to delete a colour from the listbox, first highlight, then press the Delete button.

Edit

This option allows you to edit a colour, either by name or RGB value.

Select sounds

If you select this option the dialog shown below will be displayed:




You have the option to select an alarm to sound any time an <action> message is display. For the <action> message definition please see the Edit database option described above. To select a different sound you should press the Browse button and select another .wav file. To test a sound you should select it first then press the Test button, if you do not want a sound for a specific event simply leave the <Alarm> unchecked.

Passwords

The passwords option allows you to view, add or delete password levels.

If you select this option the dialog shown on the following page will be displayed:




The above dialog will display a list of names on the left of all those persons who have the authority to gain access to Intertraff Parking Manager and Review.

When you first run the Parking Manager you will notice that a number of the menu options are disabled. A Username and password have been set to enable you to again access to the full level to setup your system. User 'bulb' and Password 'bulb' will allow full access.

Once you have full access you should select the Edit Menu and Passwords, this will display the above dialog box. If you do not want to use passwords on your system then there is a way around it. Access please the File/program Options menu and in the Property Page TAB please mark the check box Automatic Login.

Access Periods

This dialog allows you to setup specific times and dates when you would like the ANPR system to be monitoring vehicles.



Access Periods allows you to set-up certain days of the week and times which it required monitoring to take place, this can be used when a premises is only open at certain times of the day – it prevents continuous monitoring if not required.

7

Plate Manage

The Plate Manage menu contains the following four options:

Accept Record
Edit Record
Delete Record
New Record


Accept Record, Edit Record, New Record and Delete Record. These will allow you to manually allow entry to vehicles as you require. The buttons are explained individually below:

Accept Record

When a number plate has been recognised it will be displayed within the plate list, if you wish to allow that vehicle to enter the premises via an access control method then this button should be selected and access will be permitted.

Edit Record

This will display the dialog below:



The number plate which was currently selected within the plate list will be displayed within the

Plate box, you may correct this plate if required.

New Record

This will do the same as above for the Edit Record button but the number plate will not be displayed within the Plate textbox.

Delete Record

This option will delete the currently selected record from file.

WINDOWS

The submenu New Window can be used to open a new ANPR window. Cascade, Tile and Arrange Icons can be useful to automatically sort on the monitor all the active ANPR windows.

HELP

About BPM

Selecting this option will display an About Box showing details of Intertraff Parking Manager demo version 1.0

8

Intertraff Parking Backstage

User Interface

The following screen shows the user interface when selecting to use Intertraff Parking Managing Review, this can be run directly from the Parking Manager or from within the main windows program menu.

Intertraff Parking Backstage

File Options Help

BJ582BY	11/01/05	19:31	Lane 1
BJ582BY	11/01/05	19:32	Lane 1
BJ582BY	11/01/05	19:43	Lane 1
BJ582BY	11/01/05	19:44	Lane 1
BJ582BY	11/01/05	19:45	Lane 1
BJ582BY	11/01/05	19:47	Lane 1
BJ582BY	11/01/05	19:48	Lane 1
BJ582BY	11/01/05	19:49	Lane 1
BJ582BY	11/01/05	19:51	Lane 1

Search

9 Records

Search Criteria

☒ Full/Part Plate Search:
BJ582BY

☐ Hours Range:
19:21 to 19:21

☐ Use Calendar:
gennaio 2005
11/01/2005 to 11/01/2005

Lane Selection

☐ Lane 1
☐ Lane 2
☐ Lane 3
☐ Lane 4

Category Selection

☐ None
☐ Category1
☐ Category2
☐ Category3
☐ Category4
☐ Category5
☐ Category6
☐ Category7
☐ Category8

Plate Patch:
BJ-582BY

Plate Text:
BJ582BY

Name:
Category:
Vehicle:
Action:

Ready NUM

When the Parking Manager is launched the Review is also opened and minimised, allowing automatic updating of information from one program to the other. The Review is designed to work in conjunction with the Intertraff Parking Manager. The Review enables you to look back

through the history files, (files saved by the Parking Manager). These history files are stored in extension type .bpz.

Stored Details

The .bpz file contains images of the captured vehicles along with a plate patch and relating details to the time, date, category and location of capture.

As you can see in the previous example the following details have been stored:

- Image of Vehicle
- Plate Patch
- Recognised Number Plate
- Date of Capture
- Time of Capture
- Location of Capture (Lane ID)
- Category

Also the user details additionally shows:

- Driver Name
- Vehicle Colour
- Action Message

The record which is selected within the listbox is that which relates to the image displayed on the right. The Plate Patch is displayed below the image (to the left) and the recognised plate (transmitted plate) is displayed below.

The remaining section of the interface contains a calendar and different search options.

Calendar

The calendar will look like the one shown below:



You will notice that a red circle is placed over today's date. Any dates which relate to captured vehicles within the .bpz file will be shown in bold on the calendar.

There is a checkbox to the left of the calendar, labelled Calendar, if you wish to disable the use of the Calendar then uncheck this box.

Searching Option

Lane Selection

On the right of the Calendar checkbox is an option group titled Lane Selection, this group contains 4 checkboxes, Lane 1, Lane 2, Lane 3 and Lane 4. If you wish to make a search on a specific lane (or specific selection of lanes) then you should select this lane(s) as appropriate.

Full/Part Plate Search

To enable this option you must first select the checkbox. You may then enter a full registration plate (without spaces) or Part of the registration plate.

Date Range

If you wish to search between specific dates then these dates should be entered here.

Hours Range

If you wish to search between specific times, then these times should be entered here.

Example Search:

This example shows how to make a search on all vehicles with the following criteria:

- Registration beginning with the letter T
- Entered the Premises between the dates of 1st April 2004 and 8th April 2004
- Entered between the times of 6am and 9am
- Entering only on Lane 1
- Search only for Category one (Employees)

You should select the following:

- Lane 1 checkbox within the Lane Selection
- "T" within the Plate/Part Plate Search
- Date options should be 01/04/04 to 08/04/04
- Time options should be 06:00:00 AM to 09:00:00 AM
- Category one within the Category Section

Press the Search button, all matching records will be displayed within the list box at the top left section of the screen.

Menu Options

Intertraff Parking Manager Review contains the following Menu Options:

Open History File
Open Current File
View Audit Trail
Analyse In and Out
Log On
Log Off
Exit

Open History File

This option enables you to open a .bpz file (previously created by the Parking Manager). Once you have selected this option you will be presented with a windows Open dialog to locate the relevant file.

All the dates which this file contains captured vehicles of will be displayed in bold on the calendar. Use the arrow button (at the top of the calendar) to move between months to locate a date relating to the file. Once you find a date displayed in bold use the mouse to double-click on this date and all the captured data relating to that date, (within the file) will be displayed within the list box.

Open Current Database


This option enables you to open the current History file (.bpz)

View Audit Trail

This option will display a dialog listing any useful events.

Analyse In & Out

This option will display the following dialog:



The list box on the left, shown in the above diagram displays all the records held within the current history file which is in use. The listbox on the right displays some results when prompted by selecting the buttons below it. These buttons are explained below:

Currently IN

This option will display a list of all the vehicles who have entered the site but not yet exited into the listbox on the right side of the dialog.

Matching Plates

This option will find all the records which have a matching registration plate to the one selected within the listbox on the left hand side, and display these records in the listbox on the right hand side.

Entered Vehicles

This option will display all the records which have entered the site into the listbox on the right side of the dialog.

Exited Vehicles

This option will display all the records which have exited from the site into the listbox on the right hand side.

Find Next Occurrence

This option will move to the next record which has a matching registration, from the one currently selected in the listbox on the left side of the dialog.

Find Previous Occurrence

This option will move to the previous record which has a matching registration, from the one currently selected in the listbox on the left side of the dialog.

Close

This option will close the dialog.

Log On

This option will display the password prompt to enable a user to log on with their own unique username and password which will provide them with a preset level of privileges

Log Off

Use this option to log off as the current user to prevent other users using your level of privileges.

Exit

This option will close your Parking Manager Review session.

Options

Search Immediately

If you are looking through a file containing no more than 1000 records then you may benefit from this option. Selecting this option will automatically begin a search as you have entered the criteria. You do not need to press the Search button at the top of the screen.

If you have this option selected and you are browsing through a very large file (with thousands of records) then this will cause your program to run very slowly, as it will be attempting to perform searches each time you press a key.

Help

About BPM

Selecting this option will display an About Box showing details of Intertraff Parking Manager demo version 1.0