

Version	Frame Name	Frame Description	CAN Id	Signal Name	Signal Description	Type	Bit Position	Length (bits)	Scale Factor	Offset	Min	Max	Unit	Frame Length	RTR?	User?
21.0.1	Status 0	Periodic status frame 0	8051800	Channel 0 Current	Current from PDH Channel 0	Float	0	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051800	Channel 1 Current	Current from PDH Channel 1	Float	10	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051800	Channel 2 Current	Current from PDH Channel 2	Float	20	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051800	Channel 0 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 0	Unsigned	30	1	1	0	0	1		8	N	Y
21.0.1			8051800	Channel 1 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 1	Unsigned	31	1	1	0	0	1		8	N	Y
21.0.1			8051800	Channel 3 Current	Current from PDH Channel 3	Float	32	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051800	Channel 4 Current	Current from PDH Channel 4	Float	42	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051800	Channel 5 Current	Current from PDH Channel 5	Float	52	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051800	Channel 2 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 2	Unsigned	62	1	1	0	0	1		8	N	Y
21.0.1			8051800	Channel 3 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 3	Unsigned	63	1	1	0	0	1		8	N	Y
21.0.1	Status 1	Periodic status frame 1	8051840	Channel 6 Current	Current from PDH Channel 6	Float	0	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051840	Channel 7 Current	Current from PDH Channel 7	Float	10	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051840	Channel 8 Current	Current from PDH Channel 8	Float	20	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051840	Channel 4 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 4	Unsigned	30	1	1	0	0	1		8	N	Y
21.0.1			8051840	Channel 5 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 5	Unsigned	31	1	1	0	0	1		8	N	Y
21.0.1			8051840	Channel 9 Current	Current from PDH Channel 9	Float	32	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051840	Channel 10 Current	Current from PDH Channel 10	Float	42	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051840	Channel 11 Current	Current from PDH Channel 11	Float	52	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051840	Channel 6 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 6	Unsigned	62	1	1	0	0	1		8	N	Y
21.0.1			8051840	Channel 7 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 7	Unsigned	63	1	1	0	0	1		8	N	Y
21.0.1	Status 2	Periodic status frame 2	8051880	Channel 12 Current	Current from PDH Channel 12	Float	0	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051880	Channel 13 Current	Current from PDH Channel 13	Float	10	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051880	Channel 14 Current	Current from PDH Channel 14	Float	20	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051880	Channel 8 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 8	Unsigned	30	1	1	0	0	1		8	N	Y
21.0.1			8051880	Channel 9 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 9	Unsigned	31	1	1	0	0	1		8	N	Y
21.0.1			8051880	Channel 15 Current	Current from PDH Channel 15	Float	32	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051880	Channel 16 Current	Current from PDH Channel 16	Float	42	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051880	Channel 17 Current	Current from PDH Channel 17	Float	52	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			8051880	Channel 10 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 10	Unsigned	62	1	1	0	0	1		8	N	Y
21.0.1			8051880	Channel 11 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 11	Unsigned	63	1	1	0	0	1		8	N	Y
21.0.1	Status 3	Periodic status frame 3	80518C0	Channel 18 Current	Current from PDH Channel 18	Float	0	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			80518C0	Channel 19 Current	Current from PDH Channel 19	Float	10	10	0.125	0	0	127.875	A	8	N	Y
21.0.1			80518C0	Channel 12 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 12	Unsigned	20	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 13 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 13	Unsigned	21	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 14 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 14	Unsigned	22	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 15 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 15	Unsigned	23	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 20 Current	Current from PDH Channel 20	Float	24	8	0.125	0	0	31.9375	A	8	N	Y
21.0.1			80518C0	Channel 21 Current	Current from PDH Channel 21	Float	32	8	0.125	0	0	31.9375	A	8	N	Y
21.0.1			80518C0	Channel 22 Current	Current from PDH Channel 22	Float	40	8	0.125	0	0	31.9375	A	8	N	Y
21.0.1			80518C0	Channel 23 Current	Current from PDH Channel 23	Float	48	8	0.125	0	0	31.9375	A	8	N	Y
21.0.1			80518C0	Channel 16 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 16	Unsigned	56	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 17 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 17	Unsigned	57	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 18 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 18	Unsigned	58	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 19 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 19	Unsigned	59	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 20 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 20	Unsigned	60	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 21 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 21	Unsigned	61	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 22 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 22	Unsigned	62	1	1	0	0	1		8	N	Y
21.0.1			80518C0	Channel 23 Breaker Fault	The breaker is currently tripped or disconnected on PDH Channel 23	Unsigned	63	1	1	0	0	1		8	N	Y
21.0.1	Status 4	Periodic status frame 4	8051900	VBus	Bus voltage	Float	0	12	0.0078125	0	0	31.9921875	V	8	N	Y
21.0.1			8051900	System Enabled	The system is enabled	Unsigned	12	1	1	0	0	1		8	N	Y
21.1.6			8051900	RoboRIO Present	A roboRIO is currently connected	Unsigned	13	1	1	0	0	1		8	N	Y
21.0.1			8051900	RSVD0	Reserved Bits	Unsigned	14	2	1	0	0			8	N	Y
21.1.0			8051900	Brownout Fault	The input voltage is below specified minimum voltage	Unsigned	16	1	1	0	0			8	N	Y
21.1.0			8051900	RSVD1	Reserved Bits	Unsigned	17	1	1	0	0			8	N	Y
21.1.0			8051900	CAN Warning Fault	CAN RX or TX error levels has exceeded the warning threshold	Unsigned	18	1	1	0	0			8	N	Y
21.1.0			8051900	Hardware Fault	The device has malfunctioned	Unsigned	19	1	1	0	0			8	N	Y
21.0.1			8051900	Switch Channel State	The switch channel commanded state	Unsigned	20	1	1	0	0			8	N	Y
21.1.0			8051900	Sticky Brownout Fault	The input voltage has gone blow specified minimum voltage	Unsigned	21	1	1	0	0			8	N	Y
21.1.0			8051900	RSVD2	Reserved Bits	Unsigned	22	1	1	0	0			8	N	Y
21.1.0			8051900	Sticky CAN Warning Fault	CAN RX or TX error levels have exceeded the warning threshold	Unsigned	23	1	1	0	0			8	N	Y
21.1.0			8051900	Sticky CAN Bus Off Fault	The CAN bus has previously experienced a 'Bus Off' event	Unsigned	24	1	1	0	0			8	N	Y
21.1.0			8051900	Sticky Hardware Fault	The device has malfunctioned	Unsigned	25	1	1	0	0			8	N	Y
21.1.0			8051900	Sticky Firmware Fault	The device firmware malfunctioned and reset during operation	Unsigned	26	1	1	0	0			8	N	Y

Version	Frame Name	Frame Description	CAN Id	Signal Name	Signal Description	Type	Bit Position	Length (bits)	Scale Factor	Offset	Min	Max	Unit	Frame Length	RTR?	User?
21.1.0			8051900	Sticky CH20 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 20	Unsigned	27	1	1	0	0			8	N	Y
21.1.0			8051900	Sticky CH21 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 21	Unsigned	28	1	1	0	0			8	N	Y
21.1.0			8051900	Sticky CH22 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 22	Unsigned	29	1	1	0	0			8	N	Y
21.1.0			8051900	Sticky CH23 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 23	Unsigned	30	1	1	0	0			8	N	Y
21.1.0			8051900	Sticky Has Reset Fault	The device has reset	Unsigned	31	1	1	0	0			8	N	Y
21.0.1			8051900	Total Current	Total current measured by the device	Unsigned	32	8	2	0	0	510 A		8	N	Y
21.1.2			8051900	Sticky CH0 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 0	Unsigned	40	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH1 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 1	Unsigned	41	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH2 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 2	Unsigned	42	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH3 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 3	Unsigned	43	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH4 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 4	Unsigned	44	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH5 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 5	Unsigned	45	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH6 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 6	Unsigned	46	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH7 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 7	Unsigned	47	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH8 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 8	Unsigned	48	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH9 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 9	Unsigned	49	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH10 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 10	Unsigned	50	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH11 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 11	Unsigned	51	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH12 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 12	Unsigned	52	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH13 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 13	Unsigned	53	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH14 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 14	Unsigned	54	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH15 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 15	Unsigned	55	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH16 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 16	Unsigned	56	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH17 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 17	Unsigned	57	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH18 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 18	Unsigned	58	1	1	0	0			8	N	Y
21.1.2			8051900	Sticky CH19 Breaker Fault	The breaker has been tripped or disconnected on PDH Channel 19	Unsigned	59	1	1	0	0			8	N	Y
21.0.1	Set Switch Channel	Set the switch channel output	8050840	Output Set Value	Enable/Disable the switch channel	Unsigned	0	1	1	0	0			1	N	Y
21.0.1	Version	Get the version of the PDH device	8052600	Firmware Fix	Fix version of the device firmware	Unsigned	0	8	1	0	0			8	Y	Y
21.0.1			8052600	Firmware Minor	Minor version of the device firmware	Unsigned	8	8	1	0	0			8	Y	Y
21.0.1			8052600	Firmware Year	Major or year release of the device firmware	Unsigned	16	8	1	0	0			8	Y	Y
21.0.1			8052600	Hardware Minor	Minor version of the device hardware	Unsigned	24	8	1	0	0			8	Y	Y
21.1.5			8052600	Hardware Major	Major version of the device hardware	Unsigned	32	8	1	0	0			8	Y	Y
21.0.1			8052600	Unique ID	Device Unique ID	Unsigned	40	24	1	0	0			8	Y	Y
21.1.0	Clear Faults	Clear sticky faults on the device	8051B80											0	N	Y