

TPMS OTR, CONSTRUCTION, MINING & EXTREME DUTY

260554	<b>TPMS OTR SENSOR</b> Accurate and Reliable Real-Time Tyre Pressure and Temperature Monitoring	each
260550	<b>TPMS VALOR EXTREME KIT</b> Each vehicle requires one kit. For ordering purposes, 4 or 6 sensors must be added to complete the installation. The programming tool is used to program the sensors.	each
260517	<b>TPMS VALOR SENSOR PROGRAM TOOL</b> TPMS Valor Sensor Programming Tool	each



TPMS PASSENGER

260300	<b>TPMS PROGRAMMING TOOL CUB</b>	each
260340	<b>TPMS KIT CUB 4 WHEEL CP41</b>	each
260343	<b>TPMS KIT CUB 4 WHEEL BP-45 (4x4)</b>	each
260345	<b>TPMS KIT CUB 6 WHEEL TRAILER CP63</b>	each
260355	<b>TPMS KIT CUB 22 WHEEL TRUCK</b>	each



TPMS TRUCK, HORSE AND TRAILER AND BUS TPMS

260506 12304	<b>TPMS VALOR KIT FOR TRUCK/BUS/RV 2 AXLE</b> <b>TPMS VALOR KIT FOR MOTORHOMES</b>	each
260350	<b>TPMS KIT CUB 6 WHEEL BUS</b>	each
2605011	<b>TPMS HEAVY HAULERS KIT</b>	each
260500	<b>TPMS VALOR KIT FOR TRUCK/HORSE</b>	each
260502	<b>TPMS VALOR KIT FOR SINGLE TRAILER</b>	each
260504	<b>TPMS VALOR KIT FOR MULTIPLE TRAILER</b>	each
260510	<b>TPMS VALOR SENSOR TRUCK PRES/TEMP W/ID MODULE</b>	each
260515	<b>TPMS VALOR SENSOR BAND S/STEEL FOR TRUCK</b>	each



TPMS VALVES & TOOLS

260310	<b>TPMS SENSOR AND VALVE 433mHZ CLAMP-IN</b>	each
260315	<b>TPMS SENSOR AND VALVE 433mHZ SNAP-IN VALVE</b>	each
260320	<b>TPMS SENSOR AND VALVE 315mHZ CLAMP-IN</b>	each
260325	<b>TPMS SENSOR AND VALVE 315mHZ SNAP-IN VALVE</b>	each
211400	<b>VALVE TUBELESS FOR TPMS TR413 EACH LOOSE</b>	each

