

## mx53 内核编译步骤

这篇文章详解了如何针对 mx53 CPU 编译内核，其中包含了一些针对 mx53 的必要的驱动。

### 1、解压内核源码包，该内核版本为 Linux2.6.35.3。

```
tar zxvf kernel_imx.tar.gz
```


### 2、配置内核

由于 2.6.35 标准内核已经包括对 Freescale i.MX 平台的支持，所以我们要官方提供的配置文件基础之上进行适当的裁减。去除不需要的模块，仅下我们需要的模块。


在 arch/arm/configs 目录下有 imx5\_defconfig，这个文件是官方提供的基于 i.mx5 系列 CPU 的默认配置文件。我们要在这个基础上进行修改。

```
cp arch/arm/configs/imx5_defconfig . 拷贝预配置文件到内核根目录下
```


```
make imx5_defconfig menuconfig 执行配置程序
```




配置内核允许动态加载模块，[\*] Enable loadable module support，这样我们就能通过 insmod、rmmod 动态地向内核中添加、移除驱动程序了。在调试期间是非常方便的。




选择处理器类型，内核中已经有 Freescale iMX 平台的支持了，我们直接选择就行了。在这里选择 MMU 模块，支持内存管理单元。




配置网络功能，使内核包含 TCP/IP 协议栈，支持 Socket 功能，在 IP 层支持 DHCP，为了实现自动获取 IP 地址。



配置驱动程序，使内核支持 MTD 设备、块设备等。这里最主要的是要选择 FEC 网卡驱动。网卡驱动程序的路径在 Device drivers->Network device support->Ethernet (10 or 100Mbit)->FEC ethernet controller。




选择 MMC/SD 支持，路径在 Device drivers->MMC/SD/SDIO support，将 MMC block device driver 勾选上，将 Freescale i.MX Secure Digital Host Controller Interface support 勾选上。




串口驱动，路径在 Device drivers->Character devices->Serial drivers, [\*] MXC Internal serial port support。







配置内核支持的文件系统，这里配置上 ext2/3/4，网络文件系统选择 NFS client support。这样在挂载 NFS 的时候会用到。

BE 北京柘园生物设备有限公司





混杂文件系统选项中有针对 Flash 存储设备的文件系统 jffs2 和 ubifs，也一并选上。



内核中其他的功能模块，根据需要进行相应的选择。

### 3、编译内核

在编译内核之前需要配置好交叉编译器的路径，应该这里是针对于 ARM 平台进行交叉编译，我们直接将路径导入到用户的.bashrc 中。这样配置一次就可以了。

```
vim ~/.bashrc
```

在文件的末尾加上如下两行：

```
export ARCH=arm
```

```
export CROSS_COMPILE=/home/zhangshaoyan/i.mx53/arm-eabi-4.4.0/bin/arm-eabi-
```

```
export PATH=$PATH:/home/zhangshaoyan/i.mx53/u-boot-imx/tools
```

因为在编译生成 u-boot format 的内核时，需要使用到编译 u-boot 生成的程序 mkimage，这里我们也一并导出到环境变量 PATH 中了。



```
export ARCH=arm
export CROSS_COMPILE=/home/zhangshaoyan/i.mx53/arm-eabi-4.4.0/bin/arm-eabi-
export PATH=$PATH:/usr/local/arm/4.3.2/bin/:/home/zhangshaoyan/i.mx53/uboot-imx/tools
```

下面开始编译，直接输入命令：make uImage

```
zhangshaoyan@ubuntu:~/i.mx53/kernel_imx$ make uImage
scripts/kconfig/conf -s arch/arm/Kconfig
CHK include/linux/version.h
CHK include/generated/utsrelease.h
make[1]: `include/generated/mach-types.h' is up to date.
CC arch/arm/kernel/asm-offsets.s
GEN include/generated/asm-offsets.h
CALL scripts/checksyscalls.sh
CC init/main.o
CHK include/generated/compile.h
CC init/version.o
CC init/do_mounts.o
LD init/mounts.o
CC init/noinitramfs.o
LD init/built-in.o
CC arch/arm/kernel/compat.o
CC arch/arm/kernel/elf.o
AS arch/arm/kernel/entry-armv.o
AS arch/arm/kernel/entry-common.o
CC arch/arm/kernel/irq.o
CC arch/arm/kernel/process.o
CC arch/arm/kernel/ptrace.o
CC arch/arm/kernel/return_address.o
```

#### 4、编译完成

编译完成后，会在 arch/arm/boot 文件夹下生成 uImage 文件。这个文件就是我们刚才编译好的。使用 MFG Tool 烧写内核时，直接使用这里生成的内核映像文件即可。

```
OBJCOPY arch/arm/boot/Image
Kernel: arch/arm/boot/Image is ready
AS arch/arm/boot/compressed/head.o
GZIP arch/arm/boot/compressed/piggy.gzip
AS arch/arm/boot/compressed/piggy.gzip.o
CC arch/arm/boot/compressed/misc.o
SHIPPED arch/arm/boot/compressed/lib1funcs.S
AS arch/arm/boot/compressed/lib1funcs.o
LD arch/arm/boot/compressed/vmlinux
OBJCOPY arch/arm/boot/zImage
Kernel: arch/arm/boot/zImage is ready
UIMAGE arch/arm/boot/uImage
Image Name: Linux-2.6.35.3
Created: Tue Dec 18 22:06:21 2012
Image Type: ARM Linux Kernel Image (uncompressed)
Data Size: 3027828 Bytes = 2956.86 kB = 2.89 MB
Load Address: 70008000
Entry Point: 70008000
Image arch/arm/boot/uImage is ready
zhangshaoyan@ubuntu:~/i.mx53/kernel_imx$
```

shell.albert

2012/12/19