

netif functions: netif_set_default and netif_set_up

25 February 2026 19:12

netif_set_default

Syntax

```
void netif_set_default(struct netif *netif);
```

Purpose

Sets default network interface.

Operates On

- Updates global pointer inside lwIP
- No hardware access

netif_set_up

Syntax

```
void netif_set_up(struct netif *netif);
```

Purpose

Marks interface as active.

Operates On

- Enables interface in lwIP state machine
- Does not start hardware (driver already initialized)