

NovTech User Guide

Meerkat™

Document Name: User Guide

Document Number: 001-013-02-04-05

Rev. 1.0

8/2017





Contact Information:

Home Page:

www.novtech.com

E-mail:

sales@novtech.com

Address:

7401 Wiles Road, Suite 229
Coral Springs, FL 33067
United States
+1-(954) 341-3320

Support:

support@novtech.com

Information in this document is provided solely to enable system and software implementers to use NovTech products. There are no express or implied copyright licenses granted hereunder to design or fabricate any circuits or circuits based on the information in this document. NovTech reserves the right to make changes without further notice to any products herein. NovTech makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does NovTech assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NovTech data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typical", must be validated for each customer application by customer's technical experts. NovTech does not convey any license under its patent rights nor the rights of others. NovTech products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the NovTech product could create a situation where personal injury or death may occur. Should Buyer purchase or use NovTech products for any such unintended or unauthorized application, Buyer shall indemnify and hold NovTech and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that NovTech was negligent regarding the design or manufacture of the part.

Learn More: For more information about NovTech products, please visit www.novtech.com.

NovTech™ and the NovTech logo are trademarks of NovTech, Inc. All other product or service names are the property of their respective owners. © NovTech, Inc. 2017. All rights reserved.

Revision History

Revision Number	Date	Changes	Notes
1.0	08/2017	Initial Release	


Table 1- Provides a revision history for this user guide.

1 Registering Meerkat™

Please register your Meerkat™ at <http://www.novtech.com/registration>

Provide the serial # from the back side of the Meerkat™ board.

Provide the requested information and select “Meerkat” from the version drop down.

The form is titled "Register your NovTech Product" in bold black text. It contains several input fields: "Name *" with two sub-fields for "First Name" and "Last Name"; "Company *" with a single wide field; "Email Address *" with a single wide field; "Phone" with four separate input boxes; and a "Country" dropdown menu. Below the country menu is a "Version" dropdown menu with a list of options: "IoT Octopus", "NetLeap", "NOVPEK™CVLite", "NOVPEK™i.MX7", "NOVPEK™i.MX6", and "NOVPEK™CV". The "NetLeap" option is currently selected and highlighted in blue. At the bottom of the form is a black "SUBMIT" button.

Register your NovTech Product

Name *

First Name Last Name

Company *

Email Address *

Phone

Country (###) ### ####

Version

- IoT Octopus
- NetLeap
- NOVPEK™CVLite
- NOVPEK™i.MX7
- NOVPEK™i.MX6
- NOVPEK™CV

SUBMIT

Figure 1 - Product Registration

2 Download support files

Support files can be downloaded from: <http://bit.ly/i.MX7-96B>

This location contains documents, schematics, installable tools and a Virtual Machine pre-configured with tools to speed application development.

Note that there are two distributions provided for the Meerkat:

- A graphical system with xfce and enlightenment based on Angstrom. Full source code, recipes and pre-compiled images are provided.
- A simple system with a command console. Full source code, a configured build-root and pre-compiled images are provided.

Available from the Portal is a User Manual (001-013-02-04-05) which details the contents and usage of the Virtual Machine.

3 Meerkat™ overview




Figure 2 – Meerkat™ Top



Figure 3 – Meerkat™ bottom

4 Serial Connections

The supplied cable connects to the Meerkat™ as follows:




Figure 4 - Connecting supplied cable

5 Booting Meerkat™

5.1 Hardware Setup

To setup the Meerkat™ board for booting, follow these steps:

1. Plug in the supplied USB cable to the UART port on the board and connect to PC. Verify the USB serial driver is found.
2. Insert the SD card into the SD slot.

5.2 Serial Console Setup

Open a Serial Terminal like Hyper-Terminal, putty or UConn, with settings of 115200, 8, N, 1.

For convenience, putty and a preconfigured settings file are provided in the supplied Virtual Machine (available from the download link as indicated in section 2).

The VM provides a preinstalled environment with tools to speed development.

A link to putty can be found on the desktop

Configure putty to use an 8n1 UART at 115200 bps.

For convenience, a preconfigured setting called “USB to TTL UART” is also provided in the virtual machine.





Figure 5 - Configuring Putty

5.3 Power the board

Using the provided power adaptor apply +8 to 18V power to the NovTech Meerkat™. Monitoring the serial terminal, you can stop at u-boot or boot all the way into Linux.

Note that for the graphical image, a terminal console is not available and all system control must be done through the graphical interface.



```

0), (N/A, 2000 mBm), (N/A)
[ 10.471741] cfg80211: (2474000 KHz - 2494000 KHz @ 20000 KHz), (N/A, 2000 m
Bm), (N/A)
[ 10.479996] cfg80211: (5170000 KHz - 5250000 KHz @ 80000 KHz, 160000 KHz AU
TO), (N/A, 2000 mBm), (N/A)
[ 10.496735] cfg80211: (5250000 KHz - 5330000 KHz @ 80000 KHz, 160000 KHz AU
TO), (N/A, 2000 mBm), (0 s)
[ 10.506335] cfg80211: (5490000 KHz - 5730000 KHz @ 160000 KHz), (N/A, 2000
mBm), (0 s)
[ 10.514458] cfg80211: (5735000 KHz - 5835000 KHz @ 80000 KHz), (N/A, 2000 m
Bm), (N/A)
[ 10.524804] cfg80211: (57240000 KHz - 63720000 KHz @ 2160000 KHz), (N/A, 0
mBm), (N/A)
[ OK ] Started Avahi mDNS/DNS-SD Stack.
      Starting Connection service...
      Starting Network Service...
[ OK ] Started Save/Restore Sound Card State.
[ OK ] Started Login Service.
[ OK ] Started Network Service.
[ OK ] Started Connection service.
[ OK ] Reached target Network.
      Starting Network Name Resolution...
      Starting Permit User Sessions...
      Starting Lightning Fast Webserver With Light System Requirements...
      Starting Xinetd A Powerful Replacement For Inetd...
[ OK ] Started Permit User Sessions.
[ OK ] Started Getty on tty1.
[ OK ] Started Xinetd A Powerful Replacement For Inetd.
[ OK ] Started Lightning Fast Webserver With Light System Requirements.
[ OK ] Started Network Name Resolution.
      Starting WPA supplicant...
      Starting Hostname Service...
[FAILED] Failed to start Hostname Service.
See 'systemctl status systemd-hostnamed.service' for details.
[ OK ] Started WPA supplicant.
[ 12.717983] brcmfmac: brcmf_add_if: ERROR: netdev:wlan0 already exists
[ 12.724549] brcmfmac: brcmf_add_if: ignore IF event
      Starting Authorization Manager...
[ OK ] Started Authorization Manager.
      Starting Daemon for power management...
[ OK ] Started Daemon for power management.
      Starting Disk Manager...
[ OK ] Started Disk Manager.
[ TIME ] Timed out waiting for device dev-ttymxc0.device.
[DEPEND] Dependency failed for Serial Getty on ttymxc0.
[ TIME ] Timed out waiting for device dev-ttyGS0.device.
[DEPEND] Dependency failed for Serial Getty on ttyGS0.
[ TIME ] Timed out waiting for device dev-ttymxc5.device.
[DEPEND] Dependency failed for Serial Getty on ttymxc5.
[ OK ] Reached target Login Prompts.
[ OK ] Reached target Multi-User System.
      Starting Update UTMP about System Runlevel Changes...
[ OK ] Started Update UTMP about System Runlevel Changes.

```

Figure 6 - Initial Boot of Meerkat™



6 Initial network configuration

The Meerkat will need to be configured for your specific wireless network. Once configured, the network will start automatically when the board is powered up.

6.1 Graphical image networking

The SD card delivered with your meerkat has a graphical desktop based on xfce. This desktop will require a mouse and keyboard to navigate. Those can be connected to the USB ports on the Meerkat.

The networking on this image is managed by connman, but is not enabled by default. If you want wireless networking on your Meerkat, the connman applet will need to be enabled to start at boot, and configured for your network.

After booting the Meerkat image per the instructions above, select "Applications" from the upper left corner of the screen.

Click on:

Applications->Settings->Settings Manager

Then select:

System->Session and Startup->Application Autostart->Connection Manager.

There should now be a black checkmark next to "Connection Manager".

Select "Close" (close all open settings manager windows).

Power cycle or reset your meerkat, the connman applet should be running and visible on the upper right of your screen on your next power up.

When the board comes back up, click on the Applet in the upper and select "Preferences", then select your wireless network and click "Connect" on the right-hand side of the menu. Note that "Connect" does not look like a button, but text.

If your network requires additional configuration for security, the applet will prompt you for your authentication information.



6.2 Console image networking

The console image ships with a network configuration that automatically connects to open (unsecure) networks that it finds. If successful, you will see the board retrieve an IP address via DHCP and will be able to ping to an IP address from the command line.

If your network requires additional configuration for security, you will need to provide the credentials for your network. This is accomplished from the meerkat console with the “wpa_passphrase” tool as follows:

```
wpa_passphrase YOURNET yourpassphrase >> /etc/wpa_supplicant.conf
```

which will append an entry similar to the following to your `/etc/wpa_supplicant.conf` file:

```
network={
    ssid="YOURNET"
    #psk="yourpassphrase"
    psk=0d0992b62e7ce466b47aef8ea26fcd77421f6498f225419b40364c1b4441d08d
}
```

Remember to replace *YOURNET* and *yourpassphrase* with the information specific to your network.