

WinZapi Quick Start Guide

The screenshot shows the WinZapi software interface with the following components and callouts:

- Quick Connect tabs:** Callout pointing to the 'Traction', 'Display', and 'Steering(EPS)' tabs. Text: "Quick Connect tabs. Use these to connect to individual controllers.menu."
- Parameters menu:** Callout pointing to the 'Parameters' tab. Text: "This menu operates the same as the ZapiLink"
- Quick menu tabs:** Callout pointing to the 'Parameters', 'Tester', and 'Options' tabs. Text: "Quick menu tabs Use these to select items quickly"
- Model Information:**
 - Model: AC4 TP LL 1.24
 - Type: 72V / 550A
 - Hours: 0 Hrs
 - Alarm: Capacitor charge
- * MINIMUM SPEED ***
 - Description: Minimum speed when direction selected and accelerator at minimum.
 - 0.3 Hz = minimum value
 - 0.9 Hz = maximum value
 - Default 20KW = 0.3Hz, 5KW = 0.3Hz
- Parameters Table:**

Parameters	Value	Units
Release braking	L4	
Invers. braking	L5	
Pedal braking	L2	
Max speed forw	140	Hz
Cutback speed 1	40	Hz
Cutback speed 2	20	Hz
Cutback speed 3	6	Hz
MINIMUM SPEED	0.30	Hz
Maximum current	L3	
- Buttons:**
 - Reconnect
 - Finish
 - Exit
- STILL logo:** Located at the bottom center of the window.

Callouts for bottom buttons:

- Reconnect:** "Click this to connect to selected controller not required when"
- Finish:** "This Window displays the help. To get help Right Click mouse on the desired item."
- Exit:** "This box displays prompts and user information."
- Adjustment buttons:** Callout pointing to the '<<' and '>>' buttons next to the parameters. Text: "Use these buttons to adjust the Parameter up or down."

Installation

The installation package is provided as a ZIP file to allow emailing through firewalls. Unzip the single install EXE and run.

The first time WinZapi is used after installation, it will prompt for an authorisation code. This is to control the distribution of the beta release.

The language of the beta is English only, although German French and Italian will be available for the full release.

Quick guide to getting started

To start WinZapi click the icon on the desktop or from the WinZapi folder in the start menu.

To load Parameters for Traction.

Start WinZapi.
Click on the Traction Tab.
Click the "Get Parameters" Button .

The Parameters should now be loaded and visible in the Parameters window.

To Load the Special Adjust Menu for Traction

Start WinZapi.
In the menu select "Special" and then "Special Adjust".
(A new tab should appear next to options)
Click on the Traction Tab.
Click the "Get Special Adjustments" Button .

The Special Adjustments should now be loaded and visible in the Parameters window.

Generally if an option is not visible then select it from the menu to make it visible.

To Change Language

Choose "Preferences", "Settings".
The Settings window will now be displayed.
Click the "Change Language File" button.
Choose the new Language File.
Click Open.
Click Exit to close the Settings Box.

The program language should now be updated.
