

HIMatrix M45

Safety-Related Controller

M-DO 2 01 Manual



HIMA Paul Hildebrandt GmbH
Industrial Automation

All HIMA products mentioned in this manual are protected by the HIMA trademark. Unless noted otherwise, this also applies to other manufacturers and their respective products referred to herein.

HIMax[®], HIMatrix[®], SILworX[®], XMR[®] and FlexSILon[®] are registered trademarks of HIMA Paul Hildebrandt GmbH.

All of the instructions and technical specifications in this manual have been written with great care and effective quality assurance measures have been implemented to ensure their validity. For questions, please contact HIMA directly. HIMA appreciates any suggestion on which information should be included in the manual.

Equipment subject to change without notice. HIMA also reserves the right to modify the written material without prior notice.

For further information, refer to the HIMA DVD and our website at <http://www.hima.de> and <http://www.hima.com>.

© Copyright 2014, HIMA Paul Hildebrandt GmbH

All rights reserved

Contact

HIMA contact details:

HIMA Paul Hildebrandt GmbH

P.O. Box 1261

68777 Brühl, Germany

Phone: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com

Revision index	Revisions	Type of change	
		technical	editorial
1.00	First edition of the HIMatrix M45 manual		
1.01	Revised: Chapter 6.2.2	X	X
1.02	Revised: Chapter 6.1		X

Table of Contents

1	Introduction	5
1.1	Structure and Use of this Manual	5
1.2	Target Audience	5
1.3	Formatting Conventions	6
1.3.1	Safety Notices	6
1.3.2	Operating Tips	7
2	Safety	8
2.1	Intended Use	8
2.1.1	Environmental Requirements	8
2.1.2	ESD Protective Measures	8
2.2	Residual Risk	9
2.3	Safety Precautions	9
2.4	Emergency Information	9
3	Product Description	10
3.1	Safety Function	10
3.2	Scope of Delivery	10
3.3	Type Label	11
3.4	Structure	12
3.4.1	Safety-Related Relay Outputs	12
3.4.1.1	Burner Control Applications	12
3.4.1.2	General Safety Applications	13
3.4.2	Block Diagram	14
3.4.3	Front View	15
3.4.4	LED Indicators	16
3.4.4.1	Module Status Indicators	16
3.4.4.2	I/O Indicators	17
3.5	Product Data	18
3.6	Socket	20
3.6.1	Mechanical Coding	20
3.6.2	Coding the M-DO 2 01 Module and Socket	21
3.6.2.1	Configuring the Socket Coding	21
3.6.3	Socket M-SO REL 01	22
3.6.3.1	Terminal Assignment for the Cable Plugs	23
3.6.3.2	Cable Plug Properties	23
4	Start-Up	24
4.1	Mounting	24
4.1.1	Wiring Outputs not in Use	24
4.2	Mounting Module and Socket	25
4.2.1	Mounting and Removing the Sockets	25
4.2.2	Inserting and Removing the Module	27
4.3	Configuration with SILworX	28
4.3.1	Tab Module	28
4.3.2	Tab M-DO 2 01_1: Channels	29

4.4	Connection Variants	30
4.4.1	Connecting Actuators	30
4.4.2	Applications for Fast and Safe Shutdown	31
4.4.3	Wiring one Actuator to Redundant Modules	33
5	Operation	34
5.1	Handling	34
5.2	Diagnosis	34
6	Maintenance	35
6.1	Faults	35
6.2	Maintenance Measures	35
6.2.1	Loading the Operating System	35
6.2.2	Proof Test	35
7	Decommissioning	36
8	Transport	37
9	Disposal	38
	Appendix	39
	Glossary	39
	Index of Figures	40
	Index of Tables	41
	Index	42

1 Introduction

This manual describes the technical characteristics of the module and its use. It provides information on how to install, start up and configure the module in SILworX.

1.1 Structure and Use of this Manual

The content of this manual is part of the hardware description of the HIMatrix M45 programmable electronic system.

This manual is organized in the following main chapters:

- Introduction
- Safety
- Product description
- Start-up
- Operation
- Maintenance
- Decommissioning
- Transport
- Disposal

Additionally, the following documents must be taken into account:

Name	Content	Document no.
HIMatrix M45 Safety Manual	Safety functions of the HIMatrix system	HI 800 653 E
HIMatrix M45 System Manual	Hardware description of the HIMatrix M45	HI 800 651 E
SILworX Communication Manual	Description of communication and protocols	HI 801 101 E
SILworX Online Help (OLH)	Instructions on how to use SILworX	-
SILworX First Steps Manual	Introduction to SILworX	HI 801 103 E

Table 1: Additional Relevant Documents

The latest manuals can be downloaded from the HIMA website at www.hima.com. The revision index on the footer can be used to compare the current version of existing manuals with the Internet edition.

1.2 Target Audience

This document addresses system planners, configuration engineers, programmers of automation devices and personnel authorized to implement, operate and maintain the modules and systems. Specialized knowledge of safety-related automation systems is required.

1.3 Formatting Conventions

To ensure improved readability and comprehensibility, the following fonts are used in this document:

Bold	To highlight important parts. Names of buttons, menu functions and tabs that can be clicked and used in the programming tool.
<i>Italics</i>	For parameters and system variables.
<code>Courier</code>	Literal user inputs.
RUN	Operating states are designated by capitals.
Chapter 1.2.3	Cross-references are hyperlinks even if they are not particularly marked. When the cursor hovers over a hyperlink, it changes its shape. Click the hyperlink to jump to the corresponding position.

Safety notices and operating tips are particularly marked.

1.3.1 Safety Notices

The safety notices are represented as described below.

These notices must absolutely be observed to reduce the risk to a minimum. The content is structured as follows:

- Signal word: warning, caution, notice
- Type and source of risk
- Consequences arising from non-observance
- Risk prevention

SIGNAL WORD



Type and source of risk!

Consequences arising from non-observance.

Risk prevention.

The signal words have the following meanings:

- Warning indicates hazardous situation which, if not avoided, could result in death or serious injury.
- Caution indicates hazardous situation which, if not avoided, could result in minor or modest injury.
- Notice indicates a hazardous situation which, if not avoided, could result in property damage.

NOTICE



Type and source of damage!

Damage prevention

1.3.2 Operating Tips

Additional information is structured as presented in the following example:

i

The text corresponding to the additional information is located here.

Useful tips and tricks appear as follows:

TIP

The tip text is located here.

2 Safety

All safety information, notices and instructions specified in this document must be strictly observed. The product may only be used if all guidelines and safety instructions are adhered to.

The product is operated with SELV or PELV. No imminent risk results from the product itself. The use in Ex-Zone is permitted if additional measures are taken.

2.1 Intended Use

HIMatrix components are designed for assembling safety-related controller systems.

When using the components in the HIMatrix system, comply with the following general requirements.

2.1.1 Environmental Requirements

Requirement type	Range of values
Protection class	Protection class II in accordance with IEC/EN 61131-2
Ambient temperature	0...+60 °C
Storage temperature	-40...+85 °C
Pollution	Pollution degree II in accordance with IEC/EN 61131-2
Altitude	< 2000 m
Housing	Standard: IP20
Supply voltage	24 VDC

Table 2: Environmental Requirements

Exposing the HIMatrix system to environmental conditions other than those specified in this manual can cause the HIMatrix system to malfunction.

2.1.2 ESD Protective Measures

Only personnel with knowledge of ESD protective measures may modify or extend the system or replace devices.

NOTICE



Device damage due to electrostatic discharge!

- When performing the work, make sure that the workspace is free of static, and wear an ESD wrist strap.
- If not used, ensure that the device is protected from electrostatic discharge, e.g., by storing it in its packaging.

2.2 Residual Risk

No imminent risk results from a HIMatrix M45 system itself.

Residual risk may result from:

- Faults related to engineering
- Faults related to the user program
- Faults related to the wiring

2.3 Safety Precautions

Observe all local safety requirements and use the protective equipment required on site.

2.4 Emergency Information

A HIMatrix M45 system is a part of the safety equipment of a plant. If a device or a module fails, the system enters the safe state.

In case of emergency, no action that may prevent the HIMatrix M45 systems from operating safely is permitted.

3 Product Description

The **M-DO 2 01** relay module is intended for use in the HIMatrix M45 system.

Up to 62 I/O modules can be used in a HIMatrix M45 system, if the structuring conditions as of the system manual (HI 800 651 E) are met.

The module is equipped with 2 potential-free relay outputs with forcibly guided contacts. The relay outputs are suitable for connecting ohmic and inductive loads.

The module has been certified by the TÜV for safety-related applications up to SIL 3 (IEC 61508, IEC 61511, IEC 62061 and EN 50156) as well as PL e (EN ISO 13849-1). Further safety standards, application standards and test standards are specified in the certificates available on the HIMA website.

3.1 Safety Function

The safety function meets the integrity requirements described in the corresponding test standards.

The module is designed in accordance with the de-energize-to-trip principle. If a module fault or a channel fault occurs, both relay outputs are set to the de-energized state. In both cases, the *Err* LED is blinking.

All instructions on how to use the module specified in the safety manual must be observed.

3.2 Scope of Delivery

To be able to operate, the module must be installed on a suitable socket. The socket is not included within the scope of delivery of the module.

The socket is described in Chapter 3.6.

3.3 Type Label

The type label specifies the following details:

- Product name
- Mark of conformity
- Bar code (2D code)
- Part number (Part-No.)
- Hardware revision index (HW-Rev.)
- Operating system revision index (OS-Rev.)
- Operating data (Power:)
- Production year (Prod-Year:)



Figure 1: Sample Type Label

3.4 Structure

The chapter contains the following sections:

- Safety-Related Relay Outputs
- Block Diagram
- LED Indicators

The module is equipped with a safety-related 1oo2D processor system and performs the following functions:

- Safe shutdown of the relay outputs
- Control and monitoring of the I/O level

The process data and states of the module are provided to the processor module (M-CPU) via the system bus.

3.4.1 Safety-Related Relay Outputs

The module is equipped with two relay outputs. Each relay output is switched by two relays in series, one relay of these is a safety relay and switched both relay outputs, see Figure 3. The safe shutdown capability is tested.

The relay outputs are cyclically monitored by the processor system. If the states do not correspond to the default values, a module fault has occurred and both relay outputs are set to the de-energized state.

Both relay outputs are electrically safely separated from one another and from the power supply. For safe separation, the air and creeping distances are designed in accordance with IEC 61131-2 for overvoltage class II up to 300 V.

3.4.1.1 Burner Control Applications

For burner control applications, the switching current must be limited to 60 % of the maximum allowed value using an external fuse in accordance with EN 298 and EN 50156 (VDE 0116).

At least two monitored relays must be used to shut down the entire fuel supply safely.

The relays in use comply with the the contact lifetime required for burner control applications:

- Mechanical $\geq 3 \times 10^6$ switching operations
- electrical $\geq 250\,000$ switching operations

3.4.1.2 General Safety Applications

The instructions specified in Figure 2 and in Table 8 must be observed for general safety applications:

- The maximum permissible number of switching operations.
- The maximum permissible switching currents, voltage and power.





Figure 2: Contact Lifetime

3.4.2 Block Diagram

The following block diagram illustrates the structure of the module.



1 System Bus

2 Switch

3 Watchdog

4 Safety-Related Processor System

5 Interface

6 Field Zone

Figure 3: Block Diagram

3.4.3 Front View

The following figure shows the front view of the module:




Figure 4: Front View

3.4.4 LED Indicators

The LEDs indicate the operating state of the module. The LEDs are classified as follows:

- Module status indicators
- I/O indicators

When the supply voltage is switched on, an LED test is performed and all LEDs are briefly lit.

Definition of blinking frequencies

The following table defines the blinking frequencies of the LEDs:

Name	Blinking frequencies
Blinking1	Long (approx. 600 ms) on, long (approx. 600 ms) off
Blinking2	Short (approx. 200 ms) on, short (approx. 200 ms) off, short (approx. 200 ms) on, long (approx. 600 ms) off
Blinking-x	Ethernet communication: Blinking synchronously with data transfer

Table 3: Blinking Frequencies of LEDs

3.4.4.1 Module Status Indicators

The LEDs signal the following states:

LED	Color	Status	Description
Run	Green	On	Module in RUN, normal operation
		Blinking1	Module state STOP/OS_DOWNLOAD or OPERATE (only with processor modules)
		Off	Module not in RUN, observe the other status LEDs.
Err	Red	On	Warning, e.g.: No license for additional functions (e.g., communication protocols), test mode.
		Blinking1	Fault, e.g.: <ul style="list-style-type: none"> ▪ Internal module fault detected by self-tests, e.g., hardware or voltage supply. ▪ Error while loading the operating system.
		Blinking2	Field fault, but no internal fault
		Off	Normal operation
Stop	Yellow	On	Module state STOP / VALID CONFIGURATION
		Blinking1	Module state STOP / INVALID CONFIGURATION or STOP / LOADING OS
		Off	Module not in STOP, observe the other status LEDs.
Init	Yellow	On	Module state: INIT
		Blinking1	Module state LOCKED or STOP / LOADING OS
		Off	Module state: neither INIT nor LOCKED, observe the other status LEDs.

Table 4: Module Status Indicators

3.4.4.2 I/O Indicators

Die LEDs of the I/O indicators are labeled *DO*.

LED	Color	Status	Description
DO 1, DO 2	Yellow	On	The corresponding channel is active (energized)
		Blinking2	The related channel is faulty.
		Off	The corresponding channel is not active (de-energized)

Table 5: I/O Indicators

3.5 Product Data

General	
Supply voltage	24 VDC, -15...+20 %, $r_p \leq 5$ %, PELV, SELV
Max. supply voltage	30 VDC
Current input	max. 100 mA max. 2 W
Current input of the module, all relay de-energized	54 mA (24 VDC)
Current input of the module, all relay energized	80 mA (24 VDC)
Max. reaction time of the module ¹⁾	110 ms
Electrical isolation of the channels	Yes
Ambient temperature	0...+60 °C
Storage temperature	-40...+85 °C
Humidity	max. 95 % relative humidity, non-condensing
Type of protection	IP20
Dimensions without socket (H x W x D) in mm	105 x 25 x 72
Dimensions with socket up to DIN rail (H x W x D) in mm	165 x 25.2 x 90
Weight	
Module	approx. 140 g
Socket	approx. 80 g
¹⁾ In case of an internal fault	

Table 6: Product Data

Relay Outputs	
Relay types per channel	2 relays with forcibly guided contacts
Number of channels	2 potential-free normally open contacts
Switching voltage	5...250 V
Switching current per channel	5 mA...4 A
Switching frequency	max. 4 Hz
Response time (normally-open contact closed)	Typ. 10 ms
Drop-out time, normally-closed contact closed	Typ. 3 ms
Contact material	AgCuNi + 0.2...0.4 µm Au
Contact lifetime	
- Mechanical	> 10 x 10 ⁶ switching operations
- Electrical	See Figure 2

Table 7: Specifications for the Relay Outputs

Relay Output Switching Capacity (general safety applications)		
Switching capacity DC induction-free ¹⁾	≤ 30 VDC	max. 120 W
	≤ 70 VDC	max. 100 W
	≤ 100 VDC	max. 70 W
	≤ 250 VDC	max. 60 W
Switching capacity DC (Inductive load tau = L/R = 40 ms)	≤ 30 VDC	max. 45 VA
	≤ 70 VDC	max. 38 VA
	≤ 100 VDC	max. 38 VA
	≤ 250 VDC	max. 30 VA
Switching capacity AC induction-free ¹⁾	≤ 250 VAC	max. 800 VA
Switching capacity AC cos φ > 0.5	≤ 250 VAC	max. 800 VA
¹⁾ Circuit induction-free - Free-wheeling diode - Use suitable protective circuit, e.g., RC elements, Zener diodes or varistors		


Table 8: Relays Output Switching Capacity

3.6 Socket

Socket and module form together a functional unit. The module is connected to the system bus, the power supply and the field zone via a socket. The field lines are connected to the sockets cable plugs, see Figure 6.

3.6.1 Mechanical Coding

Module and socket are mechanically coded, see Figure 5. The position of the coding pins determines the module's coding and is defined by the manufacturer. Two coding sockets accept the coding pins and must be configured in the selected module, see Chapter 3.6.2. Coding prevents the socket from improper assembling.



1 Upper Coding Pin

2 Lower Coding Pin

3 Upper Coding Socket

4 Lower Coding Socket

Figure 5: Example of Module and Socket Coding

3.6.2 Coding the M-DO 2 01 Module and Socket

To attach the module, the coding of the M-SO REL 01 socket must be set as follows:





Order	Module coding (rear view)	Position	Coding socket
Upper		1	
Lower		6	

Table 9: Module and Socket Coding

3.6.2.1 Configuring the Socket Coding

Tools and utilities:


- Screwdriver, slotted 0.8 x 4.0 mm

Configuring the upper and lower coding socket

1. Insert the screwdriver into the opening of the upper coding socket.
2. Turn the screwdriver until the required coding is set.
3. Repeat these steps for the lower coding socket.
4. Insert the module into the socket to check the coding.
5. Remove the module

3.6.3 Socket M-SO REL 01

Socket for being equipped with relay modules M-DO 2 01, see system manual (HI 800 651 E).



- | | |
|--|--|
| 1 System Bus with Power Supply | 4 Field Terminals (Cable Plugs) |
| 2 Latch (Connection to the Left Socket) | 5 Latch (Securing to DIN Rail) |
| 3 I/O Module Plug | |

Figure 6: M-SO REL 01 Socket

The latches are used to secure the socket (**2**, **5**) to the DIN rail and simultaneously to ensure connection to the socket on the left hand-side. Socket and module are connected to the processor module and the power supply via the system bus. The I/O plugs provide the connection between module and socket. The actuators are connected to the field terminals, see Chapter 3.6.3.1 and Chapter 4.4.

3.6.3.1 Terminal Assignment for the Cable Plugs

Terminal	Signal	Function
1	DO1	Relay output 1
2	DO1	Relay output 1
3	DO2	Relay output 2
4	DO2	Relay output 2

Table 10: Terminal Assignment for Cable Plugs

3.6.3.2 Cable Plug Properties

The cable plugs feature the following properties:

Connection to the Field Zone	
Cable plugs	2 pieces, with 2 poles
Wire cross-section	0.2...1.5 mm ² (single-wire) 0.2...1.5 mm ² (finely stranded) 0.2...1.5 mm ² (with wire end ferrule) 0.2...1.5 mm ² (with wire end ferrule with collar)
Stripping length	13 mm
Screwdriver	Slotted, 0.6 x 3.5
Tightening torque	0.4...0.5 Nm

Table 11: Cable Plug Properties

4 Start-Up

This chapter describes how to install, configure and connect the module. For more information, refer to HIMatrix M45 system manual (HI 800 651 E).

4.1 Mounting

The module is plugged in to the corresponding socket, which is mounted on a 35 mm DIN rail.

Observe the following points when mounting the module and the socket:

- Sockets or modules may only be removed or replaced in the de-energized state.

4.1.1 Wiring Outputs not in Use

Outputs that are not being used may stay open and need not be terminated. To prevent short-circuits and sparks in the field zone, never connect a wire to a socket if it is open on the field side.

4.2 Mounting Module and Socket

This chapter describes how to mount and remove the modules and sockets. When replacing modules, the sockets remain on the DIN rail. This saves additional wiring effort since all field lines are connected to the socket.

4.2.1 Mounting and Removing the Sockets

Tools and utilities:

- Screwdriver, slotted 1.0 x 5.5 mm


To insert the socket

1. Set the socket onto the DIN rail **1**.
2. Swivel the socket in **2**.
3. Move the socket on the DIN rail and connect it to another socket **3**.
4. Press the socket's latch upwards **4**.
 - ☒ The latch is used to attach the socket to the DIN rail, and is secured to the socket located on its left-hand side.
5. The socket mounting is completed, the field lines can be connected.

To remove the socket

Prior to removing the socket, the module must be removed and the field lines must be released from the terminals.

1. Use a screwdriver to push the blue latch downwards **4**.
2. Remove the sockets from the adjacent sockets **3**.
3. Swivel the socket out **2**.
4. Lift the socket and remove it **1**.



- 1** Setting and Lifting the Socket
- 2** Swiveling the Socket In and Out

- 3** Connecting and Disconnecting Sockets
- 4** Closing and Opening the Latch

Figure 7: Example of Socket Mounting

4.2.2 Inserting and Removing the Module

This chapter describes how to mount and remove a module in the M45 system.


Coding prevents the module from improper assembling.

To insert the module

1. Plug the module onto the socket, until the locking mechanism is engaged.

To remove the module

1. Press the latch **1** backwards as far as it can go. The locking mechanism is released.
2. Remove the module from the socket.



1 Latch for Releasing the Module

Figure 8: Example of Mounting and Removing the Module

4.3 Configuration with SILworX

The module is configured in the Hardware Editor of the SILworX programming tool.

Observe the following points when configuring the module:

To evaluate the system parameters from within the user program, they must be connected to global variables. Perform this step in the Hardware Editor using the module's detail view.

The following tables present the statuses and parameters for the module in the same order given in the SILworX Hardware Editor.

4.3.1 Tab Module

The **Module** tab contains the following system parameters:

Name		R/W	Description
Enter these statuses and parameters directly in the Hardware Editor.			
Name		W	Module name
Name	Data type	R/W	Description
The following statuses and parameters can be assigned global variables and used in the user program.			
Data valid	BOOL	R	TRUE: Current values are processed. FALSE: Initial values are processed.
Module OK	BOOL	R	TRUE: No faults detected FALSE: Faults detected on at least one channel or module.
Power Supply State	BYTE	R	Bit-coded state of the power supply units 0 = normal Bit0 = 1: Supply voltage (24 V) faulty
Temperature State	BYTE	R	Bit-coded temperature state of the module 0 = normal Bit0 = 1: Temperature threshold 1 has been exceeded Bit1 = 1: Temperature threshold 2 has been exceeded Bit2 = 1: Fault in temperature measurement For further details, refer to chapter <i>Monitoring the Temperature State</i> integrated in the system manual.

Table 12: System Parameters of the Relay Outputs, Module Tab

4.3.2 Tab M-DO 2 01_1: Channels

The **M-DO 2 01_01: Channels** tab contains the following system parameters for each relay output.

Global variables can be assigned to the statuses and parameters with -> and used in the user program. The value without -> must be directly entered.

Name	Data type	R/W	Description
Channel no.	---	R	Channel number, preset and not changeable
Channel Value [BOOL] ->	BOOL	W	Output value of the relay output: TRUE: Channel energized FALSE: Channel de-energized
-> Channel OK	BOOL	R	TRUE: Faultless channel. The channel value is valid. FALSE: Faulty channel. Channel de-energized For channel 1 or 2, the parameter is either TRUE or FALSE.
-> Trigger Failure [BOOL]	BOOL	R	Prior to close, the relay contact must be safely open. TRUE: Relay contact not yet safely open, to fulfil the requirement close. FALSE: Relay contact safely open, to fulfil the requirement close.

Table 13: Tab M-DO 2 01_01: Channels in the Hardware-Editor

4.4 Connection Variants

This chapter describes the correct wiring of the module in safety-related applications. The connection variants specified here are permitted.

The following points must be taken into account when connecting the actuators to the relay outputs:

- At both relay outputs, actuators must be supplied with the same power source, e.g., 24/48/230 VDC/VAC
- Use fuses suitable for current limiting.
 - Melting integral $\leq 100 \text{ A}^2\text{s}$
 - The breaking capacity of the fuses must be adjusted to the network to be switched.
- For operation in zone C according to IEC 61131-2, install the filter H 7013 or similar to enhance immunity to interference (surges).

CAUTION




System damage due to improper dimensioning of fuse in contact circuit!

To ensure that the fuse is dimensioned properly, observe Table 7 and Table 8 specified in the Product Data.

4.4.1 Connecting Actuators

Electromechanical control circuit devices are connected as follows:




1 Socket M-SO REL 01

Figure 9: Wiring an Actuator with DC or AC Voltage


4.4.2 Applications for Fast and Safe Shutdown

The following applications allow for fast and safe shutdown (drop-out time of the relay), and take internal module faults into account, see Figure 10, Figure 11 and Figure 12. To this end, both channels must be switched on and off simultaneously.



1 Socket M-SO I/O 01


Figure 10: Increased Safety Trough 2-Pole Connection of an Actuator



1 Socket M-SO I/O 01

Figure 11: Increased Safety Through Serial Connection of an Actuator

Additionally, the following application increases the availability of the actuator.




1 Socket M-SO I/O 01

Figure 12: Increased Availability of an Actuator

4.4.3 Wiring one Actuator to Redundant Modules

Burner applications can be performed with an actuator at redundant modules.



1 Socket

Figure 13: Redundant Wiring of an Actuator and Redundant Relay Modules

NOTICE



Burner applications

To switch off the entire fuel feed of continuously operating combustion plants where regular tests cannot be performed in sufficiently short intervals, the relay function must be tested, depending on the application, using the wiring shown above, e.g., once per day.

5 Operation

The module runs within the HIMatrix M45 system and does not require any specific monitoring. When operating the system, ensure that the air circulation is not obstructed.

5.1 Handling

Handling of the module and the HIMatrix M45 system during operation is not required. Do not pull or plug the modules during operation!

5.2 Diagnosis

The LEDs are used to give a overview of the operating state, see Chapter 3.4.4. The diagnostic history of the M45 system can also be read using SILworX.

6 Maintenance

No maintenance measures are required during normal operation.

If a failure occurs, the defective module must be replaced with a module of the same type or with a replacement model approved by HIMA.

Modules may only be replaced in the de-energized state.

Only the manufacturer is authorized to repair the module.

6.1 Faults

Refer to Chapter 3.1, for more information on the fault reaction of relay outputs.

If the test harness of the module detect safety-critical faults (module faults), the module is rebooted.

If the fault is still present, the module is rebooted again. This process is repeated as long as the fault is present. If no fault is detected, the module is restarted (RUN state).

If a further module fault occurs within the first minute after reboot, the module enters the STOP_INVALID state and will remain in this state. This means that the outputs switch to the de-energized, safe state. The evaluation of diagnostics provides information on the fault cause.

If the restart after a module fault must be prevented, the user program must be configured accordingly. To this end, use the system parameters *Emergency Stop 1...Emergency Stop 4*. If the system parameters *Emergency Stop 1...Emergency Stop 4* are used, the entire M45 system enters the STOP state.

6.2 Maintenance Measures

The following measures are required for the module:

- Load the operating system, if a new version is required
- Perform the proof test

6.2.1 Loading the Operating System

HIMA is continuously improving the operating system of the modules.

HIMA recommends using system downtimes to load the current version of the operating system into the module.

Refer to the release notes to check the impact of the operation system version on the system!

The operating system can be loaded into the module using SILworX. To this end, the HIMatrix M45 system must be in the STOP state. Otherwise, stop the system.

For more information, refer to the system manual (HI 800 651 E).



The current version of the module in use is displayed in the SILworX Control Panel. The type label specifies the version when the module is delivered, see Chapter 3.3.

6.2.2 Proof Test

HIMatrix M45 modules must be subjected to a proof test in intervals of 10 years. For more information, refer to the safety manual (HI 800 653 E).

If used in accordance with the Machinery Directive, additional functional tests must be performed.

7 Decommissioning

The decommissioning of the module is carried out after de-energization. Following steps are necessary:

1. Stop the HIMatrix M45 system.
2. Disconnect the system from the power supply.
3. Remove the module from the socket.

8 Transport

To avoid mechanical damage, HIMatrix M45 components must be transported in packaging.

Always store HIMatrix components in their original product packaging. This packaging also provides protection against electrostatic discharge.

9 Disposal

Industrial customers are responsible for correctly disposing of decommissioned HIMatrix hardware. Upon request, a disposal agreement can be arranged with HIMA.

All materials must be disposed of in an ecologically sound manner.



Appendix

Glossary

Term	Description
ARP	Address resolution protocol: Network protocol for assigning the network addresses to hardware addresses
AI	Analog input
AO	Analog output
COM	Communication Module
CRC	Cyclic redundancy check
DI	Digital input
DO	Digital output
EMC	Electromagnetic compatibility
EN	European norm
ESD	Electrostatic discharge
FB	Fieldbus
FBD	Function block diagrams
FTT	Fault tolerance time
ICMP	Internet control message protocol: Network protocol for status or error messages
IEC	International electrotechnical commission
MAC address	Media access control address: Hardware address of one network connection
PADT	Programming and debugging tool (in accordance with IEC 61131-3), PC with SILworX
PE	Protective Earth
PELV	Protective extra low voltage
PES	Programmable electronic system
R	Read: The system variable or signal provides value, e.g., to the user program
Rack ID	Base plate identification (number)
Interference-free	Supposing that two input circuits are connected to the same source (e.g., a transmitter). An input circuit is termed <i>interference-free</i> if it does not distort the signals of the other input circuit.
R/W	Read/Write (column title for system variable/signal type)
SB	System Bus
SELV	Safety extra low voltage
SFF	Safe failure fraction, portion of faults that can be safely controlled
SIL	Safety integrity level (in accordance with IEC 61508)
SILworX	Programming tool for HiMatrix systems
SNTP	Simple network time protocol (RFC 1769)
SRS	System.Rack.Slot addressing of a module
SW	Software
TMO	Timeout
W	Write: System variable is provided with value, e.g., from the user program
r_p	Peak value of a total AC component
Watchdog (WD)	Time monitoring for modules or programs. If the watchdog time is exceeded, the module or program enters the error stop state.
WDT	Watchdog time

Index of Figures

Figure 1:	Sample Type Label	11
Figure 2:	Contact Lifetime	13
Figure 3:	Block Diagram	14
Figure 4:	Front View	15
Figure 5:	Example of Module and Socket Coding	20
Figure 6:	M-SO REL 01 Socket	22
Figure 7:	Example of Socket Mounting	26
Figure 8:	Example of Mounting and Removing the Module	27
Figure 9:	Wiring an Actuator with DC or AC Voltage	30
Figure 10:	Increased Safety Through 2-Pole Connection of an Actuator	31
Figure 11:	Increased Safety Through Serial Connection of an Actuator	31
Figure 12:	Increased Availability of an Actuator	32
Figure 13:	Redundant Wiring of an Actuator and Redundant Relay Modules	33

Index of Tables

Table 1:	Additional Relevant Documents	5
Table 2:	Environmental Requirements	8
Table 3:	Blinking Frequencies of LEDs	16
Table 4:	Module Status Indicators	16
Table 5:	I/O Indicators	17
Table 6:	Product Data	18
Table 7:	Specifications for the Relay Outputs	19
Table 8:	Relays Output Switching Capacity	19
Table 9:	Module and Socket Coding	21
Table 10:	Terminal Assignment for Cable Plugs	23
Table 11:	Cable Plug Properties	23
Table 12:	System Parameters of the Relay Outputs, Module Tab	28
Table 13:	Tab M-DO 2 01_01: Channels in the Hardware-Editor	29

Index

block diagram.....	14	front view	15
burner management systems	12	safety function	10
diagnosis.....	34	specifications.....	18



SAFETY
NONSTOP

HIMA Paul Hildebrandt GmbH

P.O. Box 1261

68777 Brühl, Germany

Phone: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com Internet: www.hima.com

(1414)