



ELOP II V5.1

Supplementary Sheet for Installing



SAFETY
NONSTOP



All HIMA products mentioned in this manual are protected by the HIMA trade-mark. Unless noted otherwise, this also applies to other manufacturers and their respective products referred to herein.

All of the instructions and technical specifications in this manual have been written with great care and effective quality assurance measures have been implemented to ensure their validity. For questions, please contact HIMA directly. HIMA appreciates any suggestion on which information should be included in the manual.

Equipment subject to change without notice. HIMA also reserves the right to modify the written material without prior notice.

For further information, refer to the HIMA-DVD and our website <http://www.hima.de> and <http://www.hima.com>.

© Copyright 2010, HIMA Paul Hildebrandt GmbH

All rights reserved

Contact

HIMA Address

HIMA Paul Hildebrandt GmbH

P.O. Box 1261

68777 Brühl, Germany

Tel: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com

Revision index	Revisions	Type of Change	
		technical	editorial
1.00	First Release		
1.01	Deleted: Chapter <i>Upgrading a Hardlock</i> displaced into document HI 800 457		x
1.02	Changed: Chapter <i>Converting Existing ELOP II Projects to V5.1</i>	x	x



Supplementary Sheet for Installing ELOP II V5.1



1 System Requirements

Minimum system requirements:

- Pentium 500 MHz
- 256 MB RAM
- 500 MB hard disk space
- Resolution 1024*768 (16-bit)
- Microsoft Windows XP Professional (min. Service-Pack 2), Windows 7 Professional/ Ultimate (32-bit)

ELOP II V5.1 is applicable for all releases of the operating system BS41q/51q V7.0-8. HIMA recommends to use the current H41q/H51q operating system.

2 Starting the User Interface

Insert the **HIMA-DVD "Software.Nonstop."** into the DVD drive. The DVD user interface starts automatically after a few seconds.

Start the DVD user interface manually if certain parameters have been set (if the DVD drive's Auto-Run function is deactivated). In this case double-click the "index.htm" file in the DVD root directory.

On the menu bar, click **ELOP II** and open the ELOP II's *Installation* page. Then perform all the steps required to install ELOP II.

3 Installation

ELOP II V5.1 uses a hardlock as licensing method. Install the hardlock driver and ELOP II on the PC. Follow the setup instructions.

Installation notes for the hardlock driver:

1. Windows administrator rights on the PC are required to install the hardlock driver.
2. Ensure that the hardlock is not connected to the PC.
If a USB hardlock is used and already plugged in, remove the hardlock and restart the PC.
3. Install the hardlock driver and connect the hardlock to the PC.
The hardlock is recognized automatically. The LED on the USB hardlock is lit.

Installation notes for ELOP II V5.1:

1. Windows administrator rights on the PC are required to install ELOP II V5.1.
Upon completion of the installation process, ELOP II version 5.1 can be used with all Windows user accounts of the current workstation. User privileges of group Users are sufficient for operating ELOP II V5.1.
2. Have you already installed a previous version of ELOP II?
When installing ELOP II V5.1, do not use the same installation directory as the previous version but create a new installation directory for ELOP II V5.1.
3. The installation language (e.g., German) is used as default language for ELOP II V5.1. Upon completion of the installation process, however, it is possible to change the language, e.g. to English (use "Administration" located in the Control Center).
4. The hardlock delivered with ELOP II V5.1 has already been activated for the corresponding version. If a hardlock for a previous licence is in use, following the instructions specified in HI 800 457 E to activate it.

4 Parallel Installation of ELOP II

ELOP II version 3.0 and beyond can be installed in parallel and operated under the same windows user. Use separate installation paths when installing different ELOP II versions.

5 Converting Existing ELOP II Projects to V5.1

A project created with ELOP II V4.1 can be converted to ELOP II V5.1 directly.

i

**The conversion cannot be reversed. Save the project data before converting the project.
Please refer to the document HI 800 185 E "New Features in ELOP II V5.1" for more information
on the conversion procedure!**

6 Support

In case of problems with the installation or license activation please contact HIMA Support. The free HIMA hotline is open Monday to Friday, 8.30 am – 4.00 pm (CET/CEST).

Telephone: ++49 6202 709-255

++49 6202 709-258

Fax: ++49 6202 709-199

E-Mail: support@hima.com

HI 800 441 E
© 2010 HIMA Paul Hildebrandt GmbH
® = registered trademark of:
HIMA Paul Hildebrandt GmbH

HIMA Paul Hildebrandt GmbH
Albert-Bassermann-Str. 28 | 68782 Brühl, Germany
Phone +49 6202 709-0 | Telefax +49 6202 709-107
info@hima.com | www.hima.com



SAFETY
NONSTOP



For a detailed list of all our subsidiaries and representatives,
please visit our website: www.hima.com/contact

