

System Manual M45



HI 800 651 E

All HIMA products mentioned in this manual are protected by the HIMA trade-mark. Unless noted otherwise, this also applies to other manufacturers and their respective products referred to herein.

HIMax[®], HIMatrix[®], SILworX[®], XMR[®] and FlexSILon[®] are registered trademarks of HIMA Paul Hildebrandt GmbH.

All of the instructions and technical specifications in this manual have been written with great care and effective quality assurance measures have been implemented to ensure their validity. For questions, please contact HIMA directly. HIMA appreciates any suggestion on which information should be included in the manual.

Equipment subject to change without notice. HIMA also reserves the right to modify the written material without prior notice.

For further information, refer to the HIMA DVD and our website <http://www.hima.de> and <http://www.hima.com>.

© Copyright 2015, HIMA Paul Hildebrandt GmbH

All rights reserved

Contact

HIMA contact details:

HIMA Paul Hildebrandt GmbH

P.O. Box 1261

68777 Brühl, Germany

Phone: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com

Revision index	Revisions	Type of change	
		technical	editorial
1.00	First issue		
1.01	Revision, changed chapters: Extending the System Bus, Mounting and Removing Modules and Sockets	X	X

Table of Contents

1	Introduction	7
1.1	Structure and Use of the Document	7
1.2	Target Audience	8
1.3	Formatting Conventions	8
1.3.1	Safety Notes	8
1.3.2	Operating Tips	9
1.4	Service and Training	9
2	Safety	10
2.1	Intended Use	10
2.1.1	Scope	10
2.1.1.1	Application in Accordance with the De-Energize-to-Trip Principle	10
2.1.1.2	Use in Fire Alarm Systems	10
2.2	Environmental Requirements	10
2.2.1	Test Conditions	10
2.2.1.1	Climatic Requirements	11
2.2.1.2	Mechanical Requirements	12
2.2.1.3	EMC Requirements	12
2.2.1.4	Power Supply	13
2.3	Tasks and Responsibilities of Operators and Machine and System Manufacturers	13
2.3.1	Connection of Communication Partners	13
2.3.2	Use of Safety-Related Communication	13
2.4	ESD Protective Measures	13
2.4.1	Noxious Gases	14
2.5	Residual Risk	14
2.6	Safety Precautions	14
2.7	Emergency Information	14
3	Product Description	15
3.1	Modules	15
3.1.1	Inputs	16
3.1.1.1	Surges on Digital Inputs	16
3.1.1.2	Line Control	16
3.1.2	Outputs	17
3.2	Extending the System Bus	18
3.3	Supply Voltage Monitoring	18
3.4	Monitoring the Temperature State	19
3.4.1	Setting the Temperature Threshold for Messages	19
3.5	Short-Circuit Reaction of Output Channels	19
3.6	Alarms&Events Recording	19
3.6.1	Alarms&Events	20
3.6.2	Creating Events	20
3.6.3	Recording Events	21
3.6.4	Transfer of Events	21
3.7	Product Data	21

4	Communication	22
4.1	HiMatrix Communication Protocols M45	22
4.2	Ethernet Communication	22
4.2.1	Communication via Switches	22
4.2.2	safe ethernet	22
4.2.3	Maximum Communication Time Slice	23
4.2.4	Connectors for safe ethernet /Ethernet	23
4.2.5	Communication with the PADT	23
4.2.6	Ethernet Communication Protocols	23
4.2.6.1	SNTP	24
4.2.6.2	Modbus TCP	24
4.2.6.3	Send & Receive TCP	24
4.2.6.4	PROFINET IO and PROFIsafe	24
4.3	Fieldbus Communication	24
4.3.1	Protocols of the Fieldbus Interfaces	24
4.3.2	Restrictions for Simultaneous Operation of Protocols	25
5	Operating System	26
5.1	Functions of the Processor Operating System	26
5.2	Indication of the Operating System Versions	26
5.3	Behavior in the Event of Faults	26
5.3.1	Permanent Faults on Inputs or Outputs	26
5.3.2	Temporary Faults on Inputs or Outputs	27
5.3.3	Internal Faults	27
5.4	Processor Module	27
5.4.1	Operating States of the Processor Module	27
5.4.2	Programming	28
6	User Program	29
6.1	Modes of Operation for the User Program	29
6.2	Cycle Sequence	29
6.2.1	Multitasking	30
6.2.2	Multitasking Mode	32
6.3	Reload	36
6.3.1	Conditions for Using the Reload Function	37
6.4	Forcing	38
6.4.1	Time Limits	38
6.4.2	Force Editor	39
6.4.3	Restricting the Use of Forcing	39
7	Start-Up	40
7.1	Considerations about Heat	40
7.1.1	Heat Dissipation	40
7.1.1.1	Definitions	40
7.1.1.2	Installation Type	40
7.1.1.3	Natural Convection	41
7.2	Installation and Mounting	41
7.2.1	Mounting	41
7.2.2	Construction Depth	42

7.2.3	Mounting on a Flat Base	42
7.3	Mounting and Removing Modules and Sockets	43
7.3.1	Mounting the Socket	43
7.3.2	Inserting and Removing the Module	45
7.3.3	Changes to M45 System	45
7.4	Connecting the Input and Output Circuits	46
7.4.1	Earthing and Shielding	46
7.4.1.1	Earthing the 24 VDC System Voltage	46
7.4.1.2	Earthing Connections	47
7.4.1.3	Shielding	47
7.4.1.4	EMC Protection	47
7.4.2	Connecting the Supply Voltage	47
7.5	Configuration	47
7.5.1	Configuring the Resource	47
7.5.1.1	Resource Properties	48
7.5.1.2	Hardware System Variables for Setting the Parameters	50
7.5.1.3	Hardware System Variables for Reading the Parameters	51
7.5.1.4	Rack System Parameter Settings	54
7.5.2	Configuring the Ethernet Interfaces	54
7.5.3	Configuring the User Program	54
7.5.4	Configuration of the Hardware Image	55
7.5.5	Configuring the Inputs and Outputs	55
7.5.5.1	Use of Digital Input	56
7.5.5.2	Use of Safety-Related Counter Inputs	56
7.5.5.3	Use of Digital Input	56
7.5.6	Generating the Resource Configuration	56
7.5.7	Configuring the System ID and the Connection Parameters	57
7.5.8	Loading a Resource Configuration from the PADT	57
7.5.9	Setting the Date and the Time	58
7.6	User Management in SILworX	58
7.6.1	User Management for SILworX Projects	58
7.6.2	User Management for the Controller	59
7.6.3	Setting up User Accounts	60
7.7	Configuration with SILworX	60
7.7.1	Configuring the Ethernet Interfaces	61
7.8	Configuring Alarms and Events	62
7.9	Handling the User Program	64
7.9.1	Setting the Parameters and the Switches	64
7.9.2	Starting the Program from STOP/VALID CONFIGURATION	64
7.9.3	Restarting the Program after Errors	64
7.9.4	Stopping the Program	64
7.9.5	Program Test Mode	65
7.9.6	Online Test	65
8	Operation	66
8.1	Handling	66
8.2	Diagnosis	66
8.2.1	Light-Emitting Diode Indicators	66
8.2.2	Diagnostic History	66
8.2.3	Diagnosis in SILworX	67

9	Maintenance	69
9.1	Interferences	69
9.2	Loading Operating Systems	69
9.3	Repairing Modules and Sockets	70
10	Decommissioning	71
11	Transport	72
12	Disposal	73
	Appendix	74
	Glossary	74
	Index of Figures	75
	Index of Tables	76
	Declaration of conformity	77
	Index	78

1 Introduction

The modular HIMatrix M45 system described in this manual is safety-related and can be used for various purposes. The following conditions must be met to safely install and start up the HIMatrix M45 automation devices, and to ensure safety during their operation and maintenance:

- Knowledge of regulations.
- Proper technical implementation of the safety instructions detailed in this manual performed by qualified personnel.

HIMA shall not be held liable for severe personal injuries, damage to property or the environment caused by any of the following: unqualified personnel working on or with the devices, de-activation or bypassing of safety functions, or failure to comply with the instructions detailed in this manual (resulting in faults or impaired safety functionality).

HIMatrix M45 automation devices have been developed, manufactured and tested in compliance with the pertinent safety standards and regulations. They may only be used for the intended applications under the specified environmental conditions and only in connection with approved external devices.

1.1 Structure and Use of the Document

This system manual is composed of the following chapters:

Safety	Information on how to safely use the HIMatrix M45 system. Allowed applications and environmental requirements for operating the HIMatrix M45 systems.
Product description	Basic structure of the HIMatrix M45 system.
Communication	Brief description of the HIMatrix M45 modular systems' communication among each other and with other systems. Detailed information can be found in the communication manuals.
Operating system	Functions of the operating systems.
User program	Basic information on the user program.
Start-up, operation, maintenance, decommissioning, transport, disposal	Phases of a HIMatrix M45 system's lifecycle.
Appendix	<ul style="list-style-type: none"> ▪ Glossary ▪ Index of tables and index of figures ▪ Declaration of conformity ▪ Index

Additionally, the following documents must be taken into account:

Name	Content	Document number
HIMatrix M45 Safety Manual	Safety functions of the HIMatrix M45 system	HI 800 653 E
SILworX Communication Manual	Description of the communication protocols, ComUserTask and their configuration in SILworX	HI 801 101 E
HIMatrix M45 module manuals	Description of the HIMatrix M45 modules	
SILworX Online Help (OLH)	Instructions on how to use SILworX	-
SILworX First Steps	Introduction to SILworX using the HIMax system as an example	HI 801 103 E

Table 1: Additional Relevant Documents

The latest manuals can be downloaded from the HIMA website at www.hima.com. The revision index on the footer can be used to compare the current version of existing manuals with the Internet edition.

1.2 Target Audience

This document addresses system planners, configuration engineers, programmers of automation devices and personnel authorized to implement, operate and maintain the modules and systems. Specialized knowledge of safety-related automation systems is required.

1.3 Formatting Conventions

To ensure improved readability and comprehensibility, the following fonts are used in this document:

Bold	To highlight important parts. Names of buttons, menu functions and tabs that can be clicked and used in the programming tool.
<i>Italics</i>	For parameters and system variables.
<code>Courier</code>	Literal user inputs.
RUN	Operating states are designated by capitals.
Chapter 1.2.3	Cross-references are hyperlinks even if they are not particularly marked. When the cursor hovers over a hyperlink, it changes its shape. Click the hyperlink to jump to the corresponding position.

Safety notes and operating tips are particularly marked.

1.3.1 Safety Notes

The safety notes are represented as described below.

These notes must absolutely be observed to reduce the risk to a minimum. The content is structured as follows:

- Signal word: warning, caution, notice
- Type and source of risk
- Consequences arising from non-observance
- Risk prevention

SIGNAL WORD



Type and source of risk!

Consequences arising from non-observance

Risk prevention

The signal words have the following meanings:

- Warning indicates hazardous situation which, if not avoided, could result in death or serious injury.
- Caution indicates hazardous situation which, if not avoided, could result in minor or modest injury.
- Notice indicates a hazardous situation which, if not avoided, could result in property damage.

NOTE

Type and source of damage!
Damage prevention

1.3.2 Operating Tips

Additional information is structured as presented in the following example:

i

The text corresponding to the additional information is located here.

Useful tips and tricks appear as follows:

TIP

The tip text is located here.

1.4 Service and Training

Deadlines and the extent of actions for commissioning, testing and modifying controller systems can be agreed with the service department.

HIMA holds training, usually in-house, for software programs and the hardware of the controllers. Additionally, customer training can be offered on-site.

Refer to the HIMA website at www.hima.com for the current training program and dates. Offers for specialized, on-site training can also be provided upon request.

2 Safety

All safety information, notes and instructions specified in this document must be strictly observed. The product may only be used if all guidelines and safety instructions are adhered to.

The product is operated with SELV or PELV. No imminent risk results from the product itself. The use in Ex-Zone is permitted if additional measures are taken.

2.1 Intended Use

This chapter describes the conditions for using HIMatrix M45 systems.

2.1.1 Scope

The safety-related HIMatrix controllers can be used in applications up to SIL 3 in accordance with IEC 61508.

The HIMatrix systems are certified for use in process controllers, protective systems, burner controllers, and machine controllers.

2.1.1.1 Application in Accordance with the De-Energize-to-Trip Principle

The automation devices have been designed in accordance with the de-energize-to-trip principle.

A system that operates in accordance with the de-energize-to-trip principle adopts the de-energized state if a fault occurs.

2.1.1.2 Use in Fire Alarm Systems

HIMatrix systems are suitable for use in fire alarm systems in accordance with DIN EN 54-2 and NFPA 72. For these fire alarm systems, the following is required:

- To contain the risks, these systems must be able to adopt an active state on demand.
- Open-circuit and short-circuit detection.

The environmental requirements have to be observed!

For details, see the safety manual of the HIMatrix F systems (HI 800 023 E).

2.2 Environmental Requirements

Requirement type	
Protection class	Protection class III in accordance with IEC/EN 61131-2
Ambient temperature	0...+60 °C
Storage temperature	-40...+85 °C
Pollution	Pollution degree II in accordance with IEC/EN 61131-2
Altitude	< 2000 m
Housing	Standard: IP20
Supply voltage	24 VDC

Table 2: Environmental Requirements

All the environmental requirements specified in this manual must be observed when operating the HIMatrix system.

2.2.1 Test Conditions

The devices have been tested to ensure compliance with the following standards for EMC, climatic and environmental requirements:

Standard	Content
IEC/EN 61131-2: 2007	Programmable controllers, Part 2 Equipment requirements and tests
IEC/EN 61131-6: 2012	Programmable controllers, Part 6 Functional Safety
IEC/EN 61000-6-2: 2005	EMC Generic standards, Parts 6-2 Immunity for industrial environments
IEC/EN 61000-6-4: 2007 + A1:2011	Electromagnetic compatibility (EMC) Generic emission standard, industrial environments

Table 3: Standards for EMC, Climatic and Environmental Requirements

When using the safety-related HIMatrix control systems, the following general requirements must be met:

Requirement type	Requirement content
Protection class	Protection class III in accordance with IEC/EN 61131-2
Pollution	Pollution degree II in accordance with IEC/EN 61131-2
Altitude	< 2000 m
IP class	Standard: IP20
Requirements of the application	If required by the relevant application standards (e.g., EN 60204, EN 13849), the HIMatrix system must be installed in an enclosure of the specified protection class (e.g., IP54).

Table 4: General Requirements

2.2.1.1 Climatic Requirements

The following table lists the most important tests and limits for climatic requirements:

Standard	Climatic tests
IEC/EN 61131-2	Operating temperature: 0...+60 °C (test limits: -10...+70 °C)
	Storage temperature: -40...+85 °C
	Dry heat and cold resistance tests: +70 °C / -40 °C, 16 h, +85 °C, 1 h Power supply not connected
	Temperature changes, withstand test: Fast temperature changes: -40 °C / +70 °C power supply not connected
	Immunity test: Slow temperature changes: -10 °C / +70 °C power supply not connected
	Cyclic damp-heat withstand tests: +25 °C / +55 °C, 95 % relative humidity, Power supply not connected
EN 54-2	Damp-heat 93 % relative humidity, 40 °C, 4 days in operation 93 % relative humidity, 40 °C, 21 days, power supply not connected

Table 5: Climatic Requirements

Operating requirements other than those specified in this document are described in the device-specific or module-specific manuals.

2.2.1.2 Mechanical Requirements

The following table lists the most important tests and limits for mechanical requirements:

IEC/EN 61131-2	Mechanical tests
	Vibration immunity test: 5...8,4 Hz, 3,5 mm 8.4...150 Hz, 1 g, EUT in operation, 10 cycles per axis
	Shock immunity test: 15 g, 11 ms, EUT in operation, 3 shocks per axis and direction (18 shocks)

Table 6: Mechanical Tests

2.2.1.3 EMC Requirements

Higher interference levels are required for safety-related systems. HIMatrix systems meet these requirements in accordance with IEC 61131-6, IEC 61326-3-1, and IEC 61326-3-2. See column *Criterion FS* (Functional Safety).

IEC/EN 61131-2	Interference immunity tests	Criterion FS
IEC/EN 61000-4-2	ESD test: 6 kV contact, 8 kV air discharge	6 kV, 8 kV
IEC/EN 61000-4-3	RFI test (10 V/m): 80 MHz...2 GHz, 80 % AM RFI test (10 V/m): 2 GHz...3 GHz, 80 % AM RFI test (20 V/m): 80 MHz...1 GHz, 80 % AM	10 V/m 3 V/m 20 V/m
IEC/EN 61000-4-3	900 MHz pulses	-
IEC/EN 61000-4-4	Burst test Supply voltage: 2 kV Signal lines: 2 kV	4 kV 2 kV
IEC/EN 61000-4-5	Surge: Power lines: 2 kV CM, 1 kV DM Signal lines: 2 kV CM, 1 kV DM at AC I/O	2 kV / 1 kV 2 kV
IEC/EN 61000-4-6	High frequency, asymmetrical 10 V, 150 kHz...80 MHz, AM 20 V, ISM frequencies, 80 % AM	10 V -
IEC/EN 61000-4-12	Damped oscillatory wave test 2.5 kV L-, L+ / PE 1 kV L+ / L-	- -

Table 7: Interference Immunity Tests

IEC/EN 61000-6-4	Noise emission tests
EN 55011 Class A	Emission test: radiated, conducted

Table 8: Noise Emission Tests

2.2.1.4 Power Supply

The following table lists the most important tests and limits for the HIMatrix systems' power supply:

IEC/EN 61131-2	Verification of the DC supply characteristics
	The power supply must comply with the following standards: IEC/EN 61131-2: SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage)
	HIMatrix systems must be fuse protected as specified in this manual
	Voltage range test: 24 VDC, -20...+25 % (19.2...30.0 V)
	Momentary external current interruption immunity test: DC, PS 2: 2 ms
	Reversal of DC power supply polarity test: Refer to corresponding chapter of the system manual or data sheet of power supply.

Table 9: Verification of the DC Supply Characteristics

2.3 Tasks and Responsibilities of Operators and Machine and System Manufacturers

Operators and machine and system manufacturers are responsible for ensuring that HIMatrix systems are safely operated in automated systems and plants.

Machine and system manufacturers must sufficiently validate that the HIMatrix systems were properly programmed.

2.3.1 Connection of Communication Partners

Only devices with safe electrical separation may be connected to the communications interfaces.

2.3.2 Use of Safety-Related Communication

When implementing safety-related communications between various devices, ensure that the overall response time does not exceed the fault tolerance time. All calculations must be performed in accordance with the rules given in this chapter.

2.4 ESD Protective Measures

Only personnel with knowledge of ESD protective measures may modify or extend the system or replace a module.

NOTE



Electrostatic discharge can damage the electronic components within the HIMatrix systems!

- When performing the work, make sure that the workspace is free of static, and wear an ESD wrist strap.
- If not used, ensure that the module is protected from electrostatic discharge, e.g., by storing it in its packaging.

2.4.1 Noxious Gases

HIMatrix components may be operated without functional and safety restrictions in environments with noxious gas concentrations as described in the following standards:

- ANSI/ISA -S71.04:1985
Corrosive gases, Class G3
- DIN EN 60068-2-60: 1996 (also IEC 68-2-60: 1995)

With noxious gas concentrations higher than those mentioned in the standards, a reduced component lifetime is to be expected. The user is responsible for demonstrating that the environment is sufficiently free from noxious gases.

2.5 Residual Risk

No imminent risk results from a modular HIMatrix M45 system itself.

Residual risk may result from:

- Faults related to engineering
- Faults related to the user program
- Faults related to the wiring

2.6 Safety Precautions

Observe all local safety requirements and use the protective equipment required on site.

2.7 Emergency Information


A HIMatrix M45 system is a part of the safety equipment of a plant. If a device or a module fails, the system enters the safe state.

In case of emergency, no action that may prevent the HIMatrix M45 systems from operating safely is permitted.

3 Product Description

The modular system HIMatrix M45 is composed of modules lined up on a DIN rail.

The only processor module is located at the left-hand side of the system. If required, one to three communication modules can be added to the right of the processor module. All additional modules are positioned at the right-hand side.



- 1** Processor Module M-CPU 01
- 2** Power Module M-PWR 01
- 3** Communication Module M-COM 01
- 4** I/O Modules from Here to the Right

Figure 1: HIMatrix M45 System

The modules are inserted into sockets. The sockets are fastened to the DIN rail. This allows one to replace modules without removing the field wiring.

The sockets have a lateral electrical connection for attaching modules to the system bus and supply voltage.

The socket of the processor module also accommodates the M-PWR 01 power module **2**, which is the minimum requirement for supplying the controller with electrical power.

The M-PWR 01 power module in the processor module socket is sufficient for small controllers. If more power or isolated operation of I/O modules is required, additional power modules can be used on the DIN rail to supply the I/O modules located to the right.

The modular M45 system can also be connected to HIMatrix F60 and compact systems via **safeethernet**.

3.1 Modules

All HIMatrix M45 system modules are 165 mm in height.

Certain slots are specified for the first power module, the processor module, and communication modules if used, see above.

NOTE**Controller damage!**

Inserting and removing the modules during operation is not permitted.

Prior to modifying the assembly, ensure that the controller is shut down!

After modifying a controller assembly, its user program must be adapted to the change and reloaded.

Pluggable clamps located on the modules' sockets are used to connect sensors and actuators. The modules indicate the status of digital signals via LEDs located on the front plate.

3.1.1 Inputs

The modules' input channels are used to transmit and adjust the signals between the sensors and the microprocessor system on the CPU module.

The safety-related modules continuously test themselves. If a fault occurs, the module restarts. If the same fault occurs again within one minute, the module shuts down and displays the fault. The controller's operating system then sets the user program's input value to the initial value.

Instead of contacts, signal sources with own voltage may also be connected. To this end, the signal source ground must be connected to the input ground.

3.1.1.1 Surges on Digital Inputs

Due to the short cycle time of the HIMatrix M45 systems, a surge pulse as described in EN 61000-4-5 can be read in to the digital inputs as a short-term high level.

To prevent malfunctions, take one of the following measures for the application:

- Install shielded input wires to prevent surges within the system.
- Activate noise blanking: a signal must be present for at least two cycles before it is evaluated.

Caution: This action increases the system's response time!



The measures specified above are not necessary if the plant design precludes surges from occurring within the system.

In particular, the design must include protective measures with respect to overvoltage, lightning, earth grounding and plant wiring in accordance with the relevant standards and the manufacturer's specifications.

3.1.1.2 Line Control

Line control is used to detect short-circuits or open-circuits, e.g., on EMERGENCY STOP inputs complying with Cat. 4 and PL e in accordance with EN ISO 13849-1. Line control can be configured for the M45 system.

Application example: The outputs TO 1 through TO 2 of the M-DI 8 01 module are connected to the digital inputs (DI) of the same module as follows:




Figure 2: Line Control

The digital outputs are pulsed. This allows monitoring of the wires to the digital inputs of the M-DI 8 01 module.

A fault reaction is triggered if one of the following faults occurs:

- Cross-circuit between two parallel wires.
- Improper connections of two lines (e.g., TO 2 to DI 3).
- Earth fault of a line (with earthed ground only).
- Open-circuit or open contacts, i.e., including when one of the two EMERGENCY STOP switches mentioned above has been engaged.

The fault reaction includes the following actions:

- The *ERROR* LED on the controller's front plate is blinking.
- The inputs are set to 0.
- An evaluable error code is created.

For more information on how to configure line control in the user program, refer to the module-specific HIMatrix M45 manuals.

3.1.2 Outputs

The module's output channels are used to transmit and adjust the signals between the microprocessor systems on the central module and the actuators.

The safety-related modules continuously test themselves. If a fault occurs, the module restarts. If the same fault occurs again within one minute, the module shuts down and displays the fault. The outputs are set to the safe de-energized state.

NOTE



Controller damage!

Plug the terminals for output circuits without a load.

- If short-circuits are present, the resulting high current may damage the terminals.

Inductive loads may be connected with no free-wheeling diode on the actuator. However, HIMA recommends connecting a protective diode directly to the actuator.

For more details on line control, refer to Chapter 3.1.1

3.2 Extending the System Bus

Systems composed of a larger or the maximum number of modules require a very long DIN rail. This can result in exceeding the width of the planned mounting space. In this case, multiple short DIN rails may replace a long one. Short rails are usually mounted one above another. An Ethernet cable connects the system bus between two rails. The Ethernet cable is connected to the system bus on either side via an extension socket. The cable connects the right extension socket, M-SO EXT 02, of the upper rail to the left extension socket, M-SO EXT 01, of the lower rail.

Only use passive Ethernet cables to extend the system bus.

The maximum length of the Ethernet cable between two extension sockets is 100 m. An M45 system bus may be extended via Ethernet cable at no more than 10 places. The maximum overall length of the Ethernet cables may be 1000 m.

Lay the Ethernet cables ensuring their adequate protection. They must not be run parallel to power supply cables.

A power module must be used after the left extension socket on each rail.

3.3 Supply Voltage Monitoring

The HIMatrix system is a single voltage system. In accordance with IEC/EN 61131-2, the required supply voltage is defined as follows:

Supply voltage	
Nominal value	24 VDC, -15...+20 % 20.4...28.8 V
Max. permissible function limits in continuous operation	18.5...30.2 V (including ripple)
Permissible ripple	$r < 5\%$ as r.m.s. value $r_{PP} < 15\%$ as value peak-to-peak
Ground	L- (negative pole) Earthing the ground is permitted, see Chapter Earthing.

Table 10: Supply Voltage

The power supply units of HIMatrix systems must comply with the SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage) requirements. At the power supply units' outputs, a maximum overvoltage of 35 V may occur in case of fault.

Observing the permitted voltage limits guarantees the system's proper operation.

The required SELV/PELV power supply units ensure safe operation.

The device monitors the 24 VDC voltage during operation. Reactions occur in accordance with the specified voltage level:

Voltage level	Reaction of the device
19.3...28.8 V	Normal operation
< 18.0 V	Alarm states (internal variables are written and provided to the inputs or outputs)
< 12.0 V	Switching off the inputs and outputs

Table 11: Operating Voltage Monitoring

The *Power Supply State* system variable is used to evaluate the operating voltage state with the programming tool or from within the user program.

3.4 Monitoring the Temperature State

One or multiple sensors are used to measure the temperature at relevant positions within the module.

If the measured temperature exceeds the defined temperature threshold, the value of the *Temperature State* system variable changes as follows:

Temperature	Temperature range	<i>Temperature State</i> [BYTE]
< 60 °C	Normal	0x00
60 °C...70 °C	High temperature	0x01
> 70 °C	Very high temperature	0x03
Back to 64 °C...54 °C ¹⁾	High temperature	0x01
Back to < 54 °C ¹⁾	Normal	0x00
¹⁾ The hysteresis of sensors is 6 °C.		

Table 12: Temperature Monitoring

If no or insufficient air circulates within a control cabinet and natural convection is not enough, the threshold associated with *High Temperature* in the HIMatrix M45 controller can already be exceeded at ambient temperatures of less than 35 °C.

This can be due to local heating or to a bad heat conduction. In particular with digital outputs, the heat levels strongly depend on their load.

The *Temperature State* system variable allows the user program to read the temperature. If the state *Very high temperature* often occurs, HIMA recommends improving the system heat dissipation, e.g., by taking additional ventilation or cooling measures, such that the long life time of the HIMatrix systems can be maintained.



The safety of the system is not compromised if the state *High Temperature* or *Very High Temperature* is entered.

3.4.1 Setting the Temperature Threshold for Messages

The temperature threshold that, if exceeded, causes a message to be issued can be defined for the M45 system. In the SILworX Hardware Editor, use the detail view for the rack to configure this setting.

3.5 Short-Circuit Reaction of Output Channels

If a short-circuit occurs in an output channel, the HIMatrix automation systems switch off the affected channel. If multiple short-circuits occur, the channels are switched off individually in accordance with their current input.

If the maximum current permitted for all outputs is exceeded, all outputs are switched off and cyclically switched on again.



The terminals for output circuits must be plugged without a load. If short-circuits are present, the resulting high current may damage the terminals.

3.6 Alarms&Events Recording

The HIMatrix M45 system is able to record alarms and sequences of events (SOE).

3.6.1 Alarms&Events

Events are state changes of a variable that are performed by the plant or controller, and are provided with a timestamp.

Alarms are events that signalize increased risk potential.

The HIMatrix system records the state changes as events specifying the time point when they occurred. The X-OPC server transfers the events to other systems such as control systems that display or evaluate the events.

HIMatrix differentiates between Boolean and scalar events.

Boolean events:

- Changes of Boolean variables, e.g., of digital inputs.
- Alarm and normal state: They can be arbitrarily assigned to the variable states.

Scalar events:

- Crossing the upper and lower limit values defined for a scalar variable.
- Scalar variables have a numeric data type, e.g., INT, REAL.
- Two upper limits and two lower limits are possible.
- The following condition must be met for the limits:
Highest limit (HH) \geq high limit (H) \geq normal range \geq low limit (L) \geq lowest limit (LL).
- A hysteresis can be effective in the following cases:
 - If the value falls below one of the upper limits.
 - If the value exceeds one of the lower limit.

A hysteresis is defined to avoid a needless large number of events when a global variable strongly oscillate around a limit.

HIMatrix M45 can only create events if they are configured in SILworX, see Chapter 7.8. Up to 4 000 alarms and events can be defined.

3.6.2 Creating Events

The processor system is able to create events.

The processor system uses global variables to create the events and stores them in the buffer, see Chapter 3.6.3. The events are created in the user program cycle.

Every event that has been read can be overwritten by a new event.

System Events

In addition to events, which records changes of global variables or input signals, processor systems create the following types of system events:

- Overflow: Some events were not stored due to buffer overflow. The timestamp of the overflow event corresponds to that of the event causing the overflow.
- Init: The event buffer was initialized.

System events contain the SRS identifier of the device causing the events.

Status Variables

Status variables provide the user program with the state of scalar events. Each of the following states is connected to a status variable and can be assigned a global variable of type BOOL:

- Normal.
- Low limit (L) exceeded.
- Lowest limit (LL) exceeded.
- High limit (H) exceeded.
- Highest limit (HH) exceeded.

The assigned status variable becomes TRUE when the corresponding state is achieved.

3.6.3 Recording Events

The processor system records the events:

The processor system stores all the events in its buffer. The buffer is part of the non-volatile memory and has a capacity of 1 000 events.

If the event buffer is full, no new events can be stored as long as no further events are read and thus marked as to be overwritten.

3.6.4 Transfer of Events

The X-OPC server reads the events from buffer and transfers them to a third-party system for evaluation and representation purposes. Four X-OPC servers can simultaneously read events out of a processor module.

3.7 Product Data

Designation	Value, range of values
Power supply Power supply module	24 VDC, -15 %...+20 %, $r_{PP} \leq 15\%$, externally fused with 32 A
	Goldcap in the processor module (for buffering date/time)
Maximum supply voltage	30 V
Operating temperature	0...+60 °C
Storage temperature	-40...+85 °C
Type of protection	IP20
Number of processor modules	1
Number of I/O modules	1...62, including the communication modules
Number of communication modules	0...3
Number of power modules	1...62

Table 13: Specifications HIMatrix M45

The specifications for the modules are detailed in the corresponding manuals.

4 Communication

Communication runs via the following interfaces:

- Ethernet interfaces
- Fieldbus interfaces

4.1 HiMatrix Communication Protocols M45

Depending on the HiMatrix controller and its interfaces, different communication protocols can be activated:

1. **safeethernet** and SNTP are activated by default in all HiMatrix systems.
2. Communication via serial interfaces requires an additional license (software activation code). For further information, refer to the SILworX communication manual (HI 801 101 E).
3. All Ethernet protocols can be tested without software activation code for 5000 operating hours.

i

After 5000 operating hours, communication continues until the controller is stopped. Afterwards, the user program cannot be started without a valid license for the protocols used in the project (invalid configuration).

Order the software activation code on time!

The software activation code can be generated on the HIMA website using the system ID of the controller (value 1...65 535).

The software activation code is intrinsically bound to this system ID. One license can only be used one time for a specific system ID. For this reason, only activate the code when the system ID has been uniquely defined.

HiMatrix M45 systems support the following Ethernet interface communication protocols.

- **safeethernet**, redundant operation possible
- Modbus TCP master
- Modbus TCP slave
- SNTP

Each protocol can be used once per controller.

Communication options for serial interfaces are described in Chapter 4.3.

4.2 Ethernet Communication

4.2.1 Communication via Switches

The HiMatrix M45 controllers are equipped with Ethernet switches with RJ-45 connectors to which Ethernet cables can be attached for connecting to other devices:

i

When configuring safety-related communication, observe the instructions specified in the safety manual (HI 800 653 E).

4.2.2 **safeethernet**

An overview of **safeethernet** is available in the corresponding chapter of the SILworX communication manual (HI 801 101 E).

The different systems can be connected to one another via Ethernet in any configuration (e.g., star or linear network); a PADT may also be connected to any device.

NOTE

Ethernet operation may be disturbed!

Ensure that no network rings result from interconnecting the controllers. Data packets may only reach a system over a single path.

If M45 controllers are connected to remote I/Os via **safeethernet**, ensure that the remote I/O is equipped with a CPU operating system V7 or higher.

4.2.3 Maximum Communication Time Slice

The maximum communication time slice is the time period in milliseconds (ms) and per cycle assigned to the processor system for processing the communication tasks.

If not all upcoming communication tasks can be processed within one cycle, the whole communication data is transferred over multiple cycles (number of communication time slices > 1).

i

When calculating the maximum response times allowed, the number of communication time slices must be equal to 1, see the communication manual (HI 801 101 E). The duration of the communication time slice must be set such that, when using the communication time slice, the cycle cannot exceed the watchdog time specified by the process.

4.2.4 Connectors for **safeethernet**/Ethernet

The connectors for Ethernet communication are located in the socket of the processor module and of the communication module.

- The processor module contains three RJ-45 connectors labeled *Ethernet1*, *Ethernet2*, and *Local*.
- The communication module has four RJ-45 connectors *Eth1...Eth4*.

To connect the HIMatrix M45 systems, only interference-free Ethernet cables may be used, e.g., shielded (STP)!

4.2.5 Communication with the PADT

A HIMatrix controller communicates with a PADT via Ethernet. A PADT is a computer that is installed with the SILworX programming tool.

The computer must be able to reach the controller via Ethernet.

A controller can simultaneously communicate with up to 5 PADTs. If this is the case, only one programming tool can access the controller with write permission. The remaining programming tools can only read information. If they try to establish a writing connection, the controller only allows them a read-only access.

4.2.6 Ethernet Communication Protocols

In addition to the **safeethernet**, HIMatrix supports the following Ethernet communication protocols:

- SNTP
- Modbus TCP
- Send & Receive TCP
- PROFINET IO and PROFI-safe

For details of the different protocols, see the communication manual (HI 801 101 E).

4.2.6.1 SNTP

The SNTP protocol (simple network time protocol) is used to synchronize the time of the HIMA resources via Ethernet. The current time can be retrieved via Ethernet in predefined time intervals from a PC, or a HIMA resource configured as SNTP server.

HIMA resources with COM OS V6 or higher, can be configured and used as SNTP server and/or as SNTP client. The SNTP server communicates with the SNTP client via the non-safe UDP protocol on port 123.

For further details on the SNTP protocol, refer to the SILworX communication manual (HI 801 101 E) or the online help of the programming tool.

4.2.6.2 Modbus TCP

The HIMA-specific designation for the **non**-safety-related Modbus TCP is Modbus Master/Slave Eth.

The fieldbus protocols Modbus master/slave can communicate with the Modbus TCP via the Ethernet interfaces of the HIMatrix controllers.

In a standard Modbus communication, the slave address and a CRC checksum are transferred in addition to the instruction code and data, while in a Modbus TCP, this function is assumed by the subordinate TCP protocol.

For further details on the Modbus TCP, refer to the SILworX communication manual (HI 801 101 E) or HIMatrix Modbus master/slave manual (HI 800 003 E).

4.2.6.3 Send & Receive TCP

S&R TCP is a manufacturer-independent, **non**-safety-related protocol for cyclic and acyclic data exchange and does not use any specific protocols other than TCP/IP.

With S&R TCP, HIMatrix systems are able to support almost every third-party system as well as PCs with implemented socket interface to TCP/IP (e.g., Winsock.dll).

For further information on the S&R protocol, refer to the SILworX communication manual (HI 801 101 E).

4.2.6.4 PROFINET IO and PROFIsafe

The non-safety-related protocol PROFINET IO and the safety-related protocol PROFIsafe must be configured using SILworX. Refer to the SILworX communication manual (HI 801 101 E) for more information on communication.

4.3 Fieldbus Communication

The communication module is equipped with three fieldbus communication terminals. These 9-pole D-sub connectors are located on the front plate of the module.

The two interfaces can operate simultaneously.

NOTE



Fieldbus operation of other devices may be disturbed!

If the controller is reset, do not connect the fieldbus interfaces to an operational fieldbus to prevent potential disturbances.

4.3.1 Protocols of the Fieldbus Interfaces

The protocols supporting the fieldbus interfaces FB1...FB3 of the communication module depend on the type of the communication module.

Table 14 shows the types of communication protocols and the fieldbus interfaces supported by them. Refer to the communication module-specific manual (HI 800 657 E) for further details.

Type	Protocols on the interfaces		
	FB1	FB2	FB3
M-COM 010 2	PROFIBUS DP master	RS485	RS422/RS485
M-COM 010 3	PROFIBUS DP slave	RS232	RS422/RS485
M-COM 010 7	CAN ¹⁾	RS485	RS422/RS485
M-COM 010 8	SSI	RS485	RS422/RS485
¹⁾ Use HIMA CAN interface cable			

Table 14: Fieldbus Submodule

The fieldbus protocols are selected when ordering the controller using the part number.

Depending on the type of communication module, the communication protocols must be activated. For further information on how to register and activate the protocols, refer to the SILworX communication manual (HI 801 101 E).

4.3.2 Restrictions for Simultaneous Operation of Protocols

- PROFIBUS DP master or slave can only be operated on one fieldbus interface, i.e., two PROFIBUS masters or slaves may not be operated at a time within a resource and, therefore, they will not function.
- Modbus master/slave RS485 can only be operated on one fieldbus interface. However, simultaneous operation via RS485 and Ethernet is allowed.

i

No safety-related communication over fieldbus interfaces can be ensured with the currently available protocols.

Only devices with safe electrical separation may be connected to the fieldbus interfaces.

5 Operating System

The operating system includes all basic functions of the HIMatrix M45 controller (PES).

Which user functions the PES should perform is specified in the user program. A code generator translates the user program into a machine code. The programming tool transfers this machine code to the controller's flash memory.

5.1 Functions of the Processor Operating System

The following table specifies all basic functions of the operating system for a processor system and the connections to the user program:

Functions of the operating system	Connections to the user program
Cyclic processing the user program	It affects variables, function blocks
Automation device configuration	Defined by selecting the controller
Processor tests	- - -
I/O module tests	Depending on the type
Reactions in the event of a fault:	Preset and not changeable The user program is responsible for the process reaction
Processor system and I/O diagnosis	Use of system signals/variables for error messages
Safe communication: peer-to-peer Non-safe communication: PROFIBUS DP, Modbus	To define the use of communication signals/variables
PADT interface: Actions allowed	Defined in the programming tool: Configuration of protective functions, User log-in

Table 15: Functions of the Processor Operating System

Each operating system is inspected by the TÜV in charge, and approved for operation in the safety-related controller. The valid versions of the operating system and corresponding signatures (CRCs) are documented in a list maintained by HIMA in co-operation with the TÜV.

Additional features of one operating system version compared to the previous version can only be exploited if a suitable version of the programming tool is used.

5.2 Indication of the Operating System Versions

The current COM and CPU operating system versions can be displayed using the module data overview, see the SILworX online help. The module data overview is activated from within the online view of the Hardware Editor, selecting the menu option **Online**.

The OS column contains the list of the current operating system versions.

5.3 Behavior in the Event of Faults

The reaction to faults detected during tests is important. The distinction between the following types of faults is made:

- Permanent faults on inputs or outputs
- Temporary faults on inputs or outputs
- Internal faults

5.3.1 Permanent Faults on Inputs or Outputs

A fault on an input or output channel has not effect on the controller. The operating system only considers the defective channel as faulty, and not the entire controller. The remaining safety functions are not affected and remain active.

If the input channels are faulty, the operating system sends the safe value 0 or the initial value for further processing.

Faulty output channels are set to the de-energized state by the operating system. If it is not possible to just switch off a single channel, the entire output module is considered as faulty.

The operating system sets the fault status signal and reports the type of fault to the user program.

If the controller is not able to switch off a given output and even the second switch-off option is not effective, the controller enters the STOP state. The outputs are then switched off by the watchdog of the processor system.

If faults are present in the I/O modules for longer than 24 hours, only the affected I/O modules are permanently switched off by the controller.

5.3.2 Temporary Faults on Inputs or Outputs

If a fault occurs in an input or output module and disappears by itself, the operating system resets the fault status and resumes normal operation.

The operating system statistically evaluates the frequency with which a fault occurs. If the specified fault frequency is exceeded, it permanently sets the module status to *faulty*. In this way, the module no longer operates, even if the fault disappears. The module is released and the fault statistics are reset when the controller operating state switches from STOP to RUN. This change acknowledges the module fault.

5.3.3 Internal Faults

In the seldom case that a HIMatrix M45 controller detects an internal fault, it restarts automatically. Should an internal fault be detected again within the first minute after start up, the HIMatrix M45 controller will remain in the STOP/INVALID CONFIGURATION state.

5.4 Processor Module

The processor module is the central component of the controller and communicates with the I/O modules of the controller via the system bus.

The processor module monitors the sequence and the proper logical execution of the operating system and user program. The following functions are monitored with respect to time:

- Processor module hardware and software self-tests
- Processor module RUN cycle (including the user program)
- I/O tests and processing of I/O signals

5.4.1 Operating States of the Processor Module

LEDs located on the front plate of the controller indicate the operating state of the processor module. The latter can also be reported by the PADT, together with other parameters specific to processor module and user program.

Stopping the processor interrupts the execution of the user program and sets the outputs of the controller and all remote I/Os to safe values.

If the user program sets the EMERGENCY STOP system variables to TRUE, the processor module enters the STOP state.

The following table specifies the most important operating states:

Mode of operation	Description
INIT	Safe state of the processor module during the initialization phase. Hardware and software tests are performed.
STOP / VALID CONFIGURATION	Safe state of the processor module with no execution of the user program All outputs of the controller are reset. Hardware and software tests are performed.
STOP / INVALID CONFIGURATION	Safe state of the processor module without a configuration loaded or after a system fault. All controller's outputs are reset, the hardware watchdog has not triggered. The processor module can only be rebooted using the PADT.
RUN	The processor module is active: The user program is run, I/O signals are processed. The processor module performs safety-related and non-safety-related communication (if configured). Hardware and software tests, and test for configured I/O modules are performed.

Table 16: Modes of Operation for the Processor Module

5.4.2 Programming

A PADT (programming and debugging tool) is used to program the HIMatrix M45 controllers. The PADT is a PC equipped with SILworX.

SILworX supports the following programming languages in accordance with IEC 61131-3:

- Function block diagrams (FBD)
- Sequential function charts (SFC)
- Structured text (function blocks)

SILworX is suitable for developing safety-related programs and for operating the controllers.

Refer to the SILworX online help and SILworX first steps manual (HI 801 103 E) for further details.

6 User Program

In accordance with the IEC 61131-3 requirements, a PADT with installed programming tool SILworX must be used to create and load the user program for the PES.

First, use SILworX to create and configure the user program for the controller's safety-related operation. To this end, observe the instructions specified in the safety manual (HI 800 653 E) and ensure that the requirements specified in the report to the certificate are met.

Upon completion of compiling, SILworX loads the user program (logic) and its configuration (connection parameters such as IP address, subnet mask and system ID) into the controller and starts them.

SILworX can be used to perform the following actions while the controller is operating:

- Starting and stopping the user program.
- Displaying and forcing variables or signals using the Force Editor.
- In test mode, executing the user program in single steps - not suitable for safety-related operation.
- Reading the diagnostic history.

This is possible, provided that SILworX and the controller are loaded with the same user program.

6.1 Modes of Operation for the User Program

Only one user program at a time can be loaded into a given controller. For this user program, the following modes of operations are allowed:

Mode of operation	Description
RUN	The processor module is in RUN. The user program is run cyclically. I/O signals are processed.
Test Mode (single step)	The processor module is in RUN. The user is run cyclically, if previously set by the user. I/O signals are processed. Do not use this function during safety-related operation!
STOP	The processor module is in STOP. The user program is not or no longer run, the outputs are reset.
ERROR	A loaded user program has been stopped due to a failure. The outputs are reset. Note: The program can only be restarted using the PADT.

Table 17: User Program Modes of Operation

6.2 Cycle Sequence

In a simplified overview, the processor module cycle (CPU cycle) of only one user program runs through the following phases:

1. Processing of the input data
2. Processing of the user program
3. Provision of the output data

These phases do not include special tasks such as reload, which might be executed within a CPU cycle.

Global variables, results from function blocks, and other data are processed in the first phase and represent the input data for the second phase. The first phase need not start at the beginning of the cycle, but may be delayed. For this reason, using timer function blocks to determine the cycle time in the user program may result in inaccurate cycle times, potentially exceeding the watchdog time.

In the third phase, the user program results are forwarded for being processed in the following cycles and supplied to the output channels.

6.2.1 Multitasking

Multitasking refers to the capability of the HiMatrix system to process up to 32 user programs within the processor module.

This allows the project's sub-functions to be separated from one another. The individual user programs can be started and stopped independently from one another. SILworX displays the states of the individual user programs in the Control Panel and enables their operation.

Using multitasking, the second phase changes so that a CPU cycle performs the following tasks:

1. Processing of the input data
2. Processing of all the user programs
3. Provision of the output data

In the second phase, the HiMatrix can run up to 32 user programs. Two scenarios are possible for each user program:

- An entire user program cycle can be run within a single CPU cycle.
- A user program cycle requires multiple CPU cycles to be completed.

These two scenarios are even possible if only **one** user program exists.

It is not possible to exchange global data between user programs within a single CPU cycle. Data written by a user program is provided immediately before phase 3, but after the user program has been completely executed. This data can thus first be used as input values at the next start of another user program cycle.

The example in Figure 3 shows both scenarios in a project containing two user programs, Prg 1 and Prg 2.




Figure 3: CPU Cycle Sequence with Multitasking

Each Prg 1 cycle is completely processed during each CPU cycle. *Prg 1* processes an input change registered by the system at the beginning of the CPU cycle **1** and delivers a reaction at the end of the cycle.

One Prg 2 cycle requires two CPU cycles to be processed. Prg 2 needs CPU cycle **1** to process an input change registered by the system at the beginning of CPU cycle **2**. For this reason, the reaction to this input change is only available at the end of CPU cycle **2**. The reaction time of Prg 2 is two times longer than that of Prg 1.

Upon completion of the first part **5** of the Prg 2 cycle under consideration, Prg 2 processing is completely aborted and only resumed when **9** starts. During its cycle, Prg 2 processes the data provided by the system during **3**. The results of Prg 2 are available to the system during **10** (e.g., for process output). The data that the system exchanges with the user program are always consistent.

The program execution order can be controlled by assigning a priority, which indicates how important the corresponding user program is compared to the others (see multitasking mode 2).

To specify the user program execution order, use the following parameters in the resources and programs or in the Multitasking Editor:

i

A license is required to use the multitasking feature.

Parameter	Description	Configurable for
Watchdog Time	Resource watchdog time	Resource, Multitasking Editor
Target Cycle Time [ms]	Required or maximum cycle time	Resource, Multitasking Editor
Multitasking Mode	Use of the execution duration unneeded by the user program, e. g., the difference between actual execution duration in one CPU cycle and the defined <i>Max. Duration for Each Cycle [μs]</i> .	Resource, Multitasking Editor
	Mode 1 The duration of a CPU cycle is based on the required execution time of all user programs.	
	Mode 2 The processor provides user programs with a higher priority the execution time not needed by user programs with a lower priority. Operation mode for high availability.	
	Mode 3 The processor waits until the execution time not needed by the user programs has expired, thus increasing the cycle.	
Target Cycle Time Mode	Use of <i>Target Cycle Time [ms]</i> .	Resource, Multitasking Editor
Program ID	ID for identifying the program when displayed in SILworX	User program
Priority	Importance of a user program; highest priority: 0.	User program
Program's Maximum Number of CPU Cycles	Maximum number of CPU cycles required to process one user program cycle.	User program
Max. Duration for Each Cycle [μs]	Time permitted for executing the user program within a CPU cycle.	User program

Table 18: Parameters Configurable for Multitasking

Observe the following rules when setting the parameters:

- If *Max. Duration for Each Cycle [μs]* is set to 0, the execution time of the user program is not limited, e.g., it is always processed completely. Therefore, the number of cycles may be set to 1 in this case.
- The sum of the *Max. Duration for Each Cycle [μs]* parameters in all user programs must not exceed the resource watchdog time. Make sure that sufficient reserve is planned for processing the remaining system tasks.

- The sum of the *Max. Duration for Each Cycle [μs]* parameters in all user programs must be large enough to ensure that sufficient reserve is available to maintain the target cycle time.
- The *Program IDs* of all user programs must be unique.

During verification and code generation, SILworX monitors that these rules are observed. These rules must also be observed when modifying the parameters online.

SILworX uses these parameters to calculate the user program watchdog time:

User program watchdog time = *watchdog time* * *maximum number of cycles*

i

The sequence control for executing the user programs is run in cycles of 250 μs. For this reason, the values set for *Max. Duration For Each Cycle [μs]* can be exceeded or under-run by up to 250 μs.

Usually, the individual user programs operate interference-free and independently to one another. However, reciprocal influence can be caused by:

- Use of the same global variables in several user programs.
- Unpredictably long runtimes can occur in individual user programs if a limit is not configured with *Max. Duration for Each Cycle [μs]*.

NOTE



Reciprocal influence of user programs is possible!

The use of the same global variables in several user programs can lead to a variety of consequences caused by the reciprocal influence among the user programs.

- **Carefully plan the use of the same global variables in several user programs.**
- **Use the cross-references in SILworX to check the use of global data. Global data may only be assigned values in one location, either in a user program or from the hardware!**

i

HIMA recommends setting the *Max. Duration for each Cycle [μs]* parameter to an appropriate value ≠ 0. This ensures that a user program with an excessively long runtime is stopped during the current CPU cycle and resumed in the next CPU cycle without affecting the other user programs.

Otherwise, an unusually long runtime for one or several user programs can cause the target cycle time, or even the resource watchdog time, to be exceeded, thus leading to an error stop of the controller.

The operating system defines in which order the user programs are executed in accordance with the following scheme:

- User programs with lower priority are executed before user programs with higher priority.
- If the user programs have the same priority, the system processes them in ascending order of the *Program IDs*.


This order is also followed when starting and stopping the user program during the start and stop of the PES, respectively.

6.2.2 Multitasking Mode

Three operation modes exist for multitasking. These modes differ in how the time that is not needed for executing the CPU cycle of the user programs is used. One of these three modes can be selected for every resource.

1. **Multitasking Mode 1** uses the unneeded time to reduce the CPU cycle. If the user program is completely processed, processing of the next user program begins immediately. In total, this results in a shorter cycle.

Example: 3 user programs (*Prg 1*, *Prg 2* and *Prg 3*) that allow a user program cycle to take up to 3 CPU cycles.




- | | |
|---|---|
| <p>1 First CPU Cycle Considered.</p> <p>2 Second CPU Cycle Considered.</p> <p>3 Third CPU Cycle Considered.</p> <p>4 Max. Duration for Each Cycle [μs] of <i>Prg 1</i> has Expired, <i>Prg 2</i> Starts.</p> <p>5 Max. Duration for Each Cycle [μs] of <i>Prg 2</i> has Expired, <i>Prg 3</i> Starts.</p> <p>6 Max. Duration per Cycle [μs] of <i>Prg 3</i> has Expired, End of the First CPU Cycle.</p> <p>7 Completion of the <i>Prg 1</i> cycle, <i>Prg 2</i> is Resumed.</p> <p>8 Completion of the <i>Prg 2</i> Cycle, <i>Prg 3</i> is Resumed.</p> | <p>9 Max. Duration per Cycle [μs] of <i>Prg 3</i> has Expired, End of the Second CPU Cycle.</p> <p>10 The Next User Program Cycle <i>Prg 1</i> Starts.</p> <p>11 Max. Duration for Each Cycle [μs] of <i>UP 1</i> has Expired. Next User Program Cycle of <i>Prg 2</i> Starts.</p> <p>12 Max. Duration for Each Cycle [μs] of <i>Prg 2</i> has Expired, <i>Prg 3</i> Starts.</p> <p>13 Completion of the User Program Cycle <i>Prg 3</i>.</p> |
|---|---|

Figure 4: Multitasking Mode 1

2. In **Multitasking Mode 2**, the unneeded duration of lower-priority user programs is distributed among higher-priority user programs. In addition to the specified *Max. Duration for Each Cycle* [μ s], these user programs can use the portions of unneeded duration. This procedure ensures high availability.

Four user programs are used in the example: *Prg 1...Prg 4*. The following priorities are allocated to the user programs:

- *Prg 1* has the lowest priority, priority *x*
- *Prg 2* and *Prg 3* have a medium priority, priority *y*
- *Prg 4* has the highest priority, priority *z*



1 First CPU Cycle Considered.

2 Second CPU Cycle Considered.

3 Third CPU Cycle Considered.

4 *Max. Duration for Each Cycle* [μ s] of *Prg 1* has Expired, *Prg 2* Starts.

5 *Max. Duration for Each Cycle* [μ s] of *Prg 2* has Expired, *Prg 3* Starts.

6 *Max. Duration for Each Cycle* [μ s] of *Prg 3* has Expired, *Prg 4* Starts.

7 *Max. Duration for Each Cycle* [μ s] of *Prg 4* has Expired, Completion of the First CPU Cycle.

8 Completion of the User Program Cycle of *Prg 1*, *Prg 2* is Resumed. The Remaining Duration is Distributed to the *Max. Duration for Each Cycle* [μ s] of *Prg 2* and *Prg 3* (Medium Priority *y*) (Arrows).

9 *Max. Duration for Each Cycle* [μ s] of *Prg 2* + Proportional Remaining Duration of *Prg 1* Expired, *Prg 3* is Resumed.

10 *Max. Duration per Cycle* [μ s] of *Prg 3* and Proportional Remaining Duration of *Prg 1* has Expired, *Prg 4* Starts.

11 *Max. Duration for Each Cycle* [μ s] of *Prg 4* has Expired, Completion of the Second CPU Cycle.

12 The Next User Program Cycle *Prg 1* Starts.

13 Completion of *Prg 1 Max. Duration for Each Cycle* [μ s], *Prg 2* is Resumed.

14 Completion of *Prg 2 Max. Duration for Each Cycle* [μ s], *Prg 3* is Resumed.

15 Completion of the *Prg 3* cycle, *Prg 4* is Resumed. The Remaining Duration is Added to *Prg 4* (Highest Priority *z*).

16 *Max. Duration for Each Cycle* [μ s] of *Prg 4* + Remaining Duration of *Prg 3* Expired, Completion of the Third CPU Cycle.

Figure 5: Multitasking Mode 2

i

The execution time not used by user programs that were not run, is not available as residual time for other user programs. User programs are not run if they are in one of the following states:

- STOP
- ERROR
- TEST_MODE

As a consequence, the number of CPU cycles required to process another user program cycle could increase.

In such a case, if the value set for *Maximum Cycle Count* is too low, the maximum time for processing a user program can be exceeded and result in an error stop!


Maximum processing time = *Max. Duration for Each Cycle [μs]* * *Maximum Number of Cycles*

Use multitasking mode 3 to verify the parameter setting!

3. **Multitasking Mode 3** does not use the unneeded duration for running the user programs, rather, it waits until the *Max. Duration for Each Cycle [μs]* of the user program is reached and then starts processing the next user program. This behavior results in CPU cycles of the same duration.

Multitasking mode 3 allows users to verify if multitasking mode 2 ensures proper program execution, even in the worst case scenario.

The example examines user programs named *Prg 1*, *Prg 2* and *Prg 3*:



- | | |
|--|---|
| <p>1 First CPU Cycle Considered.</p> <p>2 Second CPU Cycle Considered.</p> <p>3 Third CPU Cycle Considered.</p> <p>4 <i>Max. Duration for Each Cycle [μs]</i> of <i>Prg 1</i> has Expired, <i>Prg 2</i> Starts.</p> <p>5 <i>Max. Duration for Each Cycle [μs]</i> of <i>Prg 2</i> has Expired, <i>Prg 3</i> Starts.</p> <p>6 <i>Max. Duration for Each Cycle [μs]</i> of <i>Prg 3</i> has Expired, Completion of the First CPU Cycle. <i>Prg 1</i> is Resumed.</p> <p>7 Completion of the User Program Cycle <i>Prg 1</i>. Waiting for the Remaining Duration.</p> <p>8 <i>Max. Duration for Each Cycle [μs]</i> of <i>Prg 1</i> has Expired. <i>Prg 2</i> is Resumed.</p> | <p>9 Completion of the User Program Cycle <i>Prg 2</i>. Waiting for the Remaining Duration.</p> <p>10 <i>Max. Duration for Each Cycle [μs]</i> of <i>Prg 3</i> has Expired. Completion of the Second CPU Cycle.</p> <p>11 The Next User Program Cycle <i>Prg 1</i> Starts.</p> <p>12 <i>Max. Duration for Each Cycle [μs]</i> of <i>Prog 1</i> has Expired. The Next User Program Cycle of <i>Prog 2</i> Starts.</p> <p>13 <i>Max. Duration for Each Cycle [μs]</i> of <i>UP 2</i> has Expired. <i>Prg 3</i> is Resumed.</p> <p>14 Completion of the User Program Cycle <i>Prg 3</i>. Standby Time until the <i>Max. Duration for Each Cycle [μs]</i> of <i>Prg 3</i> has Expired. Completion of the Third CPU Cycle.</p> |
|--|---|

Figure 6: Multitasking Mode 3

i

In the examples illustrating the multitasking modes, input and output processing are represented as empty spaces at the beginning and the end of each CPU cycle.

6.3 Reload

If user programs were modified, the changes can be transferred to the PES during operation. The operating system checks and activates the modified user program which then assumes the control task.

i

Observe the following points when reloading step chains:

The reload information for step sequences does not take the current sequence status into account. The step sequence can be accordingly changed and set to an undefined state by performing a reload.

The user is responsible for this action.

Examples:

- Deleting the active step. As a result, no step of the step chain has the *active* state.
 - Renaming the initial step while another step is active.
As a result, a step chain has two active steps!
-

i

Observe the following points when reloading actions:

During the reload, actions are loaded with their corresponding data. All potential consequences must be carefully analyzed prior to performing a reload.

Examples:

- If a timer action qualifier is deleted due to the reload, the timer expires immediately. Depending on the remaining settings, the Q outputs can therefore be set to TRUE.
 - If the status action qualifier (e.g., the S action qualifier) is deleted for a set element, the element remains set.
 - Deleting a PO action qualifier set to TRUE actuates the trigger function.
-

i

When reloading the watchdog time, the following points must be observed:

If a reload process is to increase the watchdog time, first set the new value for the watchdog time online and then perform the reload. This avoids connection losses and the shutdown of the I/O module.

Prior to performing a reload, the operating system checks if the required additional tasks would increase the cycle time of the current user programs to such an extent that the defined watchdog time is exceeded. In this case, the reload process is aborted with an error message and the controller continues operation with the previous project configuration.

i

The controller can interrupt a running reload process.

A successful reload is ensured by planning a sufficient reserve for the reload when determining the watchdog time or temporarily increasing the controller watchdog time by a reserve.

Any temporary increases in the watchdog time must be agreed upon with the responsible test authority.

Also exceeding the target cycle time can result in a reload interruption.

The reload can only be performed if the *Reload Allowed* system parameter is set to ON and the *Reload Deactivation* system variable is set to OFF.

i

The user is responsible for ensuring that the watchdog time includes a sufficient reserve time. This should allow the user to manage the following situations:

- Variations in the user program's cycle time
- Sudden, strong cycle loads, e.g., due to communication.
- Expiration of time limits during communication.

During a reload, the global and local variables obtain the values of the corresponding variables from the previous project version. Names of local variables contain the POU instance names.

If names are changed and loaded into the PES by performing a reload, this procedure has the following consequences:

- Renaming a variable has the same effect as deleting the variable and creating a new one, i.e., it results in an initialization process. This also applies to retain variables. The variables lose their current value.
- Renaming a function block instance results in initializing all the variables, including retain variables, and all the function block instances.
- Renaming a program results in initializing all its variables and function block instances.

This behavior may have unintended effects on one or multiple user programs and therefore on the plant to be controlled!

6.3.1 Conditions for Using the Reload Function

A license is required to use the reload feature.

A reload can be performed to load the following project changes to the controller:

- Changes to the user program parameters.
- Changes to the logic of the program, function blocks and functions.
- Changes that allow a reload in accordance with Table 19.

Changes to	Type of change			
	Add	Delete	Change of the initial value	Assignment of other variables
Assigning global variables to				
User programs	•	•	•	•
System variables	•	•	•	•
I/O channels	•	•	•	•
Communication protocols	•	•	-	-
safeethernet	•	•	•	-
SOE	•	•		
Communication protocols	•	•	n.a.	n.a.
User programs	•	•**	n.a.	n.a.
System ID, rack ID	-			
IP addresses	•			
User accounts and licenses	•			
<div>• Reload possible</div> <div>- Reload not possible</div> <div>** Reload possible, but the controller must still contain at least one user program</div> <div>n.a.: not applicable</div>				

Table 19: Reloading after Changes

A reload may only be performed in accordance with the conditions mentioned in the previous section. In all the other cases, stop the controller and perform a download.

TIP

Proceed as described below to perform a reload even if global variable assignments have been added:

- While creating the user program, assign unused global variables to communication protocols.
- Assign safe value as initial value to unused global variables.

To a later time point, this assignment must only be changed and not added ensuring the possibility to perform a reload.

6.4 Forcing

Forcing is the procedure by which a variable's current value is replaced with a force value. The current value of a variable is assigned from one of the following sources:

- a physical input
- communication
- a logic operation

When a variable is being forced, its value is defined by the user.

Forcing is used for the following purposes:

- Testing the user program; in particular, in cases or conditions that cannot otherwise be tested.
- Simulating unavailable sensors when the initial values are not appropriate.

WARNING



Failure of safety-related operation possible due to forced values!

- **Forced value may lead to incorrect output values.**
- **Forcing prolongates the cycle time. This can cause the watchdog time to be exceeded.**
- **Forcing is only permitted after receiving consent from the competent test authority.**

When forcing values, the person in charge must take further technical and organizational measures to ensure that the process is sufficiently monitored in terms of safety. HIMA recommends setting a time limit for the forcing procedure, see below.

Forcing can operate at two levels:

- Global forcing: Global variables are forced for all applications.
- Local forcing: Values of local variables are forced for an individual user program.

To force a global or local variable, the following conditions must be met:

- The corresponding force switch is set.
- Forcing was started.

If forcing was started, a change to the force switch has an immediate effect.

If forcing was started and the force switch is set, a change to the force value has an immediate effect.

Local forcing can be started and stopped individually for each user program.

6.4.1 Time Limits

Different time limits can be set for global or local forcing. Once the defined time has expired, the controller stops forcing values.

It is possible to define how the HiMatrix system should behave upon expiration of the time limit:

- If global forcing is used, the following settings can be selected:
 - The resource stops.
 - The resource continues to operate.
- If local forcing is used, the following settings can be selected:
 - The user program stops.
 - The user program continues to run.

It is also possible to use forcing without time limit. In this case, the forcing procedure must be stopped manually.

If a variable is no longer forced, the process value is used again for the variable.

6.4.2 Force Editor

The SILworX Force Editor displays all the variables for which forcing is allowed. Global and local variables are grouped into two different tabs.

Use these tabs to configure the force values and set the force switches.

6.4.3 Restricting the Use of Forcing

The following measures limiting the use of forcing can be configured to avoid potential faults in the safety functionality due to its improper use:

- Configuring different user profiles with or without forcing authorization.
- Prohibit global forcing for a resource.
- Prohibit local forcing or entering new process values.
- Forcing can also be stopped immediately using a key switch.
To do so, the *Force Deactivation* system variable must be linked to a digital input connected to a key switch.
The system variable *Force Deactivation* prevents global and local forcing from being started and stops an on-going forcing process.

7 Start-Up

Commissioning of modular HIMatrix M45 system comprises the following phases:

- Mounting the DIN rail in a suitable location and its assembly with modules.
Take the dissipation of the generated heat into account.
- Electrical connection of power supply, earthing, sensors, and actuators
- Configuration
 - Writing the user program
 - Definition of safety, communication and other parameters

7.1 Considerations about Heat

The increased integration level of electronic components causes a corresponding lost heat. This depends on the external load of HIMatrix modules. Depending on the structure, the system installation and ventilation are thus of importance.

During the system installation, it must be ensured that the approved environmental requirements have been adhered to. Lowering the operating temperature increases the lifetime and the reliability of the electronic components within the systems.

7.1.1 Heat Dissipation

A closed enclosure must be designed such that the heat generated inside can be dissipated through its surface.

Mounting type and position must be chosen such that heat dissipation is ensured.

The power dissipation of the installed equipment is decisive for determining the fan components. It is assumed that heat load and unhindered natural convection are uniformly distributed (see Chapter 7.1.1.3).

7.1.1.1 Definitions

P_V [W] Power dissipation (heat capacity) of the electronic components within the enclosure

A [m²] Effective enclosure surface area (see Table 20)

k [W/m² K] Heat transfer coefficient of the enclosure, steel sheet: ~ 5.5 W/m² K

7.1.1.2 Installation Type

In accordance with the mounting or installation type, the effective enclosure surface area A is determined as follows:








Enclosure installation type in accordance with VDE 0660, Part 5	Calculation of A [m ²]
 Individual enclosure, free-standing on all sides	$A = 1.8 \times H \times (W + D) + 1.4 \times W \times D$
 Individual enclosure for wall mounting	$A = 1.4 \times W \times (H + D) + 1.8 \times H \times D$
 First or last enclosure in a suite, free-standing	$A = 1.4 \times W \times (H + D) + 1.8 \times H \times D$
 First or last enclosure in a suite, for wall mounting	$A = 1.4 \times H \times (W + D) + 1.4 \times W \times D$
 Central enclosure, free-standing	$A = 1.8 \times W \times H + 1.4 \times W \times D + H \times D$
 Central enclosure for wall mounting	$A = 1.4 \times W \times (H + D) + H \times D$
 Enclosure within a suite, for wall mounting, covered roof surface	$A = 1.4 \times W \times H + 0.7 \times W \times D + H \times D$

Table 20: Installation Type

7.1.1.3 Natural Convection

When the natural convection is used, the lost heat is dissipated through the enclosure walls. Requirement: The ambient temperature must be lower than the temperature within the enclosure.

The maximum temperature increase $(\Delta T)_{\max}$ of all electronic devices within the enclosure is calculated as follows:

$$(\Delta T)_{\max} = \frac{P_V}{k \cdot A}$$

The power dissipation P_V can be calculated based on the specifications for the electric power rating of the system and its inputs and outputs.

The temperature within an enclosure can also be calculated in accordance with VDE 0660, Part 507 (HD 528 S2).

i

All considerations about heat must take **every** component within a cabinet or enclosure into account!

7.2 Installation and Mounting

The safety-related HIMatrix M45 controller systems can be installed on mounting surfaces, and also in closed enclosures such as control stations, terminal boxes and control cabinets. They have been developed in compliance with the relevant standards for EMC, climate and environmental requirements.

The list of the standards that must be observed is specified in Chapter 2.2.1 and in the manuals for the HIMatrix M45 systems.

The protection class of the HIMatrix M45 systems (IP20) can be increased by installing them in an appropriate enclosure in accordance with the requirements. In doing so, appropriate heat dissipation must be ensured (see Chapter 7.1).

7.2.1 Mounting

The location for installing a HIMatrix M45 system must be chosen observing the ambient conditions (see Chapter 2.2) to ensure a smooth operation.

Observe the following points:

- For efficient cooling, mount the DIN rail horizontally.
 - Maintain a distance of at least 100 mm above and below the M45 system.
 - Do not mount the M45 system above heating equipment or any heat source.
- Only mount the controller with unconnected connectors.




Figure 7: Mounting Distance

i

The HIMatrix systems must be mounted such that:

- HiMatrix M45 systems are not heated up by other devices with high heat emissions.
- Devices with high EMC interference do not interfere with HiMatrix M45 systems. Observe the instructions provided by the manufacturer.

7.2.2 Construction Depth

Due to the connections for communication and I/O level, the HIMatrix M45 system has a construction depth of 90 mm. It is measured from the mounting rail.

7.2.3 Mounting on a Flat Base

The DIN rail must be secured on a flat base.

7.3 Mounting and Removing Modules and Sockets

This chapter describes how to mount and remove the modules and sockets. When replacing modules, the sockets remain on the DIN rail. This saves additional wiring effort since all field lines are connected to the socket.

7.3.1 Mounting the Socket

Tools and utilities:

- Screwdriver, slotted 1.0 x 5.5 mm


To insert the socket

1. Set the socket onto the DIN rail **1**.
2. Swivel the socket in **2**.
3. Move the socket on the DIN rail and connect it to another socket **3**.
4. Press the socket's latch upwards **4**.
 - ☒ The latch is used to attach the socket to the DIN rail, and is secured to the socket located on its left-hand side.
5. The socket mounting is completed, the field lines can be connected.

To remove the socket

Prior to removing the socket, the module must be removed and the field lines must be released from the terminals.

1. Use a screwdriver to push the blue latch downwards **4**.
2. Remove the sockets from the adjacent sockets **3**.
3. Swivel the socket out **2**.
4. Lift the socket and remove it **1**.



- 1** Setting and Lifting the Socket
- 2** Swiveling the Socket In and Out

- 3** Connecting and Disconnecting Sockets
- 4** Closing and Opening the Latch

Figure 8: Example of Socket Mounting

7.3.2 Inserting and Removing the Module

This chapter describes how to mount and remove a module in the M45 system.


Coding prevents the module from improper assembling.

To insert the module

1. Plug the module in to the socket, until the locking mechanism is engaged.

To remove the module

1. Press the latch **1** backwards as far as it can go. The locking mechanism is released.
2. Remove the module from the socket.



1 Latch for Releasing the Module

Figure 9: Example of Mounting and Removing the Module

7.3.3 Changes to M45 System

Changes to the number of modules, i.e., if modules and sockets are added or removed, may only be performed **if the supply voltage is switched off!**

Changes performed to the HIMatrix M45 system without switching off the supply voltage result in an address conflict.

Address conflicts can be repaired as follows:

- Switching the supply voltage off and on again.
- Restart the concerned modules.
To do so, restart the modules from left to right, towards increasing slot numbers.
- Restart all modules.

7.4 Connecting the Input and Output Circuits

Only personnel with knowledge of ESD protective measures may modify or extend the system wiring.

NOTE



Electrostatic discharge!

Failure to comply with these instructions can damage the electronic components.

- Prior to working with HIMA components, touch an earthed object.
- Make sure that the workspace is free of static and wear an ESD wrist strap.
- If not used, ensure that the module is protected from electrostatic discharge, e.g., by storing it in its packaging.

NOTE



Cable failure is possible under tensile load!

Do not use the shield clamp as a strain relief for the connected cable!

7.4.1 Earthing and Shielding

7.4.1.1 Earthing the 24 VDC System Voltage

All HIMatrix M45 systems must be operated with power supply units that comply with the SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage) requirements. A functional earth is prescribed to improve the electromagnetic compatibility (EMC).

All HIMatrix M45 systems can be operated with earthed L- or unearthed.

Unearthed Operation

Unearthed operation offers some advantages in terms of EMC behavior.

Some applications have specific requirements for the unearthed operation of controllers, e.g., in accordance with the EN 50156 standard, earth fault monitoring is required for unearthed operation.

Earthed Operation

The earth must be designed in accordance with the standard and must have a separate earth contact through which no power-dependent interference current may flow. Only earthing of negative pole (L-) is permitted. Earthing of positive pole (L+) is not permitted since a potential earth fault on the transmitter line would bypass the affected transmitter.

L- can only be earthed on one place within the system. L- is usually earthed directly behind the power supply unit, e.g., on the busbar. The earthing should be easily accessible and well separable. The earthing resistance must be $\leq 2 \Omega$.

7.4.1.2 Earthing Connections

The modules are earthed using the DIN rail. The DIN rail must be connected to the earthing connector of the control cabinet or enclosure.

These measures ensure a reliable earth ground and compliance with the current EMC requirements for HIMatrix M45 systems.

7.4.1.3 Shielding

The shielding must be connected to the HIMatrix M45 system and the sensor or actuator housing and earthed on one end to the HIMatrix M45 system side to form a Faraday cage.

In all other devices, the shielding must be positioned in the controller housing, terminal box, control cabinet, etc.



The shield clamp must not be used as a strain relief for the connected cable.

7.4.1.4 EMC Protection

Windows in the enclosure in which the HIMatrix M45 system is installed are permitted.

Increased EMC interferences outside the standard limit values require appropriate measures.



- For improved EMC, earth the housing.
 - The connection to the next grounding point must be as short as possible to achieve a low earthing resistance.
-

7.4.2 Connecting the Supply Voltage

The electrical connection is made via a removable connector on the processor module socket and on additional power module sockets. The connector can accept wires of up to 6 mm².

Connection	Function
L+ DC 24 V	Power supply L+ (24 VDC)
L- DC 24 V	Power supply L- (24 VDC ground)

Table 21: Connectors for Operating Voltage

If shielded wires are used for the power supply, the shielding must also be connected to the power supply connector via the earth contact.

The power supply unit must meet the IEC/EN 61131-2 requirements and comply with the low voltage directives SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage).

Check proper polarity, voltage and ripple prior to connecting the operating voltage 24 VDC.

Do not exchange the terminals L+ and L-, or connect them to other terminals of the device!

In case of a false connection, a pre-fuse blows to prevent the device from being damaged.

7.5 Configuration

This chapter describes the configuration using the SILworX programming tool.

7.5.1 Configuring the Resource

The resource properties and the hardware output variables are changed at this level.

7.5.1.1 Resource Properties

The system parameters of the resource determine the controller behavior during operation and can be set in SILworX, in the *Properties* dialog box of the resource.

Parameter	Description	Default value	Setting for safe operation
Name	Name of the resource		Arbitrary
System ID [SRS]¹⁾	System ID of the resource 1...65 535 The value assigned to the system ID must differ to the default value, otherwise the project is not able to run!	60 000	Unique value within the controller network. This network includes all controllers that can potentially be interconnected
Safety Time [ms]	Safety time in milliseconds 20...22 500 ms	600 ms	Application-specific
Watchdog Time [ms]	Watchdog time in milliseconds: 4...5000 ms	200 ms	Application-specific
Target Cycle Time [ms]	Targeted or maximum cycle time, see <i>Target Cycle Time Mode</i> , 0...7500 ms. The maximum target cycle time value may not exceed the <i>watchdog time</i> - minimum watchdog time; otherwise it is rejected by the PES. If the default value 0 ms is set, the target cycle time is not taken into account.	0 ms	Application-specific
Target Cycle Time Mode	Use of <i>Target Cycle Time [ms]</i> see Table 23.	Fixed-tolerant	Application-specific
Multitasking Mode	Mode 1 The duration of a CPU cycle is based on the required execution time of all user programs.	Mode 1	Application-specific
	Mode 2 The processor provides user programs with a higher priority the execution time not needed by user programs with a lower priority. Operation mode for high availability.		
	Mode 3 The processor waits until the execution time not needed by the user programs has expired, thus increasing the cycle.		
Max.Com. Time Slice ASYNC [ms]	Highest value in ms for the time slice used for communication during a resource cycle, see the communication manual (HI 801 101 E), 2...5000 ms	60 ms	Application-specific
Max. Duration of Configuration Connections [ms]	It defines how much time within a CPU cycle is available for configuration connections, 2...3500 ms	12 ms	Application-specific
Maximum System Bus Latency [µs]	Not applicable for HIMatrix M45 controllers!	0 µs	-

Parameter	Description	Default value	Setting for safe operation
Allow Online Settings	ON: All the switches/parameters listed below OFF can be changed online using the PADT. This is only valid if the system variable <i>Read-only in RUN</i> has the value OFF.	ON	OFF is recommended
	OFF: These parameters may not be changed online <ul style="list-style-type: none"> ▪ <i>System ID</i> ▪ <i>Autostart</i> ▪ <i>Global Forcing Allowed</i> ▪ <i>Global Force Timeout Reaction</i> ▪ <i>Load Allowed</i> ▪ <i>Reload Allowed</i> ▪ <i>Start Allowed</i> These parameters may be changed online if <i>Reload Allowed</i> is set to ON. <ul style="list-style-type: none"> ▪ Watchdog Time (for the resource) ▪ <i>Safety Time</i> ▪ <i>Target cycle time</i> ▪ <i>Target Cycle Time Mode</i> If <i>Reload Allowed</i> is set to OFF, they are not changeable online.		
	i <i>Allow Online Settings</i> can only be set to ON via reload or if the PES is stopped.		
Autostart	ON: If the processor module is connected to the supply voltage, the user program/programs start automatically	OFF	Application-specific
	OFF: The user program does not start automatically after connecting the supply voltage.		
Start Allowed	ON: A cold start or warm start permitted with the PADT in RUN or STOP	ON	Application-specific
	OFF: Start not allowed		
Load Allowed	ON: Configuration download is allowed	ON	Application-specific
	OFF: Configuration download is not allowed		
Reload Allowed	ON: Configuration reload is allowed	ON	Application-specific
	OFF: Configuration reload is not allowed. A running reload process is not aborted when switching to OFF		
Global Forcing Allowed	ON: Global forcing permitted for this resource	ON	Application-specific
	OFF: Global forcing not permitted for this resource		
Global Force Timeout Reaction	Specifies how the resource should behave when the global force timeout has expired: <ul style="list-style-type: none"> ▪ Stop Forcing ▪ Stop Resource 	Stop Forcing	Application-specific
Minimum Configuration Version	With this setting, code compatible to previous or newer CPU operating system versions in accordance with the project requirements may be generated.	SILworX V6	SILworX V6
	SILworX V2 Not applicable for HIMatrix M45 controllers!		
	SILworX V3		
	SILworX V4		
	SILworX V5		
	SILworX V6 Setting for HIMatrix M45. Generates code suitable for the CPU operating system V9. This setting ensures the compatibility with future versions.		

¹⁾ **Safety parameters** are displayed in bold.

Table 22: Resource System Parameters

The following table describes the effect of *Target Cycle Time Mode*.

Target Cycle Time Mode	Effect on user programs	Effect on reload of processor modules
Fixed	The PES maintains the target cycle time and extends the cycle if necessary. If the processing time of the user programs exceeds the target cycle time, the cycle duration is increased.	Reload is not processed if the target cycle time is not sufficient.
Fixed-tolerant		At most, the duration of every fourth cycle is increased to allow reload.
Dynamic-tolerant	HiMatrix executes the cycle as quickly as possible.	At most, the duration of every fourth cycle is increased to allow reload.
Dynamic		Reload is not processed if the target cycle time is not sufficient.

Table 23: Effect of Target Cycle Time Mode

7.5.1.2 Hardware System Variables for Setting the Parameters

These variables are used to change the behavior of the controller while it is operating in specific states. These variables are located in the hardware detail view of the SILworX Hardware Editor.

Variable	Function	Default setting	Setting for safe operation
Force Deactivation	Used to prevent forcing and to stop it immediately	FALSE	Application-specific
Spare 2... Spare 16	No function	-	-
Emergency stop 1... Emergency stop 4	Emergency stop switch to shut down the controller if faults are detected by the user program	FALSE	Application-specific
Read-only in RUN	After starting the controller, no operating action such as stop, start or download is permitted in SILworX , except for forcing and reload.	FALSE	Application-specific
Relay Contact 1... Relay Contact 4	Not applicable for M45! It controls the corresponding relay contacts, if existing.	FALSE	Application-specific
Reload Deactivation	The controller cannot be loaded by performing a reload.	FALSE	Application-specific
Power save mode	It switches the output modules to power save mode, i.e., the outputs are switched off.	FALSE	Application-specific
User LED 1... User LED 2	It controls the corresponding LED.	FALSE	Application-specific

Table 27: Hardware System Variables

Global variables can be connected to these system variables; the value of the global variables is modified using a physical input or the user program logic.

The system variables *Force Deactivation*, *Read-only in Run* and *Reload Deactivation* can be activated by authorized persons using a key switch.

Using the suitable key switch, the user is thus able to interrupt running processes, e.g., forcing.

To configure *Force Deactivation*, *Read-only in Run* or *Reload Deactivation* for being operated using a key switch

1. Assign a global variable to a system variable.
2. Assign the same global variable to a digital input.
3. Connect a key switch to the digital input.

The position of the key switch defines the system variable value.

One key switch can be used to control several system variables.

7.5.1.3 Hardware System Variables for Reading the Parameters

These system variables can be accessed in the SILworX Hardware Editor.

Select the gray background outside the (yellow) subrack representation and double-click or use the context menu to open the detail view.

Variable	Description	Data type
Number of Field Errors	Number of current I/O errors	UDINT
Number of Field Errors - Historic Count	Counted number of I/O errors (counter resettable)	UDINT
Number of Field Warnings	Number of current I/O warnings	UDINT
Number of Field Warnings - Historic Count	Counted number of I/O warnings (counter resettable)	UDINT
Communication Error Count	Number of current communication errors	UDINT
Communication Error Historic Count	Counted number of communication errors (counter resettable)	UDINT
Communication Warning Count	Number of current communication warnings	UDINT
Communication Warnings Historic Count	Counted number of communication warnings (counter resettable)	UDINT
System Error Count	Number of current system errors	UDINT
System Error Historic Count	Counted number of system errors (counter resettable)	UDINT
System Warning Count	Number of current system warnings	UDINT
System Warning Historic Count	Counted number of system warnings (counter resettable)	UDINT
Autostart	ON: When the processor module is connected to the supply voltage, it automatically starts the user program.	BOOL
	OFF: When the supply voltage is connected, the processor module enters the STOP state.	
OS Major	Operating system version contained in the processor module	UINT
OS Minor		UINT
CRC	Resource configuration checksum	UDINT
Date/time [ms portion]	System date and time in s and ms since 1970-01-01	UDINT
Date/time [s portion]		UDINT
Force Deactivation	ON: Forcing is deactivated.	BOOL
	OFF: Forcing is possible.	
Forcing Active	ON: Global or local forcing is active.	BOOL
	OFF: Global and local forcing are not active.	
Force Switch State	State of the force switch	UDINT
	0xFFFFFFFF No force switch set	
	0xFFFFFFFF At least one force switch set	
Global Forcing Started	ON: Global forcing is active.	BOOL
	OFF: Global forcing is not active.	
Spare 0...Spare 16	Reserved	USINT
Spare 17		BOOL
Last Field Warning [ms]	Date and time of the last I/O warning in s and ms since 1970-01-01	UDINT
Last Field Warning [s]		UDINT

Variable	Description	Data type
Last Communication Warning [ms]	Date and time of the last communication warning in s and ms since 1970-01-01	UDINT
Last Communication Warning [s]		UDINT
Last System Warning [ms]	Date and time of the last system warning in s and ms since 1970-01-01	UDINT
Last System Warning [s]		UDINT
Last Field Error [ms]	Date and time of the last I/O error in s and ms since 1970-01-01	UDINT
Last Field Error [s]		UDINT
Last Communication Error [ms]	Date and time of the last communication error in s and ms since 1970-01-01	UDINT
Last Communication Error [s]		UDINT
Last System Error [ms]	Date and time of the last system error in s and ms since 1970-01-01	UDINT
Last System Fault [s]		UDINT
Fan State	0x00 Fan functioning	BYTE
	0x01 Fan defective	
	0xFF Not available - for M45	
Allow Online Settings	Specifies if the online settings of the enable switch are allowed:	BOOL
	ON: The subordinate enable switches can be changed online.	
	OFF: The subordinate enable switches cannot be changed online.	
Read-only in RUN	ON: The operator actions: Stop, Start, Download are locked.	BOOL
	OFF: The operator actions: Stop, Start, Download are not locked.	
Reload Allowed	ON: Controller can be loaded by performing a reload	BOOL
	OFF: Controller cannot be loaded by performing a reload	
Reload Deactivation	ON: Loading by performing a reload is locked	BOOL
	OFF: Loading by performing a reload is possible	
Reload Cycle	TRUE during the first cycle after a reload, otherwise FALSE	BOOL
Safety Time [ms]	Safety time set for the controller in ms	UDINT
Start Allowed	ON: Start of processor module using PADT is allowed	BOOL
	OFF: Start of processor module using PADT is not allowed	
Start Cycle	ON during the first cycle after starting, otherwise OFF	BOOL

Variable	Description	Data type
Power Supply State	Bit-coded state of the power supply units.	BYTE
	Value State	
	0x00 Normal	
	0x01 Undervoltage with 24 V supply voltage	
	0x02 (Low voltage with battery) <i>not used</i>	
	0x04 Low voltage with internally generated 5 V voltage	
	0x08 Low voltage with internally generated 3.3 V voltage	
	0x10 Overvoltage with internally generated 3.3 V voltage	
	F60 modular controller:	
	Value State	
	0x00 Normal	
	0x01 Error with 24 V supply voltage	
	0x02 Battery failure	
	0x04 Error with 5 V voltage of power supply	
	0x08 Error with 3.3 V voltage of power supply	
	0x10 Undervoltage with 5 V voltage	
	0x20 Overvoltage with 5 V voltage	
	0x40 Undervoltage with 3.3 V voltage	
	0x80 Overvoltage with 3.3 V voltage	
System ID [SRS]	System ID of the controller, 1...65 535	UINT
Systemtick HIGH	Revolving millisecond counter (64-bit)	UDINT
Systemtick LOW		UDINT
Temperature state	Bit-coded temperature state of the processor module	BYTE
	Value State	
	0x00 Normal temperature	
	0x01 Temperature threshold 1 exceeded	
	0x03 Temperature threshold 2 exceeded	
	0xFF Not available	
Remaining Global Force Duration [ms]	Time in ms until the time limit set for global forcing expires.	DINT
Watchdog Time [ms]	Maximum permissible duration of a RUN cycle in ms.	UDINT
Cycle Time, last [ms]	Current cycle time in ms	UDINT
Cycle Time, max [ms]	Maximum cycle time in ms	UDINT
Cycle Time, min [ms]	Minimum cycle time in ms	UDINT
Cycle Time, average [ms]	Average cycle time in ms	UDINT

Table 28: Hardware System Variables for Reading the Parameters

7.5.1.4 Rack System Parameter Settings

The rack system parameters can be set in the Rack's online view.

Parameter	Description	Default value
Type	Spare, not changeable	-
Name	Rack name for the controller, text	HIMatrix F.. Rack
Rack ID	Not changeable	0
Temperature monitoring	Specifies the temperature threshold that, if exceeded, causes a warning message to be created: <ul style="list-style-type: none"> Warning at temperature thresholds 1 and 2 Warning at temperature threshold 2 only Warning at temperature threshold 1 only No warning at temperature thresholds 	Warning at temperature thresholds 1 and 2

Table 29: System Parameters of the Rack

7.5.2 Configuring the Ethernet Interfaces

Ethernet interfaces are configured in the Detail View of the communication module. If the remote I/Os have no communication module, the Ethernet interfaces are configured in the Detail View of the processor module. Refer to the manuals of the HIMatrix controllers and remote I/Os for more details.

7.5.3 Configuring the User Program

The following user program switches and parameters can be set in the *Properties* dialog box of the user program:

Switch / Parameter	Function	Default value	Setting for safe operation
Name	Name of the user program		Arbitrary
Program ID	ID for identifying the program when displayed in SILworX, 0...4 294 967 295.	0	Application-specific
Priority	Priority of the user program: 0...31, if multitasking is used	0	Application-specific
Program's Maximum Number of CPU Cycles	Maximum number of CPU cycles that a user program cycle may encompass.	1	Application-specific
Max. Duration for Each Cycle [μs]	Maximum time in each processor module cycle for executing the user program: 1...4 294 967 295 μs. Set to 0: No limitation.	0 μs	0 μs
Classification	Classification of the user program: <i>Safety-related</i> or <i>Standard</i> (for documentation only).	Safety-related	Application-specific
Allow Online Settings	It enables changes of other user program switches during operation. It only applies if the <i>Allowed Online Settings</i> switch for the resource is set to ON!	ON	-
Autostart	Enabled type of Autostart: Cold Start, Warm Start, Off	Warm Start	Application-specific
Start Allowed	ON: The PADT may be used to start the user program.	ON	Application-specific
	OFF: The PADT may not be used to start the user program		
Test Mode Allowed	ON The test mode is permitted for the user program.	OFF	Application-specific
	OFF The test mode is not permitted for the user program.		

Switch / Parameter	Function		Default value	Setting for safe operation
Reload Allowed	ON:	User program reload is permitted	ON	Application-specific
	OFF:	User program reload is not permitted		
Local Forcing Allowed	ON:	Forcing permitted at program level	OFF	OFF is recommended
	OFF:	Forcing not permitted at program level		
Local Force Timeout Reaction	Behavior of the user program after the forcing time has expired: <ul style="list-style-type: none"> Stop Forcing Only. Stop Program. 		Stop Forcing Only.	Application-specific
Code Generation Compatibility	SILworX V4	Code generation is compatible with SILworX V4.	SILworX V4	SILworX V4
	SILworX V3	Not applicable for HIMatrix controllers!		
	SILworX V2	Code generation is compatible with SILworX V2. Not applicable/not recommended for HIMatrix M45 controllers!		

Table 30: System Parameters of the User Program

Notes specific to the *Code Generation Compatibility* Parameter:

- In a new project, SILworX selects the latest value for the *Code Generation Compatibility* parameter. This ensures that the current, enhanced features are activated and the latest hardware and operating system versions are supported. Verify that this setting is in accordance with the hardware in use. HIMatrix M45 needs the value SILworX V4 for the parameter *Minimum Configuration Version*.
- In a project converted from a previous SILworX version, the value for *Code Generation Compatibility* remains the value set in the previous version. This ensures that the configuration CRC resulting from the code generation is the same as in the previous version and the generated configuration is compatible with the operating systems in the hardware. For this reason, the value of *Code Generation Compatibility* should not be changed for converted projects.
- If a *Minimum Configuration Version* of *SILworX V4* or higher is set for a resource (see above), the *Code Generation Compatibility* parameter must be set to *SILworX V4* in every user program.

7.5.4 Configuration of the Hardware Image

Before configuring the details of inputs, outputs and communication interfaces, create the image of the M45 hardware used in the SILworX Hardware Editor. The image contains all modules in the order they are placed on the DIN rail (or should be placed). The image is created independently of the hardware installation.

The Hardware Editor only represents processor modules, communication modules, and I/O modules. Additional hardware, as the power module M-PWR 01, cannot be represented.

While planning an M45 resource, it is possible to insert modules between adjacent modules. In this case, SILworX shifts all modules located to the right of the insertion position, one position further to the right. If a module is removed, SILworX shifts all modules to its right one position to the left.

The **Insert Linebreak** function can be used to represent the system bus extension and how the modules are distributed over multiple rails. **Insert Linebreak** wraps the modules into multiple rows. The sockets for extending the system bus necessary for the real hardware are not represented.

7.5.5 Configuring the Inputs and Outputs

In the Hardware Editor, the inputs and outputs are configured by connecting global variables to the system variables for input and output channels.

To access the system variables for input and output channels

1. Display the desired resource in the Hardware Editor.
2. Double-click the required input or output module to open the corresponding detail view.
3. In the detail view, open the tab with the required channels.

The system variables for the channels appear.

7.5.5.1 Use of Digital Input**To use the value of a digital input in the user program**

1. Define a global variable of type BOOL.
2. Enter an appropriate initial value, when defining the global variable.
3. Assign the global variable to the channel value of the input.
4. In the user program, program a safety-related fault reaction using the status *Channel OK* [BOOL].

The global variable provides values to the user program.

To get additional options for programming fault reactions in the user program, assign global variables to *Data valid* and *Module OK*. Refer to the module-specific manuals for details on the parameters.

7.5.5.2 Use of Safety-Related Counter Inputs**To use the integer value**

1. Define a global variable of type UDINT.
2. Enter an appropriate initial value, when defining the global variable.
3. Assign the global variable to the integer value -> *Counter Reading*[UDINT] of the input.
4. In the user program, program a safety-related fault reaction using the status *Module OK*.

The global variable provides values to the user program.

To get additional options for programming fault reactions in the user program, assign global variables to *Data valid* and *Module OK*. Refer to the module-specific manual for further details on how to use the parameters of the counter input.

7.5.5.3 Use of Digital Output**To write a value in the user program to a digital output**

1. Define a global variable of type BOOL containing the value to be output.
2. Enter an appropriate initial value, when defining the global variable.
3. Assign the global variable the *Value* [BOOL] -> channel value of the output.
4. In the user program, program a safety-related fault reaction using the status *Channel OK* [BOOL].

The global variable provides values to the digital output.

To get additional options for programming fault reactions in the user program, assign global variables to *Data valid* and *Module OK*. Refer to the module-specific manuals for details.

7.5.6 Generating the Resource Configuration

With the following procedure, the code is generated twice and the resulting checksums (CRCs) are compared with one another.

To generate the code for the resource configuration

1. Select the resource in the structure tree.
2. Click the **Code Generation** button on the Action Bar or select **Code Generation** from the context menu.
 - ☒ The *Code Generation* <Resource Name> dialog box appears.

3. Select **CRC Comparison** from the *Code Generation <Resource Name>* dialog box (default value).
4. In the dialog box, click **OK**.
 - ☒ An additional *Code Generation <resource name>* appears, shows the progress of the two code generation processes and is closed again. The logbook contains one row informing about the code generation result and one row reporting the result of the CRC comparison.

A valid code is generated for the resource configuration.

Generating the code twice and comparing the CRCs ensures that the non-safe PC did not cause any corruption of the user program.

7.5.7 Configuring the System ID and the Connection Parameters

To configuring the system ID and the connection parameters

1. Select the resource in the structure tree.
2. Click the **Online** button on the Action Bar or select **Online** from the context menu.
 - ☒ The *System Login* dialog box appears.
3. Click **Search**.
 - ☒ The *Search per MAC* dialog box appears.
4. Enter the MAC address valid for the controller - see the label on the housing - and click **Search**.
 - ☒ In the dialog box, the values set for IP address, subnet mask and S:R:S are displayed.
5. If the values for the project are not correct, click **Change**.
 - ☒ The *Write via MAC* dialog box appears.
6. Type correct values for the connection parameters and the SRS, and enter the access data for a user account with administrator rights valid on the controller. Click **Write**.

Connection data and SRS are configured and it is now possible to log in.

For further details, refer to the SILworX first steps manual (HI 801 103 E).

7.5.8 Loading a Resource Configuration from the PADT

Before a user program can be loaded with the connection parameters (IP address, subnet mask and system ID) into the controller, the code must have been generated for the resource, and the connection parameters for PADT and resource must be valid, see Chapter 6.9.6.

To load a resource configuration from the PADT

1. Select a resource in the structure tree.
2. Click the **Online** button on the Action Bar or select **Online** from the context menu.
3. In the *System Login* dialog box, enter a user group with administrator rights or write access.
 - ☒ The Control Panel appears in the workspace and displays the controller state.
4. In the **Online** menu, select **Resource Download**.
 - ☒ The *Resource Download* dialog box appears.
5. Click **OK** to confirm the download.
 - ☒ SILworX loads the configuration into the controller.
6. Upon completion of the loading procedure, click the **Resource Cold Start** function on the **Online** menu to start the user program.
 - ☒ After the cold start, *System State* and *Program Status* enter the RUN state.

The resource configuration is loaded from the PADT.

The Start, Stop and Load functions are also available as symbols on the Symbol Bar.

7.5.9 Setting the Date and the Time

To set the controller's time and date

1. Select a resource in the structure tree.
2. Click the **Online** button on the Action Bar or select **Online** from the context menu.
3. In the *System Login* dialog box, enter a user group with administrator rights or write access.
 - ☒ The Control Panel appears in the workspace and displays the controller state.
4. In the **Online** menu, select **Start-Up -> Set Date/Time**
 - ☒ The *Set Date/Time* dialog box appears.
5. Select one of the following options:
 - **Use the PADT date and time** - to transfer the time and date displayed for the PADT to the controller.
 - **User-defined** - to transfer the date and time from the two input boxes into the controller. Make sure that the format used for date and time is correct!
6. Click **OK** to confirm the action.

The time and the date are set for the controller.

7.6 User Management in SILworX

SILworX can set up and maintain an own user management scheme for each project and controller.

7.6.1 User Management for SILworX Projects

A PADT user management scheme for administering the access to the project can be added to every SILworX project.

If no PADT user management scheme exists, any user can open and modify the project. If a user management scheme has been defined for a project, only authorized users can open the project. Only users with the corresponding rights can modify the projects. The following authorization types exist.

Type	Description
Security Administrator (Sec Adm)	Security administrators can modify the user management scheme: setting up, deleting, changing the PADT user management scheme, and the user accounts and user groups, and setting up the default user account. Additionally, they can perform all SILworX functions.
Read and Write (R/W)	All SILworX functions, except for the user management
Read only (RO)	Read-only access, i.e., the users may not change or archive the projects.

Table 24: Authorization Types for the PADT User Management Scheme

The user management scheme allocates the rights to the user groups. The user groups allocate the rights to the user accounts assigned to them.

Characteristics of user groups:

- The name must be unique within the project and must contain 1...31 characters.
- A user group is assigned an authorization type.
- A user group may be assigned an arbitrary number of user accounts.
- A project may contain up to 100 user groups.

User account properties

- The name must be unique within the project and must contain 1...31 characters.
- A user account is assigned a user group.

- A project may contain up to 1000 user accounts.
- A user account can be the project default user.

7.6.2 User Management for the Controller

The user management scheme for a controller (PES user management) is used to protect the HIMatrix controller against unauthorized access and actions. The users and their access permissions are part of the project; they are defined with SILworX and loaded into the processor module.

The user management scheme allows administrators to define and manage the access permissions for up to ten users. The access permissions are stored in the controller and remain valid after switching off the supply voltage.

Each user account is composed of name, password and access permission. Once the project has been loaded into the controller by performing a download, the user data are available for logging in. The user accounts of a controller can also be used for the corresponding remote I/Os.

Users log in to a controller using their user name and password.

Creating user accounts is not required, but is a contribution to a safe operation. If a user management scheme is defined for a resource, it must contain at least one user with administrator rights.

Default User

The factory user settings apply if no user accounts were set up for a resource. The factory settings also apply after starting a controller with the reset pushbutton activated.

Factory settings

Number of users:	1
User ID:	Administrator
Password:	None
Access permission:	Administrator



Note that the default settings cannot be maintained if new user accounts are defined.

Parameters for User Accounts

To set up new user accounts, the following parameters must be set:

Parameter	Description
User Name	User name or ID used to log in to a controller. The user name must not contain more than 32 characters (recommended: a maximum of 16 characters) and may only be composed of letters (A ... Z, a ... z), numbers (0 ... 9) and the special characters underscore «_» and hyphen «-». The user name is case sensitive.
Password	Password assigned to a user name required for the login. The password must not contain more than 32 characters and may only be composed of letters (A...Z, a...z), numbers (0...9) and the special characters underscore «_» and hyphen «-» The password is case sensitive.
Confirm Password	Repeat the password to confirm the entry.
Access Mode	The access modes define the permission associated with the user. The following access types are available: <ul style="list-style-type: none"> ▪ Read: Users may only read information but they cannot modify the controller. ▪ Read + Operator: Similar to <i>Read</i>, but users may also: Perform a download to load and start user programs Reset cycle time and fault or error statistics Set the system time, force, restart and reset modules Start system operation for processor modules. ▪ Read + Write: Similar to Read + Operator, but users may also: Load programs into the controller Test programs ▪ Administrator: Similar to Read + Write, but users may also: Load operating systems. Modify the main enable switch setting Change the SRS Change the IP settings At least one user must have administrator rights, otherwise the controller settings are not accepted. The administrator can revoke the user's permission to access a controller by deleting the user name from the list.

Table 25: Parameters for User Accounts in the PES User Management Scheme

7.6.3 Setting up User Accounts

A user with administrator rights can access to all user accounts.

Observe the following points when setting up user accounts:

- Make sure that at least one user account is assigned with administrator rights. Define a password for the user account with administrator rights.
- In SILworX, use *Verification* to check the created user account.
- The new user accounts are valid once the code has been generated and a download has been performed to load the project into the controller. All the user accounts previously saved, e.g., the default settings, are no longer valid.

7.7 Configuration with SILworX

Depending on the application, the following elements must be configured:

- Ethernet/safeethernet.
- Standard Protocols

Refer to the SILworX communication manual (HI 801 101 E) for more information on how to configure the protocols.

7.7.1 Configuring the Ethernet Interfaces

Ethernet interfaces are configured in the Detail View of the communication module.

For HIMatrix systems, set the *Speed Mode [Mbit/s]* and *Flow Control Mode* to **Autoneg** in the Ethernet switch settings.

The parameters *ARP Aging Time*, *MAC Learning*, *IP Forwarding*, *Speed [Mbit/s]* and *Flow Control* are explained in details in the SILworX online help.

i

Replacement of one controller with identical IP address:

If a controller has its *ARP Aging Time* set to 5 minutes and its *MAC Learning* set to **Conservative**, its communication partner does not adopt the new MAC address until a period of 5 to 10 minutes after the controller is replaced. During this time period, no communication is possible with the replaced controller.

The port settings of the integrated Ethernet switch on a HIMatrix resource can be configured individually. In the **Ethernet Switch** tab, an entry can be created for each switch port.

Name	Explanation
Port	Port number as printed on the housing; per port, only one configuration may exist. Range of values: 1...n, depending on the resource
Speed [Mbit/s]	10: Data rate 10 Mbit/s 100: Data rate 100 Mbit/s Autoneg: Automatic baud rate setting Standard: Autoneg
Flow Control	Full duplex: Simultaneous communication in both directions Half duplex: Communication in both directions, but only one direction at a time Autoneg: Automatic communication control Standard: Autoneg
Autoneg also with fixed values	The <i>Advertising</i> function (forwarding the Speed and Flow Control properties) is also performed if <i>Speed</i> and <i>Flow Control</i> have fixed values. This allows other devices with ports set to Autoneg to recognize the HIMatrix ports' settings.
Limit	Limit the inbound multicast and/or broadcast packets. Off: No limitation Broadcast: Limit broadcast packets (128 kbit/s) Multicast and Broadcast: Limit multicast and broadcast packets (1024 kbit/s) Default: Broadcast

Table 26: Parameters of the Port Configuration

To modify and enter these parameters in the communication system's configuration, double-click each table cell. The parameters become operative for HIMatrix communication, once they have been re-compiled with the user program and transferred to the controller.

The properties of the communication system and Ethernet switch can also be changed online using the Control Panel. These settings become operative immediately, but they are not adopted by the user program.

Refer to the SILworX communication manual (HI 801 101 E) for more details about configuring **safeethernet**.

7.8 Configuring Alarms and Events

To define the events

1. Define a global variable for each event. Generally use global variables that have already been defined for the program.
2. Below the resource, create a new **Alarms&Events** branch, if not existing.
3. Define events in the A&E Editor.
 - Drag global variables onto the event window for Boolean or scalar events.
 - Define the details of the events, see the following tables.

The events are defined.

For further information, refer to the SILworX online help.

The parameters of the Boolean events must be entered in a table with the following columns:

Column	Description	Range of values
Name	Name for the event definition; it must be unique within the resource.	Text, max. 32 characters
Global Variable	Name of the assigned global variable (added using drag&drop)	
Data type	Data type of the global variable; it cannot be modified.	BOOL
Event Source	CPU event The processor module creates the timestamp. It creates all the events in each of its cycles. <hr/> Auto event As CPU event <hr/> Default value: Auto Event	CPU, Auto
Alarm when FALSE	Activated If the global variable value changes from TRUE to FALSE, an event is triggered. <hr/> Deactivated If the global variable value changes from FALSE to TRUE, an event is triggered. <hr/> Default value: Deactivated	Checkbox activated, deactivated
Alarm Text	Text specifying the alarm state	Text
Alarm priority	Priority of the alarm state Default value: 500	0...1000
Alarm Acknowledgment Successful	Activated The alarm state must be confirmed by the user (acknowledgement) <hr/> Deactivated The alarm state may not be confirmed by the user <hr/> Default value: Deactivated	Checkbox activated, deactivated
Return to Normal Text	Text specifying the alarm state	Text
Return to Normal Severity	Priority of the normal state Default value: 500	0...1000
Return to Normal Ack Required	The normal state must be confirmed by the user (acknowledgement) <hr/> Default value: Deactivated	Checkbox activated, deactivated

Table 27: Parameters for Boolean Events

The parameters of the scalar events must be entered in a table with the following columns:

Column	Description	Range of values
Name	Name for the event definition; it must be unique within the resource.	Text, max. 32 characters
Global Variable	Name of the assigned global variable (added using drag&drop)	
Data type	Data type of the global variable; it cannot be modified.	Depending on the global variable type
Event Source	CPU event The processor module creates the timestamp. It creates all the events in each of its cycles.	CPU, Auto
	Auto event As CPU event	
	Default value: Auto Event	
HH Alarm Text	Text specifying the alarm state of the highest limit (HH).	Text
HH Alarm Value	Highest limit (HH) triggering an event. Condition: (HH Alarm Value - Hysteresis) > H Alarm Value or HH Alarm Value = H Alarm Value	Depending on the global variable type
HH Alarm Priority	Priority of the highest limit (HH); default value: 500	0...1000
HH Alarm Acknowledgment Required	Activated The user must confirm that the highest limit (HH) has been exceeded (acknowledgment).	Checkbox activated, deactivated
	Deactivated The user may not confirm that the highest limit (HH) has been exceeded.	
	Default value: Deactivated	
H Alarm Text	Text specifying the alarm state of the high limit (H).	Text
H Alarm Value	High limit (H) triggering an event. Condition: (H Alarm Value - Hysteresis) > (L Alarm Value + Hysteresis) or H Alarm Value = L Alarm Value	Depending on the global variable type
H Alarm Priority	Priority of the high limit (H); default value: 500	0...1000
H Alarm Acknowledgment Required	Activated The user must confirm that the high limit (H) has been exceeded (acknowledgment).	Checkbox activated, deactivated
	Deactivated The user may not confirm that the high limit (H) has been exceeded.	
	Default value: Deactivated	
Return to Normal Text	Text specifying the normal state	Text
Return to Normal Severity	Priority of the normal state; default value: 500	0...1000
Return to Normal Ack Required	The normal state must be confirmed by the user (acknowledgment); default value: Deactivated	Checkbox activated, deactivated
L Alarm Text	Text specifying the alarm state of the low limit (L).	Text
L Alarm Value	Low limit (L) triggering an event. Condition: (L Alarm Value + Hysteresis) < (H Alarm Value - Hysteresis) or L Alarm Value = H Alarm Value	Depending on the global variable type
L Alarm Priority	Priority of low limit (L); default value: 500	0...1000
L Alarm Acknowledgment Required	Activated The user must confirm that the low limit (L) has been exceeded (acknowledgment).	Checkbox activated, deactivated
	Deactivated The user may not confirm that the low limit (L) has been exceeded.	
	Default value: Deactivated	
LL Alarm Text	Text specifying the alarm state of the lowest limit (LL).	Text
LL Alarm Value	Lowest limit (LL) triggering an event. Condition: (LL Alarm Value + Hysteresis) < (L Alarm Value) or LL Alarm Value = L Alarm Value	Depending on the global variable type
LL Alarm Priority	Priority of the lowest limit (LL); default value: 500	0...1000

Column	Description	Range of values
LL Alarm Acknowledgment Required	Activated The user must confirm that the lowest limit (LL) has been exceeded (acknowledgment).	Checkbox activated, deactivated
	Deactivated The user may not confirm that the lowest limit (LL) has been exceeded.	
	Default value: Deactivated	
Alarm Hysteresis	The hysteresis avoids that many events are continuously created when the process value often oscillate around a limit.	Depending on the global variable type

Table 28: Parameters for Scalar Events

i

Faulty event recording due to improper parameter settings possible!

Setting the parameters *L Alarm Value* and *H Alarm Value* to the same value can cause an unexpected behavior of the event recording since no normal range exists in such a case. For this reason, make sure that *L Alarm Value* and *H Alarm Value* are set to different values.

7.9 Handling the User Program

The PADT can be used to influence the program's function within the controller as follows:

7.9.1 Setting the Parameters and the Switches

During the user program's configuration, the parameters and the switches are set to offline and are loaded into the controller with the code-generated program. The parameters and the switches can also be set when the controller is in the STOP or RUN state, provided that the *main enable* switch has been activated. Only the elements in the NVRAM can be modified, all remaining elements are activated during the load procedure.

7.9.2 Starting the Program from STOP/VALID CONFIGURATION

Starting the program has the same effect as switching the controller's mode of operation from STOP/VALID CONFIGURATION to RUN; the program enters the RUN state too. The program enters the test mode if the test mode is active while starting the program. In accordance with IEC 61131, a cold or a warm start can also be performed in addition the starting in test mode.

i

The program can only be started if the *Start/Restart Allowed* switch was activated.

7.9.3 Restarting the Program after Errors

If the program enters the STOP/INVALID CONFIGURATION state, e.g., due to unauthorized access to operating system areas, it restarts. If the user program enters the STOP/INVALID CONFIGURATION state again within roughly one minute since the restart, it remains in this state. If this is the case, it can be restarted using the Control Panel's start button. After a restart, the operating system checks the entire program.

If automatic restarting is not desired for an application, the system parameter *Autostart* must be set to OFF.

7.9.4 Stopping the Program

If the user program is stopped, the mode switches from RUN to STOP/VALID CONFIGURATION.

7.9.5 Program Test Mode

The test mode is started from within the Control Panel, selecting **Test Mode** -> **Test Mode with Hot Start** (...Cold Start, ...Warm Start). Each Single Cycle command is used to activate a single cycle (one complete logic cycle).

Behavior of variable/signal values in test mode

The selection of cold, warm or hot start determines which variable values are used during the first cycle in test mode.

Cold start: all variables/signals are set to their initial values.

Warm start: retain signals retain their value, the remaining signals are set to their initial value.

Hot start: All variables/signals retain their current values.

Finally, the Cycle Step command can be used to start the user program in single step mode. All current values are retained for the following cycle (frozen state).

WARNING



Property damage or physical injury possible due to actuators in unsafe state!
Do not use the test mode function during safety-related operation!

7.9.6 Online Test

The *Online Test* function is used to add online test fields (OLT fields) to the program logic, to display and to force signals/variables while the controller is operating.

If the *Online Test Allowed* switch is on, the values of signals/variables can be manually entered in the corresponding OLT fields and thus forced. However, the forced values only apply until they are overwritten by the program logic.

If the *Online Test Allowed* switch is off, the values of the signals/variables in OLT fields are only displayed and cannot be modified.

For more information on how to use OLT fields, enter `OLT field` in the online help of the programming tool.

8 Operation

This chapter describes how to handle and diagnose the controller during its operation.

8.1 Handling

The controller needs not be handled during its normal operation. Only if problems arise, an intervention with the PADT may be required.

8.2 Diagnosis

A first, rough diagnosis can be performed via the light-emitting diodes (LEDs). The diagnostic history provides a more detailed analysis of the operating or error state. It can be displayed using the programming tool.

8.2.1 Light-Emitting Diode Indicators

The light emitting diodes (LEDs) indicate the module state. Function and meaning of the LEDs depend on the processor system's operating system currently in use. Refer to the module-specific manuals for details.

The function and meaning of the fieldbus LEDs are described in the SILworX communication manual (HI 801 101 E').

8.2.2 Diagnostic History

The diagnostic history records the various states of the processor module and communication system and stores them in a non-volatile memory. Both systems include a short term and a long term diagnosis. The number of entries differs for hardware layout and the operating system versions:

	CPU
Number of entries in the long term diagnosis	700
Number of entries in the short term diagnosis	700

Table 29: Maximum Number of Entries in the Diagnostic History for M-CPU 01

The long-term diagnosis of the processor system includes the following events:

- Reboot
- Changed mode of operation (INIT, RUN, STOP/VALID CONFIGURATION, STOP/INVALID CONFIGURATION),
- Changed program mode of operation (START, RUN, ERROR, TEST MODE),
- Configuration load or deletion
- Configuration and reset of switches
- Processor system failures
- Operating system download
- Forcing (setting and resetting the force switch is allowed)
- I/O module diagnostics
- Power supply and temperature diagnostics

The long-term diagnosis of the communication system includes the following events:

- Reboot of the communication system
- Changed mode of operation (INIT, RUN, STOP/VALID CONFIGURATION, STOP/INVALID CONFIGURATION),
- User log-in
- Operating system load

If the memory for the long term diagnosis is full, all data older than three days is deleted allowing new entries to be stored. If no data is older than three days, the new entries cannot be stored and get lost. A message in the long-term diagnosis warns that it was not possible to store the data.

The short-term diagnosis of the processor system includes the following events:

- Processor system diagnostics (setting the force switches and force values)
- User program diagnostics (cyclic operation)
- Communication diagnostics
- Power supply and temperature diagnostics
- I/O module diagnostics

The short-term diagnosis of the communication system includes the following events:

- **safeethernet**-related events
- Start / stop while writing to the flash memory
- Faults that can occur while loading a configuration from the flash memory
- Unsuccessful time synchronization between the communication system and the processor system

Parameter errors associated with the inputs or outputs might be not detected during the code generation. If a parameter error occurs, the message INVALID CONFIGURATION with the error source and code are displayed in the feedback box. This message helps analyzing errors due to an incorrect configuration of the inputs or outputs.

If the memory for the short-term diagnosis is full, the oldest entries are deleted to allow new data to be saved. No message appears warning that old entries are being deleted.

Diagnostic data recording is not safety-related. To read the data recorded in chronological order, use the programming tool. Reading does not delete the data stored in the controller. The programming tool is capable of storing the contents of the diagnostic window.

8.2.3 Diagnosis in SILworX

The online view in the SILworX Hardware Editor is used to access to the diagnostic panel.

To open the diagnostic panel

1. Select the **Hardware** element within the desired resource.
 2. Click **Online** on the context menu or on the Action Bar.
 - ☒ The system log-in window appears.
 3. In the system log-in window, select or enter the following information:
 - IP address of the controller
 - User and password
 - ☒ The Hardware Editor's online view appears.
 4. In the online view, select the required module, usually the processor or the communication module.
 5. Select **Diagnosis** from the context menu or the **Online** menu.
- The diagnostic panel for the required module appears.

If a controller is operating, messages about the state of the processor system, communication system and I/O modules are displayed at specific, user-defined time intervals.

9 Maintenance

The maintenance of HIMatrix M45 systems is restricted to the following:

- Removing disturbances
- Loading operating systems and user programs

9.1 Interferences

Disturbances in the M-CPU 01 processor system mostly result in the complete shut-down of the controller and are indicated via the *ERR* LED on the M-CPU 01 module.

For possible reasons for a lit *ERR* LED, refer to the M-CPU 01 module-specific manual (HI 800 655 E).

To turn off the indicators, start the **Reboot Resource** command located in the **Extra** menu associated with the Control Panel. The controller is booted and re-started.

The system automatically detects disturbances in the input and output channels during operation and displays them via the *FAULT* LED on the front plate of the corresponding module.

Even if the controller is stopped, the PADT diagnostic history can be used to read out detected faults, provided that communication was not disturbed as well.

Prior to replacing a module, check whether an external line disturbance exists and whether the corresponding sensor or actuator is ok.

9.2 Loading Operating Systems

The processor and communication modules have different operating systems that are stored in the rewritable flash memories and can be replaced, if necessary.

NOTE



Disruption of the safety-related operation!

The controller must be in the STOP state to enable the programming tool to load new operating systems.

During this time period, the operator must ensure the plant safety, e.g., by taking organizational measures.

1

- The programming tool prevents controllers from loading the operating systems in the RUN state and reports this as such.
- Interruption or incorrect termination of the loading process causes the controller to be no longer functional. It is possible, however, to reload the operating system.

The operating system for the processor system (CPU operating system) must be loaded before that for the communication system (COM operating system).

Requirements for loading operating systems:

- The new operating system must be stored in a directory that can be accessed by the programming tool.
- The PADT is connected to an Ethernet interface of the M-CPU 01 processor module.

To load the new operating system

1. Set the controller to the STOP state, if it has not already been done.
2. Open the online view of the hardware and log in to the controller with administrator rights.
3. Right-click the module, processor or communication module.
4. The context menu appears. Click **Maintenance/Service->Load Module Operating System**.

5. In the dialog box *Load Module Operating System*, select the type of the operating system to be loaded.
6. A dialog box for selecting a file appears. Select the file with the operating system that should be loaded and click **Open**.

SILworX loads the new operating system into the controller.

After loading, the loaded operating system version must be verified using the PADT.

9.3 Repairing Modules and Sockets

The operator is not authorized to repair modules and sockets of the HIMatrix M45 system. Defective HIMatrix M45 modules must be returned to HIMA for repair after being tested by the operator with a brief description of the fault.

Equipment with a safety certificate is safety-relevant. The validity of the certificate expires if unauthorized repair is performed to safety-related devices of the HIMatrix system.

The warranty is void and no legal responsibility is taken for unauthorized repair.

10 Decommissioning

Remove the supply voltage to decommission the modular controller. Afterwards it is possible to pull out the pluggable screw terminal connector blocks for inputs and outputs and the Ethernet cables, and to remove the module.

11 Transport

To avoid mechanical damage, HIMatrix components must be transported in packaging.

Always store HIMatrix components in their original product packaging. This packaging also provides protection against electrostatic discharge. Note that the product packaging alone is not suitable for transport.

12 Disposal

Industrial customers are responsible for correctly disposing of decommissioned HIMatrix hardware. Upon request, a disposal agreement can be arranged with HIMA.

All materials must be disposed of in an ecologically sound manner.



Appendix

Glossary

Term	Description
ARP	Address resolution protocol: Network protocol for assigning the network addresses to hardware addresses
AI	Analog input
AO	Analog output
COM	Communication module
CRC	Cyclic redundancy check
DI	Digital input
DO	Digital output
ELOP II Factory	Programming tool for HIMatrix systems
EMC	Electromagnetic compatibility
EN	European norm
ESD	Electrostatic discharge
FB	Fieldbus
FBD	Function block diagrams
FTT	Fault tolerance time
ICMP	Internet control message protocol: Network protocol for status or error messages
IEC	International electrotechnical commission
MAC Address	Media access control address: Hardware address of one network connection
PADT	Programming and debugging tool (in accordance with IEC 61131-3), PC with SILworX or ELOP II Factory
PE	Protective earth
PELV	Protective extra low voltage
PES	Programmable electronic system
R	Read: The system variable or signal provides value, e.g., to the user program
Rack ID	Base plate identification (number)
Interference-free	Supposing that two input circuits are connected to the same source (e.g., a transmitter). An input circuit is termed <i>interference-free</i> if it does not distort the signals of the other input circuit.
R/W	Read/Write (column title for system variable/signal type)
SELV	Safety extra low voltage
SFF	Safe failure fraction, portion of faults that can be safely controlled
SIL	Safety integrity level (in accordance with IEC 61508)
SILworX	Programming tool for HIMatrix systems
SNTP	Simple network time protocol (RFC 1769)
SRS	System.Rack.Slot addressing of a module
SW	Software
TMO	Timeout
W	Write: System variable/signal is provided with value, e.g., from the user program
r_{pp}	Peak-to-peak value of a total AC component
Watchdog (WD)	Time monitoring for modules or programs. If the watchdog time is exceeded, the module or program enters the STOP_ERROR state.
WDT	Watchdog time

Index of Figures

Figure 1:	HIMatrix M45 System	15
Figure 2:	Line Control	17
Figure 3:	CPU Cycle Sequence with Multitasking	30
Figure 4:	Multitasking Mode 1	33
Figure 5:	Multitasking Mode 2	34
Figure 6:	Multitasking Mode 3	35
Figure 7:	Mounting Distance	42
Figure 8:	Example of Socket Mounting	44
Figure 9:	Example of Mounting and Removing the Module	45

Index of Tables

Table 1:	Additional Relevant Documents	7
Table 2:	Environmental Requirements	10
Table 3:	Standards for EMC, Climatic and Environmental Requirements	11
Table 4:	General Requirements	11
Table 5:	Climatic Requirements	11
Table 6:	Mechanical Tests	12
Table 7:	Interference Immunity Tests	12
Table 8:	Noise Emission Tests	12
Table 9:	Verification of the DC Supply Characteristics	13
Table 10:	Supply Voltage	18
Table 11:	Operating Voltage Monitoring	18
Table 12:	Temperature Monitoring	19
Table 13:	Specifications HIMatrix M45	21
Table 14:	Fieldbus Submodule	25
Table 15:	Functions of the Processor Operating System	26
Table 16:	Modes of Operation for the Processor Module	28
Table 17:	User Program Modes of Operation	29
Table 18:	Parameters Configurable for Multitasking	31
Table 19:	Reloading after Changes	37
Table 20:	Installation Type	40
Table 21:	Connectors for Operating Voltage	47
Table 22:	Resource System Parameters	49
Table 23:	Effect of Target Cycle Time Mode	50
Table 24:	Authorization Types for the PADT User Management Scheme	58
Table 25:	Parameters for User Accounts in the PES User Management Scheme	60
Table 26:	Parameters of the Port Configuration	61
Table 27:	Parameters for Boolean Events	62
Table 28:	Parameters for Scalar Events	64
Table 29:	Maximum Number of Entries in the Diagnostic History for M-CPU 01	66

Declaration of conformity

For the HIMatrix M45 system, declarations of conformity exist for the following directives:

- EMC Directive
- Low Voltage Directive
- EX Directive

The current declarations of conformity are available on the HIMA website www.hima.com.

Index

alarm (see event)	19	restrictions	39
communication		forcing	38
configuration of Ethernet interfaces	61	Hardware Editor	50
communication time slice		monitoring the temperature state	19
maximum	23	noxious gases	14
counter inputs		online test	65
use	56	operating conditions	
de-energize-to-trip principle	10	ESD protection	13
diagnostic history	66	operating system	26
diagnostic indicators		loading	69
SILworX	67	PADT user management scheme	58
digital inputs		PES user management scheme	59
use	56	processor module	
digital outputs		operating states	27
use	56	processor system	27
Ereignis		safeethernet	22
Definition - F*03	62	temperature monitoring	19
Ethernet	22	test conditions	10
switch	22	climatic	11
event		EMC	12
creation - F*03	20	mechanical	12
in general	19	power supply	13
recording – F*03	21	user account	58
faults		user group	58
internal	27	user program	29
permanent in connection with I/Os	26	restart after errors	64
reaction to	26	stop	64
temporary in connection with I/Os	27	test mode	65
forcing	38	voltage supply monitoring	18



SAFETY
NONSTOP

HIMA Paul Hildebrandt GmbH

P.O. Box 1261

68777 Brühl, Germany

Phone: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com Internet: www.hima.com

(1404)

HI 800 651 E © by HIMA Paul Hildebrandt GmbH