



Manual

---

# HIMax<sup>®</sup>

---

## X-DI 32 52

### Digital Input Module

---



All of the HIMA products mentioned in this manual are trademark protected. This also applies for other manufacturers and their products which are mentioned unless stated otherwise.

HIQuad®, HIQuad®X, HIMax®, HIMatrix®, SILworX®, XMR®, HICore® and FlexSILon® are registered trademarks of HIMA Paul Hildebrandt GmbH.

All of the technical specifications and information in this manual were prepared with great care and effective control measures were employed for their compilation. For questions, please contact HIMA directly. HIMA appreciates any suggestion on which information should be included in the manual.

Equipment subject to change without notice. HIMA also reserves the right to modify the written material without prior notice.

All the current manuals can be obtained upon request by sending an e-mail to: [documentation@hima.com](mailto:documentation@hima.com).

© Copyright 2019, HIMA Paul Hildebrandt GmbH

All rights reserved.

## Contact

HIMA Paul Hildebrandt GmbH

P.O. Box 1261

68777 Brühl

Phone: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: [info@hima.com](mailto:info@hima.com)

| Document designation               | Description   |
|------------------------------------|---|
| HI 801 174 D, Rev. 11.00 (1942)    | German original document                            |
| HI 801 175 E, Rev. 11.00.00 (1948) | English translation of the German original document |

## Table of Contents

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>Introduction</b>   | <b>5</b>  |
| 1.1      | Structure and Use of This Manual                              | 5         |
| 1.2      | Target Audience   | 5         |
| 1.3      | Writing Conventions   | 6         |
| 1.3.1    | Safety Notices  | 6         |
| 1.3.2    | Operating Tips  | 7         |
| <b>2</b> | <b>Safety</b>   | <b>8</b>  |
| 2.1      | Intended Use  | 8         |
| 2.1.1    | Environmental Requirements                                    | 8         |
| 2.1.2    | ESD Protective Measures                                       | 8         |
| 2.2      | Residual Risk   | 8         |
| 2.3      | Safety Precautions  | 8         |
| <b>3</b> | <b>Product Description</b>                                    | <b>9</b>  |
| 3.1      | Safety Function   | 9         |
| 3.1.1    | Response in the Event of a Fault                              | 9         |
| 3.2      | Scope of Delivery   | 9         |
| 3.3      | Type Label  | 10        |
| 3.4      | Structure   | 11        |
| 3.4.1    | Block Diagram   | 11        |
| 3.4.2    | Indicators  | 12        |
| 3.4.3    | Module Status Indicators                                      | 14        |
| 3.4.4    | System Bus Indicators   | 15        |
| 3.4.5    | I/O Indicators  | 15        |
| 3.5      | Product Data  | 16        |
| 3.6      | Connector Boards  | 18        |
| 3.6.1    | Mechanical Coding of Connector Boards                         | 18        |
| 3.6.2    | Coding of X-CB 005 5x Connector Boards                        | 19        |
| 3.6.3    | Connector Boards with Screw Terminals                         | 20        |
| 3.6.4    | Terminal Assignment for Connector Boards with Screw Terminals | 21        |
| 3.6.5    | Connector Boards with Cable Plug                              | 22        |
| 3.6.6    | Pin Assignment for Connector Boards with Cable Plug           | 23        |
| 3.6.7    | Mono Connector Board Redundancy using 2 Base Plates           | 24        |
| 3.6.8    | Pin Assignment for X-CB 005 55                                | 25        |
| 3.7      | System Cables   | 26        |
| 3.7.1    | System Cable X-CA 002   | 26        |
| 3.7.2    | System Cable X-CA 009   | 27        |
| 3.7.3    | Cable Plug Coding   | 27        |
| <b>4</b> | <b>Start-Up</b>   | <b>28</b> |
| 4.1      | Mounting  | 28        |
| 4.1.1    | Wiring Unused Inputs  | 28        |
| 4.2      | Mounting and Removing the Module                              | 29        |
| 4.2.1    | Mounting a Connector Board                                    | 29        |
| 4.2.2    | Mounting and Removing a Module                                | 31        |
| 4.3      | Configuring the Module in SILworX                             | 33        |

|            |  |           |
|------------|--|-----------|
| 4.3.1      | The <b>Module</b> Tab                                    | 34        |
| 4.3.2      | The <b>I/O Submodule DI 32_52</b> Tab                    | 35        |
| 4.3.3      | The <b>I/O Submodule DI32_52: Channels</b> Tab           | 37        |
| 4.3.4      | Description of <i>Submodule Status [DWORD]</i>           | 38        |
| 4.3.5      | Description of <i>Diagnostic Status [DWORD]</i>          | 39        |
| <b>4.4</b> | <b>Connection Variants</b>                               | <b>40</b> |
| 4.4.1      | Wiring with Proximity Switch or Wired Mechanical Contact | 40        |
| 4.4.2      | Wiring Transmitters via Field Termination Assembly       | 42        |
| 4.4.3      | Redundant Connection via 2 Base Plates                   | 43        |
| <b>5</b>   | <b>Operation</b>   | <b>44</b> |
| 5.1        | Handling   | 44        |
| 5.2        | Diagnostics  | 44        |
| <b>6</b>   | <b>Maintenance</b>                                       | <b>45</b> |
| 6.1        | Maintenance Measures                                     | 45        |
| <b>7</b>   | <b>Decommissioning</b>                                   | <b>46</b> |
| <b>8</b>   | <b>Transport</b>   | <b>47</b> |
| <b>9</b>   | <b>Disposal</b>  | <b>48</b> |
|            | <b>Appendix</b>  | <b>49</b> |
|            | Glossary   | 49        |
|            | Index of Figures   | 50        |
|            | Index of Tables  | 51        |
|            | Index  | 52        |

# 1 Introduction

This manual describes the technical characteristics of the module and its use. It provides information on how to install, start up and configure the module in SILworX.

## 1.1 Structure and Use of This Manual

The content of this manual is part of the hardware description of the HIMax programmable electronic system.

This manual contains the following main chapters:

- Introduction
- Safety
- Product description
- Start-up
- Operation
- Maintenance
- Decommissioning
- Transport
- Disposal

Additionally, the following documents must be taken into account:

| Document                   | Content   | Document no. |
|----------------------------|---|--------------|
| HIMax system manual        | Hardware description of the HIMax system                                  | HI 801 001 E |
| HIMax safety manual        | Safety functions of the HIMax system                                      | HI 801 003 E |
| HIMax maintenance manual   | Description of significant operational and maintenance actions.           | HI 801 171 E |
| Communication manual       | Description of safeethernet communication and of the available protocols. | HI 801 101 E |
| Automation security manual | Description of automation security aspects related to the HIMA systems.   | HI 801 373 E |
| SILworX first steps manual | Introduction to SILworX   | HI 801 103 E |
| SILworX online help (OLH)  | Instructions on how to use SILworX  | ---          |

Table 1: Additional Applicable Manuals

The current manuals can be obtained upon request by sending an e-mail to: [documentation@hima.com](mailto:documentation@hima.com). Registered customers can download the product documentation from the HIMA Extranet.

## 1.2 Target Audience

This document is aimed at the planners, design engineers, programmers and the persons authorized to start up, operate and maintain the automation systems. Specialized knowledge of safety-related automation systems is required.

## 1.3 Writing Conventions

To ensure improved readability and comprehensibility, the following writing conventions are used in this document:

|                      |  |
|----------------------|--|
| <b>Bold</b>          | To highlight important parts.<br>Names of buttons, menu functions and tabs that can be clicked and used in the programming tool.   |
| <i>Italics</i>       | Parameters and system variables, references.   |
| <code>Courier</code> | Literal user inputs.   |
| <b>RUN</b>           | Operating states are designated by capitals.   |
| Chapter 1.2.3        | Cross-references are hyperlinks even if they are not specially marked.<br>In the electronic document (PDF): When the mouse pointer hovers over a hyperlink, it changes its shape. Click the hyperlink to jump to the corresponding position. |

Safety notices and operating tips are specially marked.

### 1.3.1 Safety Notices

Safety notices must be strictly observed to ensure the lowest possible risk.

The safety notices are represented as described below.

- Signal word: warning, caution, notice.
- Type and source of risk.
- Consequences arising from non-observance.
- Risk prevention.

The signal words have the following meanings:

- Warning indicates hazardous situations which, if not avoided, could result in death or serious injury.
- Caution indicates hazardous situation which, if not avoided, could result in minor or moderate injury.
- Notice indicates a hazardous situation which, if not avoided, could result in property damage.

#### **SIGNAL WORD**



**Type and source of risk!**  
**Consequences arising from non-observance.**  
**Risk prevention.**

---

#### **NOTICE**



**Type and source of damage!**  
**Damage prevention.**

---

1.3.2      Operating Tips

Additional information is structured as presented in the following example:

---

**i**      The text giving additional information is located here.

---

Useful tips and tricks appear as follows:

---

**TIP**      The tip text is located here.

---

## 2 Safety

All safety information, notes and instructions specified in this document must be strictly observed. The product may only be used if all guidelines and safety instructions are adhered to.

The product is operated with SELV or PELV. No imminent risk results from the product itself. Use in the Ex zone is only permitted if additional measures are taken.

### 2.1 Intended Use

HIMax components are designed for assembling safety-related controller systems.

When using the components in the HIMax system, comply with the following general requirements.

#### 2.1.1 Environmental Requirements

All the environmental requirements specified in this manual must be observed when operating the HIMax system. The environmental requirements are listed in the product data.

#### 2.1.2 ESD Protective Measures

Only personnel with knowledge of ESD protective measures may modify or extend the system or replace components.

### NOTICE



#### Damage to the HIMax system due to electrostatic discharge!

- When performing the work, make sure that the workspace is free of static, and wear a grounding strap.
- If not used, ensure that the components are protected from electrostatic discharge, e.g., by storing them in their packaging.

### 2.2 Residual Risk

No imminent risk results from a HIMA system itself.

Residual risk may result from:

- Faults related to engineering.
- Faults in the user program.
- Faults related to the wiring.

### 2.3 Safety Precautions

Observe all local safety requirements and use the protective equipment required on site.



### 3 Product Description

The X-DI 32 52 is a digital NonSIL input module and it is intended for use in the programmable electronic system (PES) HIMax.

The module is used to evaluate up to 32 proximity switches in accordance with EN 60947-5-6 (NAMUR) or wired contacts.

The module can be inserted into any of the base plate slots with the exception of the slots reserved for system bus modules. Refer to the system manual (HI 801 001 E) for details.

It can be operated with safety-related modules and other NonSIL modules within one base plate. Safety-related and NonSIL modules may not be wired redundantly.

The module is interference-free. In particular with respect to EMC, electrical safety, communication to the X-SB and X-CPU modules, and the user program.

Module and connector boards are mechanically coded, see Chapter 3.6. Coding prevents installation of unsuitable I/O modules.

Refer to the HIMax safety manual (HI 801 003 E) for further information on the standards used to test and certify the modules and the HIMax system.

The certificates and the EU type test certificate are available on the HIMA website.

#### 3.1 Safety Function

The module does not perform any safety-related functions.

The module evaluates the input signals of proximity switches and mechanical contacts and monitors the proximity switch and mechanical contact circuit for open-circuits and short-circuits.

The parameters and status for this module must not be used for safety functions.

##### 3.1.1 Response in the Event of a Fault

If a fault occurs, the assigned input variables transmit the initial value (default value = 0) to the user program.

The initial values must be set to 0 to ensure that the input variables transmit the value 0 to the user program if a fault occurs. If the raw value is evaluated instead of the process value, users must program the monitoring function and the value in the event of faults from within the user program.

The module activates the *Error* LED on the front plate.

#### 3.2 Scope of Delivery

To operate, the module must be installed on a matching connector board. If a field termination assembly (FTA) is used, a system cable is required to connect the connector board to the FTA. Connector boards, system cables and FTAs are not included within the scope of delivery.

The connector boards are described in Chapter 3.7, the system cables are described in Chapter 3.8. The FTAs are described in separate manuals.

### 3.3 Type Label

The type label specifies the following important details:

- Product name
- Mark of conformity
- Bar code (2D or 1D code)
- Part number (Part-No.)
- Hardware revision index (HW-Rev.)
- Operating system revision index (OS-Rev.)
- Supply voltage (Power)
- Ex specifications (if applicable)
- Production year (Prod-Year:)



Figure 1: Sample Type Label

### 3.4 Structure

The module has 32 digital inputs. Each channel measures the input signals through an internal measuring facility.

4 short-circuit-proof, current limited supplies feed 8 supply outputs each. One supply output is assigned to each input.

The 32 inputs can be used to evaluate the values measured for the proximity switches or wired contacts.


The switching thresholds for generating digital signals can be set in SILworX.

The processor system within the I/O module controls and monitors the I/O level. The data and states of the I/O module are provided to the processor modules via the redundant system bus. The system bus has a redundant structure for reasons of availability. Redundancy is only ensured if both system bus modules are inserted in the base plates and configured in SILworX.

The module is equipped with LEDs to indicate the status of the digital inputs, see Chapter 3.4.2.

#### 3.4.1 Block Diagram

The following block diagram illustrates the structure of the module.



**1** Field level: Proximity switch and mechanical contact

**2** Interface

**3** Processor system

**4** System buses

Figure 2: Block Diagram

3.4.2 Indicators

The following figure shows the front view of the module with the LEDs.




Figure 3: Indicators

The LEDs indicate the operating state of the module. All LEDs should be considered together. The LEDs on the module are divided into the following groups:

- Module status indicators (Run, Error, Stop, Init).
- System bus indicators (A, B).
- I/O indicators (DI 1...32, Field).

After connecting the supply voltage, an LED test is performed and all the LEDs are lit for at least 2 s. The color of 2-color LEDs changes once during the test.

#### Definition of blinking frequencies

The following table defines the blinking frequencies:

| Definition | Blinking frequencies   |
|------------|--|
| Blinking1  | Long (600 ms) on, long (600 ms) off.   |
| Blinking2  | Short (200 ms) on, short (200 ms) off, short (200 ms) on, long (600 ms) off. |
| Blinking-x | Ethernet communication: Blinking synchronously with data transmission.       |

Table 2: Blinking Frequencies of the LEDs

Some LEDs can report warnings (On) and faults or errors (Blinking1), see the following tables. The indication of errors or faults has priority over the indication of warnings. Warnings cannot be reported if errors or faults are being signaled.

## 3.4.3 Module Status Indicators

These LEDs are located on the upper part of the front plate.

| LED   | Color  | Status    | Description   |
|-------|--------|-----------|---|
| Run   | Green  | On        | Module in the RUN state, normal operation.  |
|       |        | Blinking1 | Module state<br>STOP / LOADING OS   |
|       |        | Off       | Module not in the RUN state,<br>observe the other status LEDs.  |
| Error | Red    | On        | System warning, for example: <ul style="list-style-type: none"> <li>No license for additional functions (e.g., communication protocols), test mode.</li> <li>Temperature warning</li> </ul>                             |
|       |        | Blinking1 | System error, for example: <ul style="list-style-type: none"> <li>Internal module faults detected by self-tests, e.g., hardware or voltage supply faults.</li> <li>Fault while loading the operating system.</li> </ul> |
|       |        | Off       | No faults detected  |
| Stop  | Yellow | On        | Module state<br>STOP / VALID CONFIGURATION  |
|       |        | Blinking1 | The module is in one of the following states: <ul style="list-style-type: none"> <li>STOP / INVALID CONFIGURATION</li> <li>STOP / LOADING OS</li> </ul>   |
|       |        | Off       | Module not in the STOP state,<br>observe the other status LEDs.   |
| Init  | Yellow | On        | Module state: INIT  |
|       |        | Blinking1 | The module is in one of the following states: <ul style="list-style-type: none"> <li>LOCKED</li> <li>STOP / LOADING OS</li> </ul>   |
|       |        | Off       | Module is in none of the states described,<br>observe the other status LEDs.  |

Table 3: Module Status Indicators

### 3.4.4 System Bus Indicators

The system bus indicator LEDs are labeled *Sys Bus*.

| LED | Color  | Status    | Description  |
|-----|--------|-----------|--|
| A   | Green  | On        | Physical and logical connection to the system bus module in slot 1.  |
|     |        | Blinking1 | No physical connection to the system bus module in slot 1.   |
|     | Yellow | Blinking1 | The physical connection to the system bus module in slot 1 has been established.<br>No connection to a (redundant) processor module running in system operation. |
| B   | Green  | On        | Physical and logical connection to the system bus module in slot 2.  |
|     |        | Blinking1 | No physical connection to the system bus module in slot 2.   |
|     | Yellow | Blinking1 | The physical connection to the system bus module in slot 2 has been established.<br>No connection to a (redundant) processor module running in system operation. |
| A+B | Off    | Off       | Neither physical nor logical connection to the system bus modules in slot 1 and slot 2.  |

Table 4: System Bus Indicators

### 3.4.5 I/O Indicators

The LEDs of the I/O indicators are labeled *Channel*.

| LED              | Color  | Status    | Description        |
|------------------|--------|-----------|--------------------|
| DI 1...DI 3<br>2 | Yellow | On        | High level present |
|                  |        | Blinking2 | Channel fault      |
|                  |        | Off       | Low level present  |
| Field            | Red    | Blinking2 | Without function   |
|                  |        | Off       |                    |

Table 5: I/O Indicators

### 3.5 Product Data

| General information               |   |
|-----------------------------------|---|
| Supply voltage                    | 24 VDC, -15...+20 %, $r_p \leq 5\%$<br>SELV, PELV   |
| Current consumption               | 250 mA at 24 VDC (without channels and supplies)<br>Max. 1 A (in case of short-circuit of the supplies) |
| Protection class                  | Protection class III in accordance with IEC/EN 61131-2  |
| Ambient temperature               | 0...+60 °C  |
| Transport and storage temperature | -40...+70 °C  |
| Humidity                          | Max. 95 % relative humidity, non-condensing   |
| Pollution                         | Pollution degree II in accordance with IEC/EN 60664-1   |
| Installation height               | < 2000 m  |
| Degree of protection              | IP20  |
| Dimensions (H x W x D) in mm      | 310 x 29.2 x 230  |
| Weight                            | Approx. 1 kg  |

Table 6: Product Data




Figure 4: Views



| Digital inputs                               |  |
|--|--|
| Number of inputs (number of channels)        | 32 unipolar with reference pole DI-<br>Not galvanically separated from one another                     |
| Type of input                                | Digital signal inputs for proximity switches in accordance with EN 60947-5-6 (NAMUR) or wired contacts |
| Rated input current                          | 0...9 mA<br>Switching thresholds freely configurable in SILworX  |
| Operating range: input current               | 0...9.3 mA (max. 12.5 mA with proximity switch supply)   |
| Resolution                                   | 12-bit   |
| LSB value (LSB = Least Significant Bit)      | 0.1 $\mu$ A  |
| Shunt for current measurement                | 1000 $\Omega$ , on the connector board   |
| Cable length                                 | The wire length depends on the wire resistance $\leq$ 50 $\Omega$ , in accordance with EN 60947-5-6    |
| Measured value refresh (in the user program) | Cycle time of the user program   |
| Metrological errors from the full scale      |  |
| Accuracy: intrinsic errors                   | $< \pm 0.5$ % incl. shunt  |
| Accuracy: operating errors                   | $< \pm 1$ % at 0...60 °C, incl. shunt  |

Table 7: Specifications for Digital Inputs

| Standard values for the digital inputs                                       |  |
|--|--|
| Proximity switch in accordance with EN 60947-5                               | Verify the values of the proximity switches actually in use  |
| Switch-on threshold Low -> High  | 1.7 mA   |
| Switch-off threshold High -> Low   | 1.5 mA   |
| Open-circuit   | $\leq 0.2$ mA  |
| Short-circuit  | $\geq 6.25$ mA   |
| Mechanical contact with resistor combination (1 k $\Omega$ / 10 k $\Omega$ ) | Verify the values actually used for the resistor combination |
| Switch-on threshold Low -> High  | 1.8 mA   |
| Switch-off threshold High -> Low   | 1.4 mA   |
| Open-circuit   | $\leq 0.2$ mA  |
| Short-circuit  | $\geq 6.55$ mA   |

Table 8: Standard Values for Digital Inputs

| Supply   |                       |
|--|-----------------------|
| Number of supplies   | 4 with 8 outputs each |
| Output voltage for supply  | 8.2 VDC, $\pm 5$ %    |
| Assignment of supply outputs   |                       |
| The voltage output assigned to each input must be used for power supply. |                       |
| S1+...S8+  | DI1+...DI8+           |
| S9+...S16+   | DI9+...DI16+          |
| S17+...S24+  | DI17+...DI24+         |
| S25+...S32+  | DI25+...DI32+         |

Table 9: Supply Specifications

### 3.6 Connector Boards

A connector board connects the module to the field level. Module and connector board together form a functional unit. Insert the connector board into the appropriate slot prior to mounting the module.

The following connector boards are available for the module:

| Connector board | Description  |
|-----------------|--|
| X-CB 005 51     | Mono connector board with screw terminals.           |
| X-CB 005 52     | Redundant connector board with screw terminals.      |
| X-CB 005 53     | Mono connector board with cable plug.                |
| X-CB 005 54     | Redundant connector board with cable plug.           |
| X-CB 005 55     | Mono connector board with cable plug, redundant FTA. |

Table 10: Available Connector Boards


#### 3.6.1 Mechanical Coding of Connector Boards

I/O modules and connector boards are mechanically coded starting from hardware revision index (HW-Rev.) 00. Coding avoids installation of improper I/O modules thus preventing negative effects on redundant modules and the field level.

Apart from that, improper equipment has no effect on the HIMax system since only I/O modules properly configured in SILworX can enter the RUN state.

I/O modules and the corresponding connector boards have a mechanical coding in the form of wedges. The coding wedges in the female connector of the connector board match with the male connector recesses of the I/O module plug, see Figure 5.

Coded I/O modules can only be plugged in to the corresponding connector boards.



- 1** Male connector recess
- 2** Prepared male connector recess
- 3** Coding wedge
- 4** Guideway for coding wedge

Figure 5: Coding Example

Coded I/O modules can be plugged in to uncoded connector boards. Uncoded I/O modules cannot be plugged in to coded connector boards.

### 3.6.2 Coding of X-CB 005 5x Connector Boards

The following table specifies the position of the coding wedges on the I/O module plug:

| a7 | a13 | a20 | a26 | e7 | e13 | e20 | e26 |
|----|-----|-----|-----|----|-----|-----|-----|
|    |     |     |     | X  | X   | X   |     |

Table 11: Position of Coding Wedges

3.6.3 Connector Boards with Screw Terminals




Figure 6: Connector Boards with Screw Terminals

## 3.6.4 Terminal Assignment for Connector Boards with Screw Terminals

| Pin no. | Designation | Signal | Pin no. | Designation | Signal |
|---------|-------------|--------|---------|-------------|--------|
| 1       | 01a         | S1+    | 1       | 02a         | S2+    |
| 2       | 01b         | DI1+   | 2       | 02b         | DI2+   |
| 3       | 03a         | S3+    | 3       | 04a         | S4+    |
| 4       | 03b         | DI3+   | 4       | 04b         | DI4+   |
| 5       | 05a         | S5+    | 5       | 06a         | S6+    |
| 6       | 05b         | DI5+   | 6       | 06b         | DI6+   |
| 7       | 07a         | S7+    | 7       | 08a         | S8+    |
| 8       | 07b         | DI7+   | 8       | 08b         | DI8+   |
| Pin no. | Designation | Signal | Pin no. | Designation | Signal |
| 1       | 09a         | S9+    | 1       | 10a         | S10+   |
| 2       | 09b         | DI9+   | 2       | 10b         | DI10+  |
| 3       | 11a         | S11+   | 3       | 12a         | S12+   |
| 4       | 11b         | DI11+  | 4       | 12b         | DI12+  |
| 5       | 13a         | S13+   | 5       | 14a         | S14+   |
| 6       | 13b         | DI13+  | 6       | 14b         | DI14+  |
| 7       | 15a         | S15+   | 7       | 16a         | S16+   |
| 8       | 15b         | DI15+  | 8       | 16b         | DI16+  |
| Pin no. | Designation | Signal | Pin no. | Designation | Signal |
| 1       | 17a         | S17+   | 1       | 18a         | S18+   |
| 2       | 17b         | DI17+  | 2       | 18b         | DI18+  |
| 3       | 19a         | S19+   | 3       | 20a         | S20+   |
| 4       | 19b         | DI19+  | 4       | 20b         | DI20+  |
| 5       | 21a         | S21+   | 5       | 22a         | S22+   |
| 6       | 21b         | DI21+  | 6       | 22b         | DI22+  |
| 7       | 23a         | S23+   | 7       | 24a         | S24+   |
| 8       | 23b         | DI23+  | 8       | 24b         | DI24+  |
| Pin no. | Designation | Signal | Pin no. | Designation | Signal |
| 1       | 25a         | S25+   | 1       | 26a         | S26+   |
| 2       | 25b         | DI25+  | 2       | 26b         | DI26+  |
| 3       | 27a         | S27+   | 3       | 28a         | S28+   |
| 4       | 27b         | DI27+  | 4       | 28b         | DI28+  |
| 5       | 29a         | S29+   | 5       | 30a         | S30+   |
| 6       | 29b         | DI29+  | 6       | 30b         | DI30+  |
| 7       | 31a         | S31+   | 7       | 32a         | S32+   |
| 8       | 31b         | DI31+  | 8       | 32b         | DI32+  |

Table 12: Terminal Assignment for Connector Boards with Screw Terminals

Cable plugs attached to the connector board pin headers are used to connect to the field level.

The cable plugs feature the following characteristics:

| Connection to the field level |   |
|-------------------------------|---|
| Cable plugs                   | 8 pieces, with 8 poles  |
| Wire cross-section            | 0.2...1.5 mm <sup>2</sup> (single-wire)<br>0.2...1.5 mm <sup>2</sup> (finely stranded)<br>0.2...1.5 mm <sup>2</sup> (with wire end ferrule) |
| Stripping length              | 6 mm  |
| Screwdriver                   | Slotted 0.4 x 2.5 mm  |
| Tightening torque             | 0.2...0.25 Nm   |

Table 13: Cable Plug Characteristics

## 3.6.5 Connector Boards with Cable Plug

**Mono**

X-CB 005 53

**Redundant**

X-CB 005 54


**1** I/O module plug**2** Connection to the field level  
(cable plug in row 1)**3** Connection to the field level  
(cable plug in row 32)**4** Coding of cable plugs

Figure 7: Connector Boards with Cable Plug

### 3.6.6 Pin Assignment for Connector Boards with Cable Plug

HIMA provides ready-made system cables for use with these connector boards, see Chapter 3.7. The cable plug and the connector boards are coded.

#### i

#### Connector pin assignment!

The following table describes the connector pin assignment of the system cable plug.

The wire color coding complies with IEC 60304. The color abbreviations used are in accordance with IEC 60757.

| Row | c      |                    | b      |                    | a                             |                    |
|-----|--------|--------------------|--------|--------------------|-------------------------------|--------------------|
|     | Signal | Color              | Signal | Color              | Signal                        | Color              |
| 1   | S32+   | PKBN <sup>1)</sup> | DI32+  | WHPK <sup>1)</sup> | Internal use<br><sup>2)</sup> | BNRD <sup>1)</sup> |
| 2   | S31+   | GYBN <sup>1)</sup> | DI31+  | WHGY <sup>1)</sup> |                               | WHRD <sup>1)</sup> |
| 3   | S30+   | YEBN <sup>1)</sup> | DI30+  | WHYE <sup>1)</sup> |                               | BNBU <sup>1)</sup> |
| 4   | S29+   | BNGN <sup>1)</sup> | DI29+  | WHGN <sup>1)</sup> |                               | WHBU <sup>1)</sup> |
| 5   | S28+   | RDBU <sup>1)</sup> | DI28+  | GYPK <sup>1)</sup> |                               |                    |
| 6   | S27+   | VT <sup>1)</sup>   | DI27+  | BK <sup>1)</sup>   |                               |                    |
| 7   | S26+   | RD <sup>1)</sup>   | DI26+  | BU <sup>1)</sup>   |                               |                    |
| 8   | S25+   | PK <sup>1)</sup>   | DI25+  | GY <sup>1)</sup>   |                               |                    |
| 9   | S24+   | YE <sup>1)</sup>   | DI24+  | GN <sup>1)</sup>   |                               |                    |
| 10  | S23+   | BN <sup>1)</sup>   | DI23+  | WH <sup>1)</sup>   |                               |                    |
| 11  | S22+   | RDBK               | DI22+  | BUBK               |                               |                    |
| 12  | S21+   | PKBK               | DI21+  | GYBK               |                               |                    |
| 13  | S20+   | PKRD               | DI20+  | GYRD               |                               |                    |
| 14  | S19+   | PKBU               | DI19+  | GYBU               |                               |                    |
| 15  | S18+   | YEBK               | DI18+  | GNBK               |                               |                    |
| 16  | S17+   | YERD               | DI17+  | GNRD               |                               |                    |
| 17  | S16+   | YEBU               | DI16+  | GNBU               |                               |                    |
| 18  | S15+   | YEPK               | DI15+  | PKGK               |                               |                    |
| 19  | S14+   | YEGY               | DI14+  | GYGN               |                               |                    |
| 20  | S13+   | BNBK               | DI13+  | WHBK               |                               |                    |
| 21  | S12+   | BNRD               | DI12+  | WHRD               |                               |                    |
| 22  | S11+   | BNBU               | DI11+  | WHBU               |                               |                    |
| 23  | S10+   | PKBN               | DI10+  | WHPK               |                               |                    |
| 24  | S9+    | GYBN               | DI9+   | WHGY               |                               |                    |
| 25  | S8+    | YEBN               | DI8+   | WHYE               |                               |                    |
| 26  | S7+    | BNGN               | DI7+   | WHGN               |                               |                    |
| 27  | S6+    | RDBU               | DI6+   | GYPK               |                               |                    |
| 28  | S5+    | VT                 | DI5+   | BK                 |                               |                    |
| 29  | S4+    | RD                 | DI4+   | BU                 |                               |                    |
| 30  | S3+    | PK                 | DI3+   | GY                 |                               |                    |
| 31  | S2+    | YE                 | DI2+   | GN                 |                               |                    |
| 32  | S1+    | BN                 | DI1+   | WH                 |                               |                    |

<sup>1)</sup> Additional orange ring if one wire color is repeated.  
<sup>2)</sup> The wires must be isolated individually! No other use is permitted!

Table 14: Pin Assignment for the System Cable Plug

3.6.7 Mono Connector Board Redundancy using 2 Base Plates




Figure 8: X-CB 005 55 Mono Connector Board with Cable Plug



### 3.6.8 Pin Assignment for X-CB 005 55

HIMA provides ready-made system cables for use with this connector board, see Chapter 3.7. The cable plug and the connector boards are coded.

#### i

#### Connector pin assignment!

The following table describes the connector pin assignment of the system cable plug.

The wire color coding complies with IEC 60304. The color abbreviations used are in accordance with IEC 60757.

| Row | e      |                    | d       |                    | c      |                    | b      |                    | a                          |                    |
|-----|--------|--------------------|---------|--------------------|--------|--------------------|--------|--------------------|----------------------------|--------------------|
|     | Signal | Color              | Signal  | Color              | Signal | Color              | Signal | Color              | Signal                     | Color              |
| 1   | S32+   | RD <sup>2)</sup>   | DI_R32+ | PKBN <sup>1)</sup> | DI32+  | WHPK <sup>1)</sup> |        |                    | Internal use <sup>3)</sup> | BNRD <sup>2)</sup> |
| 2   | S31+   | BU <sup>2)</sup>   | DI_R31+ | GYBN <sup>1)</sup> | DI31+  | WHGY <sup>1)</sup> |        |                    |                            | WHRD <sup>2)</sup> |
| 3   | S30+   | PK <sup>2)</sup>   | DI_R30+ | YEBN <sup>1)</sup> | DI30+  | WHYE <sup>1)</sup> |        |                    |                            | BNBU <sup>2)</sup> |
| 4   | S29+   | GY <sup>2)</sup>   | DI_R29+ | BNGN <sup>1)</sup> | DI29+  | WHGN <sup>1)</sup> |        |                    |                            | WHBU <sup>2)</sup> |
| 5   | S28+   | YE <sup>2)</sup>   | DI_R28+ | RDBU <sup>1)</sup> | DI28+  | GYPK <sup>1)</sup> |        |                    |                            |                    |
| 6   | S27+   | GN <sup>2)</sup>   | DI_R27+ | VT <sup>1)</sup>   | DI27+  | BK <sup>1)</sup>   |        |                    |                            |                    |
| 7   | S26+   | BN <sup>2)</sup>   | DI_R26+ | RD <sup>1)</sup>   | DI26+  | BU <sup>1)</sup>   |        |                    |                            |                    |
| 8   | S25+   | WH <sup>2)</sup>   | DI_R25+ | PK <sup>1)</sup>   | DI25+  | GY <sup>1)</sup>   |        |                    |                            |                    |
| 9   | S24+   | RDBK <sup>1)</sup> | DI_R24+ | YE <sup>1)</sup>   | DI24+  | GN <sup>1)</sup>   |        |                    |                            |                    |
| 10  | S23+   | BUBK <sup>1)</sup> | DI_R23+ | BN <sup>1)</sup>   | DI23+  | WH <sup>1)</sup>   |        |                    |                            |                    |
| 11  | S22+   | PKBK <sup>1)</sup> | DI_R22+ | RDBK               | DI22+  | BUBK               |        |                    |                            |                    |
| 12  | S21+   | GYBK <sup>1)</sup> | DI_R21+ | PKBK               | DI21+  | GYBK               |        |                    |                            |                    |
| 13  | S20+   | PKRD <sup>1)</sup> | DI_R20+ | PKRD               | DI20+  | GYRD               |        |                    |                            |                    |
| 14  | S19+   | GYRD <sup>1)</sup> | DI_R19+ | PKBU               | DI19+  | GYBU               |        |                    |                            |                    |
| 15  | S18+   | PKBU <sup>1)</sup> | DI_R18+ | YEBK               | DI18+  | GNBK               |        |                    |                            |                    |
| 16  | S17+   | GYBU <sup>1)</sup> | DI_R17+ | YERD               | DI17+  | GNRD               |        |                    |                            |                    |
| 17  | S16+   | YEBK <sup>1)</sup> | DI_R16+ | YEBU               | DI16+  | GNBU               | S-     | BNRD <sup>2)</sup> |                            |                    |
| 18  | S15+   | GNBK <sup>1)</sup> | DI_R15+ | YEPK               | DI15+  | PKGK               | S-     | WHRD <sup>2)</sup> |                            |                    |
| 19  | S14+   | YERD <sup>1)</sup> | DI_R14+ | YEGY               | DI14+  | GYGN               | S-     | BNBU <sup>2)</sup> |                            |                    |
| 20  | S13+   | GNRD <sup>1)</sup> | DI_R13+ | BNBK               | DI13+  | WHBK               | S-     | WHBU <sup>2)</sup> |                            |                    |
| 21  | S12+   | YEBU <sup>1)</sup> | DI_R12+ | BNRD               | DI12+  | WHRD               | S-     | PKBN <sup>2)</sup> |                            |                    |
| 22  | S11+   | GNBU <sup>1)</sup> | DI_R11+ | BNBU               | DI11+  | WHBU               | S-     | WHPK <sup>2)</sup> |                            |                    |
| 23  | S10+   | YEPK <sup>1)</sup> | DI_R10+ | PKBN               | DI10+  | WHPK               | S-     | GYBN <sup>2)</sup> |                            |                    |
| 24  | S9+    | PKGK <sup>1)</sup> | DI_R9+  | GYBN               | DI9+   | WHGY               | S-     | WHGY <sup>2)</sup> |                            |                    |
| 25  | S8+    | YEGY <sup>1)</sup> | DI_R8+  | YEBN               | DI8+   | WHYE               | DI-    | YEBN <sup>2)</sup> |                            |                    |
| 26  | S7+    | GYGN <sup>1)</sup> | DI_R7+  | BNGN               | DI7+   | WHGN               | DI-    | WHYE <sup>2)</sup> |                            |                    |
| 27  | S6+    | BNBK <sup>1)</sup> | DI_R6+  | RDBU               | DI6+   | GYPK               | DI-    | BNGN <sup>2)</sup> |                            |                    |
| 28  | S5+    | WHBK <sup>1)</sup> | DI_R5+  | VT                 | DI5+   | BK                 | DI-    | WHGN <sup>2)</sup> |                            |                    |
| 29  | S4+    | BNRD <sup>1)</sup> | DI_R4+  | RD                 | DI4+   | BU                 | DI-    | RDBU <sup>2)</sup> |                            |                    |
| 30  | S3+    | WHRD <sup>1)</sup> | DI_R3+  | PK                 | DI3+   | GY                 | DI-    | GYPK <sup>2)</sup> |                            |                    |
| 31  | S2+    | BNBU <sup>1)</sup> | DI_R2+  | YE                 | DI2+   | GN                 | DI-    | VT <sup>2)</sup>   |                            |                    |
| 32  | S1+    | WHBU <sup>1)</sup> | DI_R1+  | BN                 | DI1    | WH                 | DI-    | BK <sup>2)</sup>   |                            |                    |

<sup>1)</sup> Additional orange ring if one wire color is repeated for the first time.


<sup>2)</sup> Additional violet ring if one wire color is repeated for the second time.

<sup>3)</sup> The wires must be isolated individually! No other use is permitted!

Table 15: Pin Assignment for the System Cable Plug

3.7 System Cables

Depending on the type of connector board, system cable X-CA 002 or X-CA 009 is available.



**1** Identical cable plugs

Figure 9: System Cables

3.7.1 System Cable X-CA 002

System cable X-CA 002 is used to connect the X-CB 005 53/54 connector board to the field termination assembly.

| General information        |  |
|----------------------------|--|
| Cable                      | LIYY-TP 34 x 2 x 0.25 mm <sup>2</sup>  |
| Wire                       | Finely stranded  |
| Average outer diameter (d) | Approx. 15.2 mm<br>Max. 20 mm for all types of system cables                           |
| Minimum bending radius     |  |
| Fixed installation         | 5 x d  |
| Flexible application       | 10 x d   |
| Burning behavior           | Flame retardant and self-extinguishing in accordance with IEC 60332-1-2, IEC 60332-2-2 |
| Length                     | 8...30 m   |
| Color coding               | Based on DIN 47100, see Table 14.  |

Table 16: Cable Data X-CA 002

The system cable is available in the following standard length:

| System cables  | Description                      | Length | Weight |
|----------------|----------------------------------|--------|--------|
| X-CA 002 01 8  | Coded cable plugs on both sides. | 8 m    | 3.5 kg |
| X-CA 002 01 15 |                                  | 15 m   | 6.5 kg |
| X-CA 002 01 30 |                                  | 30 m   | 13 kg  |

Table 17: Available System Cables X-CA 002

### 3.7.2 System Cable X-CA 009

System cable X-CA 009 is used to connect the X-CB 005 55 connector board to the field level via field termination assembly.

| General information        |  |
|----------------------------|--|
| Cable                      | LIYCY-TP 58 x 2 x 0.14 mm <sup>2</sup>   |
| Wire                       | Finely stranded  |
| Average outer diameter (d) | Approx. 18.3 mm,<br>Max. 20 mm for all types of system cables                          |
| Minimum bending radius     |  |
| Fixed installation         | 5 x d  |
| Flexible application       | 10 x d   |
| Burning behavior           | Flame retardant and self-extinguishing in accordance with IEC 60332-1-2, IEC 60332-2-2 |
| Length                     | 8...30 m   |
| Color coding               | Based on DIN 47100, see Table 15.  |

Table 18: Cable Data X-CA 009

The system cable is available in the following standard length:

| System cables  | Description                      | Length | Weight  |
|----------------|----------------------------------|--------|---------|
| X-CA 009 01 8  | Coded cable plugs on both sides. | 8 m    | 4.25 kg |
| X-CA 009 01 15 |                                  | 15 m   | 8 kg    |
| X-CA 009 01 30 |                                  | 30 m   | 16 kg   |

Table 19: Available System Cables X-CA 009

### 3.7.3 Cable Plug Coding

The cable plugs are equipped with 3 coding pins. Therefore, cable plugs only match connector boards and FTAs with the corresponding recesses, see Figure 7 and Figure 8.

## 4 Start-Up

This chapter describes how to install, configure and connect the module. For further details, refer to the HIMax system manual (HI 801 001 E).

### 4.1 Mounting

Observe the following points when mounting the module:

- Only operate the module with the appropriate fan components. For further details, see the system manual (HI 801 001 E).
- Only operate the module with the suitable connector board. For further details, see Chapter 3.6.
- The module, including its connected components, must be installed to ensure compliance with the requirements for degree of protection IP20 or higher in accordance with EN 60529:1991 + A1:2000.

#### NOTICE



##### **Damage due to incorrect wiring!**

**Failure to comply with these instructions can damage the electronic components.**

**Observe the following points.**

- Plugs and terminals connected to the field level.
  - Take the appropriate grounding measures when connecting the plugs and terminals to the field level.
  - Use shielded cables with twisted pairs.
  - Use one twisted pair for each measuring inputs.
  - If shielded cables are used, connect the shielding on both sides. On the module side, the shielding must be connected to the cable shield rail (use SK 20 shield connection terminal block or similar).
  - If finely stranded wires are used, HIMA recommends fastening ferrules to the wire ends. The terminals must be suitable for fastening the cross-sections of the cables in use.
- If the supply is used, utilize the supply output used for the assigned input, see Table 9.
- HIMA recommends using the supply of the module.

If an external current source is malfunctioning, the affected module's measuring input can be overloaded and damaged. If an external current source is used, the switching thresholds must be checked after a non-transient overload occurred at the measuring inputs.
- The inputs can be interconnected redundantly using the corresponding connector boards, see Chapter 3.6.

#### 4.1.1 Wiring Unused Inputs

Inputs that are not being used may stay open and need not be terminated. To prevent short-circuits in the field, never connect a wire to a connector board if it is open on the field level.

## 4.2 Mounting and Removing the Module

This chapter describes how to replace an existing module or mount a new one.

When removing the module, the connector board remains in the HiMax base plate. This saves additional wiring effort at the clamp terminals since all field terminals are connected via the connector board of the module.

### 4.2.1 Mounting a Connector Board

#### Tools and utilities:

- Screwdriver, cross PH 1 or slotted 0.8 x 4.0 mm.
- Matching connector board.

#### To install the connector board

1. Insert the connector board into the guiding rail with the groove facing upwards (see following drawing). Fit the groove into the guiding rail pin.
2. Place the connector board on the cable shield rail.
3. Secure the captive screws to the base plate. First screw in the lower screws than the upper ones.

#### To remove the connector board

1. Release the captive screws from the base plate.
2. Carefully lift the lower section of the connector board from the cable shield rail.
3. Remove the connector board from the guiding rail.




Figure 10: Example of how to Insert the Mono Connector Board




Figure 11: Example of how to Secure the Mono Connector Board with Captive Screws

**i**

These instructions also apply for redundant connector boards. The number of used slots varies in accordance with the connector board type. The number of captive screws depends on the connector board type.

### 4.2.2 Mounting and Removing a Module

This chapter describes how to mount and remove the HIMax module. A module can be mounted and removed while the HIMax system is operating.

#### NOTICE



**Damage to bus and power sockets due to module jamming!**

**Failure to comply with these instructions can damage the controller.**

**Always insert the module in the base plate carefully.**

#### Tools and utilities:


- Screwdriver, slotted 0.8 x 4.0 mm.
- Screwdriver, slotted 1.2 x 8.0 mm.

#### To insert the modules

1. Open the cover plate on the fan rack:
  - ☒ Move the locks to the *open* position.
  - ☒ Lift the cover plate and insert it into the fan rack.
2. Insert the top of the module into the hook-in rail, see **1**.
3. Swivel the lower edge of the module towards the base plate and apply light pressure to snap it into place, see **2**.
4. Tighten the screws, see **3**.
5. Pull the cover plate out of the fan rack and close it.
6. Lock the cover plate.

#### To remove the modules

1. Open the cover plate on the fan rack:
  - ☒ Move the locks to the *open* position.
  - ☒ Lift the cover plate and insert it into the fan rack.
2. Release the screw, see **3**.
3. Swivel the lower edge of the module away from the base plate. Lift and apply light pressure to remove the module from the hook-in rail, see **2** and **1**.
4. Pull the cover plate out of the fan rack and close it.
5. Lock the cover plate.



**1** Inserting and removing a module

**2** Swiveling the module in and out

**3** Securing and releasing a module

Figure 12: Mounting and Removing a Module

**i**

If the HIMax system is operating, do not open the cover plate of the fan rack for more than a few minutes (< 10 min) since this affects the forced cooling.



### 4.3 Configuring the Module in SILworX

The module is configured in the Hardware Editor of the SILworX programming tool.

Observe the following points when configuring the module:

- To diagnose the module and channels, both the statuses and the measured value can be evaluated within the user program. For further details on the system parameters, refer to the following tables.
- For short-circuit and open-circuit monitoring, 2 thresholds are detected by the module. The switching thresholds can be set in SILworX in the module configuration.
- When scaling the input value -> *Raw Value [DINT]*, users must make sure that the scaling result is within the range of values for the REAL data type. Representation of the scaling result must be possible with a REAL variable.
- If the proximity switch supply of the module is used, activate the parameter *Supply X ON* parameter.
- If the modules are redundantly connected, the proximity switch supply group must be activated using the parameter *Supply X ON*.
- If a redundancy group is created, its configuration is defined in the tabs. The tabs specific to the redundancy group differ from those of the individual modules, see the following tables.

To evaluate the system parameters in the user program, they must be assigned to global variables. Perform this step in the Hardware Editor using the module's detail view.

The following tables present the system parameters for the module in the same order as in the SILworX Hardware Editor.

---

**TIP**

A scientific calculator such as the Windows® calculator with the corresponding view can be used to convert hexadecimal values to bit strings.

---

### 4.3.1 The **Module** Tab

The **Module** tab contains the following system parameters for the module:

| System parameter  | Data type                                  | R/W | Description   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
|---|--|-----|---|--------|-------------|------------|-----------------------------|------------|-----------------------------------|------------|-----------------------------------|------------|------------------------------|------------|------------------------------|------------|------------------------------|------------|--------------------------------|------------|--|---|--|
| Name  | ---  | W   | Module name.  |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| Spare Module  | ---  | W   | Activated: It is not considered a fault if a module of the redundancy group is missing in the base plate.<br>Deactivated: It is considered a fault if a module of the redundancy group is missing in the base plate.<br>Default setting: Deactivated<br><b>It is only displayed in the redundancy group tab!</b>  |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| Noise Blanking  | ---  | W   | Allow noise blanking performed by the process module (Activated/Deactivated).<br>Default setting: Activated<br>The processor module delays its response to transient interference until the safety time. The user program retains its last valid process value.<br>Refer to the system manual (HI 801 001 E) for further details on noise blanking.   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| System parameter  | Data type                                  | R/W | Description   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| The following statuses and parameters can be assigned global variables and used in the user program.                    |  |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| Module OK   | BOOL                                       | R   | TRUE:<br>Mono operation: No module faults.<br>Redundancy operation: At least one of the redundant modules has no module fault (OR logic).<br>FALSE:<br>Module fault.<br>Channel fault (no external faults).<br>The module is not plugged in.<br>Observe the <i>Module Status</i> parameter!   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| Module Status   | DWORD                                      | R   | Status of the module. <table><tr><th>Coding</th><th>Description</th></tr><tr><td>0x00000001</td><td>Module fault. <sup>1)</sup></td></tr><tr><td>0x00000002</td><td>Temperature threshold 1 exceeded.</td></tr><tr><td>0x00000004</td><td>Temperature threshold 2 exceeded.</td></tr><tr><td>0x00000008</td><td>Incorrect temperature value.</td></tr><tr><td>0x00000010</td><td>Voltage on L1+ is defective.</td></tr><tr><td>0x00000020</td><td>Voltage on L2+ is defective.</td></tr><tr><td>0x00000040</td><td>Internal voltage is defective.</td></tr><tr><td>0x80000000</td><td>No connection to the module. <sup>1)</sup></td></tr><tr><td colspan="2"><sup>1)</sup> These faults affect the <i>Module OK</i> status and need not be separately evaluated in the user program.</td></tr></table> | Coding | Description | 0x00000001 | Module fault. <sup>1)</sup> | 0x00000002 | Temperature threshold 1 exceeded. | 0x00000004 | Temperature threshold 2 exceeded. | 0x00000008 | Incorrect temperature value. | 0x00000010 | Voltage on L1+ is defective. | 0x00000020 | Voltage on L2+ is defective. | 0x00000040 | Internal voltage is defective. | 0x80000000 | No connection to the module. <sup>1)</sup> | <sup>1)</sup> These faults affect the <i>Module OK</i> status and need not be separately evaluated in the user program. |  |
| Coding  | Description                                |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| 0x00000001  | Module fault. <sup>1)</sup>                |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| 0x00000002  | Temperature threshold 1 exceeded.          |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| 0x00000004  | Temperature threshold 2 exceeded.          |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| 0x00000008  | Incorrect temperature value.               |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| 0x00000010  | Voltage on L1+ is defective.               |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| 0x00000020  | Voltage on L2+ is defective.               |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| 0x00000040  | Internal voltage is defective.             |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| 0x80000000  | No connection to the module. <sup>1)</sup> |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| <sup>1)</sup> These faults affect the <i>Module OK</i> status and need not be separately evaluated in the user program. |  |     |   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| Timestamp [μs]  | DWORD                                      | R   | Microsecond fraction of the timestamp.<br>Point in time when the digital inputs were measured.  |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |
| Timestamp [s]   | DWORD                                      | R   | Second fraction of the timestamp.<br>Point in time when the digital inputs were measured.   |        |             |            |                             |            |                                   |            |                                   |            |                              |            |                              |            |                              |            |                                |            |  |   |  |

Table 20: The **Module** Tab in the Hardware Editor

### 4.3.2 The I/O Submodule DI 32\_52 Tab

The I/O Submodule DI32\_52 tab contains the following system parameters:

| System parameters  | Data type | R/W | Description   |
|--|-----------|-----|---|
| Enter these statuses and parameters directly in the Hardware Editor.                                 |           |     |   |
| Name   | ---       | R   | Tab name  |
| Show Signal Overflow   | BOOL      | W   | Show signal overflow with <i>Field</i> LED (Activated/Deactivated).<br>Default setting: Activated   |
| Supply 1 ON  | BOOL      | W   | Use module's proximity switch supplies for Channel 1 to Channel 8 (Activated/Deactivated).<br>Default setting: Activated  |
| Supply 2 ON  | BOOL      | W   | Use module's proximity switch supplies for Channel 9 to Channel 16 (Activated/Deactivated).<br>Default setting: Activated   |
| Supply 3 ON  | BOOL      | W   | Use module's proximity switch supplies for Channel 17 to Channel 24 (Activated/Deactivated).<br>Default setting: Activated  |
| Supply 4 ON  | BOOL      | W   | Use module's proximity switch supplies for Channel 25 to Channel 32 (Activated/Deactivated).<br>Default setting: Activated  |
| System parameter   | Data type | R/W | Description   |
| The following statuses and parameters can be assigned global variables and used in the user program. |           |     |   |
| Diagnostic Request   | DINT      | W   | To request a diagnostic value, the appropriate ID must be sent to the module using the parameter <i>Diagnostic Request</i> (for coding details, see Chapter 4.3.5).   |
| Diagnostic Response  | DINT      | R   | As soon as <i>Diagnostic Response</i> returns the ID of <i>Diagnostic Request</i> (for coding details, see Chapter 4.3.5), <i>Diagnostic Status</i> contains the diagnostic value requested.  |
| Diagnostic Status  | DWORD     | R   | Requested diagnostic value in accordance with <i>Diagnostic Response</i> .<br>The IDs of <i>Diagnostic Request</i> and <i>Diagnostic Response</i> can be evaluated in the user program. <i>Diagnostic Status</i> only contains the requested diagnostic value when both <i>Diagnostic Request</i> and <i>Diagnostic Response</i> have the same ID.                            |
| Background Test Error  | BOOL      | R   | TRUE: Background test is faulty.<br>FALSE: Background test is not faulty.   |
| Restart on Error   | BOOL      | W   | The <i>Restart on Error</i> parameter can be used to cause any I/O module that is shut down permanently due to errors or faults to once again enter the RUN state. To do so, set the <i>Restart on Error</i> parameter from FALSE to TRUE.<br>The I/O module performs a complete self-test and only enters the RUN state if no faults are detected.<br>Default setting: FALSE |

| System parameters | Data type | R/W | Description  |
|-------------------|-----------|-----|--|
| Submodule OK      | BOOL      | R   | TRUE: No submodule fault, no channel faults.<br>FALSE: Submodule fault, channel faults (external faults included). |
| Submodule Status  | DWORD     | R   | Bit-coded submodule status.<br>For coding details, see Chapter 4.3.4.  |

Table 21: The **I/O Submodule DI 32\_52** Tab in the Hardware Editor

The proximity switch supplies of the module are short-circuit-proof. The module switches off the corresponding proximity switch supply if the total current is exceeded ( $> 200\text{ mA}$ ). If the overload disappears within 30 s, the proximity switch supply is switched on again. If the overload is still present after 30 s, the module attempts to restart the proximity switch supply in intervals of 60 s.

Short transient interferences ( $< 5\text{ ms}$ ) do not cause the proximity switch supply to switch off.

Switching off a proximity switch supply affects all inputs of this group (Table 9), i.e., the digital values of these inputs are reset to their initial values. If line monitoring (OC) was configured, the module also reports an open-circuit in all 8 inputs.

The configured proximity switch supplies are switched on in the STOP-VALID status of the HIMax controller.

The proximity switch supply outputs of the module cannot be forced and may only be configured in the Hardware Editor.

The voltage limits of the proximity switch supply outputs are safely monitored by the module. In case of overvoltage, undervoltage or overcurrent, the corresponding status *Supply X OK* is set to FALSE.

For supplying a channel, the voltage output assigned to the input must be used (e.g., S1+ with DI1+).

### 4.3.3 The I/O Submodule DI32\_52: Channels Tab

The **I/O Submodule DI32\_52: Channels** tab contains the following system parameters for each digital input.

Global variables can be assigned to the system parameters with **->** and used in the user program. The value without **->** must be directly entered.

| System parameter        | Data type | R/W | Description  |
|-------------------------|-----------|-----|--|
| Channel no.             | ---       | R   | Channel number, preset and cannot be changed.  |
| SP LOW                  | DINT      | W   | Upper limit of LOW level.<br><i>SP LOW</i> (switching point LOW) is the limit value: if this limit is exceeded, the module detects LOW and switches off the <i>Channel</i> LED.<br>Restriction: $SP\ LOW \leq SP\ HIGH$<br>Default setting: 14 000 (1.4 mA)  |
| SP HIGH                 | DINT      | W   | Lower limit for the high level.<br><i>SP HIGH</i> (switching point HIGH) is the limit value: if this limit is exceeded, the module detects a HIGH and switches on the <i>Channel</i> LED.<br>Restriction: $SP\ LOW \leq SP\ HIGH$<br>Default setting: 18 000 (1.8 mA)  |
| -> Channel Value [BOOL] | BOOL      | R   | Boolean channel process value in accordance with the limits <i>SP LOW</i> and <i>SP HIGH</i> .   |
| -> Channel OK [BOOL]    | BOOL      | R   | TRUE: Fault-free channel.<br>The input value is valid.<br>FALSE: Faulty channel.<br>The input value is set to 0.   |
| OC Limit                | DINT      | W   | Threshold in mA for detecting an open-circuit.<br>If the analog measured value falls under <i>OC Limit</i> , the module detects an open-circuit and switches off the <i>Channel</i> LED for this channel.<br>Default setting: 2000 (0.2 mA)  |
| -> OC [BOOL]            | BOOL      | R   | TRUE: Open-circuit present.<br>FALSE: No open-circuit present.<br>Defined through <i>OC Limit</i> .  |
| SC Limit                | DINT      | W   | Threshold in mA for detecting a short-circuit.<br>If the measured analog value exceeds <i>SC Limit</i> , the module detects a short-circuit and sets the <i>Channel</i> LED for this channel to Blinking2.<br>Default setting: 65 500 (6.55 mA)  |
| -> SC [BOOL]            | BOOL      | R   | TRUE: Short-circuit present.<br>FALSE: No short-circuit present.<br>Defined through <i>SC Limit</i> .  |
| T on [μs]               | UDINT     | W   | Time on Delay<br>The module only indicates a level change from LOW to HIGH if the high level is present for longer than the configured time $t_{on}$ .<br>The time on delay cannot be extended by more than the cycle time of the module. This also results in a delayed evaluation of the <b>-&gt; Channel Value [BOOL]</b> parameter.<br>Range of values: $0 \dots (2^{32}-1)$<br>Granularity: 1000 μs, e.g., 0, 1000, 2000, ...<br>Default setting: 0 |

| System parameter    | Data type | R/W | Description   |
|---------------------|-----------|-----|---|
| T off [μs]          | UDINT     | W   | Time off delay<br>The module only indicates a level change from HIGH to LOW if the low level is present for longer than the configured time $t_{off}$ .<br>The time off delay cannot be extended by more than the cycle time of the module. This also results in a delayed evaluation of the -> <i>Channel Value [BOOL]</i> parameter.<br>Range of values: $0 \dots (2^{32}-1)$<br>Granularity: 1000 μs, e.g., 0, 1000, 2000, ...<br>Default setting: 0 |
| -> Raw Value [DINT] | DINT      | R   | Unhandled analog value measured for the channel<br>Range of values: 0...93 000 (0...9.3 mA)   |
| Redund.             | BOOL      | R   | Requirement: The redundant module must exist.<br>Activated: The channel redundancy for this channel is active.<br>Deactivated: Deactivate the channel redundancy for this channel.<br>Default setting: Deactivated  |
| Redundancy Value    | BYTE      | W   | Setting for determining the redundancy value.<br><ul style="list-style-type: none"> <li>▪ Min</li> <li>▪ Max</li> <li>▪ Average</li> </ul> Default setting: Max<br><b>It is only displayed in the redundancy group tab!</b>   |

Table 22: The **I/O Submodule DI32\_52: Channels** Tab in the Hardware Editor

#### 4.3.4 Description of *Submodule Status [DWORD]*

The following table specifies the coding of the *Submodule Status* parameter:

| Coding     | Description  |
|------------|--|
| 0x00000001 | Fault in hardware unit (submodule).                  |
| 0x00000004 | Faults detected while configuring the hardware unit. |
| 0x00000008 | Fault detected while checking the coefficients.      |

Table 23: Coding of *Submodule Status [DWORD]*

### 4.3.5 Description of *Diagnostic Status* [DWORD]

The following table specifies the coding of the *Diagnostic Status* parameter:

| ID          | Description  |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
|-------------|--|--------|-------------|--------|-------------------------------------|--------|--------------------------------------|--------|--|--------|--|--------|-------------------------|
| 0           | Diagnostic values are indicated consecutively.   |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 100         | Bit-coded temperature status.<br>0 = normal.<br>Bit0 = 1: Temperature threshold 1 has been exceeded.<br>Bit1 = 1: Temperature threshold 2 has been exceeded.<br>Bit2 = 1: Fault in temperature measurement.  |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 101         | Measured temperature (10 000 digits/ °C).  |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 200         | Bit-coded voltage status.<br>0 = normal.<br>Bit0 = 1: L1+ (24 V) is faulty.<br>Bit1 = 1: L2+ (24 V) is faulty.   |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 201         | Not used!  |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 202         |  |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 203         |  |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 300         | Comparator 24 V undervoltage (BOOL).   |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 1001...1032 | Status of the channels 1...32. <table border="1"> <thead> <tr> <th>Coding</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0x0001</td><td>Fault in hardware unit (submodule).</td></tr> <tr> <td>0x0002</td><td>Channel fault due to internal fault.</td></tr> <tr> <td>0x0400</td><td>SC / OC limits violated or<br/>Channel or module fault.</td></tr> <tr> <td>0x2000</td><td>Underflow or overflow of the measured value.</td></tr> <tr> <td>0x4000</td><td>Channel not configured.</td></tr> </tbody> </table> | Coding | Description | 0x0001 | Fault in hardware unit (submodule). | 0x0002 | Channel fault due to internal fault. | 0x0400 | SC / OC limits violated or<br>Channel or module fault. | 0x2000 | Underflow or overflow of the measured value. | 0x4000 | Channel not configured. |
| Coding      | Description  |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 0x0001      | Fault in hardware unit (submodule).  |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 0x0002      | Channel fault due to internal fault.   |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 0x0400      | SC / OC limits violated or<br>Channel or module fault.   |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 0x2000      | Underflow or overflow of the measured value.   |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |
| 0x4000      | Channel not configured.  |        |             |        |                                     |        |                                      |        |  |        |  |        |                         |

Table 24: Coding for *Diagnostic Status* [DWORD]

## 4.4 Connection Variants

This chapter describes the technically proper wiring of the module. The following connection variants are permitted.

**i**

The mechanical contacts must be connected to a resistor combination, e.g., 1 k $\Omega$  and 10 k $\Omega$ , to detect open-circuits and short-circuits, see also Chapter 3.4.1 and Chapter 3.5.

### 4.4.1 Wiring with Proximity Switch or Wired Mechanical Contact

The inputs are wired via connector boards. Special connector boards are available for redundantly wiring the modules.

The proximity switch supplies are decoupled using diodes. This ensures that the proximity switch supplies of 2 modules can supply one proximity switch if the modules are redundant to one another.

Connector boards X-CB 005 51 (with screw terminals) or X-CB 005 53 (with cable plug) can be used to perform the wiring in accordance with Figure 13.





Figure 13: 1-Channel Proximity Switch or Wired Mechanical Contact



When redundantly wired as specified in Figure 14, the modules are inserted in the base plate next to each other and on a common connector board. Connector boards X-CB 005 52 (with screw terminals) or X-CB 005 54 (with cable plug) can be used.



### 1 Proximity switch supply

## 2 Processing of analog measured value

Figure 14: Redundant Proximity Switch or Wired Mechanical Contact

#### 4.4.2 Wiring Transmitters via Field Termination Assembly

Proximity switches are connected via the X-FTA 002 01 as described in Figure 15. For further information, refer to the X-FTA 002 01 manual (HI 801 117 E).




Figure 15: Connection via Field Termination Assembly

#### 4.4.3 Redundant Connection via 2 Base Plates

The figure shows the connection of one proximity switch or wired contact if the redundant modules are inserted in different base plates or not located adjacently in the rack. The shunts are placed on the field termination assembly.




Figure 16: Redundant Connection via 2 Base Plates

## 5 Operation

The module runs within a HIMax base plate and does not require any specific monitoring.

### 5.1 Handling

Direct handling of the module is not foreseen.

The module is operated from within the PADT, e.g., for forcing the digital inputs. For further details, refer to the SILworX documentation.

### 5.2 Diagnostics

LEDs on the front side of the module indicate the module state, see Chapter 3.4.2.

The diagnostic history of the module can also be read out using SILworX. Chapter 4.3.4 and Chapter 4.3.5 describe the most important diagnostic statuses.

---

#### **i**

If a module is plugged in to a base plate, it generates diagnostic messages during its initialization phase indicating faults such as incorrect voltage values.

These messages only indicate a module fault if they occur after the system starts operation.

---

## 6 Maintenance

Defective modules must be replaced with a faultless module of the same type or with an approved replacement model.

When replacing modules, observe the instructions specified in the system manual (HI 801 001 E).

### 6.1 Maintenance Measures

As part of product maintenance, HIMA is continuously improving the operating systems of the modules. HIMA recommends using system downtimes to load the current operating system versions into the modules.

---

#### i

The current operating system versions of modules are displayed in the SILworX Control Panel. The type label specifies the delivered module version, see Chapter 3.3.

---

Before loading operating systems into the modules, check the system compatibilities and restrictions of the operating system versions. To this end, use the applicable release notes. Use SILworX to load the operating systems into the modules and ensure that these are in the STOP state.

## 7 Decommissioning

To decommission the module, remove it from the base plate. For more details, refer to Chapter *Mounting and Removing the Module*.

## **8 Transport**

To avoid mechanical damage, the components must be transported in packaging.

Always store the components in their original product packaging. This packaging also provides protection against electrostatic discharge (ESD). Note that the product packaging alone is not sufficient for transport.

## 9 Disposal

Industrial customers are responsible for correctly disposing of decommissioned hardware. Upon request, a disposal agreement can be arranged with HIMA.

All materials must be disposed of in an ecologically sound manner.





## Appendix

### Glossary

| Term              | Description   |
|-------------------|---|
| AI                | Analog input  |
| AO                | Analog output   |
| ARP               | Address resolution protocol, ne2rk protocol for assigning the ne2rk addresses to hardware addresses   |
| COM               | Communication module  |
| CRC               | Cyclic redundancy check   |
| DI                | Digital input   |
| DO                | Digital output  |
| EMC               | Electromagnetic compatibility   |
| EN                | European standard   |
| ESD               | Electrostatic discharge   |
| FB                | Fieldbus  |
| FBD               | Function block diagrams   |
| HW                | Hardware  |
| ICMP              | Internet control message protocol, ne2rk protocol for status or error messages                        |
| IEC               | International electrotechnical commission   |
| Interference-free | Inputs are designed for interference-free operation and can be used in circuits with safety functions |
| MAC               | Media access control address, hardware address of one ne2rk connection                                |
| PADT              | Programming and debugging tool (in accordance with IEC 61131-3), PC with SILworX                      |
| PELV              | Protective extra low voltage  |
| PES               | Programmable electronic system  |
| R                 | Read, the variable is read out  |
| R/W               | Read/Write, column title for system variable type   |
| Rack ID           | Base plate identification (number)  |
| $i_P$             | Peak value of a total AC component  |
| SB                | System bus (module)   |
| SC/OC             | Short-circuit/open-circuit  |
| SELV              | Safety extra low voltage  |
| SFF               | Safe failure fraction, portion of faults that can be safely controlled                                |
| SIL               | Safety integrity level (in accordance with IEC 61508)   |
| SILworX           | Programming tool  |
| SNTP              | Simple ne2rk time protocol (RFC 1769)   |
| SRS               | System.Rack.Slot, addressing of a module  |
| SW                | Software  |
| TMO               | Timeout   |
| W                 | Write, the variable receives a value, e.g., from the user program                                     |
| WD                | Watchdog, device for monitoring the system's correct operation. Signal for fault-free process         |
| WDT               | Watchdog time   |

**Index of Figures**

|                   |  |           |
|-------------------|--|-----------|
| <b>Figure 1:</b>  | <b>Sample Type Label</b>   | <b>10</b> |
| <b>Figure 2:</b>  | <b>Block Diagram</b>   | <b>11</b> |
| <b>Figure 3:</b>  | <b>Indicators</b>  | <b>12</b> |
| <b>Figure 4:</b>  | <b>Views</b>   | <b>16</b> |
| <b>Figure 5:</b>  | <b>Coding Example</b>  | <b>19</b> |
| <b>Figure 6:</b>  | <b>Connector Boards with Screw Terminals</b>                                 | <b>20</b> |
| <b>Figure 7:</b>  | <b>Connector Boards with Cable Plug</b>                                      | <b>22</b> |
| <b>Figure 8:</b>  | <b>X-CB 005 55 Mono Connector Board with Cable Plug</b>                      | <b>24</b> |
| <b>Figure 9:</b>  | <b>System Cables</b>   | <b>26</b> |
| <b>Figure 10:</b> | <b>Example of how to Insert the Mono Connector Board</b>                     | <b>29</b> |
| <b>Figure 11:</b> | <b>Example of how to Secure the Mono Connector Board with Captive Screws</b> | <b>30</b> |
| <b>Figure 12:</b> | <b>Mounting and Removing a Module</b>  | <b>32</b> |
| <b>Figure 13:</b> | <b>1-Channel Proximity Switch or Wired Mechanical Contact</b>                | <b>40</b> |
| <b>Figure 14:</b> | <b>Redundant Proximity Switch or Wired Mechanical Contact</b>                | <b>41</b> |
| <b>Figure 15:</b> | <b>Connection via Field Termination Assembly</b>                             | <b>42</b> |
| <b>Figure 16:</b> | <b>Redundant Connection via 2 Base Plates</b>                                | <b>43</b> |

**Index of Tables**

|                  |   |           |
|------------------|---|-----------|
| <b>Table 1:</b>  | <b>Additional Applicable Manuals</b>                                  | <b>5</b>  |
| <b>Table 2:</b>  | <b>Blinking Frequencies of the LEDs</b>                               | <b>13</b> |
| <b>Table 3:</b>  | <b>Module Status Indicators</b>                                       | <b>14</b> |
| <b>Table 4:</b>  | <b>System Bus Indicators</b>  | <b>15</b> |
| <b>Table 5:</b>  | <b>I/O Indicators</b>   | <b>15</b> |
| <b>Table 6:</b>  | <b>Product Data</b>   | <b>16</b> |
| <b>Table 7:</b>  | <b>Specifications for Digital Inputs</b>                              | <b>17</b> |
| <b>Table 8:</b>  | <b>Standard Values for Digital Inputs</b>                             | <b>17</b> |
| <b>Table 9:</b>  | <b>Supply Specifications</b>  | <b>17</b> |
| <b>Table 10:</b> | <b>Available Connector Boards</b>                                     | <b>18</b> |
| <b>Table 11:</b> | <b>Position of Coding Wedges</b>                                      | <b>19</b> |
| <b>Table 12:</b> | <b>Terminal Assignment for Connector Boards with Screw Terminals</b>  | <b>21</b> |
| <b>Table 13:</b> | <b>Cable Plug Characteristics</b>                                     | <b>21</b> |
| <b>Table 14:</b> | <b>Pin Assignment for the System Cable Plug</b>                       | <b>23</b> |
| <b>Table 15:</b> | <b>Pin Assignment for the System Cable Plug</b>                       | <b>25</b> |
| <b>Table 16:</b> | <b>Cable Data X-CA 002</b>  | <b>26</b> |
| <b>Table 17:</b> | <b>Available System Cables X-CA 002</b>                               | <b>26</b> |
| <b>Table 18:</b> | <b>Cable Data X-CA 009</b>  | <b>27</b> |
| <b>Table 19:</b> | <b>Available System Cables X-CA 009</b>                               | <b>27</b> |
| <b>Table 20:</b> | <b>The Module Tab in the Hardware Editor</b>                          | <b>34</b> |
| <b>Table 21:</b> | <b>The I/O Submodule DI 32_52 Tab in the Hardware Editor</b>          | <b>36</b> |
| <b>Table 22:</b> | <b>The I/O Submodule DI32_52: Channels Tab in the Hardware Editor</b> | <b>38</b> |
| <b>Table 23:</b> | <b>Coding of <i>Submodule Status [DWORD]</i></b>                      | <b>38</b> |
| <b>Table 24:</b> | <b>Coding for <i>Diagnostic Status [DWORD]</i></b>                    | <b>39</b> |

Index

|                             |    |                                   |    |
|-----------------------------|----|-----------------------------------|----|
| Block diagram .....         | 11 | Light emitting diodes, LEDs ..... | 13 |
| Connection variant .....    | 41 | Module status indicators .....    | 14 |
| Connector board .....       | 18 | Safety function .....             | 9  |
| with cable plug.....        | 23 | Specifications.....               | 16 |
| with screw terminals .....  | 20 | Inputs .....                      | 17 |
| Diagnostics                 |    | Module .....                      | 16 |
| I/O indicators .....        | 15 | Proximity switch supply .....     | 17 |
| System bus indicators ..... | 15 |                                   |    |



MANUAL  
X-DI 32 52

---

HI 801 175 E


For further information, please contact:

**HIMA Paul Hildebrandt GmbH**

Albert-Bassermann-Str. 28  
68782 Brühl, Germany

Phone: +49 6202 709-0  
Fax +49 6202 709-107  
E-mail: [info@hima.com](mailto:info@hima.com)

Learn more about HIMax online:

 <https://www.hima.com/en/products-services/himax/>



[www.hima.com](http://www.hima.com)