



## Manic SPS Switch

### Performance Level Setting Instructions



When making performance level changes the engine can be running. For safety please STOP the car before making any ECU performance level changes.

***Do not attempt to make ECU performance level changes while the car is moving.***

1. Select switch position on the SPS for the desired Performance Level
2. Plug SPS into OBDII Port under the dash, adjacent to the left side foot well panel (kick panel)
3. When you hear "3 CONSECUTIVE BEEPS" the performance level change has been completed. The 3 BEEP SEQUENCE will continue until the SPS switch is removed.
4. Remove the SPS from OBD II connection.



**CAUTION:** Do not allow your dealer or anyone else to re-flash your ECU with a stock or any other program. Doing so will erase the Manic Performance Tune. It cannot be restored for free. The programming fee has to be paid again to get the performance flash re-installed. (This is because of the anti-pirating software lock installed by Manic)



## SPS Settings

**SWITCH POSITION 0 = DO NOT USE**

**SWITCH POSITION 1 = Stock Power Level**

**SWITCH POSITION 2 = Performance Level A (approx. 25% of total power increase)**

**SWITCH POSITION 3 = Performance Level B (approx. 50% of total power increase)**

**SWITCH POSITION 4 = Performance Level C | MAXIMUM POWER | (100% power increase)**

**SWITCH POSITION 5-9 = NOT USED**