

Sowillo IoT Board WiFi Connection HOWTO

This article describes configuring Sowilo Box to be used with the user WiFi network.

Sowillo IoT board comes with a pre-flashed firmware that will connect to a Sowillo MQTT server.

First, you need to connect your Sowillo IoT board to WiFi. This can be done via the captive portal in a few steps:

- Wait 5 seconds after switching board to Captive Portal with Ext Button and find "SowilloSetup" WiFi network
- Connect to "SowilloSetup" without password
- Open the SignIn page from Android messages, select "Configure WiFi" option and wait for WiFi networks scan finished.
- Select Your WiFi network from the list enter Your Password. fields "WiFi_SSID_Name" and "Password" should be filled, then save settings.

13:18 4G

Sign in to SowilloSetup
192.168.4.1

Sowillo Configurator

Box ID: 9c9c1fc5-873e

SSID

password

kids

100%

ph_net

100%

TP_LINK_KALINA

64%

Static IP

10.0.1.99

Static Gateway

10.0.1.1

Subnet

255.255.255.0

Save

WiFi Setup