

SD Data logger Configuration

1) Meter Configurations

- a) Connect the meter to power
- b) M52 Send Log-Data to
 - i) Press **M**, **5**, and **2** to go to Menu 52;
 - ii) Press **ENT** to enter edit mode. Change it to 0. Internal SerBus by pressing **▼/-**. Press **ENT** to confirm.
- c) M50 Data Logger Option
 - i) Press **M**, **5**, and **0** to go to Menu 50;
 - ii) Press **ENT** to enter edit mode. Change Data Logger Option to ON by pressing **▼/-**. Press **ENT** to confirm and go to next;
 - iii) Go to the data you want to record by pressing **▲/+** or **▼/-** and repeating last step.
- d) M51 Data Logger Setup
 - i) Press **M**, **5**, and **1** to go to Menu 51;
 - ii) Press **ENT** to enter edit mode. To start recording immediately leave the Start Time to **:**:** (HH:mm:ss), otherwise key in the time with keypad. Press **ENT** to confirm and go to next;
*Note: Press **.** to enter **
 - iii) Set the record interval (HH:mm:ss) using the keypad. Press **ENT** to confirm and go to next;
 - iv) Set the Log Times using the keypad. Press **ENT** to confirm and start recording.
Note: Set Log Times to 9999 for non-stop recording.

2) SD Data Logger

- a) Check the SD card and make sure it is not locked;



- b) Plug the SD card to SD-USB convertor, and plug the convertor to computer;



- c) Try to read and write on the card to make sure the card is working properly.

3) Wiring

- a) Disconnect the power of the meter;
- b) Remove the four screws;



- c) Check if the cable is properly connected.

