



Software Developers Kit

SDK-ATEM Switchers

February 2021

Mac OS™

Windows™

Contents

Introduction	35
Welcome	35
Overview	35
Section 1 — API Design	35
1.1 Overview	35
1.2 Object Model	35
1.3 Object Interfaces	36
1.4 Reference Counting	36
1.5 Interface Stability	36
1.5.1 New Interfaces	36
1.5.2 Updated Interfaces	36
1.5.3 Deprecated Interfaces	37
1.5.4 Removed Interfaces	37
1.6 Interface Reference	37
1.6.1 IUnknown Interface	37
1.6.1.1 IUnknown::QueryInterface method	37
1.6.1.2 IUnknown::AddRef method	38
1.6.1.3 IUnknown::Release method	38
1.7 Using the Switcher API in a project	38
1.7.1 Basic Types	38
1.7.2 Accessing Switcher devices	40
1.7.2.1 Windows	40
1.7.2.2 macOS OS	40
Section 2 — Basic Switcher Control	41
2.1 General Information	41
2.1.1 Switcher Configuration and Transitions	41
2.1.2 Switcher Interface Diagram	41
2.2 Switcher Data Types	42
2.2.1 Basic Switcher Data Types	42
2.2.2 Switcher Event Type	42
2.2.3 Switcher Power Status	42
2.2.4 Switcher Video Mode	43
2.2.5 Switcher Down Conversion Methods	44
2.2.6 Switcher Input Event Type	44
2.2.7 Switcher External Port Types	45
2.2.8 Switcher Port Types	45
2.2.9 Switcher Input Availability	46
2.2.10 Switcher Mix Effect Block Events	46
2.2.11 Switcher Connection Errors	47

2.2.12	Switcher MultiView Layouts	47
2.2.13	Switcher Serial Port Functions	48
2.2.14	Switcher 3G-SDI Output Levels	48
2.2.15	Switcher Mix Minus Output Audio Modes	48
2.2.16	Switcher Color Events	48
2.2.17	Switcher Aux Events	48
2.2.18	Switcher MultiView Events	49
2.2.19	Switcher Serial Port Events	49
2.2.20	Switcher Mix Minus Output Events	49
2.2.21	Save And Recall Type	49
2.2.22	Switcher TimeCode Mode Type	50
2.3	Interface Reference	50
2.3.1	IBMDSwitcherDiscovery Interface	50
2.3.1.1	IBMDSwitcherDiscovery::ConnectTo method	50
2.3.2	IBMDSwitcher Interface	51
2.3.2.1	IBMDSwitcher::GetProductName method	52
2.3.2.2	IBMDSwitcher::GetVideoMode method	52
2.3.2.3	IBMDSwitcher::SetVideoMode method	53
2.3.2.4	IBMDSwitcher::DoesSupportVideoMode method	53
2.3.2.5	IBMDSwitcher::DoesVideoModeChangeRequireReconfiguration method	54
2.3.2.6	IBMDSwitcher::GetMethodForDownConvertedSD method	54
2.3.2.7	IBMDSwitcher::SetMethodForDownConvertedSD method	55
2.3.2.8	IBMDSwitcher::GetDownConvertedHDVideoMode method	55
2.3.2.9	IBMDSwitcher::SetDownConvertedHDVideoMode method	56
2.3.2.10	IBMDSwitcher::DoesSupportDownConvertedHDVideoMode method	56
2.3.2.11	IBMDSwitcher::GetMultiViewVideoMode method	57
2.3.2.12	IBMDSwitcher::SetMultiViewVideoMode method	57
2.3.2.13	IBMDSwitcher::Get3GSDIOutputLevel method	58
2.3.2.14	IBMDSwitcher::Set3GSDIOutputLevel method	58
2.3.2.15	IBMDSwitcher::DoesSupportMultiViewVideoMode method	59
2.3.2.16	IBMDSwitcher::GetPowerStatus method	59
2.3.2.17	IBMDSwitcher::GetTimeCode method	60
2.3.2.18	IBMDSwitcher::SetTimeCode method	60
2.3.2.19	IBMDSwitcher::RequestTimeCode method	61
2.3.2.20	IBMDSwitcher::GetTimeCodeLocked method	61
2.3.2.21	IBMDSwitcher::GetTimeCodeMode method	61
2.3.2.22	IBMDSwitcher::SetTimeCodeMode method	62
2.3.2.23	IBMDSwitcher::GetAreOutputsConfigurable method	62
2.3.2.24	IBMDSwitcher::GetSuperSourceCascade method	63
2.3.2.25	IBMDSwitcher::SetSuperSourceCascade method	63
2.3.2.26	IBMDSwitcher::DoesSupportAutoVideoMode method	64
2.3.2.27	IBMDSwitcher::GetAutoVideoMode method	64
2.3.2.28	IBMDSwitcher::GetAutoVideoModeDetected method	65
2.3.2.29	IBMDSwitcher::SetAutoVideoMode method	65
2.3.2.30	IBMDSwitcher::Createliterator method	66

2.3.2.31	BMDSwitcher::AddCallback method	66
2.3.2.32	BMDSwitcher::RemoveCallback method	67
2.3.3	BMDSwitcherCallback Interface	67
2.3.3.1	BMDSwitcherCallback::Notify method	68
2.3.4	BMDSwitcherInputIterator Interface	68
2.3.4.1	BMDSwitcherInputIterator::Next method	69
2.3.4.2	BMDSwitcherInputIterator::GetById method	69
2.3.5	BMDSwitcherInput Interface	70
2.3.5.1	BMDSwitcherInput::AddCallback method	71
2.3.5.2	BMDSwitcherInput::RemoveCallback method	71
2.3.5.3	BMDSwitcherInput::GetInputId method	72
2.3.5.4	BMDSwitcherInput::GetPortType method	72
2.3.5.5	BMDSwitcherInput::GetInputAvailability method	73
2.3.5.6	BMDSwitcherInput::SetShortName method	73
2.3.5.7	BMDSwitcherInput::GetShortName method	74
2.3.5.8	BMDSwitcherInput::SetLongName method	74
2.3.5.9	BMDSwitcherInput::GetLongName method	75
2.3.5.10	BMDSwitcherInput::AreNamesDefault method	75
2.3.5.11	BMDSwitcherInput::ResetNames method	76
2.3.5.12	BMDSwitcherInput::IsProgramTallied method	76
2.3.5.13	BMDSwitcherInput::IsPreviewTallied method	76
2.3.5.14	BMDSwitcherInput::GetAvailableExternalPortTypes method	77
2.3.5.15	BMDSwitcherInput::SetCurrentExternalPortType method	77
2.3.6	BMDSwitcherInputCallback Interface	78
2.3.6.1	BMDSwitcherInputCallback::Notify method	78
2.3.7	BMDSwitcherMixEffectBlockIterator Interface	79
2.3.7.1	BMDSwitcherMixEffectBlockIterator::Next method	79
2.3.8	BMDSwitcherMixEffectBlock Interface	80
2.3.8.1	BMDSwitcherMixEffectBlock::GetProgramInput method	81
2.3.8.2	BMDSwitcherMixEffectBlock::SetProgramInput method	81
2.3.8.3	BMDSwitcherMixEffectBlock::GetPreviewInput method	82
2.3.8.4	BMDSwitcherMixEffectBlock::SetPreviewInput method	82
2.3.8.5	BMDSwitcherMixEffectBlock::GetPreviewLive method	83
2.3.8.6	BMDSwitcherMixEffectBlock::GetPreviewTransition method	83
2.3.8.7	BMDSwitcherMixEffectBlock::SetPreviewTransition method	83
2.3.8.8	BMDSwitcherMixEffectBlock::PerformAutoTransition method	84
2.3.8.9	BMDSwitcherMixEffectBlock::PerformCut method	84
2.3.8.10	BMDSwitcherMixEffectBlock::GetInTransition method	84
2.3.8.11	BMDSwitcherMixEffectBlock::GetTransitionPosition method	85
2.3.8.12	BMDSwitcherMixEffectBlock::SetTransitionPosition method	85
2.3.8.13	BMDSwitcherMixEffectBlock::GetTransitionFramesRemaining method	85
2.3.8.14	BMDSwitcherMixEffectBlock::PerformFadeToBlack method	86
2.3.8.15	BMDSwitcherMixEffectBlock::GetFadeToBlackRate method	86
2.3.8.16	BMDSwitcherMixEffectBlock::SetFadeToBlackRate method	86
2.3.8.17	BMDSwitcherMixEffectBlock::GetFadeToBlackFramesRemaining method	87

2.3.8.18	IBMDSwitcherMixEffectBlock::GetFadeToBlackFullyBlack method	87
2.3.8.19	IBMDSwitcherMixEffectBlock::SetFadeToBlackFullyBlack method	87
2.3.8.20	IBMDSwitcherMixEffectBlock::GetInFadeToBlack method	88
2.3.8.21	IBMDSwitcherMixEffectBlock::GetFadeToBlackInTransition method	88
2.3.8.22	IBMDSwitcherMixEffectBlock::GetInputAvailabilityMask method	89
2.3.8.23	IBMDSwitcherMixEffectBlock::CreateIterator method	89
2.3.8.24	IBMDSwitcherMixEffectBlock::AddCallback method	90
2.3.8.25	IBMDSwitcherMixEffectBlock::RemoveCallback method	90
2.3.9	IBMDSwitcherMixEffectBlockCallback Interface	91
2.3.9.1	IBMDSwitcherMixEffectBlockCallback::Notify method	91
2.3.10	IBMDSwitcherInputColor Interface	92
2.3.10.1	IBMDSwitcherInputColor::GetHue method	92
2.3.10.2	IBMDSwitcherInputColor::SetHue method	93
2.3.10.3	IBMDSwitcherInputColor::GetSaturation method	93
2.3.10.4	IBMDSwitcherInputColor::SetSaturation method	93
2.3.10.5	IBMDSwitcherInputColor::GetLuma method	94
2.3.10.6	IBMDSwitcherInputColor::SetLuma method	94
2.3.10.7	IBMDSwitcherInputColor::AddCallback method	95
2.3.10.8	IBMDSwitcherInputColor::RemoveCallback method	95
2.3.11	IBMDSwitcherInputColorCallback Interface	96
2.3.11.1	IBMDSwitcherInputColorCallback::Notify method	96
2.3.12	IBMDSwitcherInputAux Interface	97
2.3.12.1	IBMDSwitcherInputAux::GetInputSource method	97
2.3.12.2	IBMDSwitcherInputAux::SetInputSource method	98
2.3.12.3	IBMDSwitcherInputAux::GetInputAvailabilityMask method	98
2.3.12.4	IBMDSwitcherInputAux::AddCallback method	99
2.3.12.5	IBMDSwitcherInputAux::RemoveCallback method	99
2.3.13	IBMDSwitcherInputAuxCallback Interface	100
2.3.13.1	IBMDSwitcherInputAuxCallback::Notify method	100
2.3.14	IBMDSwitcherMultiViewIterator Interface	101
2.3.14.1	IBMDSwitcherMultiViewIterator::Next method	101
2.3.15	IBMDSwitcherMultiView Interface	102
2.3.15.1	IBMDSwitcherMultiView::CanChangeLayout method	103
2.3.15.2	IBMDSwitcherMultiView::GetLayout method	103
2.3.15.3	IBMDSwitcherMultiView::SetLayout method	104
2.3.15.4	IBMDSwitcherMultiView::SupportsQuadrantLayout method	104
2.3.15.5	IBMDSwitcherMultiView::GetWindowInput method	105
2.3.15.6	IBMDSwitcherMultiView::SetWindowInput method	105
2.3.15.7	IBMDSwitcherMultiView::GetWindowCount method	106
2.3.15.8	IBMDSwitcherMultiView::GetInputAvailabilityMask method	106
2.3.15.9	IBMDSwitcherMultiView::CanRouteInputs method	107
2.3.15.10	IBMDSwitcherMultiView::SupportsVuMeters method	107
2.3.15.11	IBMDSwitcherMultiView::CurrentInputSupportsVuMeter method	108
2.3.15.12	IBMDSwitcherMultiView::GetVuMeterEnabled method	108
2.3.15.13	IBMDSwitcherMultiView::SetVuMeterEnabled method	109

2.3.15.14	IBMDSwitcherMultiView::CanAdjustVuMeterOpacity method	109
2.3.15.15	IBMDSwitcherMultiView::GetVuMeterOpacity method	110
2.3.15.16	IBMDSwitcherMultiView::SetVuMeterOpacity method	110
2.3.15.17	IBMDSwitcherMultiView::CanToggleSafeAreaEnabled method	111
2.3.15.18	IBMDSwitcherMultiView::CurrentInputSupportsSafeArea method	111
2.3.15.19	IBMDSwitcherMultiView::GetSafeAreaEnabled method	112
2.3.15.20	IBMDSwitcherMultiView::SetSafeAreaEnabled method	112
2.3.15.21	IBMDSwitcherMultiView::SupportsProgramPreviewSwap method	113
2.3.15.22	IBMDSwitcherMultiView::GetProgramPreviewSwapped method	113
2.3.15.23	IBMDSwitcherMultiView::SetProgramPreviewSwapped method	114
2.3.15.24	IBMDSwitcherMultiView::AddCallback method	114
2.3.15.25	IBMDSwitcherMultiView::RemoveCallback method	115
2.3.16	IBMDSwitcherMultiViewCallback Interface	115
2.3.16.1	IBMDSwitcherMultiViewCallback::Notify method	116
2.3.17	IBMDSwitcherSerialPortIterator Interface	116
2.3.17.1	IBMDSwitcherSerialPortIterator::Next method	117
2.3.18	IBMDSwitcherSerialPort Interface	117
2.3.18.1	IBMDSwitcherSerialPort::SetFunction method	118
2.3.18.2	IBMDSwitcherSerialPort::GetFunction method	118
2.3.18.3	IBMDSwitcherSerialPort::DoesSupportFunction method	119
2.3.18.4	IBMDSwitcherSerialPort::AddCallback method	119
2.3.18.5	IBMDSwitcherSerialPort::RemoveCallback method	120
2.3.19	IBMDSwitcherSerialPortCallback Interface	120
2.3.19.1	IBMDSwitcherSerialPortCallback::Notify method	121
2.3.20	IBMDSwitcherMixMinusOutputIterator Interface	121
2.3.20.1	IBMDSwitcherMixMinusOutputIterator::Next method	122
2.3.21	IBMDSwitcherMixMinusOutput Interface	122
2.3.21.1	IBMDSwitcherMixMinusOutput::GetAvailableAudioModes method	123
2.3.21.2	IBMDSwitcherMixMinusOutput::GetAudioMode method	123
2.3.21.3	IBMDSwitcherMixMinusOutput::SetAudioMode method	124
2.3.21.4	IBMDSwitcherMixMinusOutput::HasMinusAudioInputId method	124
2.3.21.5	IBMDSwitcherMixMinusOutput::GetMinusAudioInputId method	125
2.3.21.6	IBMDSwitcherMixMinusOutput::AddCallback method	125
2.3.21.7	IBMDSwitcherMixMinusOutput::RemoveCallback method	126
2.3.22	IBMDSwitcherMixMinusOutputCallback Interface	126
2.3.22.1	IBMDSwitcherMixMinusOutputCallback::Notify method	127
2.3.23	IBMDSwitcherSaveRecall Interface	127
2.3.23.1	IBMDSwitcherSaveRecall::Save method	128
2.3.23.2	IBMDSwitcherSaveRecall::Clear method	128

Section 3 — Advanced Transitions 129

3.1	Data Types	129
3.1.1	Mix Parameters Event Type	129
3.1.2	Dip Parameters Event Type	129
3.1.3	Wipe Parameters Event Type	129

3.1.4	DVE Parameters Event Type	130
3.1.5	Stinger Parameters Event Type	130
3.1.6	Transition Parameters Event Type	131
3.1.7	Transition Style	131
3.1.8	Transition Selection	131
3.1.9	DVE Transition Style	131
3.1.10	Stinger Transition Source	132
3.2	Interface Reference	133
3.2.1	IBMDSwitcherTransitionMixParameters Interface	133
3.2.1.1	IBMDSwitcherTransitionMixParameters::GetRate method	133
3.2.1.2	IBMDSwitcherTransitionMixParameters::SetRate method	133
3.2.1.3	IBMDSwitcherTransitionMixParameters::AddCallback method	134
3.2.1.4	IBMDSwitcherTransitionMixParameters::RemoveCallback method	134
3.2.2	IBMDSwitcherTransitionMixParametersCallback Interface	135
3.2.2.1	IBMDSwitcherTransitionMixParametersCallback::Notify method	135
3.2.3	IBMDSwitcherTransitionDipParameters Interface	136
3.2.3.1	IBMDSwitcherTransitionDipParameters::GetRate method	136
3.2.3.2	IBMDSwitcherTransitionDipParameters::SetRate method	137
3.2.3.3	IBMDSwitcherTransitionDipParameters::GetInputDip method	137
3.2.3.4	IBMDSwitcherTransitionDipParameters::SetInputDip method	137
3.2.3.5	IBMDSwitcherTransitionDipParameters::AddCallback method	138
3.2.3.6	IBMDSwitcherTransitionDipParameters::RemoveCallback method	138
3.2.4	IBMDSwitcherTransitionDipParametersCallback Interface	139
3.2.4.1	IBMDSwitcherTransitionDipParametersCallback::Notify method	139
3.2.5	IBMDSwitcherTransitionWipeParametersCallback Interface	140
3.2.5.1	IBMDSwitcherTransitionWipeParametersCallback::Notify method	140
3.2.6	IBMDSwitcherTransitionWipeParameters Interface	141
3.2.6.1	IBMDSwitcherTransitionWipeParameters::GetRate method	142
3.2.6.2	IBMDSwitcherTransitionWipeParameters::SetRate method	142
3.2.6.3	IBMDSwitcherTransitionWipeParameters::GetPattern method	142
3.2.6.4	IBMDSwitcherTransitionWipeParameters::SetPattern method	143
3.2.6.5	IBMDSwitcherTransitionWipeParameters::GetBorderSize method	143
3.2.6.6	IBMDSwitcherTransitionWipeParameters::SetBorderSize method	143
3.2.6.7	IBMDSwitcherTransitionWipeParameters::GetInputBorder method	144
3.2.6.8	IBMDSwitcherTransitionWipeParameters::SetInputBorder method	144
3.2.6.9	IBMDSwitcherTransitionWipeParameters::GetSymmetry method	144
3.2.6.10	IBMDSwitcherTransitionWipeParameters::SetSymmetry method	145
3.2.6.11	IBMDSwitcherTransitionWipeParameters::GetSoftness method	145
3.2.6.12	IBMDSwitcherTransitionWipeParameters::SetSoftness method	145
3.2.6.13	IBMDSwitcherTransitionWipeParameters::GetHorizontalOffset method	146
3.2.6.14	IBMDSwitcherTransitionWipeParameters::SetHorizontalOffset method	146
3.2.6.15	IBMDSwitcherTransitionWipeParameters::GetVerticalOffset method	146
3.2.6.16	IBMDSwitcherTransitionWipeParameters::SetVerticalOffset method	147
3.2.6.17	IBMDSwitcherTransitionWipeParameters::GetReverse method	147
3.2.6.18	IBMDSwitcherTransitionWipeParameters::SetReverse method	147

3.2.6.19	IBMDSwitcherTransitionWipeParameters::GetFlipFlop method	148
3.2.6.20	IBMDSwitcherTransitionWipeParameters::SetFlipFlop method	148
3.2.6.21	IBMDSwitcherTransitionWipeParameters::AddCallback method	149
3.2.6.22	IBMDSwitcherTransitionWipeParameters::RemoveCallback method	149
3.2.7	IBMDSwitcherTransitionDVEParameters Interface	150
3.2.7.1	IBMDSwitcherTransitionDVEParameters::GetRate method	151
3.2.7.2	IBMDSwitcherTransitionDVEParameters::SetRate method	151
3.2.7.3	IBMDSwitcherTransitionDVEParameters::GetLogoRate method	152
3.2.7.4	IBMDSwitcherTransitionDVEParameters::SetLogoRate method	152
3.2.7.5	IBMDSwitcherTransitionDVEParameters::GetReverse method	152
3.2.7.6	IBMDSwitcherTransitionDVEParameters::SetReverse method	153
3.2.7.7	IBMDSwitcherTransitionDVEParameters::GetFlipFlop method	153
3.2.7.8	IBMDSwitcherTransitionDVEParameters::SetFlipFlop method	153
3.2.7.9	IBMDSwitcherTransitionDVEParameters::GetStyle method	154
3.2.7.10	IBMDSwitcherTransitionDVEParameters::SetStyle method	154
3.2.7.11	IBMDSwitcherTransitionDVEParameters::DoesSupportStyle method	155
3.2.7.12	IBMDSwitcherTransitionDVEParameters::GetNumSupportedStyles method	155
3.2.7.13	IBMDSwitcherTransitionDVEParameters::GetSupportedStyles method	156
3.2.7.14	IBMDSwitcherTransitionDVEParameters::GetInputFill method	156
3.2.7.15	IBMDSwitcherTransitionDVEParameters::SetInputFill method	157
3.2.7.16	IBMDSwitcherTransitionDVEParameters::GetInputCut method	157
3.2.7.17	IBMDSwitcherTransitionDVEParameters::SetInputCut method	158
3.2.7.18	IBMDSwitcherTransitionDVEParameters::GetFillInputAvailabilityMask method	158
3.2.7.19	IBMDSwitcherTransitionDVEParameters::GetCutInputAvailabilityMask method	159
3.2.7.20	IBMDSwitcherTransitionDVEParameters::GetEnableKey method	159
3.2.7.21	IBMDSwitcherTransitionDVEParameters::SetEnableKey method	160
3.2.7.22	IBMDSwitcherTransitionDVEParameters::GetPreMultiplied method	160
3.2.7.23	IBMDSwitcherTransitionDVEParameters::GetPreMultiplied method	160
3.2.7.24	IBMDSwitcherTransitionDVEParameters::GetClip method	161
3.2.7.25	IBMDSwitcherTransitionDVEParameters::SetClip method	161
3.2.7.26	IBMDSwitcherTransitionDVEParameters::GetGain method	161
3.2.7.27	IBMDSwitcherTransitionDVEParameters::SetGain method	162
3.2.7.28	IBMDSwitcherTransitionDVEParameters::GetInverse method	162
3.2.7.29	IBMDSwitcherTransitionDVEParameters::SetInverse method	162
3.2.7.30	IBMDSwitcherTransitionDVEParameters::AddCallback method	163
3.2.7.31	IBMDSwitcherTransitionDVEParameters::RemoveCallback method	163
3.2.8	IBMDSwitcherTransitionDVEParametersCallback Interface	164
3.2.8.1	IBMDSwitcherTransitionDVEParametersCallback::Notify method	164
3.2.9	IBMDSwitcherTransitionStingerParameters Interface	165
3.2.9.1	IBMDSwitcherTransitionStingerParameters::GetSource method	166
3.2.9.2	IBMDSwitcherTransitionStingerParameters::SetSource method	166
3.2.9.3	IBMDSwitcherTransitionStingerParameters::GetPreMultiplied method	166
3.2.9.4	IBMDSwitcherTransitionStingerParameters::SetPreMultiplied method	167
3.2.9.5	IBMDSwitcherTransitionStingerParameters::GetClip method	167
3.2.9.6	IBMDSwitcherTransitionStingerParameters::SetClip method	167

3.2.9.7	IBMDSwitcherTransitionStingerParameters::GetGain method	168
3.2.9.8	IBMDSwitcherTransitionStingerParameters::SetGain method	168
3.2.9.9	IBMDSwitcherTransitionStingerParameters::GetInverse method	168
3.2.9.10	IBMDSwitcherTransitionStingerParameters::SetInverse method	169
3.2.9.11	IBMDSwitcherTransitionStingerParameters::GetPreroll method	169
3.2.9.12	IBMDSwitcherTransitionStingerParameters::SetPreroll method	169
3.2.9.13	IBMDSwitcherTransitionStingerParameters::GetClipDuration method	170
3.2.9.14	IBMDSwitcherTransitionStingerParameters::SetClipDuration method	170
3.2.9.15	IBMDSwitcherTransitionStingerParameters::GetTriggerPoint method	170
3.2.9.16	IBMDSwitcherTransitionStingerParameters::SetTriggerPoint method	171
3.2.9.17	IBMDSwitcherTransitionStingerParameters::GetMixRate method	171
3.2.9.18	IBMDSwitcherTransitionStingerParameters::SetMixRate method	171
3.2.9.19	IBMDSwitcherTransitionStingerParameters::AddCallback method	172
3.2.9.20	IBMDSwitcherTransitionStingerParameters::RemoveCallback method	172
3.2.10	IBMDSwitcherTransitionStingerParametersCallback Interface	173
3.2.10.1	IBMDSwitcherTransitionStingerParametersCallback::Notify method	173
3.2.11	IBMDSwitcherTransitionParameters Interface	174
3.2.11.1	IBMDSwitcherTransitionParameters::GetTransitionStyle method	174
3.2.11.2	IBMDSwitcherTransitionParameters::GetNextTransitionStyle method	175
3.2.11.3	IBMDSwitcherTransitionParameters::SetNextTransitionStyle method	175
3.2.11.4	IBMDSwitcherTransitionParameters::GetTransitionSelection method	175
3.2.11.5	IBMDSwitcherTransitionParameters::SetNextTransitionSelection method	176
3.2.11.6	IBMDSwitcherTransitionParameters::GetNextTransitionSelection method	176
3.2.11.7	IBMDSwitcherTransitionParameters::AddCallback method	177
3.2.11.8	IBMDSwitcherTransitionParameters::RemoveCallback method	177
3.2.12	IBMDSwitcherTransitionParametersCallback Interface	178
3.2.12.1	IBMDSwitcherTransitionParametersCallback::Notify method	178

Section 4 — Switcher Media 179

4.1	General Information	179
4.1.1	Uploading a Still or Clip	179
4.1.2	Downloading a Still or Clip	179
4.2	Media Data Types	180
4.2.1	Switcher Pixel Format	180
4.2.2	Media Player Source Type	180
4.2.3	Media Pool Event Type	180
4.2.4	BMDSwitcherStillCaptureEventType	181
4.3	Interface Reference	181
4.3.1	IBMDSwitcherMediaPlayerCallback Interface	181
4.3.1.1	IBMDSwitcherMediaPlayerCallback::SourceChanged method	181
4.3.1.2	IBMDSwitcherMediaPlayerCallback::PlayingChanged method	182
4.3.1.3	IBMDSwitcherMediaPlayerCallback::LoopChanged method	182
4.3.1.4	IBMDSwitcherMediaPlayerCallback::AtBeginningChanged method	182
4.3.1.5	IBMDSwitcherMediaPlayerCallback::ClipFrameChanged method	183
4.3.2	IBMDSwitcherMediaPlayerIterator Interface	183

4.3.2.1	IBMDSwitcherMediaPlayerIterator::Next method	183
4.3.3	IBMDSwitcherMediaPlayer Interface	184
4.3.3.1	IBMDSwitcherMediaPlayer::GetSource method	184
4.3.3.2	IBMDSwitcherMediaPlayer::SetSource method	185
4.3.3.3	IBMDSwitcherMediaPlayer::GetPlaying method	185
4.3.3.4	IBMDSwitcherMediaPlayer::SetPlaying method	186
4.3.3.5	IBMDSwitcherMediaPlayer::GetLoop method	186
4.3.3.6	IBMDSwitcherMediaPlayer::SetLoop method	186
4.3.3.7	IBMDSwitcherMediaPlayer::GetAtBeginning method	187
4.3.3.8	IBMDSwitcherMediaPlayer::SetAtBeginning method	187
4.3.3.9	IBMDSwitcherMediaPlayer::GetClipFrame method	187
4.3.3.10	IBMDSwitcherMediaPlayer::SetClipFrame method	188
4.3.3.11	IBMDSwitcherMediaPlayer::AddCallback method	188
4.3.3.12	IBMDSwitcherMediaPlayer::RemoveCallback method	189
4.3.4	IBMDSwitcherFrame Interface	189
4.3.4.1	IBMDSwitcherFrame::GetWidth method	189
4.3.4.2	IBMDSwitcherFrame::GetHeight method	190
4.3.4.3	IBMDSwitcherFrame::GetRowBytes method	190
4.3.4.4	IBMDSwitcherFrame::GetPixelFormat method	190
4.3.4.5	IBMDSwitcherFrame::GetBytes method	191
4.3.5	IBMDSwitcherAudio Interface	191
4.3.5.1	IBMDSwitcherFrame::GetSize method	191
4.3.5.2	IBMDSwitcherAudio::GetBytes method	192
4.3.6	IBMDSwitcherLockCallback Interface	192
4.3.6.1	IBMDSwitcherLockCallback::Obtained method	192
4.3.7	IBMDSwitcherStillsCallback Interface	193
4.3.7.1	IBMDSwitcherStillsCallback::Notify method	193
4.3.8	IBMDSwitcherStills Interface	194
4.3.8.1	IBMDSwitcherStills::GetCount method	194
4.3.8.2	IBMDSwitcherStills::IsValid method	195
4.3.8.3	IBMDSwitcherStills::GetName method	195
4.3.8.4	IBMDSwitcherStills::SetName method	196
4.3.8.5	IBMDSwitcherStills::GetHash method	196
4.3.8.6	IBMDSwitcherStills::SetInvalid method	197
4.3.8.7	IBMDSwitcherStills::Lock method	197
4.3.8.8	IBMDSwitcherStills::Unlock method	198
4.3.8.9	IBMDSwitcherStills::Upload method	198
4.3.8.10	IBMDSwitcherStills::Download method	199
4.3.8.11	IBMDSwitcherStills::CancelTransfer method	199
4.3.8.12	IBMDSwitcherStills::GetProgress method	200
4.3.8.13	IBMDSwitcherStills::AddCallback method	200
4.3.8.14	IBMDSwitcherStills::RemoveCallback method	201
4.3.9	IBMDSwitcherStillCaptureCallback Interface	201
4.3.9.1	IBMDSwitcherStillCaptureCallback::Notify method	202
4.3.10	IBMDSwitcherStillCapture Interface	202

4.3.10.1	IBMDSwitcherStillCapture::IsAvailable method	203
4.3.10.2	IBMDSwitcherStillCapture::CaptureStill method	203
4.3.10.3	IBMDSwitcherStillCapture::AddCallback method	203
4.3.10.4	IBMDSwitcherStillCapture::RemoveCallback method	204
4.3.11	IBMDSwitcherClipCallback Interface	204
4.3.11.1	IBMDSwitcherClipCallback::Notify method	205
4.3.12	IBMDSwitcherClip Interface	206
4.3.12.1	IBMDSwitcherClip::GetIndex method	207
4.3.12.2	IBMDSwitcherClip::IsValid method	207
4.3.12.3	IBMDSwitcherClip::GetName method	208
4.3.12.4	IBMDSwitcherClip::SetName method	208
4.3.12.5	IBMDSwitcherClip::SetValid method	209
4.3.12.6	IBMDSwitcherClip::SetInvalid method	209
4.3.12.7	IBMDSwitcherClip::GetFrameCount method	210
4.3.12.8	IBMDSwitcherClip::GetMaxFrameCount method	210
4.3.12.9	IBMDSwitcherClip::IsFrameValid method	211
4.3.12.10	IBMDSwitcherClip::GetFrameHash method	211
4.3.12.11	IBMDSwitcherClip::IsAudioValid method	212
4.3.12.12	IBMDSwitcherClip::GetAudioName method	212
4.3.12.13	IBMDSwitcherClip::SetAudioName method	213
4.3.12.14	IBMDSwitcherClip::GetAudioHash method	213
4.3.12.15	IBMDSwitcherClip::SetAudioInvalid method	214
4.3.12.16	IBMDSwitcherClip::Lock method	214
4.3.12.17	IBMDSwitcherClip::Unlock method	215
4.3.12.18	IBMDSwitcherClip::UploadFrame method	215
4.3.12.19	IBMDSwitcherClip::DownloadFrame method	216
4.3.12.20	IBMDSwitcherClip::UploadAudio method	216
4.3.12.21	IBMDSwitcherClip::DownloadAudio method	217
4.3.12.22	IBMDSwitcherClip::CancelTransfer method	217
4.3.12.23	IBMDSwitcherClip::GetProgress method	217
4.3.12.24	IBMDSwitcherClip::AddCallback method	218
4.3.12.25	IBMDSwitcherClip::RemoveCallback method	218
4.3.13	IBMDSwitcherMediaPoolCallback Interface	219
4.3.13.1	IBMDSwitcherMediaPoolCallback::ClipFrameMaxCountsChanged method	219
4.3.13.2	IBMDSwitcherMediaPoolCallback::FrameTotalForClipsChanged method	219
4.3.14	IBMDSwitcherMediaPool Interface	220
4.3.14.1	IBMDSwitcherMediaPool::GetStills method	220
4.3.14.2	IBMDSwitcherMediaPool::GetClip method	221
4.3.14.3	IBMDSwitcherMediaPool::GetClipCount method	221
4.3.14.4	IBMDSwitcherMediaPool::CreateFrame method	222
4.3.14.5	IBMDSwitcherMediaPool::CreateAudio method	222
4.3.14.6	IBMDSwitcherMediaPool::GetFrameTotalForClips method	223
4.3.14.7	IBMDSwitcherMediaPool::GetClipMaxFrameCounts method	223
4.3.14.8	IBMDSwitcherMediaPool::Clear method	224
4.3.14.9	IBMDSwitcherMediaPool::SetClipMaxFrameCounts method	224

4.3.14.10	IBMDSwitcherMediaPool::DoesVideoModeChangeClearMediaPool method	225
4.3.14.11	IBMDSwitcherMediaPool::AddCallback method	225
4.3.14.12	IBMDSwitcherMediaPool::RemoveCallback method	226

Section 5 — Keyers 227

5.1	Key Data Types	227
5.1.1	Key Type	227
5.1.2	Fly Key Frames	227
5.1.3	Border Bevel Options	228
5.1.4	Key Event Type	228
5.1.5	Luminance Key Parameters Event Type	228
5.1.6	Chroma Key Parameters Event Type	229
5.1.7	Pattern Key Parameters Event Type	229
5.1.8	Pattern Key Parameters Event Type	230
5.1.9	DVE Key Parameters Event Type	230
5.1.10	Fly Key Parameters Event Type	231
5.1.11	Downstream Key Event Type	232
5.2	Interface Reference	233
5.2.1	IBMDSwitcherKeyIterator Interface	233
5.2.1.1	IBMDSwitcherKeyIterator::Next method	233
5.2.2	IBMDSwitcherKey Interface	234
5.2.2.1	IBMDSwitcherKey::DoesSupportAdvancedChroma method	235
5.2.2.2	IBMDSwitcherKey::GetType method	235
5.2.2.3	IBMDSwitcherKey::SetType method	235
5.2.2.4	IBMDSwitcherKey::GetInputCut method	236
5.2.2.5	IBMDSwitcherKey::SetInputCut method	236
5.2.2.6	IBMDSwitcherKey::GetInputFill method	237
5.2.2.7	IBMDSwitcherKey::SetInputFill method	237
5.2.2.8	IBMDSwitcherKey::GetFillInputAvailabilityMask method	238
5.2.2.9	IBMDSwitcherKey::GetCutInputAvailabilityMask method	238
5.2.2.10	IBMDSwitcherKey::GetOnAir method	239
5.2.2.11	IBMDSwitcherKey::SetOnAir method	239
5.2.2.12	IBMDSwitcherKey::CanBeDVEKey method	239
5.2.2.13	IBMDSwitcherKey::GetMasked method	240
5.2.2.14	IBMDSwitcherKey::SetMasked method	240
5.2.2.15	IBMDSwitcherKey::GetMaskTop method	240
5.2.2.16	IBMDSwitcherKey::SetMaskTop method	241
5.2.2.17	IBMDSwitcherKey::GetMaskBottom method	241
5.2.2.18	IBMDSwitcherKey::SetMaskBottom method	241
5.2.2.19	IBMDSwitcherKey::GetMaskLeft method	242
5.2.2.20	IBMDSwitcherKey::SetMaskLeft method	242
5.2.2.21	IBMDSwitcherKey::GetMaskRight method	242
5.2.2.22	IBMDSwitcherKey::SetMaskRight method	243
5.2.2.23	IBMDSwitcherKey::ResetMask method	243
5.2.2.24	IBMDSwitcherKey::GetTransitionSelectionMask method	243

5.2.2.25	IBMDSwitcherKey::AddCallback method	244
5.2.2.26	IBMDSwitcherKey::RemoveCallback method	244
5.2.3	IBMDSwitcherKeyCallback Interface	245
5.2.3.1	IBMDSwitcherKeyCallback::Notify method	245
5.2.4	IBMDSwitcherKeyLumaParameters Interface	246
5.2.4.1	IBMDSwitcherKeyLumaParameters::GetPreMultiplied method	246
5.2.4.2	IBMDSwitcherKeyLumaParameters::SetPreMultiplied method	247
5.2.4.3	IBMDSwitcherKeyLumaParameters::GetClip method	247
5.2.4.4	IBMDSwitcherKeyLumaParameters::SetClip method	248
5.2.4.5	IBMDSwitcherKeyLumaParameters::GetGain method	248
5.2.4.6	IBMDSwitcherKeyLumaParameters::SetGain method	248
5.2.4.7	IBMDSwitcherKeyLumaParameters::GetInverse method	249
5.2.4.8	IBMDSwitcherKeyLumaParameters::SetInverse method	249
5.2.4.9	IBMDSwitcherKeyLumaParameters::AddCallback method	250
5.2.4.10	IBMDSwitcherKeyLumaParameters::RemoveCallback method	250
5.2.5	IBMDSwitcherKeyLumaParametersCallback Interface	251
5.2.5.1	IBMDSwitcherKeyLumaParametersCallback::Notify method	251
5.2.6	IBMDSwitcherKeyChromaParameters Interface	252
5.2.6.1	IBMDSwitcherKeyChromaParameters::GetHue method	252
5.2.6.2	IBMDSwitcherKeyChromaParameters::SetHue method	253
5.2.6.3	IBMDSwitcherKeyChromaParameters::GetGain method	253
5.2.6.4	IBMDSwitcherKeyChromaParameters::SetGain method	253
5.2.6.5	IBMDSwitcherKeyChromaParameters::GetYSuppress method	254
5.2.6.6	IBMDSwitcherKeyChromaParameters::SetYSuppress method	254
5.2.6.7	IBMDSwitcherKeyChromaParameters::GetLift method	254
5.2.6.8	IBMDSwitcherKeyChromaParameters::SetLift method	255
5.2.6.9	IBMDSwitcherKeyChromaParameters::GetNarrow method	255
5.2.6.10	IBMDSwitcherKeyChromaParameters::SetNarrow method	255
5.2.6.11	IBMDSwitcherKeyChromaParameters::AddCallback method	256
5.2.6.12	IBMDSwitcherKeyChromaParameters::RemoveCallback method	256
5.2.7	IBMDSwitcherKeyChromaParametersCallback Interface	257
5.2.7.1	IBMDSwitcherKeyChromaParametersCallback::Notify method	257
5.2.8	IBMDSwitcherKeyAdvancedChromaParameters Interface	258
5.2.8.1	IBMDSwitcherKeyAdvancedChromaParameters:: GetForegroundLevel method	259
5.2.8.2	IBMDSwitcherKeyAdvancedChromaParameters::SetForegroundLevel method	260
5.2.8.3	IBMDSwitcherKeyAdvancedChromaParameters::GetBackgroundLevel method	260
5.2.8.4	IBMDSwitcherKeyAdvancedChromaParameters::SetForegroundLevel method	260
5.2.8.5	IBMDSwitcherKeyAdvancedChromaParameters::GetKeyEdge method	261
5.2.8.6	IBMDSwitcherKeyAdvancedChromaParameters::SetKeyEdge method	261
5.2.8.7	IBMDSwitcherKeyAdvancedChromaParameters::GetSpillSuppress method	261
5.2.8.8	IBMDSwitcherKeyAdvancedChromaParameters::SetSpillSuppress method	262
5.2.8.9	IBMDSwitcherKeyAdvancedChromaParameters::GetFlareSuppress method	262
5.2.8.10	IBMDSwitcherKeyAdvancedChromaParameters::SetFlareSuppress method	262
5.2.8.11	IBMDSwitcherKeyAdvancedChromaParameters::GetBrightness method	263
5.2.8.12	IBMDSwitcherKeyAdvancedChromaParameters::SetBrightness method	263

5.2.8.13	IBMDSwitcherKeyAdvancedChromaParameters::GetContrast method	263
5.2.8.14	IBMDSwitcherKeyAdvancedChromaParameters::SetContrast method	264
5.2.8.15	IBMDSwitcherKeyAdvancedChromaParameters::GetSaturation method	264
5.2.8.16	IBMDSwitcherKeyAdvancedChromaParameters::SetSaturation method	264
5.2.8.17	IBMDSwitcherKeyAdvancedChromaParameters::GetRed method	265
5.2.8.18	IBMDSwitcherKeyAdvancedChromaParameters::SetRed method	265
5.2.8.19	IBMDSwitcherKeyAdvancedChromaParameters::GetGreen method	265
5.2.8.20	IBMDSwitcherKeyAdvancedChromaParameters::SetGreen method	266
5.2.8.21	IBMDSwitcherKeyAdvancedChromaParameters::GetBlue method	266
5.2.8.22	IBMDSwitcherKeyAdvancedChromaParameters::SetBlue method	266
5.2.8.23	IBMDSwitcherKeyAdvancedChromaParameters::GetSampling ModeEnabled method	267
5.2.8.24	IBMDSwitcherKeyAdvancedChromaParameters::SetSamplingModeEnabled method	267
5.2.8.25	IBMDSwitcherKeyAdvancedChromaParameters::GetPreviewEnabled method	268
5.2.8.26	IBMDSwitcherKeyAdvancedChromaParameters::SetPreviewEnabled method	268
5.2.8.27	IBMDSwitcherKeyAdvancedChromaParameters::GetCursorXPosition method	268
5.2.8.28	IBMDSwitcherKeyAdvancedChromaParameters::SetCursorXPosition method	269
5.2.8.29	IBMDSwitcherKeyAdvancedChromaParameters::GetCursorYPosition method	269
5.2.8.30	IBMDSwitcherKeyAdvancedChromaParameters::SetCursorYPosition method	269
5.2.8.31	IBMDSwitcherKeyAdvancedChromaParameters::GetCursorSize method	270
5.2.8.32	IBMDSwitcherKeyAdvancedChromaParameters::SetCursorSize method	270
5.2.8.33	IBMDSwitcherKeyAdvancedChromaParameters::GetSampledColor method	271
5.2.8.34	IBMDSwitcherKeyAdvancedChromaParameters::SetSampledColor method	271
5.2.8.35	IBMDSwitcherKeyAdvancedChromaParameters::ResetKeyAdjustments method	272
5.2.8.36	IBMDSwitcherKeyAdvancedChromaParameters::ResetChromaCorrection method	272
5.2.8.37	IBMDSwitcherKeyAdvancedChromaParameters::ResetColorAdjustments method	272
5.2.8.38	IBMDSwitcherKeyAdvancedChromaParameters::AddCallback method	273
5.2.8.39	IBMDSwitcherKeyAdvancedChromaParameters::RemoveCallback method	273
5.2.9	IBMDSwitcherKeyAdvancedChromaParametersCallback Interface	274
5.2.9.1	IBMDSwitcherKeyAdvancedChromaParametersCallback::Notify method	274
5.2.10	IBMDSwitcherKeyPatternParameters Interface	275
5.2.10.1	IBMDSwitcherKeyPatternParameters::GetPattern method	275
5.2.10.2	IBMDSwitcherKeyPatternParameters::SetPattern method	276
5.2.10.3	IBMDSwitcherKeyPatternParameters::GetSize method	276
5.2.10.4	IBMDSwitcherKeyPatternParameters::SetSize method	277
5.2.10.5	IBMDSwitcherKeyPatternParameters::GetSymmetry method	277
5.2.10.6	IBMDSwitcherKeyPatternParameters::SetSymmetry method	277
5.2.10.7	IBMDSwitcherKeyPatternParameters::GetSoftness method	278
5.2.10.8	IBMDSwitcherKeyPatternParameters::SetSoftness method	278
5.2.10.9	IBMDSwitcherKeyPatternParameters::GetHorizontalOffset method	278
5.2.10.10	IBMDSwitcherKeyPatternParameters::SetHorizontalOffset method	279
5.2.10.11	IBMDSwitcherKeyPatternParameters::GetVerticalOffset method	279
5.2.10.12	IBMDSwitcherKeyPatternParameters::SetVerticalOffset method	279
5.2.10.13	IBMDSwitcherKeyPatternParameters::GetInverse method	280
5.2.10.14	IBMDSwitcherKeyPatternParameters::SetInverse method	280
5.2.10.15	IBMDSwitcherKeyPatternParameters::AddCallback method	281

5.2.10.16	IBMDSwitcherKeyPatternParameters::RemoveCallback method	281
5.2.11	IBMDSwitcherKeyPatternParametersCallback Interface	282
5.2.11.1	IBMDSwitcherKeyPatternParametersCallback::Notify method	282
5.2.12	IBMDSwitcherKeyDVEParameters Interface	283
5.2.12.1	IBMDSwitcherKeyDVEParameters::GetShadow method	284
5.2.12.2	IBMDSwitcherKeyDVEParameters::SetShadow method	285
5.2.12.3	IBMDSwitcherKeyDVEParameters::GetLightSourceDirection method	285
5.2.12.4	IBMDSwitcherKeyDVEParameters::SetLightSourceDirection method	285
5.2.12.5	IBMDSwitcherKeyDVEParameters::GetLightSourceAltitude method	286
5.2.12.6	IBMDSwitcherKeyDVEParameters::SetLightSourceAltitude method	286
5.2.12.7	IBMDSwitcherKeyDVEParameters::GetBorderEnabled method	286
5.2.12.8	IBMDSwitcherKeyDVEParameters::SetBorderEnabled method	287
5.2.12.9	IBMDSwitcherKeyDVEParameters::GetBorderBevel method	287
5.2.12.10	IBMDSwitcherKeyDVEParameters::SetBorderBevel method	288
5.2.12.11	IBMDSwitcherKeyDVEParameters::GetBorderWidthIn method	288
5.2.12.12	IBMDSwitcherKeyDVEParameters::SetBorderWidthIn method	289
5.2.12.13	IBMDSwitcherKeyDVEParameters::GetBorderWidthOut method	289
5.2.12.14	IBMDSwitcherKeyDVEParameters::SetBorderWidthOut method	289
5.2.12.15	IBMDSwitcherKeyDVEParameters::GetBorderSoftnessIn method	290
5.2.12.16	IBMDSwitcherKeyDVEParameters::SetBorderSoftnessIn method	290
5.2.12.17	IBMDSwitcherKeyDVEParameters::GetBorderSoftnessOut method	290
5.2.12.18	IBMDSwitcherKeyDVEParameters::SetBorderSoftnessOut method	291
5.2.12.19	IBMDSwitcherKeyDVEParameters::GetBorderBevelSoftness method	291
5.2.12.20	IBMDSwitcherKeyDVEParameters::SetBorderBevelSoftness method	291
5.2.12.21	IBMDSwitcherKeyDVEParameters::GetBorderBevelPosition method	292
5.2.12.22	IBMDSwitcherKeyDVEParameters::SetBorderBevelPosition method	292
5.2.12.23	IBMDSwitcherKeyDVEParameters::GetBorderOpacity method	292
5.2.12.24	IBMDSwitcherKeyDVEParameters::SetBorderOpacity method	293
5.2.12.25	IBMDSwitcherKeyDVEParameters::GetBorderHue method	293
5.2.12.26	IBMDSwitcherKeyDVEParameters::SetBorderHue method	293
5.2.12.27	IBMDSwitcherKeyDVEParameters::GetBorderSaturation method	294
5.2.12.28	IBMDSwitcherKeyDVEParameters::SetBorderSaturation method	294
5.2.12.29	IBMDSwitcherKeyDVEParameters::GetBorderLuma method	294
5.2.12.30	IBMDSwitcherKeyDVEParameters::SetBorderLuma method	295
5.2.12.31	IBMDSwitcherKeyDVEParameters::GetMasked method	295
5.2.12.32	IBMDSwitcherKeyDVEParameters::SetMasked method	295
5.2.12.33	IBMDSwitcherKeyDVEParameters::GetMaskTop method	296
5.2.12.34	IBMDSwitcherKeyDVEParameters::SetMaskTop method	296
5.2.12.35	IBMDSwitcherKeyDVEParameters::GetMaskBottom method	296
5.2.12.36	IBMDSwitcherKeyDVEParameters::SetMaskBottom method	297
5.2.12.37	IBMDSwitcherKeyDVEParameters::GetMaskLeft method	297
5.2.12.38	BMDSwitcherKeyDVEParameters::SetMaskLeft method	297
5.2.12.39	BMDSwitcherKeyDVEParameters::GetMaskRight method	298
5.2.12.40	BMDSwitcherKeyDVEParameters::SetMaskRight method	298
5.2.12.41	IBMDSwitcherKeyDVEParameters::ResetMask method	298

5.2.12.42	IBMDSwitcherKeyDVEParameters::AddCallback method	299
5.2.12.43	IBMDSwitcherKeyDVEParameters::RemoveCallback method	299
5.2.13	IBMDSwitcherKeyDVEParametersCallback Interface	300
5.2.13.1	IBMDSwitcherKeyDVEParametersCallback::Notify method	300
5.2.14	IBMDSwitcherKeyFlyParameters Interface	301
5.2.14.1	IBMDSwitcherKeyFlyParameters::GetFly method	302
5.2.14.2	IBMDSwitcherKeyFlyParameters::SetFly method	302
5.2.14.3	IBMDSwitcherKeyFlyParameters::GetCanFly method	302
5.2.14.4	IBMDSwitcherKeyFlyParameters::GetRate method	303
5.2.14.5	IBMDSwitcherKeyFlyParameters::SetRate method	303
5.2.14.6	IBMDSwitcherKeyFlyParameters::GetSizeX method	304
5.2.14.7	IBMDSwitcherKeyFlyParameters::SetSizeX method	304
5.2.14.8	IBMDSwitcherKeyFlyParameters::GetSizeY method	305
5.2.14.9	IBMDSwitcherKeyFlyParameters::SetSizeY method	305
5.2.14.10	IBMDSwitcherKeyFlyParameters::GetCanScaleUp method	306
5.2.14.11	IBMDSwitcherKeyFlyParameters::GetPositionX method	306
5.2.14.12	IBMDSwitcherKeyFlyParameters::SetPositionX method	307
5.2.14.13	IBMDSwitcherKeyFlyParameters::GetPositionY method	307
5.2.14.14	IBMDSwitcherKeyFlyParameters::SetPositionY method	307
5.2.14.15	IBMDSwitcherKeyFlyParameters::GetRotation method	308
5.2.14.16	IBMDSwitcherKeyFlyParameters::SetRotation method	308
5.2.14.17	IBMDSwitcherKeyFlyParameters::GetCanRotate method	308
5.2.14.18	IBMDSwitcherKeyFlyParameters::ResetRotation method	309
5.2.14.19	IBMDSwitcherKeyFlyParameters::ResetDVE method	309
5.2.14.20	IBMDSwitcherKeyFlyParameters::ResetDVEFull method	309
5.2.14.21	IBMDSwitcherKeyFlyParameters::IsKeyFrameStored method	310
5.2.14.22	IBMDSwitcherKeyFlyParameters::StoreAsKeyFrame method	310
5.2.14.23	IBMDSwitcherKeyFlyParameters::RunToKeyFrame method	311
5.2.14.24	IBMDSwitcherKeyFlyParameters::IsAtKeyFrames method	311
5.2.14.25	IBMDSwitcherKeyFlyParameters::GetKeyFrameParameters method	312
5.2.14.26	IBMDSwitcherKeyFlyParameters::IsRunning method	312
5.2.14.27	IBMDSwitcherKeyFlyParameters::AddCallback method	313
5.2.14.28	IBMDSwitcherKeyFlyParameters::RemoveCallback method	313
5.2.15	IBMDSwitcherKeyFlyParametersCallback Interface	314
5.2.15.1	IBMDSwitcherKeyFlyParametersCallback::Notify method	314
5.2.16	IBMDSwitcherKeyFlyKeyFrameParametersInterface	315
5.2.16.1	IBMDSwitcherKeyFlyKeyFrameParameters::GetSizeX method	316
5.2.16.2	IBMDSwitcherKeyFlyKeyFrameParameters::SetSizeX method	317
5.2.16.3	IBMDSwitcherKeyFlyKeyFrameParameters::GetSizeY method	317
5.2.16.4	IBMDSwitcherKeyFlyKeyFrameParameters::SetSizeY method	318
5.2.16.5	IBMDSwitcherKeyFlyKeyFrameParameters::GetCanScaleUp method	318
5.2.16.6	IBMDSwitcherKeyFlyKeyFrameParameters::GetPositionX method	319
5.2.16.7	IBMDSwitcherKeyFlyKeyFrameParameters::SetPositionX method	319
5.2.16.8	IBMDSwitcherKeyFlyKeyFrameParameters::GetPositionY method	319
5.2.16.9	IBMDSwitcherKeyFlyKeyFrameParameters::SetPositionY method	320

5.2.16.10	IBMDSwitcherKeyFlyKeyFrameParameters::GetRotation method	320
5.2.16.11	IBMDSwitcherKeyFlyKeyFrameParameters::SetRotation method	320
5.2.16.12	IBMDSwitcherKeyFlyKeyFrameParameters::GetCanRotate method	321
5.2.16.13	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderWidthOut method	321
5.2.16.14	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderWidthOut method	321
5.2.16.15	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderWidthIn method	322
5.2.16.16	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderWidthIn method	322
5.2.16.17	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSoftnessOut method	322
5.2.16.18	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSoftnessOut method	323
5.2.16.19	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSoftnessIn method	323
5.2.16.20	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSoftnessIn method	323
5.2.16.21	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderBevelSoftness method	324
5.2.16.22	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderBevelSoftness method	324
5.2.16.23	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderBevelPosition method	324
5.2.16.24	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderBevelPosition method	325
5.2.16.25	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderOpacity method	325
5.2.16.26	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderOpacity method	325
5.2.16.27	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderHue method	326
5.2.16.28	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderHue method	326
5.2.16.29	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSaturation method	326
5.2.16.30	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSaturation method	327
5.2.16.31	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLuma method	327
5.2.16.32	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLuma method	327
5.2.16.33	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLightSourceDirection method	328
5.2.16.34	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLightSourceDirection method	328
5.2.16.35	IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLightSourceAltitude method	329
5.2.16.36	IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLighSourceAltitude method	329
5.2.16.37	IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskTop method	330
5.2.16.38	IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskTop method	330
5.2.16.39	IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskBottom method	330
5.2.16.40	IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskBottom method	331
5.2.16.41	IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskLeft method	331
5.2.16.42	IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskLeft method	331
5.2.16.43	IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskRight method	332
5.2.16.44	IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskRight method	332
5.2.16.45	IBMDSwitcherKeyFlyKeyFrameParameters::AddCallback method	333
5.2.16.46	IBMDSwitcherKeyFlyKeyFrameParameters::RemoveCallback method	333
5.2.17	IBMDSwitcherKeyFlyKeyFrameParametersCallback Interface	334
5.2.17.1	IBMDSwitcherKeyFlyKeyFrameParametersCallback::Notify method	334
5.2.18	IBMDSwitcherDownstreamKeyIterator Interface	335
5.2.18.1	IBMDSwitcherDownstreamKeyIterator::Next method	335
5.2.19	IBMDSwitcherDownstreamKey Interface	336
5.2.19.1	IBMDSwitcherDownstreamKey::GetInputCut method	337
5.2.19.2	IBMDSwitcherDownstreamKey::SetInputCut method	338
5.2.19.3	IBMDSwitcherDownstreamKey::GetInputFill method	338

5.2.19.4	IBMDSwitcherDownstreamKey::SetInputFill method	339
5.2.19.5	IBMDSwitcherDownstreamKey::GetFillInputAvailabilityMask method	339
5.2.19.6	IBMDSwitcherDownstreamKey::GetCutInputAvailabilityMask method	340
5.2.19.7	IBMDSwitcherDownstreamKey::GetTie method	340
5.2.19.8	IBMDSwitcherDownstreamKey::SetTie method	341
5.2.19.9	IBMDSwitcherDownstreamKey::GetRate method	341
5.2.19.10	IBMDSwitcherDownstreamKey::SetRate method	342
5.2.19.11	IBMDSwitcherDownstreamKey::GetOnAir method	342
5.2.19.12	IBMDSwitcherDownstreamKey::SetOnAir method	343
5.2.19.13	IBMDSwitcherDownstreamKey::PerformAutoTransition method	343
5.2.19.14	IBMDSwitcherDownstreamKey::PerformAutoTransitionInDirection method	343
5.2.19.15	IBMDSwitcherDownstreamKey::IsTransitioning method	344
5.2.19.16	IBMDSwitcherDownstreamKey::IsAutoTransitioning method	344
5.2.19.17	IBMDSwitcherDownstreamKey::IsTransitionTowardsOnAir method	344
5.2.19.18	IBMDSwitcherDownstreamKey::GetFramesRemaining method	345
5.2.19.19	IBMDSwitcherDownstreamKey::GetPreMultiplied method	345
5.2.19.20	IBMDSwitcherDownstreamKey::SetPreMultiplied method	345
5.2.19.21	IBMDSwitcherDownstreamKey::GetClip method	346
5.2.19.22	IBMDSwitcherDownstreamKey::SetClip method	346
5.2.19.23	IBMDSwitcherDownstreamKey::GetGain method	346
5.2.19.24	IBMDSwitcherDownstreamKey::SetGain method	347
5.2.19.25	IBMDSwitcherDownstreamKey::GetInverse method	347
5.2.19.26	IBMDSwitcherDownstreamKey::SetInverse method	347
5.2.19.27	IBMDSwitcherDownstreamKey::GetMasked method	348
5.2.19.28	IBMDSwitcherDownstreamKey::SetMasked method	348
5.2.19.29	IBMDSwitcherDownstreamKey::GetMaskTop method	348
5.2.19.30	IBMDSwitcherDownstreamKey::SetMaskTop method	349
5.2.19.31	IBMDSwitcherDownstreamKey::GetMaskBottom method	349
5.2.19.32	IBMDSwitcherDownstreamKey::SetMaskBottom method	349
5.2.19.33	IBMDSwitcherDownstreamKey::GetMaskLeft method	350
5.2.19.34	IBMDSwitcherDownstreamKey::SetMaskLeft method	350
5.2.19.35	IBMDSwitcherDownstreamKey::GetMaskRight method	350
5.2.19.36	IBMDSwitcherDownstreamKey::SetMaskRight method	351
5.2.19.37	IBMDSwitcherDownstreamKey::ResetMask method	351
5.2.19.38	IBMDSwitcherDownstreamKey::AddCallback method	352
5.2.19.39	IBMDSwitcherDownstreamKey::RemoveCallback method	352
5.2.20	IBMDSwitcherDownstreamKeyCallback Interface	353
5.2.20.1	IBMDSwitcherDownstreamKeyCallback::Notify	353

Section 6 — SuperSource 354

6.1	SuperSource Data Types	354
6.1.1	SuperSource Box Event Type	354
6.1.2	SuperSource Border Event Type	354
6.1.3	SuperSource Input Event Type	355
6.1.4	SuperSource Art Option	355

6.2	Interface Reference	356
6.2.1	IBMDSwitcherInputSuperSource Interface	356
6.2.1.1	IBMDSwitcherInputSuperSource::GetInputCut method	357
6.2.1.2	IBMDSwitcherInputSuperSource::SetInputCut method	357
6.2.1.3	IBMDSwitcherInputSuperSource::GetInputFill method	357
6.2.1.4	IBMDSwitcherInputSuperSource::SetInputFill method	358
6.2.1.5	IBMDSwitcherInputSuperSource::GetFillInputAvailabilityMask method	358
6.2.1.6	IBMDSwitcherInputSuperSource::GetCutInputAvailabilityMask method	359
6.2.1.7	IBMDSwitcherInputSuperSource::GetArtOption method	359
6.2.1.8	IBMDSwitcherInputSuperSource::SetArtOption method	360
6.2.1.9	IBMDSwitcherInputSuperSource::GetPreMultiplied method	360
6.2.1.10	IBMDSwitcherInputSuperSource::SetPreMultiplied method	361
6.2.1.11	IBMDSwitcherInputSuperSource::GetClip method	361
6.2.1.12	IBMDSwitcherInputSuperSource::SetClip method	361
6.2.1.13	IBMDSwitcherInputSuperSource::GetGain method	362
6.2.1.14	IBMDSwitcherInputSuperSource::SetGain method	362
6.2.1.15	IBMDSwitcherInputSuperSource::GetInverse method	362
6.2.1.16	IBMDSwitcherInputSuperSource::SetInverse method	363
6.2.1.17	IBMDSwitcherInputSuperSource::SupportsBorder method	363
6.2.1.18	IBMDSwitcherInputSuperSource::AddCallback method	364
6.2.1.19	IBMDSwitcherInputSuperSource::RemoveCallback method	364
6.2.2	IBMDSwitcherInputSuperSourceCallback Interface	365
6.2.2.1	IBMDSwitcherInputSuperSourceCallback::Notify method	365
6.2.3	IBMDSwitcherSuperSourceBoxIterator Interface	366
6.2.3.1	IBMDSwitcherSuperSourceBoxIterator::Next method	366
6.2.4	IBMDSwitcherSuperSourceBox Interface	367
6.2.4.1	IBMDSwitcherSuperSourceBox::GetEnabled method	368
6.2.4.2	IBMDSwitcherSuperSourceBox::SetEnabled method	368
6.2.4.3	IBMDSwitcherSuperSourceBox::GetInputSource method	368
6.2.4.4	IBMDSwitcherSuperSourceBox::SetInputSource method	369
6.2.4.5	IBMDSwitcherSuperSourceBox::GetPositionX method	369
6.2.4.6	IBMDSwitcherSuperSourceBox::SetPositionX method	369
6.2.4.7	IBMDSwitcherSuperSourceBox::GetPositionY method	370
6.2.4.8	IBMDSwitcherSuperSourceBox::SetPositionY method	370
6.2.4.9	IBMDSwitcherSuperSourceBox::GetSize method	370
6.2.4.10	IBMDSwitcherSuperSourceBox::SetSize method	371
6.2.4.11	IBMDSwitcherSuperSourceBox::GetCropped method	371
6.2.4.12	IBMDSwitcherSuperSourceBox::SetCropped method	371
6.2.4.13	IBMDSwitcherSuperSourceBox::GetCropTop method	372
6.2.4.14	IBMDSwitcherSuperSourceBox::SetCropTop method	372
6.2.4.15	IBMDSwitcherSuperSourceBox::GetCropBottom method	372
6.2.4.16	IBMDSwitcherSuperSourceBox::SetCropBottom method	373
6.2.4.17	IBMDSwitcherSuperSourceBox::GetCropLeft method	373
6.2.4.18	IBMDSwitcherSuperSourceBox::SetCropLeft method	373
6.2.4.19	IBMDSwitcherSuperSourceBox::GetCropRight method	374

6.2.4.20	IBMDSwitcherSuperSourceBox::SetCropRight method	374
6.2.4.21	IBMDSwitcherSuperSourceBox::ResetCrop method	374
6.2.4.22	IBMDSwitcherSuperSourceBox::GetInputAvailabilityMask method	375
6.2.4.23	IBMDSwitcherSuperSourceBox::AddCallback method	375
6.2.4.24	IBMDSwitcherSuperSourceBox::RemoveCallback method	375
6.2.5	IBMDSwitcherSuperSourceBoxCallback Interface	376
6.2.5.1	IBMDSwitcherSuperSourceBoxCallback::Notify method	376
6.2.6	IBMDSwitcherSuperSourceBorder Interface	377
6.2.6.1	IBMDSwitcherSuperSourceBorder::GetBorderEnabled method	378
6.2.6.2	IBMDSwitcherSuperSourceBorder::SetBorderEnabled method	378
6.2.6.3	IBMDSwitcherSuperSourceBorder::GetBorderBevel method	378
6.2.6.4	IBMDSwitcherSuperSourceBorder::SetBorderBevel method	379
6.2.6.5	IBMDSwitcherSuperSourceBorder::GetBorderWidthOut method	379
6.2.6.7	IBMDSwitcherSuperSourceBorder::SetBorderWidthOut method	379
6.2.6.8	IBMDSwitcherSuperSourceBorder::GetBorderWidthIn method	380
6.2.6.9	IBMDSwitcherSuperSourceBorder::SetBorderWidthIn method	380
6.2.6.10	IBMDSwitcherSuperSourceBorder::GetBorderSoftnessOut method	380
6.2.6.11	IBMDSwitcherSuperSourceBorder::SetBorderSoftnessOut method	381
6.2.6.12	IBMDSwitcherSuperSourceBorder::GetBorderSoftnessIn method	381
6.2.6.13	IBMDSwitcherSuperSourceBorder::SetBorderSoftnessIn method	381
6.2.6.14	IBMDSwitcherSuperSourceBorder::GetBorderBevelSoftness method	382
6.2.6.15	IBMDSwitcherSuperSourceBorder::SetBorderBevelSoftness method	382
6.2.6.16	IBMDSwitcherSuperSourceBorder::GetBorderBevelPosition method	382
6.2.6.17	IBMDSwitcherSuperSourceBorder::SetBorderBevelPosition method	383
6.2.6.18	IBMDSwitcherSuperSourceBorder::GetBorderHue method	383
6.2.6.19	IBMDSwitcherSuperSourceBorder::SetBorderHue method	383
6.2.6.20	IBMDSwitcherSuperSourceBorder::GetBorderSaturation method	384
6.2.6.21	IBMDSwitcherSuperSourceBorder::SetBorderSaturation method	384
6.2.6.22	IBMDSwitcherSuperSourceBorder::GetBorderLuma method	384
6.2.6.23	IBMDSwitcherSuperSourceBorder::SetBorderLuma method	385
6.2.6.24	IBMDSwitcherSuperSourceBorder::GetBorderLightSourceDirection method	385
6.2.6.25	IBMDSwitcherSuperSourceBorder::SetBorderLightSourceDirection method	385
6.2.6.26	IBMDSwitcherSuperSourceBorder::GetBorderLightSourceAltitude method	386
6.2.6.27	IBMDSwitcherSuperSourceBorder::SetBorderLightSourceAltitude method	386
6.2.7	IBMDSwitcherSuperSourceBorderCallback Interface	387
6.2.7.1	IBMDSwitcherSuperSourceBorderCallback::Notify method	387

Section 7 — Audio Mixing 388

7.1	Original Audio Mixing Data Types	388
7.1.1	Original Audio Mixer Event Type	388
7.1.2	Original Audio Mixer Audio Input Identifier	388
7.1.3	Original Audio Mixer Audio Input Type	388
7.1.4	Original Audio Mixer Mix Option	388
7.1.5	Original Audio Mixer Audio Input Event Type	389
7.1.6	Original Audio Mixer Monitor Output Event Type	389

7.1.7	Original Audio Mixer Audio Headphone Output Event Type	389
7.2	Fairlight Audio Mixing Data Types	390
7.2.1	Fairlight Audio Mixer Event Type	390
7.2.2	Fairlight Audio Input Type	390
7.2.3	Fairlight Audio Input Configuration	390
7.2.4	Fairlight Audio Source Identifier	390
7.2.5	Fairlight Audio Source Type	390
7.2.6	Fairlight Audio Mix Option	391
7.2.7	Fairlight Audio Equalizer Band Shape	391
7.2.8	Fairlight Audio Equalizer Band Frequency Range	391
7.2.9	Fairlight Audio Analog Input Level	391
7.2.10	Fairlight Audio Analog Input Mic Power Mode	392
7.2.11	Fairlight Audio Input Event Type	392
7.2.12	Fairlight Audio Source Event Type	392
7.2.13	Fairlight Audio Equalizer Event Type	393
7.2.14	Fairlight Audio Equalizer Band Event Type	393
7.2.15	Fairlight Audio Dynamics Event Type	393
7.2.16	Fairlight Audio Limiter Event Type	393
7.2.17	Fairlight Audio Compressor Event Type	394
7.2.18	Fairlight Audio Expander Event Type	394
7.2.19	Fairlight Audio Headphone Output Event Type	395
7.2.20	Fairlight Audio Solo Event Type	395
7.2.21	Fairlight Analog Audio Input Event Type	395
7.3	Talkback Data Types	395
7.3.1	Switcher Talkback Event Type	395
7.3.2	Switcher Talkback ID Type	396
7.4	Original Audio Mixing Interface Reference	396
7.4.1	IBMDSwitcherAudioMixer Interface	396
7.4.1.1	IBMDSwitcherAudioMixer::GetProgramOutGain method	397
7.4.1.2	IBMDSwitcherAudioMixer::SetProgramOutGain method	397
7.4.1.3	IBMDSwitcherAudioMixer::GetProgramOutBalance method	397
7.4.1.4	IBMDSwitcherAudioMixer::GetProgramOutFollowFadeToBlack method	398
7.4.1.5	IBMDSwitcherAudioMixer::SetProgramOutFollowFadeToBlack method	398
7.4.1.6	IBMDSwitcherAudioMixer::SetProgramOutBalance method	398
7.4.1.7	IBMDSwitcherAudioMixer::GetAudioFollowVideoCrossfadeTransition	399
7.4.1.8	IBMDSwitcherAudioMixer::SetAudioFollowVideoCrossfadeTransition	399
7.4.1.9	IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable method	400
7.4.1.10	IBMDSwitcherAudioMixer::ResetProgramOutLevelNotificationPeaks method	400
7.4.1.11	IBMDSwitcherAudioMixer::ResetAllLevelNotificationPeaks method	401
7.4.1.12	IBMDSwitcherAudioMixer::AddCallback method	401
7.4.1.13	IBMDSwitcherAudioMixer::RemoveCallback method	402
7.4.1.14	IBMDSwitcherAudioMixer::CreateIterator method	402
7.4.2	IBMDSwitcherAudioMixerCallback Interface	403
7.4.2.1	IBMDSwitcherAudioMixerCallback::Notify method	403
7.4.2.2	IBMDSwitcherAudioMixerCallback::ProgramOutLevelNotification method	404

7.4.3	IBMDSwitcherAudioInputIterator Interface	404
7.4.3.1	IBMDSwitcherAudioInputIterator::Next method	405
7.4.3.2	IBMDSwitcherAudioInputIterator::GetById method	405
7.4.4	IBMDSwitcherAudioInput Interface	406
7.4.4.1	IBMDSwitcherAudioInput::GetType method	406
7.4.4.2	IBMDSwitcherAudioInput::GetCurrentExternalPortType method	407
7.4.4.3	IBMDSwitcherAudioInput::GetMixOption method	407
7.4.4.4	IBMDSwitcherAudioInput::SetMixOption method	408
7.4.4.5	IBMDSwitcherAudioInput::GetGain method	408
7.4.4.6	IBMDSwitcherAudioInput::SetGain method	409
7.4.4.7	IBMDSwitcherAudioInput::GetBalance method	409
7.4.4.8	IBMDSwitcherAudioInput::SetBalance method	410
7.4.4.9	IBMDSwitcherAudioInput::IsMixedIn method	410
7.4.4.10	IBMDSwitcherAudioInput::GetAudioInputId method	411
7.4.4.11	IBMDSwitcherAudioInput::ResetLevelNotificationPeaks method	411
7.4.4.12	IBMDSwitcherAudioInput::AddCallback method	412
7.4.4.13	IBMDSwitcherAudioInput::RemoveCallback method	412
7.4.5	IBMDSwitcherAudioInputCallback Interface	413
7.4.5.1	IBMDSwitcherAudioInputCallback::Notify method	413
7.4.5.2	IBMDSwitcherAudioInputCallback::LevelNotification method	414
7.4.6	IBMDSwitcherAudioInputXLR Interface	415
7.4.6.1	IBMDSwitcherAudioInputXLR::HasRCAToXLR method	415
7.4.6.2	IBMDSwitcherAudioInputXLR::GetRCAToXLREnabled method	416
7.4.6.3	IBMDSwitcherAudioInputXLR::SetRCAToXLREnabled method	416
7.4.6.4	IBMDSwitcherAudioInputXLR::AddCallback method	417
7.4.6.5	IBMDSwitcherAudioInputXLR::RemoveCallback method	417
7.4.7	IBMDSwitcherAudioInputXLRCallback Interface	418
7.4.7.1	IBMDSwitcherAudioInputXLRCallback::Notify method	418
7.4.8	IBMDSwitcherAudioMonitorOutputIterator Interface	419
7.4.8.1	IBMDSwitcherAudioMonitorOutputIterator::Next method	419
7.4.9	IBMDSwitcherAudioMonitorOutput Interface	420
7.4.9.1	IBMDSwitcherAudioMonitorOutput::GetMonitorEnable method	421
7.4.9.2	IBMDSwitcherAudioMonitorOutput::SetMonitorEnable method	421
7.4.9.3	IBMDSwitcherAudioMonitorOutput::GetMute method	422
7.4.9.4	IBMDSwitcherAudioMonitorOutput::SetMute method	422
7.4.9.5	IBMDSwitcherAudioMonitorOutput::GetGain method	422
7.4.9.6	IBMDSwitcherAudioMonitorOutput::SetGain method	423
7.4.9.7	IBMDSwitcherAudioMonitorOutput::GetSolo method	423
7.4.9.8	IBMDSwitcherAudioMonitorOutput::SetSolo method	423
7.4.9.9	IBMDSwitcherAudioMonitorOutput::GetSoloInput method	424
7.4.9.10	IBMDSwitcherAudioMonitorOutput::SetSoloInput method	424
7.4.9.11	IBMDSwitcherAudioMonitorOutput::GetDim method	425
7.4.9.12	IBMDSwitcherAudioMonitorOutput::SetDim method	425
7.4.9.13	IBMDSwitcherAudioMonitorOutput::GetDimLevel method	425
7.4.9.14	IBMDSwitcherAudioMonitorOutput::SetDimLevel method	426

7.4.9.15	IBMDSwitcherAudioMonitorOutput::ResetLevelNotificationPeaks method	426
7.4.9.16	IBMDSwitcherAudioMonitorOutput::AddCallback method	427
7.4.9.17	IBMDSwitcherAudioMonitorOutput::RemoveCallback method	427
7.4.10	IBMDSwitcherAudioMonitorOutputCallback Interface	428
7.4.10.1	IBMDSwitcherAudioMonitorOutputCallback::Notify method	428
7.4.10.2	IBMDSwitcherAudioMonitorOutputCallback::LevelNotification method	429
7.4.11	IBMDSwitcherAudioHeadphoneOutputIterator Interface	430
7.4.11.1	IBMDSwitcherAudioHeadphoneOutputIterator::Next method	430
7.4.12	IBMDSwitcherAudioHeadphoneOutput Interface	431
7.4.12.1	IBMDSwitcherAudioHeadphoneOutput::GetGain method	431
7.4.12.2	IBMDSwitcherAudioHeadphoneOutput::SetGain method	432
7.4.12.3	IBMDSwitcherAudioHeadphoneOutput::GetInputProgramOutGain method	432
7.4.12.4	IBMDSwitcherAudioHeadphoneOutput::SetInputProgramOutGain method	433
7.4.12.5	IBMDSwitcherAudioHeadphoneOutput::GetInputTalkbackGain method	433
7.4.12.6	IBMDSwitcherAudioHeadphoneOutput::SetInputTalkbackGain method	433
7.4.12.7	IBMDSwitcherAudioHeadphoneOutput::GetInputSidetoneGain method	434
7.4.12.8	IBMDSwitcherAudioHeadphoneOutput::SetInputSidetoneGain method	434
7.4.12.9	IBMDSwitcherAudioHeadphoneOutput::AddCallback method	435
7.4.12.10	IBMDSwitcherAudioHeadphoneOutput::RemoveCallback method	435
7.4.13	IBMDSwitcherAudioHeadphoneOutputCallback Interface	436
7.4.13.1	IBMDSwitcherAudioHeadphoneOutputCallback::Notify method	436
7.5	Fairlight Audio Mixing Interface Reference	437
7.5.1	IBMDSwitcherFairlightAudioMixer Interface	437
7.5.1.1	IBMDSwitcherFairlightAudioMixer::GetMasterOutEffect method	438
7.5.1.2	IBMDSwitcherFairlightAudioMixer::GetMasterOutFaderGain method	438
7.5.1.3	IBMDSwitcherFairlightAudioMixer::SetMasterOutFaderGain method	439
7.5.1.4	IBMDSwitcherFairlightAudioMixer::GetMasterOutFollowFadeToBlack method	439
7.5.1.5	IBMDSwitcherFairlightAudioMixer::SetMasterOutFollowFadeToBlack method	440
7.5.1.6	IBMDSwitcherFairlightAudioMixer::GetAudioFollowVideoCrossfadeTransition method	440
7.5.1.7	IBMDSwitcherFairlightAudioMixer::SetAudioFollowVideoCrossfadeTransition method	441
7.5.1.8	IBMDSwitcherFairlightAudioMixer::SetAllLevelNotificationsEnabled method	441
7.5.1.9	IBMDSwitcherFairlightAudioMixer::ResetMasterOutPeakLevels method	442
7.5.1.10	IBMDSwitcherFairlightAudioMixer::ResetAllPeakLevels method	442
7.5.1.11	IBMDSwitcherFairlightAudioMixer::CreateIterator method	442
7.5.1.12	IBMDSwitcherFairlightAudioMixer::AddCallback method	443
7.5.1.13	IBMDSwitcherFairlightAudioMixer::RemoveCallback method	443
7.5.2	IBMDSwitcherFairlightAudioMixerCallback Interface	444
7.5.2.1	IBMDSwitcherFairlightAudioMixerCallback::Notify method	444
7.5.2.2	IBMDSwitcherFairlightAudioMixerCallback::MasterOutLevelNotification method	445
7.5.3	IBMDSwitcherFairlightAudioInputIterator Interface	446
7.5.3.1	IBMDSwitcherFairlightAudioInputIterator::Next method	446
7.5.3.2	IBMDSwitcherFairlightAudioInputIterator::GetById method	447
7.5.4	IBMDSwitcherFairlightAudioInput Interface	447
7.5.4.1	IBMDSwitcherFairlightAudioInput::GetType method	448
7.5.4.2	IBMDSwitcherFairlightAudioInput::GetCurrentExternalPortType method	448

7.5.4.3	IBMDSwitcherFairlightAudioInput::GetSupportedConfigurations method	449
7.5.4.4	IBMDSwitcherFairlightAudioInput::GetConfiguration method	449
7.5.4.5	IBMDSwitcherFairlightAudioInput::SetConfiguration method	450
7.5.4.6	IBMDSwitcherFairlightAudioInput::GetId method	450
7.5.4.7	IBMDSwitcherFairlightAudioInput::CreateIterator method	451
7.5.4.8	IBMDSwitcherFairlightAudioInput::AddCallback method	451
7.5.4.9	IBMDSwitcherFairlightAudioInput::RemoveCallback method	452
7.5.5	IBMDSwitcherFairlightAudioInputCallback Interface	452
7.5.5.1	IBMDSwitcherFairlightAudioInputCallback::Notify method	453
7.5.6	IBMDSwitcherFairlightAudioSourceIterator Interface	453
7.5.6.1	IBMDSwitcherFairlightAudioSourceIterator::Next method	454
7.5.6.2	IBMDSwitcherFairlightAudioSourceIterator::GetById method	454
7.5.7	IBMDSwitcherFairlightAudioSource Interface	455
7.5.7.1	IBMDSwitcherFairlightAudioSource::IsActive method	456
7.5.7.2	IBMDSwitcherFairlightAudioSource::GetSourceType method	456
7.5.7.3	IBMDSwitcherFairlightAudioSource::GetMaxDelayFrames method	457
7.5.7.4	IBMDSwitcherFairlightAudioSource::GetDelayFrames method	457
7.5.7.5	IBMDSwitcherFairlightAudioSource::SetDelayFrames method	457
7.5.7.6	IBMDSwitcherFairlightAudioSource::GetInputGain method	458
7.5.7.7	IBMDSwitcherFairlightAudioSource::SetInputGain method	458
7.5.7.8	IBMDSwitcherFairlightAudioSource::HasStereoSimulation method	458
7.5.7.9	IBMDSwitcherFairlightAudioSource::GetStereoSimulationIntensity method	459
7.5.7.10	IBMDSwitcherFairlightAudioSource::SetStereoSimulationIntensity method	459
7.5.7.11	IBMDSwitcherFairlightAudioSource::GetEffect method	460
7.5.7.12	IBMDSwitcherFairlightAudioSource::GetPan method	460
7.5.7.13	IBMDSwitcherFairlightAudioSource::SetPan method	461
7.5.7.14	IBMDSwitcherFairlightAudioSource::GetFaderGain method	461
7.5.7.15	IBMDSwitcherFairlightAudioSource::SetFaderGain method	461
7.5.7.16	IBMDSwitcherFairlightAudioSource::GetSupportedMixOptions method	462
7.5.7.17	IBMDSwitcherFairlightAudioSource::GetMixOption method	462
7.5.7.18	IBMDSwitcherFairlightAudioSource::SetMixOption method	462
7.5.7.19	IBMDSwitcherFairlightAudioSource::IsMixedIn method	463
7.5.7.20	IBMDSwitcherFairlightAudioSource::ResetOutputPeakLevels method	463
7.5.7.21	IBMDSwitcherFairlightAudioSource::GetId method	463
7.5.7.22	IBMDSwitcherFairlightAudioSource::AddCallback method	464
7.5.7.23	IBMDSwitcherFairlightAudioSource::RemoveCallback method	464
7.5.8	IBMDSwitcherFairlightAudioSourceCallback Interface	465
7.5.8.1	IBMDSwitcherFairlightAudioSourceCallback::Notify method	465
7.5.8.2	IBMDSwitcherFairlightAudioSourceCallback::OutputLevelNotification method	466
7.5.9	IBMDSwitcherFairlightAudioEqualizer Interface	467
7.5.9.1	IBMDSwitcherFairlightAudioEqualizer::GetEnabled method	467
7.5.9.2	IBMDSwitcherFairlightAudioEqualizer::SetEnabled method	468
7.5.9.3	IBMDSwitcherFairlightAudioEqualizer::GetGain method	468
7.5.9.4	IBMDSwitcherFairlightAudioEqualizer::SetGain method	468
7.5.9.5	IBMDSwitcherFairlightAudioEqualizer::Reset method	469

7.5.9.6	IBMDSwitcherFairlightAudioEqualizer::CreateIterator method	469
7.5.9.7	IBMDSwitcherFairlightAudioEqualizer::AddCallback method	470
7.5.9.8	IBMDSwitcherFairlightAudioEqualizer::RemoveCallback method	470
7.5.10	IBMDSwitcherFairlightAudioEqualizerCallback Interface	471
7.5.10.1	IBMDSwitcherFairlightAudioEqualizerCallback::Notify method	471
7.5.11	IBMDSwitcherFairlightAudioEqualizerBandIterator Interface	472
7.5.11.1	IBMDSwitcherFairlightAudioEqualizerBandIterator::Next method	472
7.5.12	IBMDSwitcherFairlightAudioEqualizerBand Interface	473
7.5.12.1	IBMDSwitcherFairlightAudioEqualizerBand::GetEnabled method	474
7.5.12.2	IBMDSwitcherFairlightAudioEqualizerBand::SetEnabled method	474
7.5.12.3	IBMDSwitcherFairlightAudioEqualizerBand::GetSupportedShapes method	475
7.5.12.4	IBMDSwitcherFairlightAudioEqualizerBand::GetShape method	475
7.5.12.5	IBMDSwitcherFairlightAudioEqualizerBand::SetShape method	476
7.5.12.6	IBMDSwitcherFairlightAudioEqualizerBand::GetSupportedFrequencyRanges method	476
7.5.12.7	IBMDSwitcherFairlightAudioEqualizerBand::GetFrequencyRange method	477
7.5.12.8	IBMDSwitcherFairlightAudioEqualizerBand::SetFrequencyRange method	477
7.5.12.9	IBMDSwitcherFairlightAudioEqualizerBand::GetFrequencyRangeMinMax method	478
7.5.12.10	IBMDSwitcherFairlightAudioEqualizerBand::GetFrequency method	478
7.5.12.11	IBMDSwitcherFairlightAudioEqualizerBand::SetFrequency method	479
7.5.12.12	IBMDSwitcherFairlightAudioEqualizerBand::GetGain method	479
7.5.12.13	IBMDSwitcherFairlightAudioEqualizerBand::SetGain method	479
7.5.12.14	IBMDSwitcherFairlightAudioEqualizerBand::GetQFactor method	480
7.5.12.15	IBMDSwitcherFairlightAudioEqualizerBand::SetQFactor method	480
7.5.12.16	IBMDSwitcherFairlightAudioEqualizerBand::Reset method	480
7.5.12.17	IBMDSwitcherFairlightAudioEqualizerBand::AddCallback method	481
7.5.12.18	IBMDSwitcherFairlightAudioEqualizerBand::RemoveCallback method	481
7.5.13	IBMDSwitcherFairlightAudioEqualizerBandCallback Interface	482
7.5.13.1	IBMDSwitcherFairlightAudioEqualizerBandCallback::Notify method	482
7.5.14	IBMDSwitcherFairlightAudioDynamicsProcessor Interface	483
7.5.14.1	IBMDSwitcherFairlightAudioDynamicsProcessor::GetProcessor method	483
7.5.14.2	IBMDSwitcherFairlightAudioDynamicsProcessor::GetMakeupGain method	484
7.5.14.3	IBMDSwitcherFairlightAudioDynamicsProcessor::SetMakeupGain method	484
7.5.14.4	IBMDSwitcherFairlightAudioDynamicsProcessor::Reset method	484
7.5.14.5	IBMDSwitcherFairlightAudioDynamicsProcessor::ResetInput PeakLevels method	485
7.5.14.6	IBMDSwitcherFairlightAudioDynamicsProcessor::ResetOutput PeakLevels method	485
7.5.14.7	IBMDSwitcherFairlightAudioDynamicsProcessor::AddCallback method	486
7.5.14.8	IBMDSwitcherFairlightAudioDynamicsProcessor::RemoveCallback method	486
7.5.15	IBMDSwitcherFairlightAudioDynamicsProcessorCallback Interface	487
7.5.15.1	IBMDSwitcherFairlightAudioDynamicsProcessorCallback::Notify method	487
7.5.15.2	IBMDSwitcherFairlightAudioDynamicsProcessorCallback::InputLevel Notification method	488
7.5.15.3	IBMDSwitcherFairlightAudioDynamicsProcessorCallback::OutputLevel Notification method	489
7.5.16	IBMDSwitcherFairlightAudioLimiter Interface	489
7.5.16.1	IBMDSwitcherFairlightAudioLimiter::GetEnabled method	490
7.5.16.2	IBMDSwitcherFairlightAudioLimiter::SetEnabled method	490
7.5.16.3	IBMDSwitcherFairlightAudioLimiter::GetThreshold method	491

7.5.16.4	IBMDSwitcherFairlightAudioLimiter::SetThreshold method	491
7.5.16.5	IBMDSwitcherFairlightAudioLimiter::GetAttack method	491
7.5.16.6	IBMDSwitcherFairlightAudioLimiter::SetAttack method	492
7.5.16.7	IBMDSwitcherFairlightAudioLimiter::GetHold method	492
7.5.16.8	IBMDSwitcherFairlightAudioLimiter::SetHold method	492
7.5.16.9	IBMDSwitcherFairlightAudioLimiter::GetRelease method	493
7.5.16.10	IBMDSwitcherFairlightAudioLimiter::SetRelease method	493
7.5.16.11	IBMDSwitcherFairlightAudioLimiter::Reset method	493
7.5.16.12	IBMDSwitcherFairlightAudioLimiter::AddCallback method	494
7.5.16.13	IBMDSwitcherFairlightAudioLimiter::RemoveCallback method	494
7.5.17	IBMDSwitcherFairlightAudioLimiterCallback Interface	495
7.5.17.1	IBMDSwitcherFairlightAudioLimiterCallback::Notify method	495
7.5.17.2	IBMDSwitcherFairlightAudioLimiterCallback::GainReductionLevelNotification method	496
7.5.18	IBMDSwitcherFairlightAudioCompressor Interface	496
7.5.18.1	IBMDSwitcherFairlightAudioCompressor::GetEnabled method	497
7.5.18.2	IBMDSwitcherFairlightAudioCompressor::SetEnabled method	497
7.5.18.3	IBMDSwitcherFairlightAudioCompressor::GetThreshold method	498
7.5.18.4	IBMDSwitcherFairlightAudioCompressor::SetThreshold method	498
7.5.18.5	IBMDSwitcherFairlightAudioCompressor::GetAttack method	498
7.5.18.6	IBMDSwitcherFairlightAudioCompressor::SetAttack method	499
7.5.18.7	IBMDSwitcherFairlightAudioCompressor::GetHold method	499
7.5.18.8	IBMDSwitcherFairlightAudioCompressor::SetHold method	499
7.5.18.9	IBMDSwitcherFairlightAudioCompressor::GetRelease method	500
7.5.18.10	IBMDSwitcherFairlightAudioCompressor::SetRelease method	500
7.5.18.11	IBMDSwitcherFairlightAudioCompressor::Reset method	500
7.5.18.12	IBMDSwitcherFairlightAudioCompressor::AddCallback method	501
7.5.18.13	IBMDSwitcherFairlightAudioCompressor::RemoveCallback method	501
7.5.19	IBMDSwitcherFairlightAudioCompressorCallback Interface	502
7.5.19.1	IBMDSwitcherFairlightAudioCompressorCallback::Notify method	502
7.5.19.2	IBMDSwitcherFairlightAudioCompressorCallback::GainReductionLevel Notification method	503
7.5.20	IBMDSwitcherFairlightAudioExpander Interface	503
7.5.20.1	IBMDSwitcherFairlightAudioExpander::GetEnabled method	504
7.5.20.2	IBMDSwitcherFairlightAudioExpander::SetEnabled method	505
7.5.20.3	IBMDSwitcherFairlightAudioExpander::GetGateMode method	505
7.5.20.4	IBMDSwitcherFairlightAudioExpander::SetGateMode method	505
7.5.20.5	IBMDSwitcherFairlightAudioExpander::GetThreshold method	506
7.5.20.6	IBMDSwitcherFairlightAudioExpander::SetThreshold method	506
7.5.20.7	IBMDSwitcherFairlightAudioExpander::GetRange method	506
7.5.20.8	IBMDSwitcherFairlightAudioExpander::SetRange method	507
7.5.20.9	IBMDSwitcherFairlightAudioExpander::GetRatio method	507
7.5.20.10	IBMDSwitcherFairlightAudioExpander::SetRatio method	507
7.5.20.11	IBMDSwitcherFairlightAudioExpander::GetAttack method	508
7.5.20.12	IBMDSwitcherFairlightAudioExpander::SetAttack method	508
7.5.20.13	IBMDSwitcherFairlightAudioExpander::GetHold method	508
7.5.20.14	IBMDSwitcherFairlightAudioExpander::SetHold method	509

7.5.20.15	IBMDSwitcherFairlightAudioExpander::GetRelease method	509
7.5.20.16	IBMDSwitcherFairlightAudioExpander::SetRelease method	509
7.5.20.17	IBMDSwitcherFairlightAudioExpander::Reset method	510
7.5.20.18	IBMDSwitcherFairlightAudioExpander::AddCallback method	510
7.5.20.19	IBMDSwitcherFairlightAudioExpander::RemoveCallback method	511
7.5.21	IBMDSwitcherFairlightAudioExpanderCallback Interface	511
7.5.21.1	IBMDSwitcherFairlightAudioExpanderCallback::Notify method	512
7.5.21.2	IBMDSwitcherFairlightAudioExpanderCallback::GainReductionLevel Notification method	512
7.5.22	IBMDSwitcherFairlightAudioHeadphoneOutputIterator Interface	513
7.5.22.1	IBMDSwitcherFairlightAudioHeadphoneOutputIterator::Next method	513
7.5.23	IBMDSwitcherFairlightAudioHeadphoneOutput Interface	514
7.5.23.1	IBMDSwitcherFairlightAudioHeadphoneOutput::DoesSupportSolo method	515
7.5.23.2	IBMDSwitcherFairlightAudioHeadphoneOutput::DoesSupportMute method	515
7.5.23.3	IBMDSwitcherFairlightAudioHeadphoneOutput::GetGain method	516
7.5.23.4	IBMDSwitcherFairlightAudioHeadphoneOutput::SetGain method	516
7.5.23.5	IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputMasterOutGain method	517
7.5.23.6	IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputMasterOutGain method	517
7.5.23.7	IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputMasterOutMute method	518
7.5.23.8	IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputMasterOutMute method	518
7.5.23.9	IBMDSwitcherFairlightAudioHeadphoneOutput::DoesSupportTalkback method	519
7.5.23.10	IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputTalkbackGain method	519
7.5.23.11	IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputTalkbackGain method	520
7.5.23.12	IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputTalkbackMute method	520
7.5.23.13	IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputTalkbackMute method	521
7.5.23.14	IBMDSwitcherFairlightAudioHeadphoneOutput::DoesSupportSidetone method	521
7.5.23.15	IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputSidetoneGain method	522
7.5.23.16	IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputSidetoneGain method	522
7.5.23.17	IBMDSwitcherFairlightAudioHeadphoneOutput::AddCallback method	523
7.5.23.18	IBMDSwitcherFairlightAudioHeadphoneOutput::RemoveCallback method	523
7.5.24	IBMDSwitcherFairlightAudioHeadphoneOutputCallback Interface	524
7.5.24.1	IBMDSwitcherFairlightAudioHeadphoneOutputCallback::Notify method	524
7.5.25	IBMDSwitcherFairlightAnalogAudioInput Interface	525
7.5.25.1	IBMDSwitcherFairlightAnalogAudioInput::GetSupportedInputLevels method	525
7.5.25.2	IBMDSwitcherFairlightAnalogAudioInput::GetInputLevel method	526
7.5.25.3	IBMDSwitcherFairlightAnalogAudioInput::SetInputLevel method	526
7.5.25.4	IBMDSwitcherFairlightAnalogAudioInput::GetSupportedMicPowerModes method	527
7.5.25.5	IBMDSwitcherFairlightAnalogAudioInput::GetMicPowerMode method	527
7.5.25.6	IBMDSwitcherFairlightAnalogAudioInput::SetMicPowerMode method	528
7.5.25.7	IBMDSwitcherFairlightAnalogAudioInput::AddCallback method	528
7.5.25.8	IBMDSwitcherFairlightAnalogAudioInput::RemoveCallback method	529
7.5.26	IBMDSwitcherFairlightAnalogAudioInputCallback Interface	529
7.5.26.1	IBMDSwitcherFairlightAnalogAudioInputCallback::Notify method	530
7.5.27	IBMDSwitcherFairlightAudioSolo Interface	530
7.5.27.1	IBMDSwitcherFairlightAudioSolo::GetSolo method	531
7.5.27.2	IBMDSwitcherFairlightAudioSolo::SetSolo method	531

7.5.27.3	IBMDSwitcherFairlightAudioSolo::GetSoloInput method	532
7.5.27.4	IBMDSwitcherFairlightAudioSolo::SetSoloInput method	532
7.5.27.5	IBMDSwitcherFairlightAudioSolo::AddCallback method	533
7.5.27.6	IBMDSwitcherFairlightAudioSolo::RemoveCallback method	533
7.5.28	IBMDSwitcherFairlightAudioSoloCallback Interface	534
7.5.28.1	IBMDSwitcherFairlightAudioSoloCallback::Notify method	534
7.6	Talkback Interface Reference	535
7.6.1	IBMDSwitcherTalkbackIterator Interface	535
7.6.1.1	IBMDSwitcherTalkbackIterator::Next method	535
7.6.1.2	IBMDSwitcherTalkbackIterator::GetById method	536
7.6.2	IBMDSwitcherTalkback Interface	536
7.6.2.1	IBMDSwitcherTalkback::GetId method	537
7.6.2.2	IBMDSwitcherTalkback::GetMuteSDI method	537
7.6.2.3	IBMDSwitcherTalkback::SetMuteSDI method	537
7.6.2.4	IBMDSwitcherTalkback::InputCanMuteSDI method	538
7.6.2.5	IBMDSwitcherTalkback::CurrentInputSupportsMuteSDI method	538
7.6.2.6	IBMDSwitcherTalkback::GetInputMuteSDI method	539
7.6.2.7	IBMDSwitcherTalkback::SetInputMuteSDI method	539
7.6.2.8	IBMDSwitcherTalkback::AddCallback method	540
7.6.2.9	IBMDSwitcherTalkback::RemoveCallback method	540
7.6.3	IBMDSwitcherTalkbackCallback Interface	541
7.6.3.1	IBMDSwitcherTalkbackCallback::Notify method	541

Section 8 — Camera Control 542

8.1	Camera Control Data Types	542
8.1.1	Switcher Camera Control Event Type	542
8.1.2	Switcher Camera Control Parameter Type	542
8.2	Interface Reference	543
8.2.1	Switcher Camera Control Parameter Iterator	543
8.2.1.1	IBMDSwitcherCameraControlParameterIterator::Next method	543
8.2.2	IBMDSwitcherCameraControlCallback Interface	544
8.2.2.1	IBMDSwitcherCameraControlCallback::Notify method	544
8.2.3	IBMDSwitcherCameraControl Interface	545
8.2.3.1	IBMDSwitcherCameraControl::CreateIterator method	546
8.2.3.2	IBMDSwitcherCameraControl::GetPeriodicFlushInterval method	546
8.2.3.3	IBMDSwitcherCameraControl::SetPeriodicFlushInterval method	547
8.2.3.4	IBMDSwitcherCameraControl::GetParameterInfo method	547
8.2.3.5	IBMDSwitcherCameraControl::GetParameterPeriodicFlushEnabled method	548
8.2.3.6	IBMDSwitcherCameraControl::SetParameterPeriodicFlushEnabled method	548
8.2.3.7	IBMDSwitcherCameraControl::SetFlags method	549
8.2.3.8	IBMDSwitcherCameraControl::ToggleFlags method	549
8.2.3.9	IBMDSwitcherCameraControl::GetFlags method	550
8.2.3.10	IBMDSwitcherCameraControl::SetBytes method	550
8.2.3.11	IBMDSwitcherCameraControl::OffsetBytes method	551
8.2.3.12	IBMDSwitcherCameraControl::GetBytes method	551

8.2.3.13	IBMDSwitcherCameraControl::SetInt16s method	552
8.2.3.14	IBMDSwitcherCameraControl::OffsetInt16s method	552
8.2.3.15	IBMDSwitcherCameraControl::GetInt16s method	553
8.2.3.16	IBMDSwitcherCameraControl::SetInt32s method	553
8.2.3.17	IBMDSwitcherCameraControl::OffsetInt32s method	554
8.2.3.18	IBMDSwitcherCameraControl::GetInt32s method	554
8.2.3.19	IBMDSwitcherCameraControl::SetInt64s method	555
8.2.3.20	IBMDSwitcherCameraControl::OffsetInt64s method	555
8.2.3.21	IBMDSwitcherCameraControl::GetInt64s method	556
8.2.3.22	IBMDSwitcherCameraControl::OffsetFloats method	556
8.2.3.23	IBMDSwitcherCameraControl::SetFloats method	557
8.2.3.24	IBMDSwitcherCameraControl::GetFloats method	557
8.2.3.25	IBMDSwitcherCameraControl::AddCallback method	558
8.2.3.26	IBMDSwitcherCameraControl::RemoveCallback method	558

Section 9 — Macros 559

9.1	General Information	559
9.1.1	Macro Indexes and Identification	559
9.1.2	Recording a Macro	559
9.1.3	Downloading a Macro	559
9.1.4	Uploading a Macro	560
9.1.5	Unsupported Operations	560
9.2	Macro Data Types	560
9.2.1	Macro Pool Event Type	560
9.2.2	Macro Control Event Type	561
9.2.3	Macro Run Status	561
9.2.4	Macro Record Status	561
9.3	Interface Reference	561
9.3.1	IBMDSwitcherMacroPool Interface	561
9.3.1.1	IBMDSwitcherMacroPool::GetMaxCount method	562
9.3.1.2	IBMDSwitcherMacroPool::Delete method	562
9.3.1.3	IBMDSwitcherMacroPool::IsValid method	563
9.3.1.4	IBMDSwitcherMacroPool::HasUnsupportedOps method	563
9.3.1.5	IBMDSwitcherMacroPool::GetName method	564
9.3.1.6	IBMDSwitcherMacroPool::SetName method	564
9.3.1.7	IBMDSwitcherMacroPool::GetDescription method	565
9.3.1.8	IBMDSwitcherMacroPool::SetDescription method	565
9.3.1.9	IBMDSwitcherMacroPool::CreateMacro method	566
9.3.1.10	IBMDSwitcherMacroPool::Upload method	566
9.3.1.11	IBMDSwitcherMacroPool::Download method	567
9.3.1.12	IBMDSwitcherMacroPool::AddCallback method	567
9.3.1.13	IBMDSwitcherMacroPool::RemoveCallback method	568
9.3.2	IBMDSwitcherTransferMacro Interface	568
9.3.2.1	IBMDSwitcherTransferMacro::Cancel method	569
9.3.2.2	IBMDSwitcherTransferMacro::GetProgress method	569

9.3.2.3	IBMDSwitcherTransferMacro::GetMacro method	569
9.3.3	IBMDSwitcherMacro Interface	570
9.3.3.1	IBMDSwitcherMacro::GetSize method	570
9.3.3.2	IBMDSwitcherMacro::GetBytes method	570
9.3.4	IBMDSwitcherMacroPoolCallback Interface	571
9.3.4.1	IBMDSwitcherMacroPoolCallback::Notify method	571
9.3.5	IBMDSwitcherMacroControl Interface	572
9.3.5.1	IBMDSwitcherMacroControl::Run method	572
9.3.5.2	IBMDSwitcherMacroControl::GetLoop method	573
9.3.5.3	IBMDSwitcherMacroControl::SetLoop method	573
9.3.5.4	IBMDSwitcherMacroControl::ResumeRunning method	574
9.3.5.5	IBMDSwitcherMacroControl::StopRunning method	574
9.3.5.6	IBMDSwitcherMacroControl::Record method	575
9.3.5.7	IBMDSwitcherMacroControl::RecordUserWait method	575
9.3.5.8	IBMDSwitcherMacroControl::RecordPause method	576
9.3.5.9	IBMDSwitcherMacroControl::StopRecording method	576
9.3.5.10	IBMDSwitcherMacroControl::GetRunStatus method	577
9.3.5.11	IBMDSwitcherMacroControl::GetRecordStatus method	577
9.3.5.12	IBMDSwitcherMacroControl::AddCallback method	578
9.3.5.13	IBMDSwitcherMacroControl::RemoveCallback method	578
9.3.6	IBMDSwitcherMacroControlCallback Interface	579
9.3.6.1	IBMDSwitcherMacroControlCallback::Notify method	579

Section 10 — HyperDeck 580

10.1	General Information	580
10.1.1	HyperDeck Interfaces	580
10.1.2	HyperDeck Remote Control	580
10.1.3	HyperDeck Clip Cache	580
10.1.4	HyperDeck Configuration	580
10.1.5	HyperDeck Clip Cache Configuration	581
10.2	Hyperdeck Types	581
10.2.1	BMDSwitcherHyperDeckClipEventType	581
10.2.2	BMDSwitcherHyperDeckEventType	581
10.2.3	BMDSwitcherHyperDeckClipId	582
10.2.4	BMDSwitcherHyperDeckId	582
10.2.5	BMDSwitcherHyperDeckPlayerState	582
10.2.6	BMDSwitcherHyperDeckConnectionStatus	583
10.2.7	BMDSwitcherHyperDeckStorageMediaState	583
10.2.8	BMDSwitcherHyperDeckErrorType	583
10.3	Interface Reference	584
10.3.1	IBMDSwitcherHyperDeckIterator Interface	584
10.3.1.1	IBMDSwitcherHyperDeckIterator::Next method	584
10.3.1.2	IBMDSwitcherHyperDeckIterator::GetById method	585
10.3.2	IBMDSwitcherHyperDeck Interface	585
10.3.2.1	IBMDSwitcherHyperDeck::GetId method	587

10.3.2.2	IBMDSwitcherHyperDeck::GetConnectionStatus method	587
10.3.2.3	IBMDSwitcherHyperDeck::IsRemoteAccessEnabled method	588
10.3.2.4	IBMDSwitcherHyperDeck::GetStorageMediaCount method	588
10.3.2.5	IBMDSwitcherHyperDeck::GetStorageMediaState method	589
10.3.2.6	IBMDSwitcherHyperDeck::GetActiveStorageMedia method	589
10.3.2.7	IBMDSwitcherHyperDeck::SetActiveStorageMedia method	590
10.3.2.8	IBMDSwitcherHyperDeck::GetClipCount method	590
10.3.2.9	IBMDSwitcherHyperDeck::CreateIterator method	591
10.3.2.10	IBMDSwitcherHyperDeck::GetSwitcherInput method	591
10.3.2.11	IBMDSwitcherHyperDeck::SetSwitcherInput method	592
10.3.2.12	IBMDSwitcherHyperDeck::GetFrameRate method	592
10.3.2.13	IBMDSwitcherHyperDeck::IsInterlacedVideo method	593
10.3.2.14	IBMDSwitcherHyperDeck::IsDropFrameTimeCode method	593
10.3.2.15	IBMDSwitcherHyperDeck::GetPlayerState method	594
10.3.2.16	IBMDSwitcherHyperDeck::GetCurrentClip method	594
10.3.2.17	IBMDSwitcherHyperDeck::SetCurrentClip method	595
10.3.2.18	IBMDSwitcherHyperDeck::GetCurrentClipTime method	595
10.3.2.19	IBMDSwitcherHyperDeck::SetCurrentClipTime method	596
10.3.2.20	IBMDSwitcherHyperDeck::GetCurrentTimelineTime method	596
10.3.2.21	IBMDSwitcherHyperDeck::SetCurrentTimelineTime method	597
10.3.2.22	IBMDSwitcherHyperDeck::GetEstimatedRecordTimeRemaining method	597
10.3.2.23	IBMDSwitcherHyperDeck::Play method	598
10.3.2.24	IBMDSwitcherHyperDeck::Record method	598
10.3.2.25	IBMDSwitcherHyperDeck::Stop method	598
10.3.2.26	IBMDSwitcherHyperDeck::Shuttle method	599
10.3.2.27	IBMDSwitcherHyperDeck::GetShuttleSpeed method	599
10.3.2.28	IBMDSwitcherHyperDeck::Jog method	599
10.3.2.29	IBMDSwitcherHyperDeck::GetLoopedPlayback method	600
10.3.2.30	IBMDSwitcherHyperDeck::SetLoopedPlayback method	600
10.3.2.31	IBMDSwitcherHyperDeck::GetSingleClipPlayback method	601
10.3.2.32	IBMDSwitcherHyperDeck::SetSingleClipPlayback method	601
10.3.2.33	IBMDSwitcherHyperDeck::GetAutoRollOnTake method	602
10.3.2.34	IBMDSwitcherHyperDeck::SetAutoRollOnTake method	602
10.3.2.35	IBMDSwitcherHyperDeck::GetAutoRollOnTakeFrameDelay method	603
10.3.2.36	IBMDSwitcherHyperDeck::SetAutoRollOnTakeFrameDelay method	603
10.3.2.37	IBMDSwitcherHyperDeck::GetNetworkAddress method	604
10.3.2.38	IBMDSwitcherHyperDeck::SetNetworkAddress method	604
10.3.2.39	IBMDSwitcherHyperDeck::AddCallback method	605
10.3.2.40	IBMDSwitcherHyperDeck::RemoveCallback method	605
10.3.3	IBMDSwitcherHyperDeckCallback Interface	606
10.3.3.1	IBMDSwitcherHyperDeckCallback::Notify method	606
10.3.3.2	IBMDSwitcherHyperDeckCallback::NotifyError method	607
10.3.4	IBMDSwitcherHyperDeckClipIterator Interface	607
10.3.4.1	IBMDSwitcherHyperDeckClipIterator::Next method	608
10.3.4.2	IBMDSwitcherHyperDeckClipIterator::GetById method	608

10.3.5	IBMDSwitcherHyperDeckClip Interface	609
10.3.5.1	IBMDSwitcherHyperDeckClip::IsValid method	609
10.3.5.2	IBMDSwitcherHyperDeckClip::IsInfoAvailable method	610
10.3.5.3	IBMDSwitcherHyperDeckClip::GetId method	610
10.3.5.4	IBMDSwitcherHyperDeckClip::GetName method	611
10.3.5.5	IBMDSwitcherHyperDeckClip::GetDuration method	611
10.3.5.6	IBMDSwitcherHyperDeckClip::GetTimelineStart method	612
10.3.5.7	IBMDSwitcherHyperDeckClip::GetTimelineEnd method	612
10.3.5.8	IBMDSwitcherHyperDeckClip::AddCallback method	613
10.3.5.9	IBMDSwitcherHyperDeckClip::RemoveCallback method	613
10.3.6	IBMDSwitcherHyperDeckClipCallback Interface	614
10.3.6.1	IBMDSwitcherHyperDeckClipCallback::Notify method	614

Section 11 — Streaming 615

11.1	General Information	615
11.1.1	Video and Audio Encoding	615
11.2	Streaming Data Types	615
11.2.1	Streaming State	615
11.2.2	Streaming Error	615
11.2.3	Streaming Event Type	616
11.3	Interface Reference	616
11.3.1	IBMDSwitcherStreamRTMP Interface	616
11.3.1.1	IBMDSwitcherStreamRTMP::StartStreaming method	617
11.3.1.2	IBMDSwitcherStreamRTMP::StopStreaming method	618
11.3.1.3	IBMDSwitcherStreamRTMP::IsStreaming method	618
11.3.1.4	IBMDSwitcherStreamRTMP::GetStatus method	618
11.3.1.5	IBMDSwitcherStreamRTMP::SetServiceName method	619
11.3.1.6	IBMDSwitcherStreamRTMP::GetServiceName method	619
11.3.1.7	IBMDSwitcherStreamRTMP::SetUrl method	620
11.3.1.8	IBMDSwitcherStreamRTMP::GetUrl method	620
11.3.1.9	IBMDSwitcherStreamRTMP::SetKey method	620
11.3.1.10	IBMDSwitcherStreamRTMP::GetKey method	621
11.3.1.11	IBMDSwitcherStreamRTMP::SetVideoBitrates	621
11.3.1.12	IBMDSwitcherStreamRTMP::GetVideoBitrates	622
11.3.1.13	IBMDSwitcherStreamRTMP::SetAudioBitrates method	622
11.3.1.14	IBMDSwitcherStreamRTMP::GetAudioBitrates method	623
11.3.1.15	IBMDSwitcherStreamRTMP::RequestDuration method	623
11.3.1.16	IBMDSwitcherStreamRTMP::GetDuration method	624
11.3.1.17	IBMDSwitcherStreamRTMP::GetTimecode method	624
11.3.1.18	IBMDSwitcherStreamRTMP::GetTimecode method	625
11.3.1.19	IBMDSwitcherStreamRTMP::GetCacheUsed method	625
11.3.1.20	IBMDSwitcherStreamRTMP::SetAuthentication method	625
11.3.1.21	IBMDSwitcherStreamRTMP::GetAuthentication method	626
11.3.1.22	IBMDSwitcherStreamRTMP::SetLowLatency method	626
11.3.1.23	IBMDSwitcherStreamRTMP::GetLowLatency method	627

11.3.1.24	IBMDSwitcherStreamRTMP::AddCallback method	627
11.3.1.25	IBMDSwitcherStreamRTMP::RemoveCallback method	628
11.3.2	IBMDSwitcherStreamRTMPCallback Interface	628
11.3.2.1	IBMDSwitcherStreamRTMPCallback::Notify method	629
11.3.2.2	IBMDSwitcherStreamRTMPCallback::NotifyStatus method Interface	629

Section 12 — Recording 630

12.1	General Information	630
12.1.1	Video and Audio Encoding	630
12.1.2	Working Set of Disks	630
12.2	Recording Data Types	630
12.2.1	Recording State	630
12.2.2	Recording Error	630
12.2.3	Recording Disk Status	631
12.2.4	Recording Event Type	631
12.2.5	Recording Disk Availability Event Type	631
12.2.6	Recording Disk Event Type	631
12.3	Interface Reference	632
12.3.1	IBMDSwitcherRecordAV Interface	632
12.3.1.1	IBMDSwitcherRecordAV::StartRecording method	633
12.3.1.2	IBMDSwitcherRecordAV::StopRecording method	633
12.3.1.3	IBMDSwitcherRecordAV::SwitchDisk method	633
12.3.1.4	IBMDSwitcherRecordAV::IsRecording method	634
12.3.1.5	IBMDSwitcherRecordAV::GetStatus method	634
12.3.1.6	IBMDSwitcherRecordAV::SetFilename method	635
12.3.1.7	IBMDSwitcherRecordAV::GetFilename method	635
12.3.1.8	IBMDSwitcherRecordAV::SetRecordInAllCameras method	636
12.3.1.9	IBMDSwitcherRecordAV::GetRecordInAllCameras method	636
12.3.1.10	IBMDSwitcherRecordAV::DoesSupportISORecording method	637
12.3.1.11	IBMDSwitcherRecordAV::SetRecordAllISOInputs method	637
12.3.1.12	IBMDSwitcherRecordAV::GetRecordAllISOInputs method	638
12.3.1.13	IBMDSwitcherRecordAV::GetWorkingSetLimit method	638
12.3.1.14	IBMDSwitcherRecordAV::SetWorkingSetDisk method	639
12.3.1.15	IBMDSwitcherRecordAV::GetWorkingSetDisk method	639
12.3.1.16	IBMDSwitcherRecordAV::GetActiveDiskIndex method	640
12.3.1.17	IBMDSwitcherRecordAV::RequestDuration method	640
12.3.1.18	IBMDSwitcherRecordAV::GetDuration method	641
12.3.1.19	IBMDSwitcherRecordAV::GetTimecode method	641
12.3.1.20	IBMDSwitcherRecordAV::GetTotalRecordingTimeAvailable method	642
12.3.1.21	IBMDSwitcherRecordAV::CreateIterator method	642
12.3.1.22	IBMDSwitcherRecordAV::AddCallback method	643
12.3.1.23	IBMDSwitcherRecordAV::RemoveCallback method	643
12.3.2	IBMDSwitcherRecordAVCallback Interface	644
12.3.2.1	IBMDSwitcherRecordAVCallback::Notify method	644
12.3.2.2	IBMDSwitcherRecordAVCallback::NotifyWorkingSetChange method	645

12.3.2.3	IBMDSwitcherRecordAVCallback::NotifyDiskAvailability method	645
12.3.2.4	IBMDSwitcherRecordAVCallback::NotifyStatus method	646
12.3.3	IBMDSwitcherRecordDiskIterator Interface	646
12.3.3.1	IBMDSwitcherRecordDiskIterator::Next method	647
12.3.3.2	IBMDSwitcherRecordDiskIterator::GetById method	647
12.3.4	IBMDSwitcherRecordDisk Interface	648
12.3.4.1	IBMDSwitcherRecordDisk::GetId method	648
12.3.4.2	IBMDSwitcherRecordDisk::GetVolumeName method	649
12.3.4.3	IBMDSwitcherRecordDisk::GetRecordingTimeAvailable method	649
12.3.4.4	IBMDSwitcherRecordDisk::GetStatus method	650
12.3.4.5	IBMDSwitcherRecordDisk::AddCallback method	650
12.3.4.6	IBMDSwitcherRecordDisk::RemoveCallback method	651
12.3.5	IBMDSwitcherRecordDiskCallback Interface	651
12.3.5.1	IBMDSwitcherRecordDiskCallback::Notify method	652

Introduction

Welcome

Thanks for downloading the Blackmagic Design Switcher Software Developers Kit (SDK).

Overview

The Switcher SDK provides a stable, cross- platform interface to a Blackmagic Design Switcher product line. The SDK provides both low-level control of hardware and high-level interfaces to allow developers to easily perform common tasks.

The Switcher SDK consists of a set of interface descriptions & sample applications which demonstrate the use of the features of the Switcher hardware. The details of the SDK are described in this document. Some Switcher capabilities, such as uncompressed USB 3 video capture and H.264 video streaming, must be accessed using the separate DeckLink SDK.

The Switcher SDK supports Microsoft Windows and macOS OS.

You can download the Switcher SDK and DeckLink SDK from the Blackmagic Design support center at:

www.blackmagicdesign.com/support

The product family is ATEM Live production switchers.

If you're looking for detailed answers regarding technologies used by Blackmagic Design, such as codecs, core media, APIs, SDK and more, visit the Blackmagic Software Developers Forum. The forum is a helpful place for you to engage with both Blackmagic support staff and other forum members who can answer developer specific questions and provide further information. The Software Developers forum can be found within the Blackmagic Design Forum at **forum.blackmagicdesign.com**

If you wish to ask questions outside of the software developers forum, please contact us at:

developer@blackmagicdesign.com

Section 1 — API Design

1.1 Overview

The libraries supporting the Blackmagic SDK are shipped as part of the product installers for each supported product line. Applications built against the interfaces shipped in the SDK will dynamically link against the library installed on the end-user's system.

1.2 Object Model

The SDK interface is modeled on Microsoft's Component Object Model (COM). On Microsoft Windows platforms, it is provided as a native COM interface registered with the operating system. On other platforms application code is provided to allow the same COM style interface to be used.

The COM model provides a paradigm for creating flexible and extensible interfaces without imposing much overhead or baggage.

1.3 Object Interfaces

The Switcher API provides programmatic access to all current Blackmagic Design ATEM Switchers.

The Switcher API provides high-level interfaces for configuring switcher inputs and performing switcher operations such as making a transition. Some switcher devices delivering uncompressed video over USB 3 or H.264 video streams over USB 2, but this capability must be accessed using the DeckLink API. Refer to the documentation for the DeckLink SDK at www.blackmagicdesign.com/support

Functionality within the API is accessed via “object interfaces”. Each object in the system may inherit from and be accessed via a number of object interfaces. Typically the developer is able to interact with object interfaces and leave the underlying objects to manage themselves.

Each object interface class has a Globally Unique ID (GUID) called an “Interface ID”. On platforms with native COM support, an IID may be used to obtain a handle to an exported interface object from the OS, which is effectively an entry point to an installed API.

Each interface may have related interfaces that are accessed by providing an IID to an existing object interface (see `IUnknown::QueryInterface`). This mechanism allows new interfaces to be added to the API without breaking API or ABI compatibility.

1.4 Reference Counting

The API uses reference counting to manage the life cycle of object interfaces.

The developer may need to add or remove references on object interfaces (see `IUnknown::AddRef` and `IUnknown::Release`) to influence their life cycle as appropriate in the application.

1.5 Interface Stability

The SDK provides a set of stable interfaces for accessing Blackmagic Design hardware. Whilst the published interfaces will remain stable, developers need to be aware of some issues they may encounter as new products, features and interfaces become available.

1.5.1 New Interfaces

Major pieces of new functionality may be added to the SDK as a whole new object interface. Already released applications will not be affected by the additional functionality. Developers making use of the new functionality should be sure to check the return of `CoCreateInstance` and/or `QueryInterface` as these interfaces will not be available on users systems which are running an older release of the Blackmagic software.

Developers can choose to either reduce the functionality of their application when an interface is not available, or to notify the user that they must install a later version of the Blackmagic software.

1.5.2 Updated Interfaces

As new functionality is added to the SDK, some existing interfaces may need to be modified or extended. To maintain compatibility with released software, the original interface will be deprecated but will remain available and maintain its unique identifier (IID). The replacement interface will have a new identifier and remain as similar to the original as possible.

1.5.3 Deprecated Interfaces

Interfaces which have been replaced with an updated version, or are no longer recommended for use are “deprecated”. Deprecated interfaces are moved out of the main interface description files into an interface description file named according to the release in which the interface was deprecated. Deprecated interfaces are also renamed with a suffix indicating the release prior to the one in which they were deprecated.

It is recommended that developers update their applications to use the most recent SDK interfaces when they release a new version of their applications. As an interim measure, developers may include the deprecated interface descriptions, and updating the names of the interfaces in their application to access the original interface functionality.

1.5.4 Removed Interfaces

Interfaces that have been deprecated for some time may eventually be removed in a major driver update if they become impractical to support.

1.6 Interface Reference

Every object interface subclasses the **IUnknown** interface.

1.6.1 IUnknown Interface

Each API interface is a subclass of the standard COM base class – **IUnknown**.

The **IUnknown** object interface provides reference counting and the ability to look up related interfaces by interface ID. The interface ID mechanism allows interfaces to be added to the API without impacting existing applications.

Public Member Functions	
Method	Description
QueryInterface	Provides access to supported child interfaces of the object.
AddRef	Increments the reference count of the object.
Release	Decrements the reference count of the object. When the final reference is removed, the object is freed.

1.6.1.1 IUnknown::QueryInterface method

The **QueryInterface** method looks up a related interface of an object interface.

Syntax

```
HRESULT QueryInterface (REFIID id, void **outputInterface);
```

Parameters

Name	Direction	Description
id	in	Interface ID of interface to lookup.
output Interface	out	New object interface or NULL on failure.

Return Values

Value	Description
E_NOINTERFACE	Interface was not found.
S_OK	Success.

1.6.1.2 IUnknown::AddRef method

The **AddRef** method increments the reference count for an object interface.

Syntax

```
ULONG AddRef();
```

Return Values

Value	Description
Count	New reference count – for debug purposes only.

1.6.1.3 IUnknown::Release method

The **Release** method decrements the reference count for an object interface. When the last reference is removed from an object, the object will be destroyed.

Syntax

```
ULONG Release();
```

Return Values

Value	Description
Count	New reference count – for debug purposes only.

1.7 Using the Switcher API in a project

The supplied sample applications provide examples of how to include the Switcher API in a project on each supported platform.

To use the Switcher API in your project, one or more files need to be included:

Windows	Switchers X.Y\Win\Include\BMDSwitcherAPI.idl
macOS	Switchers X.Y/macOS/Include/BMDSwitcherAPI.h

1.7.1 Basic Types

boolean

boolean is represented differently on each platform by using its system type:

Windows	BOOL
macOS	bool

String

String are represented differently on each platform, using the most appropriate system type:

Windows	BSTR
macOS	CFStringRef

int64_t

The 64 bit integer type is represented differently on each platform, using the most appropriate system type:

Windows	<code>long long</code>
macOS	<code>int64_t</code>

int32_t

The 32 bit integer type is represented differently on each platform, using the most appropriate system type:

Windows	<code>int</code>
macOS	<code>int32_t</code>

uint32_t

The 32 bit unsigned type is represented differently on each platform, using the most appropriate system type:

Windows	<code>unsigned int</code>
macOS	<code>uint32_t</code>

int16_t

The signed 16 bit integer type is represented differently on each platform, using the most appropriate system type:

Windows	<code>short</code>
macOS	<code>int16_t</code>

uint16_t

The 16 bit unsigned type is represented differently on each platform, using the most appropriate system type:

Windows	<code>unsigned short</code>
macOS	<code>uint16_t</code>

int8_t

The signed 8 bit integer type is represented differently on each platform, using the most appropriate system type:

Windows	<code>signed char</code>
macOS	<code>int8_t</code>

uint8_t

The 8 bit unsigned type is represented differently on each platform, using the most appropriate system type:

Windows	<code>unsigned short</code>
macOS	<code>uint8_t</code>

1.7.2 Accessing Switcher devices

Switcher devices are accessed via the **IBMDSwitcherDiscovery** interface. How a reference to an **IBMDSwitcherDiscovery** is obtained varies between platforms depending on their level of support for COM:

1.7.2.1 Windows

The main entry point to the Switcher API is the **CBMDSwitcherDiscovery** class. This class should be obtained from COM using `CoCreateInstance`:

```
IBMDSwitcherDiscovery* switcherDiscovery = NULL;  
  
CoCreateInstance (CLSID_CBMDSwitcherDiscovery, NULL, CLSCTX_ALL,  
                 IID_IBMDSwitcherDiscovery, (void*)&switcherDiscovery);
```

On success, `CoCreateInstance` returns an `HRESULT` of `S_OK` and `switcherDiscovery` points to a new **IBMDSwitcherDiscovery** object interface.

1.7.2.2 macOS OS

On macOS OS a C++ entry point is provided to access an **IBMDSwitcherDiscovery** interface:

```
IBMDSwitcherDiscovery* switcherDiscovery = CreateBMDSwitcherDiscoveryInstance();
```

On success, `switcherDiscovery` will point to a new **IBMDSwitcherDiscovery** object interface otherwise it will be set to `NULL`.

Section 2 — Basic Switcher Control

The Switcher API provides a framework for controlling ATEM switcher devices. The API enables operations such as configuring switcher inputs, performing a transition and making a cut.


2.1 General Information

2.1.1 Switcher Configuration and Transitions

An application for controlling a switcher may perform the following steps:

- Use `IBMDSwitcherDiscovery::ConnectTo` to connect to a switcher device and obtain an `IBMDSwitcher` object interface
- Use `IBMDSwitcher::CreateIterator` to get an `IBMDSwitcherInputIterator` object interface
- For each `IBMDSwitcherInput` returned by `IBMDSwitcherInputIterator::Next` retrieve the input's unique Id using `IBMDSwitcherInput::GetInputId` and retrieve other properties of the input, such as the input's name, using `IBMDSwitcherInput::GetShortName` or `IBMDSwitcherInput::GetLongName`
- Use `IBMDSwitcher::CreateIterator` to get an `IBMDSwitcherMixEffectBlockIterator` object interface
- Obtain an `IBMDSwitcherMixEffectBlock` object interface using `IBMDSwitcherMixEffectBlockIterator::Next`
- Use `IBMDSwitcherMixEffectBlock::SetProgramInput` and `IBMDSwitcherMixEffectBlock::SetPreviewInput` to set the Program and Preview inputs to the mix effect block by assigning the input Ids returned by `IBMDSwitcherInput::GetInputId`
- Perform a transition between Program and Preview inputs by calling `IBMDSwitcherMixEffectBlock::PerformAutoTransition`
- Install a callback using `IBMDSwitcherMixEffectBlock::AddCallback` and receive `IBMDSwitcherMixEffectBlockCallback::Notify` callbacks when `IBMDSwitcherMixEffectBlock` events occur

2.1.2 Switcher Interface Diagram



2.2 Switcher Data Types

2.2.1 Basic Switcher Data Types

BMDSwitcherInputId

BMDSwitcherInputId is a signed 64 bit integer type and used as a unique Id for each switcher input.

2.2.2 Switcher Event Type

BMDSwitcherEventType enumerates the possible event types for **IBMDSwitcherCallback**.

- **bmdSwitcherEventTypeVideoModeChanged**
The video standard changed.
- **bmdSwitcherEventTypeMethodForDownConvertedSDChanged**
The method for down converted SD output has changed.
- **bmdSwitcherEventTypeDownConvertedHDVideoModeChanged**
The down converted HD output video standard changed for a particular core video standard.
- **bmdSwitcherEventTypeMultiViewVideoModeChanged**
The MultiView standard changed for a particular core video standard.
- **bmdSwitcherEventTypePowerStatusChanged**
The power status changed.
- **bmdSwitcherEventTypeDisconnected**
The switcher disconnected.
- **bmdSwitcherEventType3GSDIOutputLevelChanged**
The 3GSDI output level changed.
- **bmdSwitcherEventTypeTimeCodeChanged**
The current timecode has changed. This only occurs when another event causes the currently cached timecode to be updated.
- **bmdSwitcherEventTypeTimeCodeLockedChanged**
The editable status of the timecode has changed.
- **bmdSwitcherEventTypeTimeCodeModeChanged**
The current timecode mode has changed.
- **bmdSwitcherEventTypeSuperSourceCascadeChanged**
The Supersource cascade mode has changed.
- **bmdSwitcherEventTypeAutoVideoModeChanged**
The auto video mode state has changed.
- **bmdSwitcherEventTypeAutoVideoModeDetectedChanged**
The auto video mode detection state has changed.

2.2.3 Switcher Power Status

BMDSwitcherPowerStatus enumerates the possible power status flags.

This type is used by the **IBMDSwitcher** object interface.

- **bmdSwitcherPowerStatusSupply1**
Supply 1 has power.
- **bmdSwitcherPowerStatusSupply2**
Supply 2 has power.

2.2.4 Switcher Video Mode

`BMDSwitcherVideoMode` enumerates the video standards employed by the switcher.

- `bmdSwitcherVideoMode525i5994NTSC`
525 pixels high, interlaced at 59.94Hz (NTSC).
- `bmdSwitcherVideoMode625i50PAL`
625 pixels high, interlaced at 50Hz (PAL).
- `bmdSwitcherVideoMode525i5994Anamorphic`
525 pixels high, interlaced at 59.94Hz (anamorphic 16:9 widescreen).
- `bmdSwitcherVideoMode625i50Anamorphic`
625 pixels high, interlaced at 50Hz (anamorphic 16:9 widescreen).
- `bmdSwitcherVideoMode720p50`
720 pixels high, progressively scanned at 50Hz.
- `bmdSwitcherVideoMode720p5994`
720 pixels high, progressively scanned at 59.94Hz.
- `bmdSwitcherVideoMode1080i50`
1080 pixels high, interlaced at 50Hz.
- `bmdSwitcherVideoMode1080i5994`
1080 pixels high, interlaced at 59.94Hz.
- `bmdSwitcherVideoMode1080p2398`
1080 pixels high, progressively scanned at 23.98Hz.
- `bmdSwitcherVideoMode1080p24`
1080 pixels high, progressively scanned at 24Hz.
- `bmdSwitcherVideoMode1080p25`
1080 pixels high, progressively scanned at 25Hz.
- `bmdSwitcherVideoMode1080p2997`
1080 pixels high, progressively scanned at 29.97Hz.
- `bmdSwitcherVideoMode1080p30`
1080 pixels high, progressively scanned at 30Hz.
- `bmdSwitcherVideoMode1080p50`
1080 pixels high, progressively scanned at 50Hz.
- `bmdSwitcherVideoMode1080p5994`
1080 pixels high, progressively scanned at 59.94Hz.
- `bmdSwitcherVideoMode4KHDp2398`
2160 pixels high, 3840 pixels wide, progressively scanned at 23.98Hz.
- `bmdSwitcherVideoMode4KHDp24`
2160 pixels high, 3840 pixels wide, progressively scanned at 24Hz.
- `bmdSwitcherVideoMode4KHDp25`
2160 pixels high, 3840 pixels wide, progressively scanned at 25Hz.
- `bmdSwitcherVideoMode4KHDp2997`
2160 pixels high, 3840 pixels wide, progressively scanned at 29.97Hz.
- `bmdSwitcherVideoMode4KHDp50`
2160 pixels high, 3840 pixels wide, progressively scanned at 50Hz.
- `bmdSwitcherVideoMode4KHDp5994`
2160 pixels high, 3840 pixels wide, progressively scanned at 59.94Hz.

- **bmdSwitcherVideoMode1080p60**
1080 pixels high, progressively scanned at 60Hz.
- **bmdSwitcherVideoMode8KHDp2398**
4320 pixels high, 7680 pixels wide, progressively scanned at 23.98Hz.
- **bmdSwitcherVideoMode8KHDp24**
4320 pixels high, 7680 pixels wide, progressively scanned at 24Hz.
- **bmdSwitcherVideoMode8KHDp25**
4320 pixels high, 7680 pixels wide, progressively scanned at 25Hz.
- **bmdSwitcherVideoMode8KHDp2997**
4320 pixels high, 7680 pixels wide, progressively scanned at 29.97Hz.
- **bmdSwitcherVideoMode8KHDp50**
4320 pixels high, 7680 pixels wide, progressively scanned at 50Hz.
- **bmdSwitcherVideoMode8KHDp5994**
4320 pixels high, 7680 pixels wide, progressively scanned at 59.94Hz.

2.2.5 Switcher Down Conversion Methods

BMDSwitcherDownConversionMethod enumerates the possible methods for SD down conversion between broadcast standards.

- **bmdSwitcherDownConversionMethodCentreCut**
Centre cut conversion.
- **bmdSwitcherDownConversionMethodLetterbox**
Letter box conversion.
- **bmdSwitcherDownConversionMethodAnamorphic**
Anamorphic conversion.

2.2.6 Switcher Input Event Type

BMDSwitcherInputEventType enumerates the possible event types for **IBMDSwitcherInputCallback**.

- **bmdSwitcherInputEventTypeShortNameChanged**
The short name of the input changed.
- **bmdSwitcherInputEventTypeLongNameChanged**
The long name of the input changed.
- **bmdSwitcherInputEventTypesProgramTalliedChanged**
Program tallying for this input was turned on or turned off.
- **bmdSwitcherInputEventTypesPreviewTalliedChanged**
Preview tallying for this input was turned on or turned off.
- **bmdSwitcherInputEventTypeAvailableExternalPortTypesChanged**
The external port types available to this input changed.
- **bmdSwitcherInputEventTypeCurrentExternalPortTypeChanged**
The current external port type of this input changed.
- **bmdSwitcherInputEventTypeAreNamesDefaultChanged**
The long or short names changed from the default OR the long and short names changed to the default.

2.2.7 Switcher External Port Types

BMDSwitcherExternalPortType enumerates the different kinds of external port type for an input. This enumeration represents a bitset since an input port may support more than one connection type.

- **bmdSwitcherExternalPortTypeSDI**
SDI connection.
- **bmdSwitcherExternalPortTypeHDMI**
HDMI connection.
- **bmdSwitcherExternalPortTypeComponent**
Component connection.
- **bmdSwitcherExternalPortTypeComposite**
Composite connection, only available in SD video modes.
- **bmdSwitcherExternalPortTypeSVideo**
SVideo connection, only available in SD video modes.
- **bmdSwitcherExternalPortTypeXLR**
XLR audio connection.
- **bmdSwitcherExternalPortTypeAESEBU**
AES EBU audio connection.
- **bmdSwitcherExternalPortTypeRCA**
RCA audio connection.
- **bmdSwitcherExternalPortTypeTSJack**
TS audio connection.
- **bmdSwitcherExternalPortTypeMADI**
MADI audio connection.
- **bmdSwitcherExternalPortTypeTRS**
TRS audio connection.

2.2.8 Switcher Port Types

BMDSwitcherPortType enumerates the possible switcher input port types available for switching.

- **bmdSwitcherPortTypeExternal**
The port is an external port with a physical connector.
- **bmdSwitcherPortTypeBlack**
The port is a black video generator port.
- **bmdSwitcherPortTypeColorBars**
The port is a colorbars generator port.
- **bmdSwitcherPortTypeColorGenerator**
The port is a color generator port.
- **bmdSwitcherPortTypeMediaPlayerFill**
The port is a media player fill port.
- **bmdSwitcherPortTypeMediaPlayerCut**
The port is a media player cut port.
- **bmdSwitcherPortTypeSuperSource**
The port is a super source port.
- **bmdSwitcherPortTypeMixEffectBlockOutput**
The port is a mix effect block output port.
- **bmdSwitcherPortTypeAuxOutput**
The port is an auxiliary output port.

- **bmdSwitcherPortTypeMultiview**
The port is a MultiView port.
- **bmdSwitcherPortTypeExternalDirect**
The port comes from an external port with a physical connection and bypasses all switcher processing.

2.2.9 Switcher Input Availability

BMDSwitcherInputAvailability enumerates the different kinds of input availability for a port. This enumeration represents a bitset since an input can have multiple availabilities.

- **bmdSwitcherInputAvailabilityMixEffectBlock0**
The input is available to be used by mix effect block 0.
- **bmdSwitcherInputAvailabilityMixEffectBlock1**
The input is available to be used by mix effect block 1.
- **bmdSwitcherInputAvailabilityMixEffectBlock2**
The input is available to be used by mix effect block 2.
- **bmdSwitcherInputAvailabilityMixEffectBlock3**
The input is available to be used by mix effect block 3.
- **bmdSwitcherInputAvailabilityAux1Output**
The input is available to be used by aux output 1.
- **bmdSwitcherInputAvailabilityAux2Output**
The input is available to be used by aux output 2.
- **bmdSwitcherInputAvailabilityAuxOutputs**
The input is available to be used by aux outputs.
- **bmdSwitcherInputAvailabilityMultiView**
The input can be routed to a MultiView window.
- **bmdSwitcherInputAvailabilitySuperSourceArt**
The input is available to be used for SuperSource Art.
- **bmdSwitcherInputAvailabilitySuperSourceBox**
The input is available to be used within a SuperSource Box.
- **bmdSwitcherInputAvailabilityInputCut**
The input is available to be used as a cut.

2.2.10 Switcher Mix Effect Block Events

BMDSwitcherMixEffectBlockEventType enumerates the possible event types for **IBMDSwitcherMixEffectBlockCallback**.

- **bmdSwitcherMixEffectBlockEventTypeProgramInputChanged**
The program input changed.
- **bmdSwitcherMixEffectBlockEventTypePreviewInputChanged**
The preview input changed.
- **bmdSwitcherMixEffectBlockEventTypeTransitionPositionChanged**
The transition position changed.
- **bmdSwitcherMixEffectBlockEventTypeTransitionFramesRemainingChanged**
The transition frames remaining changed.
- **bmdSwitcherMixEffectBlockEventTypeInTransitionChanged**
The in transition flag changed.
- **bmdSwitcherMixEffectBlockEventTypeFadeToBlackFramesRemainingChanged**
The fade to black frames remaining changed.
- **bmdSwitcherMixEffectBlockEventTypeInFadeToBlackChanged**
The in fade to black flag changed.

- **bmdSwitcherMixEffectBlockEventTypePreviewLiveChanged**
The preview live flag changed.
- **bmdSwitcherMixEffectBlockEventTypePreviewTransitionChanged**
The preview transition changed.
- **bmdSwitcherMixEffectBlockEventTypeInputAvailabilityMaskChanged**
The input availability mask changed.
- **bmdSwitcherMixEffectBlockEventTypeFadeToBlackRateChanged**
The fade to black rate changed.
- **bmdSwitcherMixEffectBlockEventTypeFadeToBlackFullyBlackChanged**
The fade to black fully black flag changed.
- **bmdSwitcherMixEffectBlockEventTypeFadeToBlackInTransitionChanged**
The fade to black in transition flag changed.

2.2.11 Switcher Connection Errors

BMDSwitcherConnectToFailure enumerates the possible errors that can occur when connecting to a switcher.

- **bmdSwitcherConnectToFailureNoResponse**
The Switcher did not respond after a connection attempt was made.
- **bmdSwitcherConnectToFailureIncompatibleFirmware**
The software on the Switcher is incompatible with the current version of the Switcher SDK.
- **bmdSwitcherConnectToFailureCorruptData**
Corrupt data was received during a connection attempt.
- **bmdSwitcherConnectToFailureStateSync**
State synchronisation failed during a connection attempt.
- **bmdSwitcherConnectToFailureStateSyncTimedOut**
State synchronisation timed out during a connection attempt.

2.2.12 Switcher MultiView Layouts

BMDSwitcherMultiViewLayout enumerates the possible layout formats for MultiView. This enumeration represents a bitset that indicates whether each quadrant of the screen displays as one large window or four small windows.

- **bmdSwitcherMultiViewLayoutProgramTop**
Program and preview reside in upper section of the screen, windows reside below.
- **bmdSwitcherMultiViewLayoutProgramBottom**
Program and preview reside in lower section of the screen, windows reside above.
- **bmdSwitcherMultiViewLayoutProgramLeft**
Program and preview reside on left hand side, windows reside on the right.
- **bmdSwitcherMultiViewLayoutProgramRight**
Program and preview reside on right hand side, windows reside on the left.
- **bmdSwitcherMultiViewLayoutTopLeftSmall**
Bitmask for the top left quadrant. If set, four small windows are shown. If not set, a single large window is shown.
- **bmdSwitcherMultiViewLayoutTopRightSmall**
Bitmask for the top right quadrant. If set, four small windows are shown. If not set, a single large window is shown.
- **bmdSwitcherMultiViewLayoutBottomLeftSmall**
Bitmask for the bottom left quadrant. If set, four small windows are shown. If not set, a single large window is shown.
- **bmdSwitcherMultiViewLayoutBottomRightSmall**
Bitmask for the bottom right quadrant. If set, four small windows are shown. If not set, a single large window is shown.

2.2.13 Switcher Serial Port Functions

BMDSwitcherSerialPortFunction enumerates the functions the serial port can perform.

- **bmdSwitcherSerialPortFunctionNone**
The serial port is not being used.
- **bmdSwitcherSerialPortFunctionPtzVisca**
The serial port is used to control a Pan-Tilt-Zoom camera using the VISCA protocol.
- **bmdSwitcherSerialPortFunctionGvg100**
If the serial port is set to this function, the switcher can be controlled by a connected GVG100 compatible editor/controller.

2.2.14 Switcher 3G-SDI Output Levels

BMDSwitcher3GSDIOutputLevel enumerates the possible 3G-SDI output encoding levels.

- **bmdSwitcher3GSDIOutputLevelA**
All 3G-SDI outputs use level A encoding.
- **bmdSwitcher3GSDIOutputLevelB**
All 3G-SDI outputs use level B encoding.

2.2.15 Switcher Mix Minus Output Audio Modes

BMDSwitcherMixMinusOutputAudioMode enumerates the different audio modes for **IBMDSwitcherMixMinusOutput**.

- **bmdSwitcherMixMinusOutputAudioModeProgramOut**
The mix minus output audio is program out.
- **bmdSwitcherMixMinusOutputAudioModeMixMinus**
The mix minus output audio is program out minus the corresponding input.

2.2.16 Switcher Color Events

BMDSwitcherInputColorEventType enumerates the possible event types for **IBMDSwitcherInputColorCallback**.

- **bmdSwitcherInputColorEventTypeHueChanged**
The hue changed.
- **bmdSwitcherInputColorEventTypeSaturationChanged**
The saturation changed.
- **bmdSwitcherInputColorEventTypeLumaChanged**
The luma changed.

2.2.17 Switcher Aux Events

BMDSwitcherInputAuxEventType enumerates the possible event types for **IBMDSwitcherInputAuxCallback**.

- **bmdSwitcherInputAuxEventTypeInputSourceChanged**
The input source changed.

2.2.18 Switcher MultiView Events

BMDSwitcherMultiViewEventType enumerates the possible event types for **IBMDSwitcherMultiViewCallback**.

- **bmdSwitcherMultiViewEventTypeLayoutChanged**
The layout changed.
- **bmdSwitcherMultiViewEventTypeWindowChanged**
Routing to a MultiView window has changed.
- **bmdSwitcherMultiViewEventTypeCurrentInputSupportsVuMeterChanged**
The input of a MultiView window changed to/from an input that supports VU meters from/to one that does not.
- **bmdSwitcherMultiViewEventTypeVuMeterEnabledChanged**
The enabled state of one of the VU meters changed.
- **bmdSwitcherMultiViewEventTypeVuMeterOpacityChanged**
The opacity of one of the VU meters changed.
- **bmdSwitcherMultiViewEventTypeCurrentInputSupportsSafeAreaChanged**
The input of a MultiView window changed to/from an input that supports safe area display from/to one that does not.
- **bmdSwitcherMultiViewEventTypeSafeAreaEnabledChanged**
The enabled state of the safe area overlay changed.
- **bmdSwitcherMultiViewEventTypeProgramPreviewSwappedChanged**
The positioning of the program and preview windows changed from standard to swapped or from swapped to standard.

2.2.19 Switcher Serial Port Events

BMDSwitcherSerialPortEventType enumerates the possible event types for **IBMDSwitcherSerialPortCallback**.

- **bmdSwitcherSerialPortEventTypeFunctionChanged**
The function of the serial port has changed.

2.2.20 Switcher Mix Minus Output Events

BMDSwitcherMixMinusOutputEventType enumerates the possible event types for **IBMDSwitcherMixMinusOutputCallback**.

- **bmdSwitcherMixMinusOutputEventTypeAvailableAudioModesChanged**
The audio modes available to this mix minus output have changed.
- **bmdSwitcherMixMinusOutputEventTypeAudioModeChanged**
The mix minus output audio mode changed.
- **bmdSwitcherMixMinusOutputEventTypeHasMinusAudioInputIdChanged**
The mix minus output has minus audio input ID flag has changed.
- **bmdSwitcherMixMinusOutputEventTypeMinusAudioInputIdChanged**
The mix minus output minus audio input ID has changed.

2.2.21 Save And Recall Type

BMDSwitcherSaveRecallType enumerates the possible operating states for the **IBMDSwitcherSaveRecall** object interface.

- **bmdSwitcherSaveRecallTypeStartupState**
This type of operating state will be restored whenever a switcher is powered on.

2.2.22 Switcher TimeCode Mode Type

BMDSwitcherTimeCodeMode enumerates the possible modes available for running timecode.

Key	Value	Description
bmdSwitcherTimeCodeModeFreeRun	'tmfr'	The timecode runs freely and typically starts at 00:00:00:00 when the switcher was powered on.
bmdSwitcherTimeCodeModeTimeOfDay	'tmttd'	The timecode runs freely and is synchronised with the current time of day.

2.3 Interface Reference

2.3.1 IBMDSwitcherDiscovery Interface

The **IBMDSwitcherDiscovery** object interface is used to connect to a physical switcher device.

A reference to an **IBMDSwitcherDiscovery** object interface may be obtained from **CoCreateInstance** on platforms with native COM support or from **CreateBMDSwitcherDiscoveryInstance** on other platforms.

Public Member Functions	
Method	Description
ConnectTo	Connect to a switcher

2.3.1.1 IBMDSwitcherDiscovery::ConnectTo method

The **ConnectTo** method connects to the specified switcher and returns an **IBMDSwitcher** object interface for the switcher.

NOTE **ConnectTo** performs a synchronous network connection. This may take several seconds depending upon hostname resolution and network response times.

If a network connection cannot be established, **ConnectTo** will attempt to connect via USB if the switcher supports it.

Syntax

```
HRESULT ConnectTo (string deviceAddress, IBMDSwitcher** switcherDevice, BMDSwitcherConnectToFailure* failReason);
```

Parameters

Name	Direction	Description
deviceAddress	in	Network hostname or IP address of switcher to connect to. Set this empty to only connect via USB.
switcherDevice	out	IBMDSwitcher object interface for the connected switcher.
failReason	out	Reason for connection failure as a BMDSwitcherConnectToFailure value.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The switcherDevice or failReason parameter is invalid.

2.3.2 IBMDSwitcher Interface

The `IBMDSwitcher` object interface represents a physical switcher device.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherDiscovery</code>	<code>IID_IBMDSwitcherDiscovery</code>	An <code>IBMDSwitcher</code> object will be returned after a successful call to the <code>IBMDSwitcherDiscovery::ConnectTo</code> method

Public Member Functions	
Method	Description
<code>GetProductName</code>	Get the product name of the switcher.
<code>GetVideoMode</code>	Get the current video standard applied across the switcher.
<code>SetVideoMode</code>	Set the video standard applied across the switcher.
<code>DoesSupportVideoMode</code>	Determines if a video standard is supported by the switcher.
<code>DoesVideoModeChangeRequireReconfiguration</code>	Determines if changing video standard will reconfigure the switcher.
<code>GetMethodForDownConvertedSD</code>	Get the SD conversion method applied when down converting between broadcast standards.
<code>SetMethodForDownConvertedSD</code>	Set the SD conversion method applied when down converting between broadcast standards.
<code>GetDownConvertedHDVideoMode</code>	Get the down converted HD video standard for a particular core video standard.
<code>SetDownConvertedHDVideoMode</code>	Set the down converted HD video standard for a particular core video standard.
<code>DoesSupportDownConvertedHDVideoMode</code>	Determines if a down converted HD video standard is supported by a particular core video standard.
<code>GetMultiViewVideoMode</code>	Get the MultiView video standard for a particular core video standard.
<code>SetMultiViewVideoMode</code>	Set the MultiView video standard for a particular core video standard.
<code>DoesSupportMultiViewVideoMode</code>	Determines if a MultiView video standard is supported by a particular core video standard.
<code>Get3GSDIOutputLevel</code>	Gets the current 3G-SDI output encoding level of the switcher
<code>Set3GSDIOutputLevel</code>	Sets the current 3G-SDI output encoding level of the switcher.
<code>GetPowerStatus</code>	Gets the power status of the switcher.
<code>GetTimeCode</code>	Get the cached timecode.
<code>SetTimeCode</code>	Set the current timecode.
<code>RequestTimeCode</code>	Request the current timecode from the switcher.
<code>GetTimeCodeLocked</code>	Get the current timecode locked flag.
<code>GetTimeCodeMode</code>	Get the current timecode mode.
<code>SetTimeCodeMode</code>	Set the current timecode mode.
<code>GetAreOutputsConfigurable</code>	Determines if all switcher outputs are fixed or configurable.
<code>GetSuperSourceCascade</code>	Get the current SuperSource cascade flag.

Public Member Functions	
Method	Description
SetSuperSourceCascade	Set the SuperSource cascade flag.
DoesSupportAutoVideoMode	Determines if auto video mode is supported by the switcher.
GetAutoVideoMode	Get the current auto video mode state.
GetAutoVideoModeDetected	Get the current state of the input video mode detection.
SetAutoVideoMode	Set the auto video mode state.
CreateIterator	Create an iterator.
AddCallback	Add a callback to receive switcher events.
RemoveCallback	Remove a callback.

2.3.2.1 IBMDSwitcher::GetProductName method

The `GetProductName` method gets the product name of the switcher.

Syntax

```
HRESULT GetProductName (string* productName);
```

Parameters

Name	Direction	Description
productName	out	The product name of the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The productName parameter is invalid.

2.3.2.2 IBMDSwitcher::GetVideoMode method

The `GetVideoMode` method gets the current video standard applied across the switcher.

Syntax

```
HRESULT GetVideoMode (BMDSwitcherVideoMode* videoMode);
```

Parameters

Name	Direction	Description
videoMode	out	The current video standard applied across the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The videoMode parameter is invalid.

2.3.2.3 IBMDSwitcher::SetVideoMode method

The `SetVideoMode` method sets the video standard applied across the switcher.

Syntax

```
HRESULT SetVideoMode (BMDSwitcherVideoMode videoMode);
```

Parameters

Name	Direction	Description
videoMode	in	The video standard applied across the switcher.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The videoMode parameter is invalid.
S_FALSE	The video standard cannot be set while auto video mode is enabled.

2.3.2.4 IBMDSwitcher::DoesSupportVideoMode method

The `DoesSupportVideoMode` method determines if a video standard is supported by the switcher.

Syntax

```
HRESULT DoesSupportVideoMode(BMDSwitcherVideoMode videoMode, boolean* supported);
```

Parameters

Name	Direction	Description
videoMode	in	The video standard.
supported	out	Boolean value that is true if the video standard is supported.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supported parameter is invalid.

2.3.2.5 IBMDSwitcher::DoesVideoModeChangeRequireReconfiguration method

The `DoesVideoModeChangeRequireReconfiguration` method determines if changing to the specified video standard will cause the switcher to be reconfigured, which may result in the switcher restarting.

Syntax

```
HRESULT DoesVideoModeChangeRequireReconfiguration  
(BMDSwitcherVideoMode videoMode, boolean* required)
```

Parameters

Name	Direction	Description
videoMode	in	The video standard.
required	out	Boolean value that is true if changing to the video standard will reconfigure the switcher.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The videoMode is not a valid video standard.
E_POINTER	The required parameter is invalid.

2.3.2.6 IBMDSwitcher::GetMethodForDownConvertedSD method

The `GetMethodForDownConvertedSD` method gets the SD conversion method applied when down converting between broadcast standards.

Syntax

```
HRESULT GetMethodForDownConvertedSD (BMDSwitcherDownConversionMethod* method);
```

Parameters

Name	Direction	Description
method	out	The conversion method.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The method parameter is invalid.

2.3.2.7 **IBMDSwitcher::SetMethodForDownConvertedSD** method

The **SetMethodForDownConvertedSD** method sets the SD conversion method applied when down converting between broadcast standards.

Syntax

```
HRESULT SetMethodForDownConvertedSD (BMDSwitcherDownConversionMethod method);
```

Parameters

Name	Direction	Description
method	in	The conversion method.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The method parameter is invalid.

2.3.2.8 **IBMDSwitcher::GetDownConvertedHDVideoMode** method

The **GetDownConvertedHDVideoMode** method gets the down converted HD output video standard for a particular core video standard.

Syntax

```
HRESULT GetDownConvertedHDVideoMode (BMDSwitcherVideoMode coreVideoMode,  
BMDSwitcherVideoMode* downConvertedHDVideoMode);
```

Parameters

Name	Direction	Description
coreVideoMode	in	The core video standard to be down converted.
downConvertedHDVideoMode	out	The mode to which the core video standard is down converted.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The downConvertedHDVideoMode parameter is invalid.
E_INVALIDARG	The coreVideoMode parameter is invalid or not supported.
E_NOTIMPL	HD down conversion is not supported.

2.3.2.9 **IBMDSwitcher::SetDownConvertedHDVideoMode** method

The **SetDownConvertedHDVideoMode** method sets the down converted HD output video standard for a particular core video standard.

Syntax

```
HRESULT SetDownConvertedHDVideoMode (BMDSwitcherVideoMode coreVideoMode,
                                     BMDSwitcherVideoMode downConvertedHDVideoMode);
```

Parameters

Name	Direction	Description
coreVideoMode	in	The core video standard to be down converted.
downConvertedHDVideoMode	in	The mode to which the core video standard is to be down converted.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The coreVideoMode or downConvertedHDVideoMode parameter is invalid or not supported.
E_NOTIMPL	HD down conversion is not supported.

2.3.2.10 **IBMDSwitcher::DoesSupportDownConvertedHDVideoMode** method

The **DoesSupportDownConvertedHDVideoMode** method determines if a down converted HD output video standard is supported by a particular core video standard.

Syntax

```
HRESULT DoesSupportDownConvertedHDVideoMode (BMDSwitcherVideoMode coreVideoMode,
                                              BMDSwitcherVideoMode downConvertedHDVideoMode,
                                              boolean* supported);
```

Parameters

Name	Direction	Description
coreVideoMode	in	The core video standard to be down converted.
downConvertedHDVideoMode	in	The down converted video standard to determine support for.
supported	out	Boolean value that is true if the downConvertedHDVideoMode is supported for the core video standard.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supported parameter is invalid.
E_INVALIDARG	The downConvertedHDVideoMode parameter is invalid.
E_NOTIMPL	The switcher does not support HD down conversion.

2.3.2.11 **IBMDSwitcher::GetMultiViewVideoMode** method

The **GetMultiViewVideoMode** method gets the MultiView video standard for a particular core video standard.

Syntax

```
HRESULT GetMultiViewVideoMode (BMDSwitcherVideoMode coreVideoMode,  
                                BMDSwitcherVideoMode* multiviewVideoMode);
```

Parameters

Name	Direction	Description
coreVideoMode	in	The core video standard.
multiviewVideoMode	out	The MultiView standard used with the core video standard.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The multiviewVideoMode parameter is invalid.
E_INVALIDARG	The coreVideoMode parameter is invalid or not supported.

2.3.2.12 **IBMDSwitcher::SetMultiViewVideoMode** method

The **SetMultiViewVideoMode** method gets the MultiView video standard for a particular core video standard.

Syntax

```
HRESULT SetMultiViewVideoMode (BMDSwitcherVideoMode coreVideoMode,  
                                BMDSwitcherVideoMode multiviewVideoMode);
```

Parameters

Name	Direction	Description
coreVideoMode	in	The core video standard.
multiviewVideoMode	in	The MultiView standard to set with the core video standard.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The coreVideoMode or multiviewVideoMode parameter is invalid or not supported.

2.3.2.13 IBMDSwitcher::Get3GSDIOutputLevel method

The `Get3GSDIOutputLevel` method gets the output encoding level for all 3G-SDI outputs of the switcher, on models supporting 3G-SDI video formats.

Syntax

```
HRESULT Get3GSDIOutputLevel (BMDSwitcher3GSDIOutputLevel* outputLevel);
```

Parameters

Name	Direction	Description
outputLevel	out	The current 3G-SDI output level.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The outputLevel parameter is invalid.
E_NOTIMPL	The connected switcher does not support 3G-SDI output.

2.3.2.14 IBMDSwitcher::Set3GSDIOutputLevel method

The `Set3GSDIOutputLevel` method sets the output encoding level for all 3G-SDI outputs of the switcher, on models supporting 3G-SDI video formats.

Syntax

```
HRESULT Set3GSDIOutputLevel (BMDSwitcher3GSDIOutputLevel outputLevel);
```

Parameters

Name	Direction	Description
outputLevel	in	The desired 3G-SDI output level.

Return Values

Value	Description
S_OK	Success.
E_NOTIMPL	The connected switcher does not support 3G-SDI output.

2.3.2.15 IBMDSwitcher::DoesSupportMultiViewVideoMode method

The `DoesSupportMultiViewVideoMode` method determines if a MultiView video standard is supported for a particular core video standard.

Syntax

```
HRESULT DoesSupportMultiViewVideoMode (BMDSwitcherVideoMode coreVideoMode,  
BMDSwitcherVideoMode multiviewVideoMode, boolean* supported);
```

Parameters

Name	Direction	Description
coreVideoMode	in	The core video standard.
multiviewVideoMode	in	The MultiView video standard to use for the coreVideoMode.
supported	out	Boolean value that is true if the MultiView video standard is supported for the coreVideoMode.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supported parameter is invalid.
E_INVALIDARG	The multiviewVideoMode parameter is invalid.

2.3.2.16 IBMDSwitcher::GetPowerStatus method

The `GetPowerStatus` method gets the connected power status, useful for models supporting multiple power sources.

Syntax

```
HRESULT GetPowerStatus (BMDSwitcherPowerStatus* powerStatus);
```

Parameters

Name	Direction	Description
powerStatus	out	The power status.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The powerStatus parameter is invalid.

2.3.2.17 IBMDSwitcher::GetTimeCode method

The `GetTimeCode` method returns the timecode that was last received from the switcher.

Syntax

```
HRESULT GetTimeCode (uint8_t* hours, uint8_t* minutes,  
                    uint8_t* seconds, uint8_t* frames, boolean* dropFrame)
```

Parameters

Name	Direction	Description
hours	out	The hours value of the timecode.
minutes	out	The minutes value of the timecode.
seconds	out	The seconds value of the timecode.
frames	out	The frames value of the timecode.
dropFrame	out	Whether the timecode is drop frame.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No timecode has been received from the switcher.
E_POINTER	A parameter is invalid.

2.3.2.18 IBMDSwitcher::SetTimeCode method

The `SetTimeCode` method sets the timecode of the switcher.

Syntax

```
HRESULT SetTimeCode (uint8_t hours, uint8_t minutes, uint8_t seconds, uint8_t frames)
```

Parameters

Name	Direction	Description
hours	in	The hours value of the timecode.
minutes	in	The minutes value of the timecode.
seconds	in	The seconds value of the timecode.
frames	in	The frames value of the timecode.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	A parameter is not a valid value.
E_FAIL	Failure.

2.3.2.19 IBMDSwitcher::RequestTimeCode method

The `RequestTimeCode` method requests the current timecode from the switcher which will be cached when received. Use the `GetTimeCode` method to get the cached timecode.

Syntax

```
HRESULT RequestTimeCode()
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.2.20 IBMDSwitcher::GetTimeCodeLocked method

The `GetTimeCodeLocked` method indicates whether the timecode can be changed with `SetTimeCode`.

Syntax

```
HRESULT GetTimeCodeLocked(boolean* timeCodeLocked)
```

Parameters

Name	Direction	Description
timeCodeLocked	out	The current timecode locked flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The timeCodeLocked parameter is invalid.

2.3.2.21 IBMDSwitcher::GetTimeCodeMode method

The `GetTimeCodeMode` method returns the current timecode mode of the switcher.

Syntax

```
HRESULT GetTimeCodeMode(BMDSwitcherTimeCodeMode* timeCodeMode)
```

Parameters

Name	Direction	Description
timeCodeMode	out	The current timecode mode.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The timeCodeMode parameter is invalid.
S_FALSE	The switcher does not support timecode mode functionality.

2.3.2.22 IBMDSwitcher::SetTimeCodeMode method

The `SetTimeCodeMode` method sets the timecode mode of the switcher.

Syntax

```
HRESULT SetTimeCodeMode(BMDSwitcherTimeCodeMode timeCodeMode)
```

Parameters

Name	Direction	Description
timeCodeMode	in	The timecode mode to be set.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The timeCodeMode parameter is invalid.
E_FAIL	Failure.

2.3.2.23 IBMDSwitcher::GetAreOutputsConfigurable method

The `GetAreOutputsConfigurable` method indicates whether all of the switcher's outputs can be configured. Some switchers have mostly fixed outputs and only a small number of configurable outputs. Other switchers only have configurable outputs.

Syntax

```
HRESULT GetAreOutputsConfigurable(boolean* configurable)
```

Parameters

Name	Direction	Description
configurable	out	Boolean that indicates if the switcher only has configurable outputs.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The configurable parameter is invalid.

2.3.2.24 IBMDSwitcher::GetSuperSourceCascade method

The `GetSuperSourceCascade` method indicates whether the SuperSource cascade mode is currently enabled.

Syntax

```
HRESULT GetSuperSourceCascade(boolean* cascade)
```

Parameters

Name	Direction	Description
cascade	out	The current SuperSource cascade flag.

Return Values

Value	Description
S_OK	Success.
E_NOTIMPL	The switcher does not support SuperSource cascade.
E_POINTER	The cascade parameter is invalid.

2.3.2.25 IBMDSwitcher::SetSuperSourceCascade method

The `SetSuperSourceCascade` method is used to enable or disable the SuperSource cascade mode.

Syntax

```
HRESULT SetSuperSourceCascade(boolean cascade)
```

Parameters

Name	Direction	Description
cascade	in	The desired SuperSource cascade flag.

Return Values

Value	Description
S_OK	Success.
E_NOTIMPL	The switcher does not support SuperSource cascade.
E_FAIL	Failure.

2.3.2.26 IBMDSwitcher::DoesSupportAutoVideoMode method

The DoesSupportAutoVideoMode method determines if auto video mode is supported by the switcher.

Syntax

```
HRESULT DoesSupportAutoVideoMode(Boolean* supported)
```

Parameters

Name	Direction	Description
supported	out	A Boolean value indicating whether the switcher supports auto video mode.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supported parameter is invalid.

2.3.2.27 IBMDSwitcher::GetAutoVideoMode method

The GetAutoVideoMode method indicates whether auto video mode is currently enabled.

Syntax

```
HRESULT GetAutoVideoMode(Boolean* enabled)
```

Parameters

Name	Direction	Description
enabled	out	A Boolean value indicating whether auto video mode is enabled.

Return Values

Value	Description
S_OK	Success.
E_NOTIMPL	The switcher does not support auto video mode.
E_POINTER	The enabled parameter is invalid.

2.3.2.28 IBMDSwitcher::GetAutoVideoModeDetected method

The GetAutoVideoModeDetected method indicates whether an input video mode has been detected.

Syntax

```
HRESULT GetAutoVideoModeDetected(Boolean* detected)
```

Parameters

Name	Direction	Description
detected	out	A Boolean value indicating whether an input video mode has been detected.

Return Values

Value	Description
S_OK	Success.
E_NOTIMPL	The switcher does not support auto video mode.
E_POINTER	The detected parameter is invalid.

2.3.2.29 IBMDSwitcher::SetAutoVideoMode method

The GetTimeCode method is used to enable or disable auto video mode.

Syntax

```
HRESULT SetAutoVideoMode(Boolean enabled)
```

Parameters

Name	Direction	Description
enabled	in	A Boolean value indicating whether auto video mode should be enabled.

Return Values

Value	Description
S_OK	Success.
E_NOTIMPL	The switcher does not support auto video mode.

2.3.2.30 IBMDSwitcher::CreateIterator method

The `CreateIterator` method creates an iterator object interface for the specified interface ID.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Iterator Interface ID to create an iterator for.
ppv	in	Pointer to returned interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_OUTOFMEMORY	Insufficient memory to create interface object.
E_NOINTERFACE	Interface was not found.

2.3.2.31 IBMDSwitcher::AddCallback method

The `AddCallback` method configures a callback to be called when events occur for an `IBMDSwitcher` object.

Pass an object implementing the `IBMDSwitcherCallback` interface to receive callbacks.

Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the <code>IBMDSwitcherCallback</code> object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.2.32 IBMDSwitcher::RemoveCallback method

The RemoveCallback method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.3 IBMDSwitcherCallback Interface

The IBMDSwitcherCallback object interface is a callback class containing methods that are called when an event occurs on an IBMDSwitcher object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	An IBMDSwitcherCallback object interface is installed with IBMDSwitcher::AddCallback and removed with IBMDSwitcher::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

2.3.3.1 IBMDSwitcherCallback::Notify method

The **Notify** is called when **IBMDSwitcher** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherEventType eventType, BMDSwitcherVideoMode coreVideoMode);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherEventType that describes the type of event that has occurred.
coreVideoMode	in	Video standard for which the event was triggered. This parameter is used in bmdSwitcherEventTypeDownConverted , HDVideoModeChanged and bmdSwitcherEventTypeMultiViewVideoModeChanged event types.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.4 IBMDSwitcherInputIterator Interface

The **IBMDSwitcherInputIterator** object interface is used to enumerate the available switcher inputs.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	IBMDSwitcher::CreateIterator returns an IBMDSwitcherInputIterator object interface when the IID_IBMDSwitcherInputIterator IID is specified.

Public Member Functions	
Method	Description
Next	Returns the next available switcher input.
GetById	Returns a switcher input for an input Id.

2.3.4.1 IBMDSwitcherInputIterator::Next method

The `Next` method returns the next available `IBMDSwitcherInput` object interface.

The `IBMDSwitcherInput` object interface must be released by the caller when no longer required.

Syntax

```
HRESULT Next (IBMDSwitcherInput** input);
```

Parameters

Name	Direction	Description
input	out	IBMDSwitcherInput object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No (more) inputs are available.
E_POINTER	The input parameter is invalid.

2.3.4.2 IBMDSwitcherInputIterator::GetById method

The `GetById` method returns the `IBMDSwitcherInput` object interface corresponding to the specified `Id`.

Syntax

```
HRESULT GetById (BMDSwitcherInputId inputId, IBMDSwitcherInput** input);
```

Parameters

Name	Direction	Description
inputId	in	BMDSwitcherInputId of input.
input	out	IBMDSwitcherInput object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The inputId parameter is invalid.
E_POINTER	The input parameter is invalid.

2.3.5 IBMDSwitcherInput Interface

The `IBMDSwitcherInput` object interface represents a physical switcher device.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherInputIterator</code>	<code>IID_IBMDSwitcherInputIterator</code>	An <code>IBMDSwitcherInput</code> interface can be obtained with <code>IBMDSwitcherInputIterator::Next</code> .

Public Member Functions	
Method	Description
<code>AddCallback</code>	Add a callback to receive input property changes.
<code>RemoveCallback</code>	Remove a callback.
<code>GetInputId</code>	Get the unique ID for this input.
<code>GetPortType</code>	Get the port type as a <code>BMDSwitcherPortType</code> .
<code>GetInputAvailability</code>	Get the outputs this input can be routed to, as a <code>BMDSwitcherInputAvailability</code> object.
<code>SetShortName</code>	Set the short name describing the switcher input as a string limited to 4 ASCII characters.
<code>GetShortName</code>	Get the short name describing the switcher input as a string limited to 4 ASCII characters.
<code>SetLongName</code>	Set the long name describing the switcher input as a Unicode string limited to 20 bytes.
<code>GetLongName</code>	Get the long name describing the switcher input as a Unicode string limited to 20 bytes.
<code>AreNamesDefault</code>	Determine if the long name and short name are both currently set to the factory default values.
<code>ResetNames</code>	Reset the long and short names for this switcher input to the factory defaults for this input.
<code>IsProgramTallied</code>	Returns a flag indicating whether the input is currently program tallied.
<code>IsPreviewTallied</code>	Returns a flag indicating whether the input is currently preview tallied.
<code>GetAvailableExternalPortTypes</code>	Get the available external port types as a bit mask of <code>BMDSwitcherExternalPortType</code> .
<code>SetCurrentExternalPortType</code>	Set the external port type for this input using a <code>BMDSwitcherExternalPortType</code> .

2.3.5.1 IBMDSwitcherInput::AddCallback method

The **AddCallback** method configures a callback to be called when a switcher input property changes.

Adding a new callback will not affect previously added callbacks. Callbacks will be called on a separate thread and in the order of their addition by **AddCallback**.

Syntax

```
HRESULT AddCallback (IBMDSwitcherInputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherInputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.5.2 IBMDSwitcherInput::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherInputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object to remove.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.5.3 IBMDSwitcherInput::GetInputId method

The `GetInputId` method gets the unique Id for the switcher input.

Syntax

```
HRESULT GetInputId (BMDSwitcherInputId* inputId);
```

Parameters

Name	Direction	Description
inputId	out	Unique Id for switcher input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inputId parameter is invalid.

2.3.5.4 IBMDSwitcherInput::GetPortType method

The `GetPortType` method returns the port type of this switcher input as a `BMDSwitcherPortType`. This can be used to determine if this input is an external port (i.e. `bmdSwitcherPortTypeExternal`), or any of the internal port types such as color bars (i.e. `bmdSwitcherPortTypeColorBars`).

Syntax

```
HRESULT GetPortType (BMDSwitcherPortType* type);
```

Parameters

Name	Direction	Description
type	out	The port type.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The type parameter is not valid.

2.3.5.5 **IBMDSwitcherInput::GetInputAvailability** method

The **GetInputAvailability** method determines which outputs this input can be routed to. The available output groups are given as a bit mask of **BMDSwitcherInputAvailability**. The value returned can be bitwise-ANDed with any **BMDSwitcherInputAvailability** value (e.g. **bmdSwitcherInputAvailabilityAuxOutputs**) to determine the availability of this input to that output group.

Syntax

```
HRESULT GetInputAvailability (BMDSwitcherInputAvailability* availability);
```

Parameters

Name	Direction	Description
availability	out	The availability of the input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The availability parameter is not valid.

2.3.5.6 **IBMDSwitcherInput::SetShortName** method

The **SetShortName** method assigns the short name describing the switcher input as a string limited to 4 ASCII characters.

Syntax

```
HRESULT SetShortName (string name);
```

Parameters

Name	Direction	Description
name	in	The short name for the switcher input, limited to 4 ASCII characters.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The name parameter is not a valid pointer.
E_INVALIDARG	The name parameter contains non-ASCII characters.

2.3.5.7 IBMDSwitcherInput::GetShortName method

The `GetShortName` method gets the short name describing the switcher input as a string limited to 4 ASCII characters.

Syntax

```
HRESULT GetShortName (string* name);
```

Parameters

Name	Direction	Description
name	out	The short name for the switcher input, limited to 4 ASCII characters.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The name parameter is not a valid pointer.

2.3.5.8 IBMDSwitcherInput::SetLongName method

The `SetLongName` method sets the long name, describing the switcher input as a Unicode string in UTF-8 format with a maximum length of 20 bytes. If a string longer than 20 bytes is provided, it will be truncated to the longest valid UTF-8 string of 20 bytes or less.

Syntax

```
HRESULT SetLongName (string name);
```

Parameters

Name	Direction	Description
name	in	The long name describing the switcher input as a Unicode string with a maximum length of 20 bytes.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The name parameter is not valid.

2.3.5.9 IBMDSwitcherInput::GetLongName method

The `GetLongName` method gets the long name for the switcher input, describing the input as a Unicode string in UTF-8 format with a maximum length of 20 bytes.

Syntax

```
HRESULT GetLongName (string* name);
```

Parameters

Name	Direction	Description
name	out	The long name describing the switcher input as a Unicode string with a maximum length of 20 bytes.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The name parameter is not valid.

2.3.5.10 IBMDSwitcherInput::AreNamesDefault method

The `AreNamesDefault` method is used to check whether the long name and short name for this input are both set to the factory defaults.

Syntax

```
HRESULT AreNamesDefault (bool* isDefault);
```

Parameters

Name	Direction	Description
isDefault	out	Boolean value indicating whether the long name and short name are both set to the factory defaults.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The isDefault parameter is not a valid pointer.

2.3.5.11 IBMDSwitcherInput::ResetNames method

The `ResetNames` method resets the long and short names for this switcher input to the factory defaults for this input.

Syntax

```
HRESULT ResetNames ();
```

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

2.3.5.12 IBMDSwitcherInput::IsProgramTallied method

The `IsProgramTallied` method determines whether this switcher input is currently program tallied.

Syntax

```
HRESULT IsProgramTallied (bool* isTallied);
```

Parameters

Name	Direction	Description
isTallied	out	Flag indicating if the input is currently program tallied.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The isTallied parameter is not valid.

2.3.5.13 IBMDSwitcherInput::IsPreviewTallied method

The `IsPreviewTallied` method determines whether this switcher input is currently preview tallied.

Syntax

```
HRESULT IsPreviewTallied (bool* isTallied);
```

Parameters

Name	Direction	Description
isTallied	out	Flag indicating if the input is currently preview tallied.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The isTallied parameter is not valid.

2.3.5.14 **BMDSwitcherInput::GetAvailableExternalPortTypes** method

The `GetAvailableExternalPortTypes` method gets the available external port types for this switcher input, given as a bit mask of `BMDSwitcherExternalPortType`. This bit mask can be bitwise-ANDed with any value of `BMDSwitcherExternalPortType` (e.g. `bmdSwitcherExternalPortTypeSDI`) to determine if that external port type is available for this input.

Syntax

```
HRESULT GetAvailableExternalPortTypes (BMDSwitcherExternalPortType* types);
```

Parameters

Name	Direction	Description
types	out	The available external port types for this switcher input as a bit mask of <code>BMDSwitcherExternalPortType</code> .

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The types parameter is not valid.

2.3.5.15 **BMDSwitcherInput::SetCurrentExternalPortType** method

The `SetCurrentExternalPortType` method sets the external port type for this input using a `BMDSwitcherExternalPortType`. The external port type is settable only for some inputs and not all external port types are valid for a given input. Call the `GetAvailableExternalPortTypes` function to determine the available external port types for this input.

Syntax

```
HRESULT SetCurrentExternalPortType (BMDSwitcherExternalPortType type);
```

Parameters

Name	Direction	Description
type	in	The external port type.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_INVALIDARG	The type parameter is not valid a valid external port type for this input.

2.3.6 IBMDSwitcherInputCallback Interface

The `IBMDSwitcherInputCallback` object interface is a callback class which is called when a switcher input event such as a property change occurs.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherInput</code>	<code>IID_IBMDSwitcherInput</code>	An <code>IBMDSwitcherInputCallback</code> object interface may be installed with <code>IBMDSwitcherInput::AddCallback</code>

Public Member Functions

Method	Description
<code>Notify</code>	A Switcher Input event occurred such as a property change.

2.3.6.1 IBMDSwitcherInputCallback::Notify method

The `Notify` method is called when a `IBMDSwitcherInput` events occur, such as property changes. This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherInputEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherInputEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>E_FAIL</code>	Failure.
<code>S_OK</code>	Success.

2.3.7 IBMDSwitcherMixEffectBlockIterator Interface

The `IBMDSwitcherMixEffectBlockIterator` object interface is used to enumerate the available mix effect blocks.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	IBMDSwitcher::CreateIterator returns an <code>IBMDSwitcherMixEffectBlockIterator</code> object interface when the <code>IID_IBMDSwitcherMixEffectBlockIterator</code> IID is specified.

Public Member Functions

Method	Description
Next	Returns the next available switcher mix effect block.

2.3.7.1 IBMDSwitcherMixEffectBlockIterator::Next method

The `Next` method returns the next available `IBMDSwitcherMixEffectBlock` object interface.

The `IBMDSwitcherMixEffectBlock` object interface must be released by the caller when no longer required.

Syntax

```
HRESULT Next (IBMDSwitcherMixEffectBlock** mixEffectBlock);
```

Parameters

Name	Direction	Description
mixEffectBlock	out	IBMDSwitcherMixEffectBlock object interface

Return Values

Value	Description
S_OK	Success.
S_FALSE	No (more) mix effect blocks are available.
E_POINTER	The mixEffectBlock parameter is invalid.

2.3.8 IBMDSwitcherMixEffectBlock Interface

The `IBMDSwitcherMixEffectBlock` object interface represents a mix effect block of a switcher device.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMixEffectBlockIterator</code>	<code>IID_IBMDSwitcherMixEffectBlockIterator</code>	<code>IBMDSwitcherMixEffectBlockIterator::Next</code> returns <code>IBMDSwitcherMixEffectBlock</code> object interfaces for each available mix effect block of a switcher device.

Public Member Functions	
Method	Description
<code>GetProgramInput</code>	Get the current program input.
<code>SetProgramInput</code>	Set the program input.
<code>GetPreviewInput</code>	Get the current preview input.
<code>SetPreviewInput</code>	Set the preview input.
<code>GetPreviewLive</code>	Get the current preview-live flag.
<code>GetPreviewTransition</code>	Get the current preview-transition flag.
<code>SetPreviewTransition</code>	Set the preview-transition flag.
<code>PerformAutoTransition</code>	Initiate an automatic transition.
<code>PerformCut</code>	Initiate a cut.
<code>GetInTransition</code>	Get the current in-transition flag.
<code>GetTransitionPosition</code>	Get the current transition position value.
<code>SetTransitionPosition</code>	Set the transition position value.
<code>GetTransitionFramesRemaining</code>	Get the number of transition frames remaining.
<code>PerformFadeToBlack</code>	Initiate a fade to black.
<code>GetFadeToBlackRate</code>	Get the current fade to black rate value.
<code>SetFadeToBlackRate</code>	Set the fade to black rate value.
<code>GetFadeToBlackFramesRemaining</code>	Get the current number of fade to black frames remaining.
<code>GetFadeToBlackFullyBlack</code>	Get the current fade-to-black-fully-black flag.
<code>SetFadeToBlackFullyBlack</code>	Set the fade-to-black-fully-black flag.
<code>GetInFadeToBlack</code>	Get the current in-fade-to-black flag.
<code>GetFadeToBlackInTransition</code>	Get the current fade-to-black-in-transition flag.
<code>GetInputAvailabilityMask</code>	Get the switcher input availability mask.
<code>CreateIterator</code>	Create an iterator.
<code>AddCallback</code>	Add a callback to receive mix effect block events.
<code>RemoveCallback</code>	Remove a callback.

2.3.8.1 IBMDSwitcherMixEffectBlock::GetProgramInput method

The `GetProgramInput` method returns the current program input to the mix effect block.

Syntax

```
HRESULT GetProgramInput (BMDSwitcherInputId* value);
```

Parameters

Name	Direction	Description
value	out	The program input currently applied to the mix effect block.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.2 IBMDSwitcherMixEffectBlock::SetProgramInput method

The `SetProgramInput` method sets the program input to apply to the mix effect block.

Syntax

```
HRESULT SetProgramInput (BMDSwitcherInputId value);
```

Parameters

Name	Direction	Description
value	in	The program input to apply to the mix effect block.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure
E_INVALIDARG	The value is not a valid identifier.

2.3.8.3 **IBMDSwitcherMixEffectBlock::GetPreviewInput** method

The `GetPreviewInput` method returns the current preview input to the mix effect block.

Syntax

```
HRESULT GetPreviewInput (BMDSwitcherInputId* value);
```

Parameters

Name	Direction	Description
value	out	The preview input currently applied to the mix effect block.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.4 **IBMDSwitcherMixEffectBlock::SetPreviewInput** method

The `SetPreviewInput` method sets the preview input to apply to the mix effect block.

Syntax

```
HRESULT SetPreviewInput (BMDSwitcherInputId value);
```

Parameters

Name	Direction	Description
value	in	The preview input to apply to the mix effect block

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The value is not a valid identifier.

2.3.8.5 IBMDSwitcherMixEffectBlock::GetPreviewLive method

The `GetPreviewLive` method indicates whether the preview is live.

Syntax

```
HRESULT GetPreviewLive (boolean* value);
```

Parameters

Name	Direction	Description
value	out	The preview live flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.6 IBMDSwitcherMixEffectBlock::GetPreviewTransition method

The `GetPreviewTransition` method indicates whether the preview transition mode is currently enabled on the mix effect block.

Syntax

```
HRESULT GetPreviewTransition (boolean* value);
```

Parameters

Name	Direction	Description
value	out	The current preview transition flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.7 IBMDSwitcherMixEffectBlock::SetPreviewTransition method

The `SetPreviewTransition` method is used to enable or disable the preview transition mode.

Syntax

```
HRESULT SetPreviewTransition (boolean value);
```

Parameters

Name	Direction	Description
value	in	The desired preview transition flag

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.8.8 **IBMDSwitcherMixEffectBlock::PerformAutoTransition** method

The **PerformAutoTransition** method initiates an automatic transition for the mix effect block.

When the transition begins and ends the **bmdSwitcherMixEffectBlockEventTypeInTransitionChanged** callback will be fired with the in transition flag set to true and then false on completion. Throughout the transition the **bmdSwitcherMixEffectBlockEventTypeTransitionPositionChanged** and **bmdSwitcherMixEffectBlockEventTypeTransitionFramesRemainingChanged** callbacks will be fired with property values corresponding to the progress through the transition.

Syntax

```
HRESULT PerformAutoTransition ();
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.8.9 **IBMDSwitcherMixEffectBlock::PerformCut** method

The **PerformCut** method initiates a cut for the mix effect block.

Syntax

```
HRESULT PerformCut ();
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.8.10 **IBMDSwitcherMixEffectBlock::GetInTransition** method

The **GetInTransition** method indicates whether a transition is occurring

Syntax

```
HRESULT GetInTransition (boolean* value);
```

Parameters

Name	Direction	Description
value	out	The current in transition flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.11 **IBMDSwitcherMixEffectBlock::GetTransitionPosition** method

The `GetTransitionPosition` method returns the current transition position value.

Syntax

```
HRESULT GetTransitionPosition (double* value);
```

Parameters

Name	Direction	Description
value	out	The current transition position value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.12 **IBMDSwitcherMixEffectBlock::SetTransitionPosition** method

The `SetTransitionPosition` method sets the transition position value.

Syntax

```
HRESULT SetTransitionPosition (double value);
```

Parameters

Name	Direction	Description
value	in	The desired transition position value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Fail.

2.3.8.13 **IBMDSwitcherMixEffectBlock::GetTransitionFramesRemaining** method

The `GetTransitionFramesRemaining` method returns the number of transition frames remaining for the transition.

Syntax

```
HRESULT GetTransitionFramesRemaining (uint32_t* value);
```

Parameters

Name	Direction	Description
value	out	The number of transition frames remaining.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid..

2.3.8.14 **IBMDSwitcherMixEffectBlock::PerformFadeToBlack** method

The **PerformFadeToBlack** method initiates a fade to black for the mix effect block.

When the fade to black begins and ends the **bmdSwitcherMixEffectBlockEventTypeInFadeToBlackChanged** callback will be fired with the in fade to black flag set to true and then false on completion. Throughout the transition the **bmdSwitcherMixEffectBlockEventTypeFadeToBlackFramesRemainingChanged** callback will be fired with values corresponding to the progress through the fade to black.

Syntax

```
HRESULT PerformFadeToBlack ();
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.8.15 **IBMDSwitcherMixEffectBlock::GetFadeToBlackRate** method

The **GetFadeToBlackRate** method returns the current fade to black rate in frames.

Syntax

```
HRESULT GetFadeToBlackRate (uint32_t* value)
```

Parameters

Name	Direction	Description
value	out	The current fade to black rate.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.16 **IBMDSwitcherMixEffectBlock::SetFadeToBlackRate** method

The **SetFadeToBlackRate** method returns the number of frames remaining for the fade to black.

Syntax

```
HRESULT SetFadeToBlackRate (uint32_t value);
```

Parameters

Name	Direction	Description
value	in	The desired fade to black rate.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The value is not a valid number of frames.

2.3.8.17 **IBMDSwitcherMixEffectBlock::GetFadeToBlackFramesRemaining** method

The `GetFadeToBlackFramesRemaining` method returns the number of frames remaining for the fade to black.

Syntax

```
HRESULT GetFadeToBlackFramesRemaining (uint32_t* value);
```

Parameters

Name	Direction	Description
value	out	The number of fade to black frames remaining.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.18 **IBMDSwitcherMixEffectBlock::GetFadeToBlackFullyBlack** method

The `GetFadeToBlackFullyBlack` method indicates whether the current frame is completely black.

Syntax

```
HRESULT GetFadeToBlackFullyBlack (boolean* value);
```

Parameters

Name	Direction	Description
value	out	The current fade to black fully black flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.19 **IBMDSwitcherMixEffectBlock::SetFadeToBlackFullyBlack** method

The `SetFadeToBlackFullyBlack` method sets the fade to black fully black flag.

Syntax

```
HRESULT SetFadeToBlackFullyBlack (boolean value);
```

Parameters

Name	Direction	Description
value	in	The desired fade to black fully black flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.8.20 IBMDSwitcherMixEffectBlock::GetInFadeToBlack method

The `GetInFadeToBlack` method indicates whether fade to black is transitioning or the frame is completely black.

Syntax

```
HRESULT GetInFadeToBlack (boolean* value);
```

Parameters

Name	Direction	Description
value	out	The current in fade to black flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.21 IBMDSwitcherMixEffectBlock::GetFadeToBlackInTransition method

The `GetFadeToBlackInTransition` method indicates whether fade to black is transitioning.

Syntax

```
HRESULT GetFadeToBlackInTransition (boolean* value);
```

Parameters

Name	Direction	Description
value	out	The current fade to black in transition flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

2.3.8.22 **IBMDSwitcherMixEffectBlock::GetInputAvailabilityMask** method

The `GetInputAvailabilityMask` method returns the corresponding `BMDSwitcherInputAvailability` bit mask value for this mix effect block. The input availability property of an `IBMDSwitcherInput` can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use by this mix effect block.

Syntax

```
HRESULT GetInputAvailabilityMask (BMDSwitcherInputAvailability* value);
```

Parameters

Name	Direction	Description
value	out	The availability of the input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.
E_FAIL	Failure.

2.3.8.23 **IBMDSwitcherMixEffectBlock::CreateIterator** method

The `CreateIterator` method creates an iterator object interface for the specified interface ID.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Iterator Interface ID to create an iterator for.
ppv	out	Pointer to return interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_OUTOFMEMORY	Insufficient memory to create interface object.
E_NOINTERFACE	Interface was not found.

2.3.8.24 **IBMDSwitcherMixEffectBlock::AddCallback** method

The **AddCallback** method configures a callback to be called when a mix effect block property changes.

Adding a new callback will not affect previously added callbacks. Callbacks will be called on a separate thread and in the order of their addition by **AddCallback**.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMixEffectBlockCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMixEffectBlockCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.8.25 **IBMDSwitcherMixEffectBlock::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMixEffectBlockCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object to remove.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.9 IBMDSwitcherMixEffectBlockCallback Interface

The `IBMDSwitcherMixEffectBlockCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherMixEffectBlock` object.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMixEffectBlock</code>	<code>IID_IBMDSwitcherMixEffectBlock</code>	An <code>IBMDSwitcherMixEffectBlockCallback</code> object interface is installed with <code>IBMDSwitcherMixEffectBlock::AddCallback</code> and removed with <code>IBMDSwitcherMixEffectBlock::RemoveCallback</code> .

Public Member Functions	
Method	Description
<code>Notify</code>	Called when an event occurs.

2.3.9.1 IBMDSwitcherMixEffectBlockCallback::Notify method

The `Notify` method is called when `IBMDSwitcherMixEffectBlock` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherMixEffectBlockEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherMixEffectBlockEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

2.3.10 IBMDSwitcherInputColor Interface

The `IBMDSwitcherInputColor` object interface is used for managing a color generator input port.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherInput</code>	<code>IID_IBMDSwitcherInput</code>	An <code>IBMDSwitcherInputColor</code> object interface can be obtained with <code>IBMDSwitcherInput::QueryInterface</code> .

Public Member Functions

Method	Description
<code>GetHue</code>	Get the current hue value.
<code>SetHue</code>	Set the hue value.
<code>GetSaturation</code>	Get the current saturation value.
<code>SetSaturation</code>	Set the saturation value.
<code>GetLuma</code>	Get the current luminance value.
<code>SetLuma</code>	Set the luminance value.
<code>AddCallback</code>	Add a color input callback.
<code>RemoveCallback</code>	Remove a color input callback.

2.3.10.1 IBMDSwitcherInputColor::GetHue method

The `GetHue` method gets the current hue value.

Syntax

```
HRESULT GetHue (double* hue);
```

Parameters

Name	Direction	Description
<code>propertyId</code>	in	Id of the property that changed as a <code>BMDSwitcherMixEffectBlockPropertyId</code>

Return Values

Value	Description
<code>E_FAIL</code>	Failure.
<code>S_OK</code>	Success.

2.3.10.2 IBMDSwitcherInputColor::SetHue method

The SetHue method sets the hue value.

Syntax

```
HRESULT SetHue (double hue);
```

Parameters

Name	Direction	Description
hue	in	The desired hue value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.10.3 IBMDSwitcherInputColor::GetSaturation method

The GetSaturation method gets the current hue value.

Syntax

```
HRESULT GetSaturation (double* sat);
```

Parameters

Name	Direction	Description
sat	out	The current sat value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The sat parameter is invalid.

2.3.10.4 IBMDSwitcherInputColor::SetSaturation method

The SetSaturation method sets the hue value.

Syntax

```
HRESULT SetSaturation (double sat);
```

Parameters

Name	Direction	Description
sat	in	The desired saturation value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.10.5 IBMDSwitcherInputColor::GetLuma method

The GetLuma method gets the current luminance value.

Syntax

```
HRESULT GetLuma (double* luma);
```

Parameters

Name	Direction	Description
luma	out	The current luminance value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The luma parameter is invalid.

2.3.10.6 IBMDSwitcherInputColor::SetLuma method

The SetLuma method sets the luminance value.

Syntax

```
HRESULT SetLuma (double luma);
```

Parameters

Name	Direction	Description
luma	in	The desired luminance value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.10.7 **IBMDSwitcherInputColor::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherInputColor** object. Pass an object implementing the **IBMDSwitcherInputColorCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherInputColorCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherInputColorCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.10.8 **IBMDSwitcherInputColor::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherInputColorCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherInputColorCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.11 IBMDSwitcherInputColorCallback Interface

The `IBMDSwitcherInputColorCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherInputColor` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherInputColor</code>	<code>IID_IBMDSwitcherInputColor</code>	An <code>IBMDSwitcherInputColorCallback</code> object interface is installed with <code>IBMDSwitcherInputColor::AddCallback</code> and removed with <code>IBMDSwitcherInputColor::RemoveCallback</code>

Public Member Functions	
Method	Description
<code>Notify</code>	Called when an event occurs.

2.3.11.1 IBMDSwitcherInputColorCallback::Notify method

The `Notify` method is called when `IBMDSwitcherInputColor` events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherInputColorEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherInputColorEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

2.3.12 IBMDSwitcherInputAux Interface

The `IBMDSwitcherInputAux` object interface is used for managing an auxiliary output port.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherInput</code>	<code>IID_IBMDSwitcherInput</code>	An <code>IBMDSwitcherInputAux</code> object interface can be obtained with <code>IBMDSwitcherInput::QueryInterface</code> .

Public Member Functions

Method	Description
<code>GetInputSource</code>	Get the selected input source.
<code>SetInputSource</code>	Select the input source.
<code>GetInputAvailabilityMask</code>	Get the corresponding <code>BMDSwitcherInputAvailability</code> bit value for auxiliary port.
<code>AddCallback</code>	Add an aux callback.
<code>RemoveCallback</code>	Remove an aux callback.

2.3.12.1 IBMDSwitcherInputAux::GetInputSource method

The `GetInputSource` method returns the currently selected input source.

Syntax

```
HRESULT GetInputSource (BMDSwitcherInputId* inputId);
```

Parameters

Name	Direction	Description
<code>inputId</code>	out	The <code>BMDSwitcherInputId</code> of the selected input source.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	Invalid <code>inputId</code> parameter.

2.3.12.2 IBMDSwitcherInputAux::SetInputSource method

The `SetInputSource` method selects an input source for this auxiliary port.

Syntax

```
HRESULT SetInputSource (BMDSwitcherInputId inputId);
```

Parameters

Name	Direction	Description
inputId	in	The <code>BMDSwitcherInputId</code> of the desired input source.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	Invalid inputId parameter.
E_FAIL	Failure.

2.3.12.3 IBMDSwitcherInputAux::GetInputAvailabilityMask method

The `GetInputAvailabilityMask` method returns the corresponding `BMDSwitcherInputAvailability` bit mask value for this auxiliary port. The input availability property of an `IBMDSwitcherInput` can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use by this auxiliary port.

Syntax

```
HRESULT GetInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	<code>BMDSwitcherInputAvailability</code> bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

2.3.12.4 IBMDSwitcherInputAux::AddCallback method

The AddCallback method configures a callback to be called when events occur for an **IBMDSwitcherInputAux** object. Pass an object implementing the **IBMDSwitcherInputAuxCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherInputAuxCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherInputAuxCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.12.5 IBMDSwitcherInputAux::RemoveCallback method

The RemoveCallback method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherInputAuxCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherInputAuxCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.13 IBMDSwitcherInputAuxCallback Interface

The `IBMDSwitcherInputAuxCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherInputAux` object.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherInputAux</code>	<code>IID_IBMDSwitcherInputAux</code>	An <code>IBMDSwitcherInputAuxCallback</code> object interface is installed with <code>IBMDSwitcherInputAux::AddCallback</code> and removed with <code>IBMDSwitcherInputAux::RemoveCallback</code>

Public Member Functions	
Method	Description
<code>Notify</code>	Called when an event occurs.

2.3.13.1 IBMDSwitcherInputAuxCallback::Notify method

The `Notify` method is called when `IBMDSwitcherInputAux` events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherInputAuxEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherInputAuxEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

2.3.14 IBMDSwitcherMultiViewIterator Interface

The `IBMDSwitcherMultiViewIterator` is used to enumerate the available `MultiViews`.

A reference to an `IBMDSwitcherMultiViewIterator` object interface may be obtained from an `IBMDSwitcher` object interface using the `CreateIterator` method. Pass `IID_IBMDSwitcherMultiViewIterator` for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcher</code>	<code>IID_IBMDSwitcher</code>	<code>IBMDSwitcher::CreateIterator</code> can return an <code>IBMDSwitcherMultiViewIterator</code> object interface.

Public Member Functions

Method	Description
<code>Next</code>	Returns a pointer to the next <code>IBMDSwitcherMultiView</code> object interface.

2.3.14.1 IBMDSwitcherMultiViewIterator::Next method

The `Next` method returns the next available `IBMDSwitcherMultiView` object interface.

Syntax

```
HRESULT Next (IBMDSwitcherMultiView** multiView);
```

Parameters

Name	Direction	Description
<code>multiView</code>	out	<code>IBMDSwitcherMultiView</code> object interface.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>S_FALSE</code>	No more <code>IBMDSwitcherMultiView</code> objects available.
<code>E_POINTER</code>	The <code>multiView</code> parameter is invalid.

2.3.15 IBMDSwitcherMultiView Interface

The `IBMDSwitcherMultiView` object interface is used for accessing control functions of a MultiView output, such as setting up the layout format, or routing different inputs to windows.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMultiViewIteator</code>	<code>IID_IBMDSwitcherMultiViewIteator</code>	An <code>IBMDSwitcherMultiView</code> object will be returned after a successful call to <code>IBMDSwitcherMultiViewIteator::Next</code> method.

Public Member Functions	
Method	Description
<code>CanChangeLayout</code>	Determine if the Multiview supports layout changing.
<code>GetLayout</code>	Get the current layout format.
<code>SetLayout</code>	Set layout format.
<code>SupportsQuadrantLayout</code>	Determine if this MultiView supports quadrant layout.
<code>GetWindowInput</code>	Get current input routing of a window.
<code>SetWindowInput</code>	Set input routing of a window.
<code>GetWindowCount</code>	Get number of windows available.
<code>GetInputAvailabilityMask</code>	Get the corresponding <code>BMDSwitcherInputAvailability</code> bit value for MultiView.
<code>CanRouteInputs</code>	Determine if this MultiView supports custom input-to-window routing.
<code>SupportsVuMeters</code>	Determine if this switcher supports the display of VU meters on the MultiView.
<code>CurrentInputSupportsVuMeter</code>	Check if the current input of a specified MultiView window supports VU meters.
<code>GetVuMeterEnabled</code>	Check if the VU meter is currently visible on a specified window.
<code>SetVuMeterEnabled</code>	Hide or show the VU meter on a specified window.
<code>CanAdjustVuMeterOpacity</code>	Determine if this MultiView supports changing the VU meter opacity.
<code>GetVuMeterOpacity</code>	Get the current MultiView VU meter opacity.
<code>SetVuMeterOpacity</code>	Set the MultiView VU meter opacity.
<code>CanToggleSafeAreaEnabled</code>	Determine if this MultiView supports toggling the safe area overlay on and off.
<code>CurrentInputSupportsSafeArea</code>	Determine if a MultiView window supports displaying the safe area overlay.
<code>GetSafeAreaEnabled</code>	Check if the safe area overlay is currently visible.
<code>SetSafeAreaEnabled</code>	Hide or show the safe area overlay.
<code>SupportsProgramPreviewSwap</code>	Determine if this MultiView supports swapping the positions of the program and preview windows.
<code>GetProgramPreviewSwapped</code>	Check if the program and preview window positions are currently swapped.
<code>SetProgramPreviewSwapped</code>	Set the program and preview window positions to standard or swapped.
<code>AddCallback</code>	Add a MultiView callback.
<code>RemoveCallback</code>	Remove a MultiView callback.

2.3.15.1 **IBMDSwitcherMultiView::CanChangeLayout** method

The **CanChangeLayout** method is used to determine if the switcher supports changing the MultiView window layout.

Most switchers are capable of changing the layout of the windows displayed in the MultiView.

Syntax

```
HRESULT CanChangeLayout(BOOLEAN* canChangeLayout)
```

Parameters

Name	Direction	Description
canChangeLayout	out	A Boolean value indicating whether the switcher supports changing the MultiView layout.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canChangeLayout parameter is invalid.

2.3.15.2 **IBMDSwitcherMultiView::GetLayout** method

The **GetLayout** method returns the current layout format.

Syntax

```
HRESULT GetLayout (BMDSwitcherMultiViewLayout* layout);
```

Parameters

Name	Direction	Description
layout	out	Current layout format as a BMDSwitcherMultiViewLayout .

Return Values

Value	Description
S_OK	Success.
E_POINTER	The layout parameter is invalid.

2.3.15.3 IBMDSwitcherMultiView::SetLayout method

The `SetLayout` method sets the layout format.

If the switcher supports quadrant layout, then `bmdSwitcherMultiViewLayoutTopLeftSmall`, `bmdSwitcherMultiViewLayoutTopRightSmall`, `bmdSwitcherMultiViewLayoutBottomLeftSmall`, and `bmdSwitcherMultiViewLayoutBottomRightSmall` are bitmask fields that can be bitwise-ORed in any combination to describe which quadrants should show four small windows. If the bit for a quadrant is not set, the quadrant will display a large window.

If a switcher does not support quadrant layout, then only `bmdSwitcherMultiViewLayoutProgramTop`, `bmdSwitcherMultiViewLayoutProgramBottom`, `bmdSwitcherMultiViewLayoutProgramLeft`, and `bmdSwitcherMultiViewLayoutProgramRight` are valid.

Syntax

```
HRESULT SetLayout (BMDSwitcherMultiViewLayout* layout);
```

Parameters

Name	Direction	Description
layout	in	Desired layout format in <code>BMDSwitcherMultiViewLayout</code> .

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	Failure.
E_POINTER	Invalid layout parameter.

2.3.15.4 IBMDSwitcherMultiView::SupportsQuadrantLayout method

The `SupportsQuadrantLayout` method is used to determine if the switcher supports quadrant layout.

Some switchers are capable of configuring each quadrant of the MultiView as either one large window or four small windows. Switchers that are not capable of independent quadrant configuration are still capable of displaying the classic ten window configuration which is made up of two large windows either at the top, bottom, left or right side of the display and eight small windows in the remaining area of the display.

Syntax

```
HRESULT SupportsQuadrantLayout (boolean* supportsQuadrantLayout)
```

Parameters

Name	Direction	Description
supportsQuadrantLayout	out	Boolean value indicating whether quadrant layout is supported by the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsQuadrantLayout parameter is invalid.

2.3.15.5 **IBMDSwitcherMultiView::GetWindowInput** method

The `GetWindowInput` method returns the current input source routed to the specified window.

Syntax

```
HRESULT GetWindowInput (uint32_t window, BMDSwitcherInputId* inputId);
```

Parameters

Name	Direction	Description
window	in	Zero-based window index.
inputId	out	Input source as a <code>BMDSwitcherInputId</code> .

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The window parameter is invalid.
E_POINTER	The inputId parameter is invalid.

2.3.15.6 **IBMDSwitcherMultiView::SetWindowInput** method

The `SetWindowInput` method routes an input source to the specified window. Note that the inputs for windows 0 and 1 are reserved for the Preview and Program outputs, and so cannot be set using this method. Calling this method with a window index of 0 or 1 will do nothing and will return `S_FALSE`.

Syntax

```
HRESULT SetWindowInput (uint32_t window, BMDSwitcherInputId inputId);
```

Parameters

Name	Direction	Description
window	in	Zero-based window index. Values of 0 and 1 are ignored.
inputId	in	<code>BMDSwitcherInputId</code> input source.

Return Values

Value	Description
S_OK	Success.
S_FALSE	The input for the specified window cannot be set using this method.
E_FAIL	Failure.
E_INVALIDARG	The window and/or inputId parameter is invalid.

2.3.15.7 **IBMDSwitcherMultiView::GetWindowCount** method

The `GetWindowCount` method returns the total number of windows available to this `MultiView`.

Syntax

```
HRESULT GetWindowCount (uint32_t* windowCount);
```

Parameters

Name	Direction	Description
windowCount	out	Total number of windows.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The windowCount parameter is invalid.

2.3.15.8 **IBMDSwitcherMultiView::GetInputAvailabilityMask** method

The `GetInputAvailabilityMask` method returns the corresponding `BMDSwitcherInputAvailability` bit mask value for this `MultiView`. The input availability property of an `IBMDSwitcherInput` can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for viewing in a window.

Syntax

```
HRESULT GetInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	<code>BMDSwitcherInputAvailability</code> bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

2.3.15.9 IBMDSwitcherMultiView::CanRouteInputs method

The `CanRouteInputs` method returns whether this MultiView has custom input-to-window routing capability. This feature allows custom selection of input sources on each window, whereas without this feature the configuration is static and the window input sources cannot be changed. If the MultiView has no such capability, any call to `SetWindowInput` will fail.

Syntax

```
HRESULT CanRouteInputs (boolean* canRoute);
```

Parameters

Name	Direction	Description
canRoute	out	Boolean that indicates if this MultiView is capable of custom input-to-window routing.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canRoute parameter is invalid.

2.3.15.10 IBMDSwitcherMultiView::SupportsVuMeters method

The `SupportsVuMeters` method is used to determine if the switcher supports the display of VU meters on the MultiView.

Syntax

```
HRESULT SupportsVuMeters (boolean* supportsVuMeters);
```

Parameters

Name	Direction	Description
supportsVuMeters	out	Boolean value indicating whether VU meters are supported by the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsVuMeters parameter is not a valid pointer.

2.3.15.11 IBMDSwitcherMultiView::CurrentInputSupportsVuMeter method

The `CurrentInputSupportsVuMeter` method is used to determine if a MultiView window is currently set to an input that supports the display of a VU meter. Some inputs, such as Color Bars and Color Generators do not support the display of a VU meter.

Syntax

```
HRESULT CurrentInputSupportsVuMeter (int32_t window, boolean* supportsVuMeter);
```

Parameters

Name	Direction	Description
window	in	Zero-based window index.
supportsVuMeter	out	Boolean value indicating whether display of a VU meter is supported by the input that is currently selected on the specified window.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the switcher does not support VU meters.
E_POINTER	The supportsVuMeter parameter is not a valid pointer.
E_INVALIDARG	The window parameter is not a valid window index.

2.3.15.12 IBMDSwitcherMultiView::GetVuMeterEnabled method

The `GetVuMeterEnabled` method is used to determine if the the VU meter is currently visible on the specified MultiView window.

Syntax

```
HRESULT GetVuMeterEnabled (uint32_t window, boolean* enabled);
```

Parameters

Name	Direction	Description
window	in	Zero-based window index.
enabled	out	Boolean value indicating whether the VU meter is currently visible on the specified window.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the switcher does not support VU meters.
E_POINTER	The enabled parameter is not a valid pointer.
E_INVALIDARG	The window parameter is not a valid window index.

2.3.15.13 **IBMDSwitcherMultiView::SetVuMeterEnabled** method

The `SetVuMeterEnabled` method is used to hide or show VU meters on the specified MultiView window.

Syntax

```
HRESULT SetVuMeterEnabled (uint32_t window, boolean enabled);
```

Parameters

Name	Direction	Description
window	in	Zero-based window index.
enabled	in	Boolean value indicating whether VU meters should be made visible on the specified window.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the switcher does not support VU meters.
E_INVALIDARG	The window parameter is not a valid window index.

2.3.15.14 **IBMDSwitcherMultiView::CanAdjustVuMeterOpacity** method

The `CanAdjustVuMeterOpacity` method is used to determine if the switcher supports changing the MultiView window VU meter opacity.

Syntax

```
HRESULT CanAdjustVuMeterOpacity(Boolean* canAdjustVuMeterOpacity)
```

Parameters

Name	Direction	Description
canAdjustVuMeterOpacity	out	Boolean value indicating whether the switcher supports changing the VU meter opacity.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canAdjustVuMeterOpacity parameter is invalid.
E_FAIL	Failure.

2.3.15.15 **IBMDSwitcherMultiView::GetVuMeterOpacity** method

The `GetVuMeterOpacity` method returns the opacity of the VU meters displayed on the MultiView as a value between zero and one. A value of 0.0 is fully transparent, and a value of 1.0 is fully opaque.

Syntax

```
HRESULT GetVuMeterOpacity (double* opacity);
```

Parameters

Name	Direction	Description
opacity	out	The opacity of the VU meters from 0.0 (fully transparent) to 1.0 (fully opaque).

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the switcher does not support VU meters.
E_POINTER	The opacity parameter is not a valid pointer.

2.3.15.16 **IBMDSwitcherMultiView::SetVuMeterOpacity** method

The `SetVuMeterOpacity` method is used to set the opacity of the VU meters displayed on the MultiView.

Syntax

```
HRESULT SetVuMeterOpacity (double opacity);
```

Parameters

Name	Direction	Description
opacity	in	The opacity of the VU meters from 0.0 (fully transparent) to 1.0 (fully opaque).

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the switcher does not support VU meters.

2.3.15.17 **IBMDSwitcherMultiView::CanToggleSafeAreaEnabled** method

The `CanToggleSafeAreaEnabled` method is used to determine whether the switcher supports toggling the safe area overlay on the MultiView preview window on and off.

Syntax

```
HRESULT CanToggleSafeAreaEnabled (boolean* canToggleSafeAreaEnabled);
```

Parameters

Name	Direction	Description
canToggleSafeAreaEnabled	out	A Boolean value indicating whether the switcher supports toggling the safe area overlay on and off.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canToggleSafeAreaEnabled parameter is not a valid pointer.

2.3.15.18 **IBMDSwitcherMultiView::CurrentInputSupportsSafeArea** method

The `CurrentInputSupportsSafeArea` method is used to determine if a MultiView window supports displaying the safe area overlay. Only large windows whose input is set to a preview output will support displaying the safe area overlay.

Syntax

```
HRESULT CurrentInputSupportsSafeArea (uint32_t window, boolean* supportsSafeArea)
```

Parameters

Name	Direction	Description
window	in	Zero-based window index.
supportsSafeArea	out	Boolean value indicating whether display of a the safe area is supported by the input that is currently selected on the specified window.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsSafeArea parameter is invalid.
E_INVALIDARG	The window parameter is not a valid window index.
E_FAIL	Failure. This can happen if the switcher does not support toggling the safe area overlay on and off.

2.3.15.19 IBMDSwitcherMultiView::GetSafeAreaEnabled method

The `GetSafeAreaEnabled` method is used to determine whether the safe area overlay is currently visible on the MultiView window.

Syntax

```
HRESULT GetSafeAreaEnabled (uint32_t window, boolean* enabled);
```

Parameters

Name	Direction	Description
window	in	Zero-based window index.
enabled	out	A Boolean value indicating whether the safe area overlay is currently visible on the MultiView window.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is not a valid pointer.
E_INVALIDARG	The window parameter is not a valid window index.

2.3.15.20 IBMDSwitcherMultiView::SetSafeAreaEnabled method

The `SetSafeAreaEnabled` method is used to hide or show the safe area overlay on the MultiView window.

Syntax

```
HRESULT SetSafeAreaEnabled (uint32_t window, boolean* enabled);
```

Parameters

Name	Direction	Description
window	in	Zero-based window index.
enabled	in	A Boolean value indicating whether the safe area overlay should be made visible on the MultiView window.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.
E_INVALIDARG	The window parameter is not a valid window index.
E_FAIL	Failure. This can happen if the switcher does not support toggling the safe area overlay on and off.

2.3.15.21 **IBMDSwitcherMultiView::SupportsProgramPreviewSwap** method

The **SupportsProgramPreviewSwap** method is used to determine if the switcher supports swapping the positions of the program and preview windows on the MultiView. Standard positioning places the preview window to the left of or above the program window. Swapping places the preview window to the right of or below the program window.

Syntax

```
HRESULT SupportsProgramPreviewSwap (boolean* supportsProgramPreviewSwap);
```

Parameters

Name	Direction	Description
supportsProgramPreviewSwap	out	A Boolean value indicating whether the switcher supports swapping the program and preview window positions on the MultiView.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsProgramPreviewSwap parameter is not a valid pointer.

2.3.15.22 **IBMDSwitcherMultiView::GetProgramPreviewSwapped** method

The **GetProgramPreviewSwapped** method is used to determine if the MultiView program and preview window positions are currently swapped.

Syntax

```
HRESULT GetProgramPreviewSwapped (boolean* swapped);
```

Parameters

Name	Direction	Description
swapped	out	A Boolean value indicating whether the program and preview window positions are currently swapped.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The swapped parameter is not a valid pointer.

2.3.15.23 **IBMDSwitcherMultiView::SetProgramPreviewSwapped** method

The **SetProgramPreviewSwapped** method is used to specify whether the MultiView program and preview window positions should be swapped.

Syntax

```
HRESULT SetProgramPreviewSwapped (boolean swapped);
```

Parameters

Name	Direction	Description
swapped	in	A Boolean value indicating whether the program and preview window positions should be swapped.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the switcher does not support swapping the positions of the program and preview windows.

2.3.15.24 **IBMDSwitcherMultiView::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherMultiView** object. Pass an object implementing the **IBMDSwitcherMultiViewCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMultiViewCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMultiViewCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.15.25 **IBMDSwitcherMultiView::RemoveCallback** method

The `RemoveCallback` method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMultiViewCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the <code>IBMDSwitcherMultiViewCallback</code> object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.16 **IBMDSwitcherMultiViewCallback** Interface

The `IBMDSwitcherMultiViewCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherMultiView` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMultiView</code>	<code>IID_IBMDSwitcherMultiView</code>	An <code>IBMDSwitcherMultiViewCallback</code> object interface is installed with <code>IBMDSwitcherMultiView::AddCallback</code> and removed with <code>IBMDSwitcherMultiView::RemoveCallback</code>

Public Member Functions

Method	Description
<code>Notify</code>	Called when an event occurs.

2.3.16.1 IBMDSwitcherMultiViewCallback::Notify method

The **Notify** method is called when **IBMDSwitcherMultiView** events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherMultiViewEventType eventType, int32_t window);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherMultiViewEventType that describes the type of event that has occurred.
window	in	This parameter is only valid when eventType is bmdSwitcherMultiViewEventTypeWindowChanged , it specifies the window index that was changed.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.17 IBMDSwitcherSerialPortIterator Interface

The **IBMDSwitcherSerialPortIterator** object interface is used to enumerate the available serial ports on the switcher.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	IBMDSwitcher::CreateIterator returns an IBMDSwitcherSerialPortIterator interface when the IID_IBMDSwitcherSerialPortIterator IID is specified.

Public Member Functions	
Method	Description
Next	Returns the next available serial port.

2.3.17.1 **IBMDSwitcherSerialPortIterator::Next** method

The Next method returns the next available **IBMDSwitcherSerialPort** object interface.

The **IBMDSwitcherSerialPort** object interface must be released by the caller when no longer required.

Syntax

```
HRESULT Next (IBMDSwitcherSerialPort** serialPort);
```

Parameters

Name	Direction	Description
serialPort	out	IBMDSwitcherSerialPort object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No (more) serial ports available.
E_POINTER	The serialPort parameter is invalid.

2.3.18 **IBMDSwitcherSerialPort** Interface

The **IBMDSwitcherSerialPort** object interface is used for managing a serial port on the switcher.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherSerialPortIterator	IID_ IBMDSwitcherSerialPortIterator	IBMDSwitcherSerialPortIterator::Next returns IBMDSwitcherSerialPort interfaces for each available serial port of a switcher device.

Public Member Functions	
Method	Description
SetFunction	Set the function of the serial port using a BMDSwitcherSerialPortFunction .
GetFunction	Returns the function of the serial port as a BMDSwitcherSerialPortFunction .
DoesSupportFunction	Check if a given BMDSwitcherSerialPortFunction is supported by the switcher.
AddCallback	Add a serial port callback.
RemoveCallback	Remove a serial port callback.

2.3.18.1 **IBMDSwitcherSerialPort::SetFunction** method

The `SetFunction` method sets the function of the serial port.

Syntax

```
HRESULT SetFunction (BMDSwitcherSerialPortFunction function);
```

Parameters

Name	Direction	Description
function	in	The function to which the serial port should be set.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The function parameter is not a valid serial port function.

2.3.18.2 **IBMDSwitcherSerialPort::GetFunction** method

The `GetFunction` method returns the current function of the serial port.

Syntax

```
HRESULT GetFunction (BMDSwitcherSerialPortFunction* function);
```

Parameters

Name	Direction	Description
function	out	A <code>BMDSwitcherSerialPortFunction</code> describing which function the serial port is currently set to.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The function parameter is not a valid pointer.

2.3.18.3 **IBMDSwitcherSerialPort::DoesSupportFunction** method

The **DoesSupportFunction** method is used to determine if a given serial port function is supported by the switcher.

Syntax

```
HRESULT DoesSupportFunction (BMDSwitcherSerialPortFunction function,  
                             boolean* supported);
```

Parameters

Name	Direction	Description
function	in	The serial port function being queried.
supported	out	Boolean value describing whether the specified function is supported by the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supported parameter is not a valid pointer.
E_INVALIDARG	The function parameter is not a valid BMDSwitcherSerialPortFunction .

2.3.18.4 **IBMDSwitcherSerialPort::AddCallback** method

The **AddCallback** method configures a callback to be called when a switcher serial port property changes, such as a change in the serial port function.

Adding a new callback will not affect previously added callbacks.

Callbacks will be called on a separate thread and in the order of their addition by **AddCallback**.

Syntax

```
HRESULT AddCallback (IBMDSwitcherSerialPortCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherSerialPortCallback interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.18.5 IBMDSwitcherSerialPort::RemoveCallback method

The RemoveCallback method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherSerialPortCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object to remove.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.19 IBMDSwitcherSerialPortCallback Interface

The IBMDSwitcherSerialPortCallback object interface is a callback class which is called when a switcher serial port event occurs, such as a change in the serial port function.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherSerialPort	IID_IBMDSwitcherSerialPort	An IBMDSwitcherSerialPortCallback interface may be installed with IBMDSwitcherSerialPort::AddCallback

Public Member Functions	
Method	Description
Notify	A Switcher Serial Port event occurred, such as a change in the serial port function.

2.3.19.1 IBMDSwitcherSerialPortCallback::Notify method

The **Notify** method is called when **IBMDSwitcherSerialPort** events occur, such as a change in the serial port function.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherSerialPortEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherSerialPortEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_FAIL	Failure.
S_OK	Success.

2.3.20 IBMDSwitcherMixMinusOutputIterator Interface

The **IBMDSwitcherMixMinusOutputIterator** is used to enumerate the available mix minus outputs for the switcher.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	IBMDSwitcher::CreateIterator returns an IBMDSwitcherMixMinusOutputIterator interface when the IID_IBMDSwitcherMixMinusOutputIterator IID is specified.

Public Member Functions	
Method	Description
Next	Returns a pointer to the next IBMDSwitcherMixMinusOutput object interface.

2.3.20.1 IBMDSwitcherMixMinusOutputIterator::Next method

The `Next` method returns the next available `IBMDSwitcherMixMinusOutput` object interface.

The `IBMDSwitcherMixMinusOutput` object interface must be released by the caller when no longer required.

Syntax

```
HRESULT Next (IBMDSwitcherMixMinusOutput** mixMinusOutput);
```

Parameters

Name	Direction	Description
mixMinusOutput	out	IBMDSwitcherMixMinusOutput object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No (more) mix minus outputs are available.
E_POINTER	The mixMinusOutput parameter is not a valid pointer.

2.3.21 IBMDSwitcherMixMinusOutput Interface

The `IBMDSwitcherMixMinusOutput` object interface is used for managing a mix minus output port.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMixMinusOutputIterator	IID_IBMDSwitcherMixMinusOutputIterator	An <code>IBMDSwitcherMixMinusOutput</code> object will be returned after a successful call to the <code>IBMDSwitcherMixMinusOutputIterator::Next</code> method.

Public Member Functions	
Method	Description
GetAvailableAudioModes	Get the available mix minus output audio modes as a bit mask of <code>BMDSwitcherMixMinusOutputAudioMode</code> .
GetAudioMode	Get the current audio mode of the output as a <code>BMDSwitcherMixMinusOutputAudioMode</code> .
SetAudioMode	Set the audio mode of the output using a <code>BMDSwitcherMixMinusOutputAudioMode</code> .
HasMinusAudioInputId	Get the current has minus audio input ID flag.
GetMinusAudioInputId	Get the <code>BMDSwitcherAudioInputId</code> of the audio input that is subtracted when in mix minus audio mode.
AddCallback	Add a mix minus output callback.
RemoveCallback	Remove a mix minus output callback.

2.3.21.1 **IBMDSwitcherMixMinusOutput::GetAvailableAudioModes** method

The `GetAvailableAudioModes` method gets the available mix minus output audio modes for this switcher, given as a bit mask of `BMDSwitcherMixMinusOutputAudioMode`. This bit mask can be bitwise-ANDed with any value of `BMDSwitcherMixMinusOutputAudioMode` (e.g. `bmdSwitcherMixMinusOutputAudioModeProgramOut`) to determine if that mix minus output audio mode is available.

Syntax

```
HRESULT GetAvailableAudioModes (BMDSwitcherMixMinusOutputAudioMode* audioModes)
```

Parameters

Name	Direction	Description
audioModes	out	The available mix minus output audio modes as a bit mask of <code>BMDSwitcherMixMinusOutputAudioMode</code> .

Return Values

Value	Description
S_OK	Success.
E_POINTER	The audioModes parameter is invalid.

2.3.21.2 **IBMDSwitcherMixMinusOutput::GetAudioMode** method

The `GetAudioMode` method returns the current audio mode of the mix minus output.

Syntax

```
HRESULT GetAudioMode (BMDSwitcherMixMinusOutputAudioMode* audioMode);
```

Parameters

Name	Direction	Description
audioMode	out	The current audio mode as a <code>BMDSwitcherMixMinusOutputAudioMode</code> .

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The audioMode parameter is not a valid pointer.

2.3.21.3 **IBMDSwitcherMixMinusOutput::SetAudioMode** method

The `SetAudioMode` method sets the audio mode of the mix minus output.

Syntax

```
HRESULT SetAudioMode (BMDSwitcherMixMinusOutputAudioMode audioMode);
```

Parameters

Name	Direction	Description
audioMode	in	The desired audio mode in <code>BMDSwitcherMixMinusOutputAudioMode</code> .

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The audioMode parameter is invalid.

2.3.21.4 **IBMDSwitcherMixMinusOutput::HasMinusAudioInputId** method

The `HasMinusAudioInputId` method returns the current has minus audio input ID flag.

Syntax

```
HRESULT HasMinusAudioInputId (boolean* hasMinusAudioInputId)
```

Parameters

Name	Direction	Description
hasMinusAudioInputId	out	The current has minus audio input ID flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The hasMinusAudioInputId parameter is invalid.

2.3.21.5 **IBMDSwitcherMixMinusOutput::GetMinusAudioInputId** method

The `GetMinusAudioInputId` method gets the `IBMDSwitcherAudioInputId` of the audio input that is subtracted when the output is in mix minus audio mode.

Syntax

```
HRESULT GetMinusAudioInputId (IBMDSwitcherAudioInputId* audioInputId);
```

Parameters

Name	Direction	Description
audioInputId	out	The <code>IBMDSwitcherAudioInputId</code> of the audio input used for mix minus.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The <code>audioInputId</code> parameter is invalid.
E_FAIL	No minus audio input assigned.

2.3.21.6 **IBMDSwitcherMixMinusOutput::AddCallback** method

The `AddCallback` method configures a callback to be called when events occur for an `IBMDSwitcherMixMinusOutput` object. Pass an object implementing the `IBMDSwitcherMixMinusOutputCallback` interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMixMinusOutputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the <code>IBMDSwitcherMixMinusOutputCallback</code> object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The <code>callback</code> parameter is invalid.

2.3.21.7 IBMDSwitcherMixMinusOutput::RemoveCallback method

The RemoveCallback method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMixMinusOutputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMixMinusOutputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

2.3.22 IBMDSwitcherMixMinusOutputCallback Interface

The IBMDSwitcherMixMinusOutputCallback object interface is a callback class containing methods that are called when an event occurs on an IBMDSwitcherMixMinusOutput object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMixMinusOutput	IID_IBMDSwitcherMixMinusOutput	An IBMDSwitcherMixMinusOutputCallback object interface is installed with IBMDSwitcherMixMinusOutput::AddCallback and removed with IBMDSwitcherMixMinusOutput::RemoveCallback.

Public Member Functions

Method	Description
Notify	Called when an event occurs.

2.3.22.1 IBMDSwitcherMixMinusOutputCallback::Notify method

The **Notify** method is called when **IBMDSwitcherMixMinusOutput** events occur, such as audio mode changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherMixMinusOutputEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherMixMinusOutputEventType that describes the type of event that occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

2.3.23 IBMDSwitcherSaveRecall Interface

The **IBMDSwitcherSaveRecall** object interface provides functionality for storing and clearing operating states.

Public Member Functions	
Method	Description
Save	Stores the current operating state to the switcher.
Clear	Clears a stored operating state from the switcher.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	An IBMDSwitcherSaveRecall object interface can be obtained with IBMDSwitcher::QueryInterface .

2.3.23.1 IBMDSwitcherSaveRecall::Save method

The Save method stores the current operating state to the switcher's persistent memory.

Syntax

```
HRESULT Save(BMDSwitcherSaveRecallType type)
```

Parameters

Name	Direction	Description
type	in	The type of operating state to store.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The type parameter is invalid.
E_FAIL	Failure.

2.3.23.2 IBMDSwitcherSaveRecall::Clear method

The Clear method clears a stored operating state from the switcher's persistent memory.

Syntax

```
HRESULT Clear(BMDSwitcherSaveRecallType type)
```

Parameters

Name	Direction	Description
type	in	The type of operating state to clear.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The type parameter is invalid.
E_FAIL	Failure.

Section 3 — Advanced Transitions

Transitions can be more advanced than making a simple cut between sources. This API provides a plethora of methods to enhance how a transition is performed.

Transitions can be more advanced than making a simple cut between sources. This API provides a plethora of methods to enhance how a transition is performed.

3.1 Data Types

3.1.1 Mix Parameters Event Type

BMDSwitcherTransitionMixParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionMixParameters**.

- **bmdSwitcherTransitionMixParametersEventTypeRateChanged**
The rate changed.

3.1.2 Dip Parameters Event Type

BMDSwitcherTransitionDipParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionDipParameters**.

- **bmdSwitcherTransitionDipParametersEventTypeRateChanged**
The rate changed.
- **bmdSwitcherTransitionDipParametersEventTypeInputDipChanged**
The dip input changed.

3.1.3 Wipe Parameters Event Type

BMDSwitcherTransitionWipeParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionWipeParameters**.

- **bmdSwitcherTransitionWipeParametersEventTypeRateChanged**
The rate changed.
- **bmdSwitcherTransitionWipeParametersEventTypePatternChanged**
The pattern changed.
- **bmdSwitcherTransitionWipeParametersEventTypeBorderSizeChanged**
The border size changed.
- **bmdSwitcherTransitionWipeParametersEventTypeInputBorderChanged**
The border input changed.
- **bmdSwitcherTransitionWipeParametersEventTypeSymmetryChanged**
The symmetry changed.
- **bmdSwitcherTransitionWipeParametersEventTypeSoftnessChanged**
The softness changed.
- **bmdSwitcherTransitionWipeParametersEventTypeHorizontalOffsetChanged**
The horizontal offset changed.
- **bmdSwitcherTransitionWipeParametersEventTypeVerticalOffsetChanged**
The vertical offset changed.
- **bmdSwitcherTransitionWipeParametersEventTypeReverseChanged**
The reverse flag changed.
- **bmdSwitcherTransitionWipeParametersEventTypeFlipFlopChanged**
The flip flop flag changed.

3.1.4 DVE Parameters Event Type

`BMDSwitcherTransitionDVEParametersEventType` enumerates the possible event types for `IBMDSwitcherTransitionDVEParameters`.

- `bmdSwitcherTransitionDVEParametersEventTypeRateChanged`
The rate changed.
- `bmdSwitcherTransitionDVEParametersEventTypeLogoRateChanged`
The logo rate changed.
- `bmdSwitcherTransitionDVEParametersEventTypeReverseChanged`
The reverse flag changed.
- `bmdSwitcherTransitionDVEParametersEventTypeFlipFlopChanged`
The flip flop flag changed.
- `bmdSwitcherTransitionDVEParametersEventTypeStyleChanged`
The style changed.
- `bmdSwitcherTransitionDVEParametersEventTypeInputFillChanged`
The fill input changed.
- `bmdSwitcherTransitionDVEParametersEventTypeInputCutChanged`
The cut input changed.
- `bmdSwitcherTransitionDVEParametersEventTypeEnableKeyChanged`
The enable key flag changed.
- `bmdSwitcherTransitionDVEParametersEventTypePreMultipliedChanged`
The pre-multiplied flag changed.
- `bmdSwitcherTransitionDVEParametersEventTypeClipChanged`
The clip changed.
- `bmdSwitcherTransitionDVEParametersEventTypeGainChanged`
The gain changed.
- `bmdSwitcherTransitionDVEParametersEventTypeInverseChanged`
The inverse flag changed.

3.1.5 Stinger Parameters Event Type

`BMDSwitcherTransitionStingerParametersEventType` enumerates the possible event types for `IBMDSwitcherTransitionStingerParameters`.

- `bmdSwitcherTransitionStingerParametersEventTypeSourceChanged`
The source changed.
- `bmdSwitcherTransitionStingerParametersEventTypePreMultipliedChanged`
The pre-multiplied flag changed.
- `bmdSwitcherTransitionStingerParametersEventTypeClipChanged`
The clip changed.
- `bmdSwitcherTransitionStingerParametersEventTypeGainChanged`
The gain changed.
- `bmdSwitcherTransitionStingerParametersEventTypeInverseChanged`
The inverse flag changed.
- `bmdSwitcherTransitionStingerParametersEventTypePrerollChanged`
The preroll changed.
- `bmdSwitcherTransitionStingerParametersEventTypeClipDurationChanged`
The clip duration changed.
- `bmdSwitcherTransitionStingerParametersEventTypeTriggerPointChanged`
The trigger point changed.
- `bmdSwitcherTransitionStingerParametersEventTypeMixRateChanged`
The mix rate changed.

3.1.6 Transition Parameters Event Type

BMDSwitcherTransitionParametersEventType enumerates the possible event types for **IBMDSwitcherTransitionParameters**.

- **bmdSwitcherTransitionParametersEventTypeTransitionStyleChanged**
The transition style changed.
- **bmdSwitcherTransitionParametersEventTypeNextTransitionStyleChanged**
The next transition style changed.
- **bmdSwitcherTransitionParametersEventTypeTransitionSelectionChanged**
The transition selection changed.
- **bmdSwitcherTransitionParametersEventTypeNextTransitionSelectionChanged**
The next transition selection changed.

3.1.7 Transition Style

BMDSwitcherTransitionStyle enumerates the possible transition styles, used by the **IBMDSwitcherTransitionParameters** object interface.

- **bmdSwitcherTransitionStyleMix** Mix style.
- **bmdSwitcherTransitionStyleDip** Dip style.
- **bmdSwitcherTransitionStyleWipe** Wipe style.
- **bmdSwitcherTransitionStyleDVE** DVE style.
- **bmdSwitcherTransitionStyleStinger** Stinger style.

3.1.8 Transition Selection

BMDSwitcherTransitionSelection is a bit set that enumerates what to include in a transition. This type is used by **IBMDSwitcherTransitionParameters** and **IBMDSwitcherKey** object interfaces.

- **bmdSwitcherTransitionSelectionBackground** Include background in transition.
- **bmdSwitcherTransitionSelectionKey1** Include key 1 in transition.
- **bmdSwitcherTransitionSelectionKey2** Include key 2 in transition.
- **bmdSwitcherTransitionSelectionKey3** Include key 3 in transition.
- **bmdSwitcherTransitionSelectionKey4** Include key 4 in transition.

3.1.9 DVE Transition Style

BMDSwitcherDVETransitionStyle enumerates the possible transition styles. This type is used by the **IBMDSwitcherTransitionDVEParameters** object interface.

- **bmdSwitcherDVETransitionStyleSwooshTopLeft**
Top left swoosh.
- **bmdSwitcherDVETransitionStyleSwooshTop**
Top swoosh.
- **bmdSwitcherDVETransitionStyleSwooshTopRight**
Top right swoosh.
- **bmdSwitcherDVETransitionStyleSwooshLeft**
Left swoosh.
- **bmdSwitcherDVETransitionStyleSwooshRight**
Right swoosh.

- **bmdSwitcherDVETransitionStyleSwooshBottomLeft**
Bottom left swoosh.
- **bmdSwitcherDVETransitionStyleSwooshBottom**
Bottom swoosh.
- **bmdSwitcherDVETransitionStyleSwooshBottomRight**
Bottom right swoosh.
- **bmdSwitcherDVETransitionStyleSpinCWTopLeft**
Top left clockwise spin.
- **bmdSwitcherDVETransitionStyleSpinCWTopRight**
Top right clockwise spin.
- **bmdSwitcherDVETransitionStyleSpinCWBottomLeft**
Bottom left clockwise spin.
- **bmdSwitcherDVETransitionStyleSpinCWBottomRight**
Bottom right clockwise spin.
- **bmdSwitcherDVETransitionStyleSpinCCWTopLeft**
Top left counterclockwise spin.
- **bmdSwitcherDVETransitionStyleSpinCCWTopRight**
Top right counterclockwise spin.
- **bmdSwitcherDVETransitionStyleSpinCCWBottomLeft**
Bottom left counterclockwise spin.
- **bmdSwitcherDVETransitionStyleSpinCCWBottomRight**
Bottom right counterclockwise spin.
- **bmdSwitcherDVETransitionStyleSqueezeTopLeft**
Top left squeeze.
- **bmdSwitcherDVETransitionStyleSqueezeTop**
Top squeeze.
- **bmdSwitcherDVETransitionStyleSqueezeTopRight**
Top right squeeze.
- **bmdSwitcherDVETransitionStyleSqueezeLeft**
Left squeeze.
- **bmdSwitcherDVETransitionStyleSqueezeRight**
Right squeeze.
- **bmdSwitcherDVETransitionStyleSqueezeBottomLeft**
Bottom left squeeze.

3.1.10 **Stinger Transition Source**

BMDSwitcherStingerTransitionSource enumerates the possible transition sources. This type is used by the **IBMDSwitcherTransitionStingerParameters** object interface.

- **bmdSwitcherStingerTransitionSourceMediaPlayer1**
Media player 1.
- **bmdSwitcherStingerTransitionSourceMediaPlayer2**
Media player 2.
- **bmdSwitcherStingerTransitionSourceMediaPlayer3**
Media player 3.
- **bmdSwitcherStingerTransitionSourceMediaPlayer4**
Media player 4.
- **bmdSwitcherStingerTransitionSourceNone**
None.

3.2 Interface Reference

3.2.1 IBMDSwitcherTransitionMixParameters Interface

The `IBMDSwitcherTransitionMixParameters` object interface is used for manipulating transition settings specific to mix parameters.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMixEffectBlock</code>	<code>IID_IBMDSwitcherMixEffectBlock</code>	An <code>IBMDSwitcherTransitionMixParameters</code> object interface can be obtained with <code>IBMDSwitcherMixEffectBlock::QueryInterface</code> .

Public Member Functions

Method	Description
<code>GetRate</code>	Get the current rate.
<code>SetRate</code>	Set the rate.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

3.2.1.1 IBMDSwitcherTransitionMixParameters::GetRate method

The `GetRate` method returns the current rate in frames.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

Name	Direction	Description
<code>frames</code>	out	The current rate.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The frames parameter is invalid.

3.2.1.2 IBMDSwitcherTransitionMixParameters::SetRate method

The `SetRate` method sets the rate in frames.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

Name	Direction	Description
<code>frames</code>	in	The desired rate in frames.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The frames parameter is invalid.

3.2.1.3 **IBMDSwitcherTransitionMixParameters::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionMixParameters** object. Pass an object implementing the **IBMDSwitcherTransitionMixParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionMixParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionMixParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.1.4 **IBMDSwitcherTransitionMixParameters::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTransitionMixParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionMixParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.2 IBMDSwitcherTransitionMixParametersCallback Interface

The `IBMDSwitcherTransitionMixParametersCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherTransitionMixParameters` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherTransitionMixParameters</code>	<code>IID_IBMDSwitcherTransitionMixParameters</code>	An <code>IBMDSwitcherTransitionMixParametersCallback</code> object interface is installed with <code>IBMDSwitcherTransitionMixParameters::AddCallback</code> and removed with <code>IBMDSwitcherTransitionMixParameters::RemoveCallback</code>

Public Member Functions	
Method	Description
<code>Notify</code>	Called when an event occurs.

3.2.2.1 IBMDSwitcherTransitionMixParametersCallback::Notify method

The `Notify` method is called when `IBMDSwitcherTransitionMixParameters` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(BMDSwitcherTransitionMixParametersEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherTransitionMixParametersEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

3.2.3 IBMDSwitcherTransitionDipParameters Interface

The `IBMDSwitcherTransitionDipParameters` object interface is used for manipulating transition settings specific to dip parameters.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMixEffectBlock	IID_IBMDSwitcherMixEffectBlock	An <code>IBMDSwitcherTransitionDipParameters</code> object interface can be obtained with <code>IBMDSwitcherMixEffectBlock::QueryInterface</code> .

Public Member Functions

Method	Description
GetRate	Get the current rate.
SetRate	Set the rate.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

3.2.3.1 IBMDSwitcherTransitionDipParameters::GetRate method

The `GetRate` method returns the current rate in frames.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

Name	Direction	Description
frames	out	The current rate.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

3.2.3.2 **IBMDSwitcherTransitionDipParameters::SetRate** method

The **SetRate** method sets the rate in frames.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	The desired rate in frames.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The frames parameter is invalid.

3.2.3.3 **IBMDSwitcherTransitionDipParameters::GetInputDip** method

The **GetInputDip** method returns the current dip input.

Syntax

```
HRESULT GetInputDip (BMDSwitcherInputId* input);
```

Parameters

Name	Direction	Description
input	out	The current dip input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The input parameter is invalid.

3.2.3.4 **IBMDSwitcherTransitionDipParameters::SetInputDip** method

The **SetInputDip** method sets the dip input.

Syntax

```
HRESULT SetInputDip (BMDSwitcherInputId input);
```

Parameters

Name	Direction	Description
input	in	The desired dip input.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The input parameter is invalid.

3.2.3.5 IBMDSwitcherTransitionDipParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionDipParameters** object. Pass an object implementing the **IBMDSwitcherTransitionDipParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionDipParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionDipParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.3.6 IBMDSwitcherTransitionDipParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTransitionDipParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionDipParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.4 IBMDSwitcherTransitionDipParametersCallback Interface

The `IBMDSwitcherTransitionDipParametersCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherTransitionDipParameters` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherTransitionDipParameters</code>	<code>IID_IBMDSwitcherTransitionDipParameters</code>	An <code>IBMDSwitcherTransitionDipParametersCallback</code> object interface is installed with <code>IBMDSwitcherTransitionDipParameters::AddCallback</code> and removed with <code>IBMDSwitcherTransitionDipParameters::RemoveCallback</code>

Public Member Functions	
Method	Description
<code>Notify</code>	Called when an event occurs.

3.2.4.1 IBMDSwitcherTransitionDipParametersCallback::Notify method

The `Notify` method is called when `IBMDSwitcherTransitionDipParameters` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherTransitionDipParametersEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherTransitionDipParametersEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

3.2.5 IBMDSwitcherTransitionWipeParametersCallback Interface

The `IBMDSwitcherTransitionWipeParametersCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherTransitionWipeParameters` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherTransitionWipeParameters</code>	<code>IID_IBMDSwitcherTransitionWipeParameters</code>	<code>IBMDSwitcherTransitionWipeParametersCallback</code> object interface is installed with <code>IBMDSwitcherTransitionWipeParameters::AddCallback</code> and removed with <code>IBMDSwitcherTransitionWipeParameters::RemoveCallback</code>

Public Member Functions

Method	Description
<code>Notify</code>	Called when an event occurs.

3.2.5.1 IBMDSwitcherTransitionWipeParametersCallback::Notify method

The `Notify` method is called when `IBMDSwitcherTransitionWipeParameters` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherTransitionWipeParametersEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherTransitionWipeParametersEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

3.2.6 IBMDSwitcherTransitionWipeParameters Interface

The `IBMDSwitcherTransitionWipeParameters` object interface is used for manipulating transition settings specific to wipe parameters.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMixEffectBlock</code>	<code>IID_IBMDSwitcherMixEffectBlock</code>	An <code>IBMDSwitcherTransitionWipeParameters</code> object interface can be obtained with <code>IBMDSwitcherMixEffectBlock::QueryInterface</code> .

Public Member Functions	
Method	Description
<code>GetRate</code>	Get the current rate.
<code>SetRate</code>	Set the rate.
<code>GetPattern</code>	Get the current pattern.
<code>SetPattern</code>	Set the pattern.
<code>GetBorderSize</code>	Get the current border size.
<code>SetBorderSize</code>	Set the border size.
<code>GetInputBorder</code>	Get the current border input.
<code>SetInputBorder</code>	Set the border input.
<code>GetSymmetry</code>	Get the current symmetry.
<code>SetSymmetry</code>	Set the symmetry.
<code>GetSoftness</code>	Get the current softness.
<code>SetSoftness</code>	Set the softness.
<code>GetHorizontalOffset</code>	Get the current horizontal offset.
<code>SetHorizontalOffset</code>	Set the horizontal offset.
<code>GetVerticalOffset</code>	Get the current vertical offset.
<code>SetVerticalOffset</code>	Set the vertical offset.
<code>GetReverse</code>	Get the current reverse flag.
<code>SetReverse</code>	Set the reverse flag.
<code>GetFlipFlop</code>	Get the current flip flop flag.
<code>SetFlipFlop</code>	Set the flip flop flag.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

3.2.6.1 IBMDSwitcherTransitionWipeParameters::GetRate method

The `GetRate` method returns the current rate in frames.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

Name	Direction	Description
frames	out	The current rate.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

3.2.6.2 IBMDSwitcherTransitionWipeParameters::SetRate method

The `SetRate` method sets the rate in frames.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	The desired rate in frames.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The frames parameter is invalid.

3.2.6.3 IBMDSwitcherTransitionWipeParameters::GetPattern method

The `GetPattern` method returns the current pattern style.

Syntax

```
HRESULT GetPattern (BMDSwitcherPatternStyle* pattern);
```

Parameters

Name	Direction	Description
pattern	out	The current pattern.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The pattern parameter is invalid.

3.2.6.4 **IBMDSwitcherTransitionWipeParameters::SetPattern** method

The `SetPattern` method sets the rate in frames.

Syntax

```
HRESULT SetPattern (BMDSwitcherPatternStyle pattern);
```

Parameters

Name	Direction	Description
frames	in	The desired pattern.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The pattern parameter is invalid.

3.2.6.5 **IBMDSwitcherTransitionWipeParameters::GetBorderSize** method

The `GetBorderSize` method returns the current border size.

Syntax

```
HRESULT GetBorderSize (double* size);
```

Parameters

Name	Direction	Description
size	out	The current border size.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The size parameter is invalid.

3.2.6.6 **IBMDSwitcherTransitionWipeParameters::SetBorderSize** method

The `SetBorderSize` method sets the border size.

Syntax

```
HRESULT SetBorderSize (double size);
```

Parameters

Name	Direction	Description
size	in	The desired border size.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.6.7 IBMDSwitcherTransitionWipeParameters::GetInputBorder method

The `GetInputBorder` method returns the current border input.

Syntax

```
HRESULT GetInputBorder (BMDSwitcherInputId* input);
```

Parameters

Name	Direction	Description
input	out	The current border input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The input parameter is invalid.

3.2.6.8 IBMDSwitcherTransitionWipeParameters::SetInputBorder method

The `SetInputBorder` method sets the border input.

Syntax

```
HRESULT SetInputBorder (BMDSwitcherInputId input);
```

Parameters

Name	Direction	Description
input	in	92.323

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The input parameter is invalid.

3.2.6.9 IBMDSwitcherTransitionWipeParameters::GetSymmetry method

The `GetSymmetry` method returns the current symmetry.

Syntax

```
HRESULT GetSymmetry (double* symmetry);
```

Parameters

Name	Direction	Description
symmetry	out	The current symmetry.

Return Values

Value	Description
S_OK	Success.

3.2.6.10 **IBMDSwitcherTransitionWipeParameters::SetSymmetry** method

The `SetSymmetry` method sets the symmetry.

Syntax

```
HRESULT SetSymmetry (double symmetry);
```

Parameters

Name	Direction	Description
symmetry	in	The desired symmetry.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.6.11 **IBMDSwitcherTransitionWipeParameters::GetSoftness** method

The `GetSoftness` method returns the current softness.

Syntax

```
HRESULT GetSoftness (double* soft);
```

Parameters

Name	Direction	Description
soft	out	The current softness.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The soft parameter is invalid.

3.2.6.12 **IBMDSwitcherTransitionWipeParameters::SetSoftness** method

The `SetSoftness` method sets the softness.

Syntax

```
HRESULT SetSoftness (double soft);
```

Parameters

Name	Direction	Description
soft	in	The desired softness.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.6.13 **IBMDSwitcherTransitionWipeParameters::GetHorizontalOffset** method

The `GetHorizontalOffset` method returns the current horizontal offset.

Syntax

```
HRESULT GetHorizontalOffset (double* hOffset);
```

Parameters

Name	Direction	Description
<code>hOffset</code>	out	The current horizontal offset.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The <code>hOffset</code> parameter is invalid.

3.2.6.14 **IBMDSwitcherTransitionWipeParameters::SetHorizontalOffset** method

The `SetHorizontalOffset` method sets the horizontal offset.

Syntax

```
HRESULT SetHorizontalOffset (double hOffset);
```

Parameters

Name	Direction	Description
<code>hOffset</code>	in	The desired horizontal offset.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

3.2.6.15 **IBMDSwitcherTransitionWipeParameters::GetVerticalOffset** method

The `GetVerticalOffset` method returns the current vertical offset.

Syntax

```
HRESULT GetVerticalOffset (double* vOffset);
```

Parameters

Name	Direction	Description
<code>vOffset</code>	out	The current vertical offset.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The <code>vOffset</code> parameter is invalid.

3.2.6.16 **IBMDSwitcherTransitionWipeParameters::SetVerticalOffset** method

The `SetVerticalOffset` method sets the vertical offset.

Syntax

```
HRESULT SetVerticalOffset (double vOffset);
```

Parameters

Name	Direction	Description
vOffset	in	The desired vertical offset.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.6.17 **IBMDSwitcherTransitionWipeParameters::GetReverse** method

The `GetReverse` method returns the current reverse flag.

Syntax

```
HRESULT GetReverse (boolean* reverse);
```

Parameters

Name	Direction	Description
reverse	out	The current reverse flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The reverse parameter is invalid.

3.2.6.18 **IBMDSwitcherTransitionWipeParameters::SetReverse** method

The `SetReverse` method sets the reverse flag.

Syntax

```
HRESULT SetReverse (boolean reverse);
```

Parameters

Name	Direction	Description
reverse	in	The desired reverse flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.6.19 IBMDSwitcherTransitionWipeParameters::GetFlipFlop method

The `GetFlipFlop` method returns the current flip flop flag.

Syntax

```
HRESULT GetFlipFlop (boolean* flipflop);
```

Parameters

Name	Direction	Description
flipflop	out	The current flip flop flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The flipflop parameter is invalid.

3.2.6.20 IBMDSwitcherTransitionWipeParameters::SetFlipFlop method

The `SetFlipFlop` method sets the flip flop flag.

Syntax

```
HRESULT SetFlipFlop (boolean flipflop);
```

Parameters

Name	Direction	Description
flipflop	in	The desired flip flop flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.6.21 IBMDSwitcherTransitionWipeParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionWipeParameters** object. Pass an object implementing the **IBMDSwitcherTransitionWipeParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionWipeParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionWipeParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.6.22 IBMDSwitcherTransitionWipeParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTransitionWipeParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionWipeParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.7 IBMDSwitcherTransitionDVEParameters Interface

The `IBMDSwitcherTransitionDVEParameters` object interface is used for manipulating transition settings specific to DVE parameters.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMixEffectBlock</code>	<code>IID_IBMDSwitcherMixEffectBlock</code>	An <code>IBMDSwitcherTransitionDVEParameters</code> object interface can be obtained with <code>IBMDSwitcherMixEffectBlock::QueryInterface</code> .

Public Member Functions	
Method	Description
<code>GetRate</code>	Get the current rate.
<code>SetRate</code>	Set the rate.
<code>GetLogoRate</code>	Get the current logo rate.
<code>SetLogoRate</code>	Set the logo rate.
<code>GetReverse</code>	Get the current reverse flag.
<code>SetReverse</code>	Set the reverse flag.
<code>GetFlipFlop</code>	Get the current flip flop flag.
<code>SetFlipFlop</code>	Set the flip flop flag.
<code>GetStyle</code>	Get the current style.
<code>SetStyle</code>	Set the style.
<code>DoesSupportStyle</code>	Gets whether the connected device supports a given DVE transition style.
<code>GetNumSupportedStyles</code>	Gets the number of supported DVE transition style types.
<code>GetSupportedStyle</code>	Gets one or more supported DVE transition styles.
<code>GetInputFill</code>	Get the current fill input.
<code>SetInputFill</code>	Set the fill input.
<code>GetInputCut</code>	Get the current cut input.
<code>SetInputCut</code>	Set the cut input.
<code>GetFillInputAvailabilityMask</code>	Get the availability mask for the fill of this input.
<code>GetCutInputAvailabilityMask</code>	Get the availability mask for the cut of this input.
<code>GetEnableKey</code>	Get the current enable key.
<code>SetEnableKey</code>	Set the enable key.
<code>GetPreMultiplied</code>	Get the current pre-multiplied flag.
<code>SetPreMultiplied</code>	Set the pre-multiplied flag.
<code>GetClip</code>	Get the current clip value.
<code>SetClip</code>	Set the clip value.
<code>GetGain</code>	Get the current gain.
<code>SetGain</code>	Set the gain.
<code>GetInverse</code>	Get the current inverse flag.
<code>SetInverse</code>	Set the inverse flag.
<code>AddCallback</code>	Add a callback.

3.2.7.1 IBMDSwitcherTransitionDVEParameters::GetRate method

The `GetRate` method returns the current rate in frames.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

Name	Direction	Description
frames	out	The current rate.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

3.2.7.2 IBMDSwitcherTransitionDVEParameters::SetRate method

The `SetRate` method sets the rate in frames.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	The desired rate in frames.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The frames parameter is invalid.

3.2.7.3 **IBMDSwitcherTransitionDVEParameters::GetLogoRate** method

The `GetLogoRate` method returns the current logo rate in frames.

Syntax

```
HRESULT GetLogoRate (uint32_t* frames);
```

Parameters

Name	Direction	Description
frames	out	The current logo rate.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

3.2.7.4 **IBMDSwitcherTransitionDVEParameters::SetLogoRate** method

The `SetLogoRate` method sets the logo rate in frames.

Syntax

```
HRESULT SetLogoRate (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	The desired logo rate in frames.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The frames parameter is invalid.

3.2.7.5 **IBMDSwitcherTransitionDVEParameters::GetReverse** method

The `GetReverse` method returns the current reverse flag.

Syntax

```
HRESULT GetReverse (boolean* reverse);
```

Parameters

Name	Direction	Description
reverse	out	The current reverse flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The reverse parameter is invalid.

3.2.7.6 IBMDSwitcherTransitionDVEParameters::SetReverse method

The `SetReverse` method sets the reverse flag.

Syntax

```
HRESULT SetReverse (boolean reverse);
```

Parameters

Name	Direction	Description
reverse	in	The desired reverse flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.7.7 IBMDSwitcherTransitionDVEParameters::GetFlipFlop method

The `GetFlipFlop` method returns the current flip flop flag.

Syntax

```
HRESULT GetFlipFlop (boolean* flipflop);
```

Parameters

Name	Direction	Description
flipflop	out	The current flip flop flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The flipflop parameter is invalid.

3.2.7.8 IBMDSwitcherTransitionDVEParameters::SetFlipFlop method

The `SetFlipFlop` method sets the flip flop flag.

Syntax

```
HRESULT SetFlipFlop (boolean flipflop);
```

Parameters

Name	Direction	Description
flipflop	in	The desired flip flop flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.7.9 IBMDSwitcherTransitionDVEParameters::GetStyle method

The `GetStyle` method returns the current style.

Syntax

```
HRESULT GetStyle (BMDSwitcherDVETransitionStyle* style);
```

Parameters

Name	Direction	Description
style	out	The current style.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The style parameter is invalid.

3.2.7.10 IBMDSwitcherTransitionDVEParameters::SetStyle method

The `SetStyle` method sets the style.

Syntax

```
HRESULT SetStyle (BMDSwitcherDVETransitionStyle style);
```

Parameters

Name	Direction	Description
style	in	The desired style.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The style parameter is invalid.

3.2.7.11 **IBMDSwitcherTransitionDVEParameters::DoesSupportStyle** method

The **DoesSupportStyle** method determines if the connected device supports a given DVE transition style.

Syntax

```
HRESULT DoesSupportStyle (BMDSwitcherDVETransitionStyle style, BMDbool* supported);
```

Parameters

Name	Direction	Description
style	in	The DVE style to check.
supported	out	Boolean status of the requested DVE transition style support.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supported parameter is invalid.

3.2.7.12 **IBMDSwitcherTransitionDVEParameters::GetNumSupportedStyles** method

The **GetNumSupportedStyles** method determines the total number of supported DVE transition styles in the connected device.

Syntax

```
HRESULT GetNumSupportedStyles (uint32_t* numSupportedStyles);
```

Parameters

Name	Direction	Description
numSupportedStyles	out	Total number of DVE transition styles supported.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The numSupportedStyles parameter is invalid.

3.2.7.13 **IBMDSwitcherTransitionDVEParameters::GetSupportedStyles** method

The **GetSupportedStyles** method retrieves a list of supported DVE transition styles supported by the connected device.

NOTE That it is the user application's responsibility to ensure the supportedStyles destination array is at least as big as **supportedStylesMaxCount**.

Syntax

```
HRESULT GetNumSupportedStyles (BMDSwitcherDVETransitionStyle* supportedStyles,  
                               uint32_t supportedStylesMaxCount);
```

Parameters

Name	Direction	Description
supportedStyles	out	List of supported DVE transition styles.
supportedStylesMaxCount	in	Maximum number of supported DVE transition styles to retrieve.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportedStyles parameter is invalid.

3.2.7.14 **IBMDSwitcherTransitionDVEParameters::GetInputFill** method

The **GetInputFill** method returns the current fill input.

Syntax

```
HRESULT GetInputFill (BMDSwitcherInputId* input);
```

Parameters

Name	Direction	Description
input	out	The current fill input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The input parameter is invalid.

3.2.7.15 **IBMDSwitcherTransitionDVEParameters::SetInputFill** method

The `SetInputFill` method sets the fill input.

Syntax

```
HRESULT SetInputFill (BMDSwitcherInputId input);
```

Parameters

Name	Direction	Description
input	in	The desired fill input.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The input parameter is invalid.

3.2.7.16 **IBMDSwitcherTransitionDVEParameters::GetInputCut** method

The `GetInputCut` method returns the current cut input.

Syntax

```
HRESULT GetInputCut (BMDSwitcherInputId* input);
```

Parameters

Name	Direction	Description
input	out	The current cut input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The input parameter is invalid.

3.2.7.17 **IBMDSwitcherTransitionDVEParameters::SetInputCut** method

The `SetInputCut` method sets the cut input.

Syntax

```
HRESULT SetInputCut (BMDSwitcherInputId input);
```

Parameters

Name	Direction	Description
input	in	The desired cut input.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The input parameter is invalid.

3.2.7.18 **IBMDSwitcherTransitionDVEParameters::GetFillInputAvailabilityMask** method

The `GetFillInputAvailabilityMask` method returns the corresponding `BMDSwitcherInputAvailability` bit mask value for fill inputs available to this DVE transition. The input availability property of an `IBMDSwitcherInput` can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a fill input for this DVE transition.

Syntax

```
HRESULT GetFillInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	BMDSwitcherInputAvailability bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

3.2.7.19 **IBMDSwitcherTransitionDVEParameters::GetCutInputAvailabilityMask** method

The **GetCutInputAvailabilityMask** method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for cut inputs available to this DVE transition. The input availability property of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a cut input for this DVE transition.

Syntax

```
HRESULT GetCutInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	BMDSwitcherInputAvailability bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

3.2.7.20 **IBMDSwitcherTransitionDVEParameters::GetEnableKey** method

The **GetEnableKey** method returns the current enableKey flag.

Syntax

```
HRESULT GetEnableKey (boolean* enableKey);
```

Parameters

Name	Direction	Description
enableKey	out	The current enableKey flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enableKey parameter is invalid.

3.2.7.21 IBMDSwitcherTransitionDVEParameters::SetEnableKey method

The `SetEnableKey` method sets the `enableKey` flag.

Syntax

```
HRESULT SetEnableKey (boolean enableKey);
```

Parameters

Name	Direction	Description
<code>enableKey</code>	in	The desired <code>enableKey</code> flag.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	Failure.

3.2.7.22 IBMDSwitcherTransitionDVEParameters::GetPreMultiplied method

The `GetPreMultiplied` method returns the current pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

Name	Direction	Description
<code>enableKey</code>	in	The desired <code>enableKey</code> flag.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The <code>preMultiplied</code> parameter is invalid.

3.2.7.23 IBMDSwitcherTransitionDVEParameters::GetPreMultiplied method

The `GetPreMultiplied` method sets the pre-multiplied flag.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

Name	Direction	Description
<code>preMultiplied</code>	in	The desired pre-multiplied flag.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

3.2.7.24 **IBMDSwitcherTransitionDVEParameters::GetClip** method

The `GetClip` method returns the current clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

Name	Direction	Description
clip	out	The current clip value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The clip parameter is invalid.

3.2.7.25 **IBMDSwitcherTransitionDVEParameters::SetClip** method

The `SetClip` method sets the clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

Name	Direction	Description
clip	in	The desired clip value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.7.26 **IBMDSwitcherTransitionDVEParameters::GetGain** method

The `GetGain` method returns the current clip.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

3.2.7.27 IBMDSwitcherTransitionDVEParameters::SetGain method

The `SetGain` method sets the gain.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.7.28 IBMDSwitcherTransitionDVEParameters::GetInverse method

The `GetInverse` method returns the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

Name	Direction	Description
inverse	out	The current inverse flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inverse parameter is invalid.

3.2.7.29 IBMDSwitcherTransitionDVEParameters::SetInverse method

The `SetInverse` method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

Name	Direction	Description
inverse	in	The desired inverse flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.7.30 IBMDSwitcherTransitionDVEParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionDVEParameters** object. Pass an object implementing the **IBMDSwitcherTransitionDVEParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionDVEParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionDVEParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.7.31 IBMDSwitcherTransitionDVEParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionDVEParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionDVEParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.8 IBMDSwitcherTransitionDVEParametersCallback Interface

The `IBMDSwitcherTransitionDVEParametersCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherTransitionDVEParameters` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherTransitionDVEParametersCallback</code>	<code>IID_IBMDSwitcherTransitionDVEParameters</code>	An <code>IBMDSwitcherTransitionDVEParametersCallback</code> object interface is installed with <code>IBMDSwitcherTransitionDVEParameters::AddCallback</code> and removed with <code>IBMDSwitcherTransitionDVEParameters::RemoveCallback</code>

Public Member Functions	
Method	Description
<code>Notify</code>	Called when an event occurs.

3.2.8.1 IBMDSwitcherTransitionDVEParametersCallback::Notify method

The `Notify` method is called when `IBMDSwitcherTransitionDVEParameters` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherTransitionDVEParametersEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherTransitionDVEParametersEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

3.2.9 IBMDSwitcherTransitionStingerParameters Interface

The `IBMDSwitcherTransitionStingerParameters` object interface is used for manipulating transition settings specific to stinger parameters.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMixEffectBlock</code>	<code>IID_IBMDSwitcherMixEffectBlock</code>	An <code>IBMDSwitcherTransitionStingerParameters</code> object interface can be obtained with <code>IBMDSwitcherMixEffectBlock::QueryInterface</code> .

Public Member Functions	
Method	Description
<code>GetSource</code>	Get the current source.
<code>SetSource</code>	Set the source.
<code>GetPreMultiplied</code>	Get the current pre-multiplied flag.
<code>SetPreMultiplied</code>	Set the pre-multiplied flag.
<code>GetClip</code>	Get the current clip value.
<code>SetClip</code>	Set the clip value.
<code>GetGain</code>	Get the current gain.
<code>SetGain</code>	Set the gain.
<code>GetInverse</code>	Get the current inverse flag.
<code>SetInverse</code>	Set the inverse flag.
<code>GetPreroll</code>	Get the current pre-roll.
<code>SetPreroll</code>	Set the pre-roll.
<code>GetClipDuration</code>	Get the current clip duration.
<code>SetClipDuration</code>	Set the clip duration.
<code>GetTriggerPoint</code>	Get the current trigger point.
<code>SetTriggerPoint</code>	Set the trigger point.
<code>GetMixRate</code>	Get the current mix rate.
<code>SetMixRate</code>	Set the mix rate.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

3.2.9.1 **IBMDSwitcherTransitionStingerParameters::GetSource** method

The `GetSource` method returns the current source.

Syntax

```
HRESULT GetSource (IBMDSwitcherStingerTransitionSource* src);
```

Parameters

Name	Direction	Description
src	out	The current source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The src parameter is invalid.

3.2.9.2 **IBMDSwitcherTransitionStingerParameters::SetSource** method

The `SetSource` method sets the rate in frames.

Syntax

```
HRESULT SetSource (IBMDSwitcherStingerTransitionSource src);
```

Parameters

Name	Direction	Description
src	in	The desired source.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The src parameter is invalid.

3.2.9.3 **IBMDSwitcherTransitionStingerParameters::GetPreMultiplied** method

The `GetPreMultiplied` method returns the current pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

Name	Direction	Description
preMultiplied	out	The current pre-multiplied flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The preMultiplied parameter is invalid.

3.2.9.4 IBMDSwitcherTransitionStingerParameters::SetPreMultiplied method

The `SetPreMultiplied` method sets the pre-multiplied flag.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

Name	Direction	Description
preMultiplied	in	The desired pre-multiplied flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.9.5 IBMDSwitcherTransitionStingerParameters::GetClip method

The `GetClip` method returns the current clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

Name	Direction	Description
clip	out	The current clip value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The clip parameter is invalid.

3.2.9.6 IBMDSwitcherTransitionStingerParameters::SetClip method

The `SetClip` method sets the clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

Name	Direction	Description
clip	in	The desired clip value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.9.7 **IBMDSwitcherTransitionStingerParameters::GetGain** method

The `GetGain` method returns the current clip.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

3.2.9.8 **IBMDSwitcherTransitionStingerParameters::SetGain** method

The `SetGain` method sets the gain.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.9.9 **IBMDSwitcherTransitionStingerParameters::GetInverse** method

The `GetInverse` method returns the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

Name	Direction	Description
inverse	out	The current inverse flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inverse parameter is invalid.

3.2.9.10 **IBMDSwitcherTransitionStingerParameters::SetInverse** method

The `SetInverse` method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

Name	Direction	Description
inverse	in	The desired inverse flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.9.11 **IBMDSwitcherTransitionStingerParameters::GetPreroll** method

The `GetPreroll` method returns the current pre-roll.

Syntax

```
HRESULT GetPreroll (uint32_t* frames);
```

Parameters

Name	Direction	Description
frames	out	The current pre-roll in frames.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

3.2.9.12 **IBMDSwitcherTransitionStingerParameters::SetPreroll** method

The `SetPreroll` method sets the pre-roll.

Syntax

```
HRESULT SetPreroll (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	The desired pre-roll in frames.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.9.13 **IBMDSwitcherTransitionStingerParameters::GetClipDuration** method

The `GetClipDuration` method returns the current clip duration.

Syntax

```
HRESULT GetClipDuration (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	out	The current clip duration in frames.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

3.2.9.14 **IBMDSwitcherTransitionStingerParameters::SetClipDuration** method

The `SetClipDuration` method sets the clip duration.

Syntax

```
HRESULT SetClipDuration (uint32_t* frames);
```

Parameters

Name	Direction	Description
frames	in	The desired clip duration in frames.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.9.15 **IBMDSwitcherTransitionStingerParameters::GetTriggerPoint** method

The `GetTriggerPoint` method returns the current trigger point.

Syntax

```
HRESULT GetTriggerPoint (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	out	The current trigger point in frames.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

3.2.9.16 **IBMDSwitcherTransitionStingerParameters::SetTriggerPoint** method

The `SetTriggerPoint` method sets the trigger point.

Syntax

```
HRESULT SetTriggerPoint (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	The desired trigger point in frames.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.9.17 **IBMDSwitcherTransitionStingerParameters::GetMixRate** method

The `GetMixRate` method returns the current mix rate.

Syntax

```
HRESULT GetMixRate (uint32_t* frames);
```

Parameters

Name	Direction	Description
frames	out	The current mix rate in frames.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

3.2.9.18 **IBMDSwitcherTransitionStingerParameters::SetMixRate** method

The `SetMixRate` method sets the mix rate.

Syntax

```
HRESULT SetMixRate (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	The desired mix rate in frames.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.9.19 IBMDSwitcherTransitionStingerParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionStingerParameters** object. Pass an object implementing the **IBMDSwitcherTransitionStingerParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTransitionStingerParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionStingerParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.9.20 IBMDSwitcherTransitionStingerParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTransitionStingerParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionStingerParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.10 IBMDSwitcherTransitionStingerParametersCallback Interface

The `IBMDSwitcherTransitionStingerParametersCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherTransitionStingerParameters` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherTransitionStingerParameters	IID_IBMDSwitcherTransitionStingerParameters	An <code>IBMDSwitcherTransitionStingerParametersCallback</code> object interface is installed with <code>IBMDSwitcherTransitionStingerParameters::AddCallback</code> and removed with <code>IBMDSwitcherTransitionStingerParameters::RemoveCallback</code>

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

3.2.10.1 IBMDSwitcherTransitionStingerParametersCallback::Notify method

The `Notify` method is called when `IBMDSwitcherTransitionStingerParameters` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(IBMDSwitcherTransitionStingerParametersEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	<code>IBMDSwitcherTransitionStingerParametersEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

3.2.11 IBMDSwitcherTransitionParameters Interface

The `IBMDSwitcherTransitionParameters` object interface is used for manipulating transition settings specific to Stinger parameters.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherTransitionParameters	IID_IBMDSwitcherTransitionParameters	An <code>IBMDSwitcherTransitionParameters</code> object interface can be obtained with <code>IBMDSwitcherMixEffectBlock::QueryInterface</code> .

Public Member Functions

Method	Description
<code>GetTransitionStyle</code>	Get the current transition style.
<code>GetNextTransitionStyle</code>	Get the next transition style.
<code>SetNextTransitionStyle</code>	Set the next transition style.
<code>GetTransitionSelection</code>	Get the current transition selection.
<code>SetNextTransitionSelection</code>	Set the next transition selection.
<code>GetNextTransitionSelection</code>	Get the next transition selection.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

3.2.11.1 IBMDSwitcherTransitionParameters::GetTransitionStyle method

The `GetTransitionStyle` method returns the current transition style.

Syntax

```
HRESULT GetTransitionStyle (IBMDSwitcherTransitionStyle* style);
```

Parameters

Name	Direction	Description
style	out	The current transition style.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The style parameter is invalid.

3.2.11.2 **IBMDSwitcherTransitionParameters::GetNextTransitionStyle** method

The `GetNextTransitionStyle` method returns the next transition style.

Syntax

```
HRESULT GetNextTransitionStyle (BMDSwitcherTransitionStyle* style);
```

Parameters

Name	Direction	Description
style	out	The next transition style.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The style parameter is invalid.

3.2.11.3 **IBMDSwitcherTransitionParameters::SetNextTransitionStyle** method

The `SetNextTransitionStyle` method sets the rate in frames.

Syntax

```
HRESULT SetNextTransitionStyle (BMDSwitcherTransitionStyle style);
```

Parameters

Name	Direction	Description
style	in	The desired style.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The style parameter is invalid.

3.2.11.4 **IBMDSwitcherTransitionParameters::GetTransitionSelection** method

The `GetTransitionSelection` method returns the current transition selection.

Syntax

```
HRESULT GetTransitionSelection (BMDSwitcherTransitionSelection* selection);
```

Parameters

Name	Direction	Description
selection	out	The current transition selection.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The selection parameter is invalid.

3.2.11.5 **IBMDSwitcherTransitionParameters::SetNextTransitionSelection** method

The `SetNextTransitionSelection` method sets the next transition selection.

Syntax

```
HRESULT SetNextTransitionSelection (BMDSwitcherTransitionSelection selection);
```

Parameters

Name	Direction	Description
selection	in	The desired next transition selection.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The selection parameter is invalid.

3.2.11.6 **IBMDSwitcherTransitionParameters::GetNextTransitionSelection** method

The `GetNextTransitionSelection` method returns the next transition selection.

Syntax

```
HRESULT GetNextTransitionSelection (BMDSwitcherTransitionSelection* selection);
```

Parameters

Name	Direction	Description
selection	out	The next transition selection.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The selection parameter is invalid.

3.2.11.7 **IBMDSwitcherTransitionParameters::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherTransitionParameters** object. Pass an object implementing the **IBMDSwitcherTransitionParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherTransitionParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.11.8 **IBMDSwitcherTransitionParameters::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback(IBMDSwitcherTransitionParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTransitionParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

3.2.12 IBMDSwitcherTransitionParametersCallback Interface

The `IBMDSwitcherTransitionParametersCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherTransitionParameters` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherTransitionParameters</code>	<code>IID_IBMDSwitcherTransitionParameters</code>	An <code>IBMDSwitcherTransitionParametersCallback</code> object interface is installed with <code>IBMDSwitcherTransitionParameters::AddCallback</code> and removed with <code>IBMDSwitcherTransitionParameters::RemoveCallback</code>

Public Member Functions

Method	Description
<code>Notify</code>	Called when an event occurs.

3.2.12.1 IBMDSwitcherTransitionParametersCallback::Notify method

The `Notify` method is called when `IBMDSwitcherTransitionParameters` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(IBMDSwitcherTransitionParametersEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>IBMDSwitcherTransitionParametersEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

Section 4 — Switcher Media

All media used by the switcher comes from its media pool, which consists of still images or video clips. Developers can upload and download from the media pool of a switcher using this SDK.

4.1 General Information

4.1.1 Uploading a Still or Clip

Here are the basic steps of uploading media to a switcher:

- 1 Ensure you are connected to a switcher and have a switcher object. Please refer to the Basic Switcher Control section for how to do this.
- 2 Get the **IBMDSwitcherMediaPool** interface from the switcher object, and use **IBMDSwitcherMediaPool::GetStills** to get the interface dedicated to all stills or **IBMDSwitcherMediaPool::GetClip** to get the interface dedicated to a particular clip.
- 3 **IBMDSwitcherStills::Lock** and **IBMDSwitcherClip::Lock** requests a lock of the switcher's stills/clip and the **IBMDSwitcherLockCallback** interface should then be used to be informed of when a lock is obtained. Many media pool operations require you to have a lock first.
- 4 If you are transferring to a clip then you probably want to stop users playing/downloading any frame in the clip by calling **IBMDSwitcherClip::SetInvalid**.
- 5 Use **IBMDSwitcherMediaPool::CreateFrame** to generate a frame object that will eventually be passed to the upload system. Populate this with your image data by filling in the frame's buffer, which is available via **IBMDSwitcherFrame::GetBytes**. Note that you do not need a lock to create a frame, but it is important that the chosen dimensions for the frame match those of the switcher's video mode when you proceed with the upload step.
- 6 Call **IBMDSwitcherStill::Upload** or **IBMDSwitcherClip::UploadFrame** to begin the transfer of the frame to the switcher. You will be notified of the outcome of this process by the **IBMDSwitherStillsCallback** or **IBMDSwitcherClipCallback** interfaces. Regardless of outcome, this notification will also include the frame that was sent.
- 7 If you are transferring to a clip then you may want to repeatedly perform steps 4 and 5, although only one frame is permitted to be transferred at a time, and upon completing clip transfers you need to use **IBMDSwitcherClip::SetValid**.
- 8 Unlock the stills or clip. If you are uploading multiple stills then you may want to repeatedly lock and unlock the stills pool to allow other users to obtain a lock.

4.1.2 Downloading a Still or Clip

The steps are very similar to uploading:

- 1 Ensure you are connected to a switcher and have a switcher object. Please refer to the Basic Switcher Control section for how to do this.
- 2 Get the **IBMDSwitcherMediaPool** interface from the switcher object, and use **IBMDSwitcherMediaPool::GetStills** to get the interface dedicated to all stills or **IBMDSwitcherMediaPool::GetClip** to get the interface dedicated to a particular clip.
- 3 **IBMDSwitcherStills::Lock** and **IBMDSwitcherClip::Lock** requests a lock of the switcher's stills/clip and the **IBMDSwitcherLockCallback** interface should then be used to be informed of when a lock is obtained. Many media pool operations require you to have a lock first.
- 4 Call **IBMDSwitcherStill::Download** or **IBMDSwitcherClip::DownloadFrame** to begin the transfer of a frame from the switcher. You will be notified of the outcome of this process by the **IBMDSwitherStillsCallback** or **IBMDSwitcherClipCallback** interfaces. For successful downloads, this notification will also include the frame that was requested.
- 5 Unlock the stills or clip. If you are downloading multiple stills then you may want to repeatedly lock and unlock the stills pool to allow other users to obtain a lock.

4.2 Media Data Types

4.2.1 Switcher Pixel Format

BMDSwitcherPixelFormat enumerates the possible pixel formats for **IBMDSwitcherFrame**.

- **bmdSwitcherPixelFormat8BitARGB**
Four bytes per pixel, alpha, red, green, blue.
- **bmdSwitcherPixelFormat8BitXRGB**
Four bytes per pixel, padding, red, green, blue.
- **bmdSwitcherPixelFormat8BitYUV**
Four bytes per two pixels, cb, y0, cr, y1.
- **bmdSwitcherPixelFormat10BitYUVA**
Eight bytes per two pixels, a0, cb, y0, a1, cr, y1.

4.2.2 Media Player Source Type

BMDSwitcherMediaPlayerSourceType enumerates the possible source types for **IBMDSwitcherMediaPlayer**.

- **bmdSwitcherMediaPlayerSourceTypeStill**
Still.
- **bmdSwitcherMediaPlayerSourceTypeClip**
Clip.

4.2.3 Media Pool Event Type

BMDSwitcherMediaPoolEventType enumerates the possible event types for **IBMDSwitcherStillsCallback** and **IBMDSwitcherClipCallback**.

- **bmdSwitcherMediaPoolEventTypeValidChanged**
The validity has changed.
- **bmdSwitcherMediaPoolEventTypeNameChanged**
The name has changed.
- **bmdSwitcherMediaPoolEventTypeHashChanged**
The hash has changed.
- **bmdSwitcherMediaPoolEventTypeAudioValidChanged**
The audio validity has changed.
- **bmdSwitcherMediaPoolEventTypeLockBusy**
All clients receive this when any client obtains a lock.
- **bmdSwitcherMediaPoolEventTypeLockIdle**
All clients receive this when no client has lock.
- **bmdSwitcherMediaPoolEventTypeTransferCompleted**
The transfer has completed.
- **bmdSwitcherMediaPoolEventTypeTransferCancelled**
The transfer has cancelled.
- **bmdSwitcherMediaPoolEventTypeTransferFailed**
The transfer has failed.
- **bmdSwitcherMediaPoolEventTypeAudioNameChanged**
The audio name has changed.
- **bmdSwitcherMediaPoolEventTypeAudioHashChanged**
The audio hash has changed.

4.2.4 BMDSwitcherStillCaptureEventType

BMDSwitcherStillCaptureEventType enumerates the possible event types for **IBMDSwitcherStillCaptureCallback**.

- **bmdSwitcherStillCaptureEventTypesAvailableChanged**
The availability of still capture has changed.

4.3 Interface Reference

4.3.1 IBMDSwitcherMediaPlayerCallback Interface

The **IBMDSwitcherMediaPlayerCallback** object interface is a callback class containing methods that are called when the source, state or properties change for an **IBMDSwitcherMediaPlayer** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMediaPlayer	IID_ IBMDSwitcherMediaPlayer	An IBMDSwitcherMediaPlayerCallback object interface is installed with IBMDSwitcherMediaPlayer::AddCallback and removed with IBMDSwitcherMediaPlayer::RemoveCallback

Public Member Functions	
Method	Description
SourceChanged	Called when the source changes.
PlayingChanged	Called when playing changes.
LoopChanged	Called when loop changes.
AtBeginningChanged	Called when the current clip frame index changes to or from zero.
ClipFrameChanged	Called when the clip frame index is set.

4.3.1.1 IBMDSwitcherMediaPlayerCallback::SourceChanged method

The **SourceChanged** method is called when the media player source changes.

Syntax

```
HRESULT SourceChanged (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.1.2 IBMDSwitcherMediaPlayerCallback::PlayingChanged method

The `PlayingChanged` method is called when the media player playing state changes.

Syntax

```
HRESULT PlayingChanged (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.1.3 IBMDSwitcherMediaPlayerCallback::LoopChanged method

The `LoopChanged` method is called when the media player loop property changes.

Syntax

```
HRESULT LoopChanged (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.1.4 IBMDSwitcherMediaPlayerCallback::AtBeginningChanged method

The `AtBeginningChanged` method is called when the media player current clip frame index changes to or from zero.

Syntax

```
HRESULT AtBeginningChanged (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.1.5 IBMDSwitcherMediaPlayerCallback::ClipFrameChanged method

The `ClipFrameChanged` method is called when the media player clip frame index is set.

Syntax

```
HRESULT ClipFrameChanged (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.2 IBMDSwitcherMediaPlayerIterator Interface

The `IBMDSwitcherMediaPlayerIterator` is used to enumerate the available media players.

A reference to an `IBMDSwitcherMediaPlayerIterator` object interface may be obtained from an `IBMDSwitcher` object interface using the `CreateIterator` method. Pass `IID_IBMDSwitcherMediaPlayerIterator` for the iid parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	<code>IBMDSwitcher::CreateIterator</code> can return an <code>IBMDSwitcherMediaPlayerIterator</code> object interface.

Public Member Functions	
Method	Description
Next	Returns a pointer to the next <code>IBMDSwitcherMediaPlayer</code> object interface.

4.3.2.1 IBMDSwitcherMediaPlayerIterator::Next method

The `Next` method returns the next available `IBMDSwitcherMediaPlayer` object interface.

Syntax

```
HRESULT Next (IBMDSwitcherMediaPlayer* mediaPlayer);
```

Parameters

Name	Direction	Description
mediaPlayer	out	<code>IBMDSwitcherMediaPlayer</code> object interface or NULL when no more media players are available.

Return Values

Value	Description
S_FALSE	No more <code>IBMDSwitcherMediaPlayer</code> objects available.
S_OK	Success.
E_POINTER	The mediaPlayer parameter is invalid.

4.3.3 IBMDSwitcherMediaPlayer Interface

The `IBMDSwitcherMediaPlayer` object interface provides the ability to play stills and clips sourced from the media pool.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMediaPlayerIterator	IID_IBMDSwitcherMediaPlayerIterator	<code>IBMDSwitcherMediaPlayerIterator::Next</code> returns an <code>IBMDSwitcherMediaPlayer</code> object interface for each available media player.

Public Member Functions	
Method	Description
GetSource	Gets the media player source.
SetSource	Sets the media player source.
GetPlaying	Gets the media player playing state.
SetPlaying	Sets the media player playing state.
GetLoop	Gets the media player loop property.
SetLoop	Sets the media player loop property.
GetAtBeginning	Gets the media player at beginning state.
SetAtBeginning	Sets the media player at beginning state.
GetClipFrame	Gets the media player clip frame index.
SetClipFrame	Sets the media player clip frame index.
AddCallback	Adds a media player callback.
RemoveCallback	Removes a media player callback.

4.3.3.1 IBMDSwitcherMediaPlayer::GetSource method

The `GetSource` method gets the source type and index for the media player.

Syntax

```
HRESULT GetSource (BMDSwitcherMediaPlayerSourceType* type, uint32_t* index);
```

Parameters

Name	Direction	Description
type	out	<code>BMDSwitcherMediaPlayerSourceType</code> specifying the source as a still or clip.
index	out	Integer specifying the index of the source.

Return Values

Value	Description
<code>E_FAIL</code>	Failure.
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The type or index parameter is invalid.

4.3.3.2 **IBMDSwitcherMediaPlayer::SetSource** method

The **SetSource** method sets the source type and index for the media player.

Syntax

```
HRESULT SetSource (BMDSwitcherMediaPlayerSourceType type, uint32_t index);
```

Parameters

Name	Direction	Description
type	in	BMDSwitcherMediaPlayerSourceType specifying the source as a still or clip.
index	in	Integer specifying the index of the source.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_INVALIDARG	The type or index parameter is invalid.

4.3.3.3 **IBMDSwitcherMediaPlayer::GetPlaying** method

The **GetPlaying** method gets the playing state for the media player.

Syntax

```
HRESULT GetPlaying (boolean* playing);
```

Parameters

Name	Direction	Description
playing	out	Boolean value specifying the playing state.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The playing parameter is invalid.

4.3.3.4 IBMDSwitcherMediaPlayer::SetPlaying method

The `SetPlaying` method sets the playing state for the media player.

Syntax

```
HRESULT SetPlaying (boolean playing);
```

Parameters

Name	Direction	Description
playing	in	Boolean value specifying the playing state.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

4.3.3.5 IBMDSwitcherMediaPlayer::GetLoop method

The `GetLoop` method gets the loop property for the media player.

Syntax

```
HRESULT GetLoop (boolean* loop);
```

Parameters

Name	Direction	Description
loop	out	Boolean value specifying the loop property.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The loop parameter is invalid.

4.3.3.6 IBMDSwitcherMediaPlayer::SetLoop method

The `SetLoop` method sets the loop property for the media player.

Syntax

```
HRESULT SetLoop (boolean loop);
```

Parameters

Name	Direction	Description
loop	in	Boolean value specifying the loop property.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

4.3.3.7 IBMDSwitcherMediaPlayer::GetAtBeginning method

The `GetAtBeginning` method gets the at beginning property for the media player.

Syntax

```
HRESULT GetAtBeginning (boolean* atBeginning);
```

Parameters

Name	Direction	Description
atBeginning	out	Boolean value that is true when the current frame index is zero and false otherwise.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The atBeginning parameter is invalid.

4.3.3.8 IBMDSwitcherMediaPlayer::SetAtBeginning method

The `SetAtBeginning` method sets the current frame index to zero for the media player.

Syntax

```
HRESULT SetAtBeginning ();
```

Parameters

none.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

4.3.3.9 IBMDSwitcherMediaPlayer::GetClipFrame method

The `GetClipFrame` method gets the clip frame index for the media player when it is not playing.

Syntax

```
HRESULT GetClipFrame (uint32_t* clipFrameIndex);
```

Parameters

Name	Direction	Description
clipFrameIndex	out	Integer value specifying the clip frame index.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The clipFrameIndex parameter is invalid.

4.3.3.10 **IBMDSwitcherMediaPlayer::SetClipFrame** method

The **SetClipFrame** method sets the clip frame index for the media player if it is not playing.

Syntax

```
HRESULT SetClipFrame (uint32_t clipFrameIndex);
```

Parameters

Name	Direction	Description
clipFrameIndex	in	Integer value specifying the clip frame index.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

4.3.3.11 **IBMDSwitcherMediaPlayer::AddCallback** method

The **AddCallback** method configures a callback to be called when the properties change for an **IBMDSwitcherMediaPlayer** object. Pass an object implementing the **IBMDSwitcherMediaPlayerCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMediaPlayerCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMediaPlayerCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

4.3.3.12 **IBMDSwitcherMediaPlayer::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMediaPlayerCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMediaPlayerCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

4.3.4 **IBMDSwitcherFrame** Interface

The **IBMDSwitcherFrame** object interface represents a frame and provides access to the frame's buffer and frame properties.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMediaPool	IID_IBMDSwitcherMediaPool	IBMDSwitcherMediaPool::CreateFrame returns an IBMDSwitcherFrame object.

Public Member Functions	
Method	Description
GetWidth	Gets the frame width in pixels.
GetHeight	Gets the frame height in pixels.
GetRowBytes	Gets the frame row size in bytes.
GetPixelFormat	Gets the pixel format.
GetBytes	Gets a pointer to the frame's buffer.

4.3.4.1 **IBMDSwitcherFrame::GetWidth** method

The **GetWidth** method returns the width of the frame in pixels.

Syntax

```
int32_t GetWidth (void);
```

Parameters

none.

Return Values

Value	Description
Width	Frame width in pixels.

4.3.4.2 IBMDSwitcherFrame::GetHeight method

The `GetHeight` method returns the height of the frame in pixels.

Syntax

```
int32_t GetHeight (void);
```

Parameters

none.

Return Values

Value	Description
Height	Frame height in pixels.

4.3.4.3 IBMDSwitcherFrame::GetRowBytes method

The `GetRowBytes` method returns the number of bytes per row in the frame.

Syntax

```
int32_t GetRowBytes (void);
```

Parameters

none.

Return Values

Value	Description
ByteCount	Frame row size in bytes.

4.3.4.4 IBMDSwitcherFrame::GetPixelFormat method

The `GetPixelFormat` method returns the pixel format of the frame.

Syntax

```
BMDSwitcherPixelFormat GetPixelFormat (void);
```

Parameters

none.

Return Values

Value	Description
PixelFormat	Frame pixel format.

4.3.4.5 IBMDSwitcherFrame::GetBytes method

The `GetBytes` method allows direct access to the data buffer of the frame. The audio format is raw 24 bit, 2 channel, 48 khz.

Syntax

```
HRESULT GetBytes (void* buffer);
```

Parameters

Name	Direction	Description
buffer	out	Pointer to the frame's raw buffer – only valid while object remains valid.

Return Values

Value	Description
E_POINTER	The buffer parameter is invalid.
S_OK	Success.

4.3.5 IBMDSwitcherAudio Interface

The `IBMDSwitcherAudio` object interface represents audio and provides access to the audio's buffer and audio size.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMediaPool	IID_IBMDSwitcherMediaPool	<code>IBMDSwitcherMediaPool::CreateAudio</code> returns an <code>IBMDSwitcherAudio</code> object.

Public Member Functions	
Method	Description
GetSize	Gets the audio size in bytes.
GetBytes	Gets the audio buffer pointer.

4.3.5.1 IBMDSwitcherFrame::GetSize method

The `GetSize` method returns the size of the audio in bytes.

Syntax

```
int32_t GetSize (void);
```

Parameters

none.

Return Values

Value	Description
ByteCount	Audio size in bytes.

4.3.5.2 IBMDSwitcherAudio::GetBytes method

The `GetBytes` method allows direct access to the data buffer of the audio.

Syntax

```
HRESULT GetBytes (void* buffer);
```

Parameters

Name	Direction	Description
buffer	out	Pointer to the audio's raw buffer – only valid while object remains valid.

Return Values

Value	Description
E_POINTER	The buffer parameter is invalid.
S_OK	Success.

4.3.6 IBMDSwitcherLockCallback Interface

The `IBMDSwitcherLockCallback` object interface is a callback class with an `Obtained` method that is called when the client receives a lock. Like all callback methods, `Obtained` may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherStills	IID_IBMDSwitcherStills	An <code>IBMDSwitcherLockCallback</code> object interface is installed with <code>IBMDSwitcherStills::Lock</code> and removed with <code>IBMDSwitcherStills::Unlock</code>
IBMDSwitcherClip	IID_IBMDSwitcherClip	An <code>IBMDSwitcherLockCallback</code> object interface is installed with <code>IBMDSwitcherClip::Lock</code> and removed with <code>IBMDSwitcherClip::Unlock</code>

Public Member Functions	
Method	Description
Obtained	Called when the client receives a lock.

4.3.6.1 IBMDSwitcherLockCallback::Obtained method

The `Obtained` method is called only for the client that receives the lock.

Syntax

```
HRESULT Obtained (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.7 IBMDSwitcherStillsCallback Interface

The **IBMDSwitcherStillsCallback** object interface is a callback class with a **Notify** method that is called when an event occurs for an **IBMDSwitcherStills** object. Like all callback methods, **Notify** may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherStills	IID_IBMDSwitcherStills	An IBMDSwitcherStillsCallback object interface is installed with IBMDSwitcherStills::AddCallback and removed with IBMDSwitcherStills::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an stills event occurs.

4.3.7.1 IBMDSwitcherStillsCallback::Notify method

The **Notify** method is called when a stills event occurs. See **BMDSwitcherMediaPoolEventType** for a list of event types that may occur.

- **bmdSwitcherMediaPoolEventTypeTransferCompleted**
IBMDSwitcherStills::Upload and **IBMDSwitcherStills::Download**.
- **bmdSwitcherMediaPoolEventTypeTransferCancelled**
IBMDSwitcherStills::Upload only.
- **bmdSwitcherMediaPoolEventTypeTransferFailed**
BMDSwitcherStills::Upload only.

IBMDSwitcherFrame ::AddRef must be called on the frame to extend its lifetime beyond the scope of this method.

Syntax

```
HRESULT Notify (BMDSwitcherMediaPoolEventType eventType, IBMDSwitcherFrame*  
               frame, int32_t index);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherMediaPoolEventType that describes the type of event that has occurred.
frame	in	The IBMDSwitcherFrame that is being transferred. May be NULL .
index	in	Specifies the still for the eventType. The index is -1 when eventType is not specific to an individual still.

Return Values

Value	Description
S_OK	Success.

4.3.8 IBMDSwitcherStills Interface

The `IBMDSwitcherStills` object interface represents the media pool stills.

The switcher stills interface provides methods to transfer stills and change still properties.

No more than one transfer can occur at a time.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMediaPool</code>	<code>IID_IBMDSwitcherMediaPool</code>	<code>IBMDSwitcherMediaPool::GetStills</code> returns an <code>IBMDSwitcherStills</code> object.

Public Member Functions	
Method	Description
<code>GetCount</code>	Gets the number of stills.
<code>IsValid</code>	Gets the validity of a still.
<code>GetName</code>	Gets the name of a still.
<code>GetHash</code>	Gets the hash of a still.
<code>SetInvalid</code>	Invalidates a still.
<code>Lock</code>	Locks all stills.
<code>Unlock</code>	Unlocks all stills.
<code>Upload</code>	Uploads a still.
<code>Download</code>	Downloads a still.
<code>CancelTransfer</code>	Cancels the upload or download.
<code>GetProgress</code>	Gets the transfer progress.
<code>AddCallback</code>	Adds a stills callback.
<code>RemoveCallback</code>	Removes a stills callback.

4.3.8.1 IBMDSwitcherStills::GetCount method

The `GetCount` method returns the number of stills.

Syntax

```
HRESULT GetCount (uint32_t* count);
```

Parameters

Name	Direction	Description
<code>count</code>	out	Number of stills.

Return Values

Value	Description
<code>E_POINTER</code>	The count parameter is NULL.
<code>S_OK</code>	Success.

4.3.8.2 **IBMDSwitcherStills::IsValid** method

The **IsValid** method returns the validity of a still. A valid still can be downloaded and used by the media player.

Syntax

```
HRESULT IsValid (uint32_t index, bool* valid);
```

Parameters

Name	Direction	Description
index	in	Still index.
valid	out	Validity of the still.

Return Values

Value	Description
E_POINTER	The valid parameter is NULL.
S_OK	Success.

4.3.8.3 **IBMDSwitcherStills::GetName** method

The **GetName** method returns the name of a still.

Syntax

```
HRESULT GetName (uint32_t index, string* name);
```

Parameters

Name	Direction	Description
index	in	Still index.
name	out	Still name.

Return Values

Value	Description
E_POINTER	The name parameter is NULL.
S_OK	Success.

4.3.8.4 **IBMDSwitcherStills::SetName** method

The **SetName** method sets the name of a still.

Syntax

```
HRESULT SetName (uint32_t index, string name);
```

Parameters

Name	Direction	Description
index	in	Still index.
name	in	The still name.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The name parameter is invalid.
E_INVALIDARG	The index parameter is invalid.

4.3.8.5 **IBMDSwitcherStills::GetHash** method

The **GetHash** method returns the hash of a still.

Syntax

```
HRESULT GetHash (uint32_t index, IBMDSwitcherHash* hash);
```

Parameters

Name	Direction	Description
index	in	Still index.
hash	out	Still hash.

Return Values

Value	Description
E_POINTER	The hash parameter is NULL.
S_OK	Success.

4.3.8.6 **IBMDSwitcherStills::SetInvalid** method

The **SetInvalid** method invalidates a still for all switcher users. A still is set valid after a successful upload. This method will only be successful if you have a lock or no other connected client has a lock.

Syntax

```
HRESULT SetInvalid (uint32_t index);
```

Parameters

Name	Direction	Description
index	in	Still index.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

4.3.8.7 **IBMDSwitcherStills::Lock** method

The **Lock** method obtains a client lock for stills. Pass an object implementing the **IBMDSwitcherLockCallback** interface to receive **IBMDSwitcherLockCallback::Obtained** when the client obtains the stills lock.

Syntax

```
HRESULT Lock (IBMDSwitcherLockCallback* lockCallback);
```

Parameters

Name	Direction	Description
lockCallback	in	Callback object implementing the IBMDSwitcherLockCallback object interface.

Return Values

Value	Description
E_POINTER	The lockCallback parameter is invalid.
E_FAIL	Failure.
S_OK	Success.

4.3.8.8 **IBMDSwitcherStills::Unlock** method

The **Unlock** method releases the previous client lock for stills.

Syntax

```
HRESULT Unlock (IBMDSwitcherLockCallback* lockCallback);
```

Parameters

Name	Direction	Description
lockCallback	in	Callback object implementing the IBMDSwitcherLockCallback object interface.

Return Values

Value	Description
E_POINTER	The lockCallback parameter is invalid.
E_FAIL	Failure.
S_OK	Success.

4.3.8.9 **IBMDSwitcherStills::Upload** method

The **Upload** method transfers a still to the media pool. The client must hold the stills lock for the duration of the transfer. No more than one transfer can occur at a time. Do not write to the frame's buffer during the transfer.

Syntax

```
HRESULT Upload (uint32_t index, string* name, IBMDSwitcherFrame* frame);
```

Parameters

Name	Direction	Description
index	in	Destination still index.
name	in	Destination still name.
frame	in	Still frame to upload. The frame dimensions must match the switcher video mode.

Return Values

Value	Description
E_POINTER	The lockCallback parameter is invalid.
E_FAIL	Failure.
S_OK	Success.
E_INVALIDARG	The index parameter is invalid.
E_OUTOFMEMORY	Unable to allocate required memory.
E_ACCESSDENIED	The client is not holding the stills lock.

4.3.8.10 **IBMDSwitcherStills::Download** method

The **Download** method transfers a still from the media pool. The client must hold the stills lock for the duration of the transfer. No more than one transfer can occur at a time.

Syntax

```
HRESULT Download (uint32_t index);
```

Parameters

Name	Direction	Description
index	in	Index of still to download.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_INVALIDARG	The index parameter is invalid.
E_OUTOFMEMORY	Unable to allocate required memory.
E_ACCESSDENIED	The client is not holding the stills lock.

4.3.8.11 **IBMDSwitcherStills::CancelTransfer** method

The **CancelTransfer** method cancels the pending transfer. If there is no pending transfer then this method has no effect.

Syntax

```
HRESULT CancelTransfer ();
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.8.12 **IBMDSwitcherStills::GetProgress** method

The **GetProgress** method gets the progress of the pending transfer. If there is no pending transfer then progress is zero.

Syntax

```
HRESULT GetProgress (double* progress);
```

Parameters

Name	Direction	Description
progress	out	Transfer progress. Range is between 0.0 and 1.0.

Return Values

Value	Description
E_POINTER	The progress parameter is invalid.
S_OK	Success.

4.3.8.13 **IBMDSwitcherStills::AddCallback** method

The **AddCallback** method configures a callback to be called when an event occurs for an **IBMDSwitcherStills** object. Pass an object implementing the **IBMDSwitcherStillsCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

IBMDSwitcherStillsCallback::Notify will be called immediately on the provided **IBMDSwitcherStillsCallback** callback object with one of the following **BMDSwitcherMediaPoolEventType** eventTypes:

- **bmdSwitcherMediaPoolEventTypeLockBusy**
- **bmdSwitcherMediaPoolEventTypeLockIdle**

Syntax

```
HRESULT AddCallback (IBMDSwitcherStillsCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherStillsCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

4.3.8.14 IBMDSwitcherStills::RemoveCallback method

The `RemoveCallback` method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherStillsCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the <code>IBMDSwitcherStillsCallback</code> object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

4.3.9 IBMDSwitcherStillCaptureCallback Interface

The `IBMDSwitcherStillCaptureCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherStillCapture` object.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherStillCapture</code>	<code>IID_IBMDSwitcherStillCapture</code>	An <code>IBMDSwitcherStillCaptureCallback</code> object interface is installed with <code>IBMDSwitcherStillCapture::AddCallback</code> and removed with <code>IBMDSwitcherStillCapture::RemoveCallback</code> .

Public Member Functions

Method	Description
<code>Notify</code>	Called when an event occurs.

4.3.9.1 IBMDSwitcherStillCaptureCallback::Notify method

The Notify method is called when **IBMDSwitcherStillCapture** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(IBMDSwitcherStillCaptureEventType eventType)
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherStillCaptureEventType that describes the type of event that has occurred.

4.3.10 IBMDSwitcherStillCapture Interface

The **IBMDSwitcherStillCapture** object interface provides functionality for capturing the program output to media pool stills.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherStills	IID_IBMDSwitcherStills	An IBMDSwitcherStillCapture object interface can be obtained with IBMDSwitcherStills::QueryInterface .

Public Member Functions	
Method	Description
IsAvailable	Determines whether the switcher is currently able to capture the program output to a media pool still.
CaptureStill	Captures the current program output frame as a media pool still.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

4.3.10.1 **IBMDSwitcherStillCapture::IsAvailable** method

The `IsAvailable` method is used to determine whether the switcher is currently able to capture the program output frame. Capture requires the media pool to have at least one empty still.

Syntax

```
HRESULT IsAvailable(Boolean* available)
```

Parameters

Name	Direction	Description
available	out	Boolean that indicates whether still capture is currently available.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The available parameter is not a valid pointer.
E_FAIL	Failure.

4.3.10.2 **IBMDSwitcherStillCapture::CaptureStill** method

The `CaptureStill` method captures the current program output frame and stores it in the first empty still in the media pool.

Syntax

```
HRESULT CaptureStill()
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen when there are no empty stills in the media pool.

4.3.10.3 **IBMDSwitcherStillCapture::AddCallback** method

The `AddCallback` method configures a callback to be called when events occur for an **IBMDSwitcherStillCapture** object. Pass an object implementing the **IBMDSwitcherStillCaptureCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherStillCaptureCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherStillCaptureCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

4.3.10.4 IBMDSwitcherStillCapture::RemoveCallback method

The RemoveCallback method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback(IBMDSwitcherStillCaptureCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherStillCaptureCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

4.3.11 IBMDSwitcherClipCallback Interface

The **IBMDSwitcherClipCallback** object interface is a callback class with a **Notify** method that is called when an event occurs for an **IBMDSwitcherClip** object. Like all callback methods, **Notify** may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherClip	IID_IBMDSwitcherClip	An IBMDSwitcherClipCallback object interface is installed with IBMDSwitcherClip::AddCallback and removed with IBMDSwitcherClip::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

4.3.11.1 **IBMDSwitcherClipCallback::Notify** method

The **Notify** method is called when a clip event occurs. See **BMDSwitcherMediaPoolEventType** for a list of event types that may occur.

The frame is set during the following transfer events, otherwise it is NULL:

- **bmdSwitcherMediaPoolEventTypeTransferCompleted**
IBMDSwitcherClip::Upload and **IBMDSwitcherClip::Download**.
- **bmdSwitcherMediaPoolEventTypeTransferCancelled**
IBMDSwitcherClip::Upload only.
- **bmdSwitcherMediaPoolEventTypeTransferFailed**
IBMDSwitcherClip::Upload only.

The audio is set during the following transfer events, otherwise it is NULL:

- **bmdSwitcherMediaPoolEventTypeTransferCompleted**
IBMDSwitcherClip::UploadAudio and **IBMDSwitcherClip::DownloadAudio**.
- **bmdSwitcherMediaPoolEventTypeTransferCancelled**
IBMDSwitcherClip::UploadAudio only.
- **bmdSwitcherMediaPoolEventTypeTransferFailed**
IBMDSwitcherClip::UploadAudio only.

IBMDSwitcherFrame::AddRef must be called on the frame to extend its lifetime beyond the scope of this method.

IBMDSwitcherAudio::AddRef must be called on the audio to extend its lifetime beyond the scope of this method.

Syntax

```
HRESULT Notify (BMDSwitcherMediaPoolEventType eventType,  
                IBMDSwitcherFrame* frame, int32_t frameIndex,  
                IBMDSwitcherAudio* audio, int32_t clipIndex);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherMediaPoolEventType that describes the type of event that has occurred.
frame	in	The IBMDSwitcherFrame that is being transferred. May be NULL.
frameIndex	in	Specifies the frame for the eventType. The index is -1 when eventType is not specific to an individual clip frame.
audio	in	The IBMDSwitcherAudio that is being transferred. May be NULL.
clipIndex	in	Specifies the clip for the eventType.

Return Values

Value	Description
S_OK	Success.

4.3.12 IBMDSwitcherClip Interface

The `IBMDSwitcherClip` object interface represents the media pool clips.

The switcher clip interface provides methods to transfer clip frames and audio and to change clip properties. No more than one transfer can occur at a time.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherMediaPool</code>	<code>IID_IBMDSwitcherClip</code>	<code>IBMDSwitcherMediaPool::GetClip</code> returns an <code>IBMDSwitcherClip</code> object.

Public Member Functions	
Method	Description
<code>GetIndex</code>	Gets the clip index.
<code>IsValid</code>	Gets the validity of the clip.
<code>GetName</code>	Gets the name of the clip.
<code>SetValid</code>	Sets the clip name and frame count and sets the clip valid.
<code>SetInvalid</code>	Invalidates the clip.
<code>GetFrameCount</code>	Gets the current clip frame count.
<code>GetMaxFrameCount</code>	Gets the maximum clip frame count.
<code>IsFrameValid</code>	Gets the validity of a clip frame.
<code>GetFrameHash</code>	Gets the hash of a clip frame.
<code>IsAudioValid</code>	Gets the validity of the clip audio.
<code>GetAudioName</code>	Gets the name of the clip audio.
<code>GetAudioHash</code>	Gets the hash of the clip audio.
<code>SetAudioInvalid</code>	Invalidates the clip audio.
<code>Lock</code>	Locks the clip.
<code>Unlock</code>	Unlocks the clip.
<code>UploadFrame</code>	Uploads a clip frame.
<code>DownloadFrame</code>	Downloads a clip frame.
<code>UploadAudio</code>	Uploads the clip audio.
<code>DownloadAudio</code>	Downloads the clip audio.
<code>CancelTransfer</code>	Cancels the transfer.
<code>GetProgress</code>	Gets the transfer progress.
<code>AddCallback</code>	Adds a clip callback.
<code>RemoveCallback</code>	Removes a clip callback.

4.3.12.1 IBMDSwitcherClip::GetIndex method

The `GetIndex` method returns the clip index.

Syntax

```
HRESULT GetIndex (uint32_t* index);
```

Parameters

Name	Direction	Description
index	out	The clip index.

Return Values

Value	Description
S_OK	Success.

4.3.12.2 IBMDSwitcherClip::IsValid method

The `IsValid` method returns the validity of the clip. A valid clip can be downloaded and played by the media player.

Syntax

```
HRESULT IsValid (bool* valid);
```

Parameters

Name	Direction	Description
valid	out	Validity of the clip.

Return Values

Value	Description
E_POINTER	The valid parameter is NULL.
S_OK	Success.

4.3.12.3 IBMDSwitcherClip::GetName method

The `GetName` method returns the name of the clip.

Syntax

```
HRESULT GetName (string* name);
```

Parameters

Name	Direction	Description
name	out	Clip name.

Return Values

Value	Description
E_POINTER	The name parameter is NULL.
S_OK	Success.

4.3.12.4 IBMDSwitcherClip::SetName method

The `SetName` method sets the name of the clip.

Syntax

```
HRESULT SetName (string name);
```

Parameters

Name	Direction	Description
name	in	The clip name.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The name parameter is invalid.

4.3.12.5 IBMDSwitcherClip::SetValid method

The **SetValid** method sets the clip name and frame count and sets the clip valid. **SetValid** has no effect unless all frames up to frameCount are valid. A valid clip can be downloaded and played by the media player.

Syntax

```
HRESULT SetValid (string name, uint32_t frameCount);
```

Parameters

Name	Direction	Description
name	in	Clip name.
frameCount	in	Clip frame count.

Return Values

Value	Description
E_POINTER	The valid parameter is NULL.
S_OK	Success.

4.3.12.6 IBMDSwitcherClip::SetInvalid method

The **SetInvalid** method invalidates every frame of a clip for all users, and should be done before uploading a new clip. A clip should then be set to valid once uploading is complete. This method will only be successful if you have a lock or no other connected client has a lock.

Syntax

```
HRESULT SetInvalid ();
```

Parameters

none.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

4.3.12.7 IBMDSwitcherClip::GetFrameCount method

The `GetFrameCount` method gets the current frame count of the clip.

Syntax

```
HRESULT GetFrameCount (uint32_t* frameCount);
```

Parameters

Name	Direction	Description
name	out	Clip frame count.

Return Values

Value	Description
E_POINTER	The frameCount parameter is NULL.
S_OK	Success.

4.3.12.8 IBMDSwitcherClip::GetMaxFrameCount method

The `GetMaxFrameCount` method gets the maximum frame count for the clip. The maximum frame count can be set using `IBMDSwitcherMediaPool::SetClipMaxFrameCounts`.

Syntax

```
HRESULT GetMaxFrameCount (uint32_t* maxFrameCount);
```

Parameters

Name	Direction	Description
maxFrameCount	out	Maximum clip frame count.

Return Values

Value	Description
E_POINTER	The maxFrameCount parameter is NULL.
S_OK	Success.

4.3.12.9 IBMDSwitcherClip::IsFrameValid method

The `IsFrameValid` method returns the validity of a clip frame.

Syntax

```
HRESULT IsFrameValid (uint32_t frameIndex, bool* valid);
```

Parameters

Name	Direction	Description
frameIndex	in	Clip frame index.
valid	out	Validity of the clip frame.

Return Values

Value	Description
E_POINTER	The valid parameter is NULL.
E_INVALIDARG	The frameIndex parameter is invalid.
S_OK	Success.

4.3.12.10 IBMDSwitcherClip::GetFrameHash method

The `GetFrameHash` method returns the hash of a clip frame.

Syntax

```
HRESULT GetFrameHash (uint32_t frameIndex, BMDSwitcherHash* hash);
```

Parameters

Name	Direction	Description
frameIndex	in	Clip frame index.
hash	out	Clip frame hash.

Return Values

Value	Description
E_POINTER	The hash parameter is NULL.
E_INVALIDARG	The frameIndex parameter is invalid.
S_OK	Success.

4.3.12.11 **IBMDSwitcherClip::IsAudioValid** method

The **IsAudioValid** method returns the validity of the clip audio. Valid clip audio can be downloaded and played by the media player.

Syntax

```
HRESULT IsAudioValid (bool* valid);
```

Parameters

Name	Direction	Description
valid	out	Validity of the clip audio.

Return Values

Value	Description
E_POINTER	The valid parameter is NULL.
S_OK	Success.

4.3.12.12 **IBMDSwitcherClip::GetAudioName** method

The **GetAudioName** method returns the name of the clip audio.

Syntax

```
HRESULT GetAudioName (string* name);
```

Parameters

Name	Direction	Description
name	out	Clip audio name.

Return Values

Value	Description
E_POINTER	The name parameter is NULL.
S_OK	Success.

4.3.12.13 **IBMDSwitcherClip::SetAudioName** method

The **SetAudioName** method sets the name of the clip audio.

Syntax

```
HRESULT SetAudioName (string name);
```

Parameters

Name	Direction	Description
name	in	The still name.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The name parameter is invalid.

4.3.12.14 **IBMDSwitcherClip::GetAudioHash** method

The **GetAudioHash** method returns the hash of the clip audio.

Syntax

```
HRESULT GetAudioHash (BMDSwitcherHash* hash);
```

Parameters

Name	Direction	Description
hash	out	Clip audio frame hash.

Return Values

Value	Description
E_POINTER	The hash parameter is NULL.
S_OK	Success.

4.3.12.15 **IBMDSwitcherClip::SetAudioInvalid** method

The **SetAudioInvalid** method invalidates the clip audio. Clip audio is set valid after a successful clip audio upload.

Syntax

```
HRESULT SetAudioInvalid ();
```

Parameters

none.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

4.3.12.16 **IBMDSwitcherClip::Lock** method

The **Lock** method obtains a client lock for the clip. Pass an object implementing the **IBMDSwitcherLockCallback** interface to receive **IBMDSwitcherLockCallback::Obtained** when the client obtains the clip lock.

Syntax

```
HRESULT Lock (IBMDSwitcherLockCallback* lockCallback);
```

Parameters

Name	Direction	Description
lockCallback	in	Callback object implementing the IBMDSwitcherLockCallback object interface.

Return Values

Value	Description
E_POINTER	The lockCallback parameter is invalid.
E_FAIL	Failure.
S_OK	Success.

4.3.12.17 **IBMDSwitcherClip::Unlock** method

The **Unlock** method releases the previous client lock for the clip.

Syntax

```
HRESULT Unlock (IBMDSwitcherLockCallback* lockCallback);
```

Parameters

Name	Direction	Description
lockCallback	in	Callback object implementing the IBMDSwitcherLockCallback object interface.

Return Values

Value	Description
E_POINTER	The lockCallback parameter is invalid.
E_FAIL	Failure.
S_OK	Success.

4.3.12.18 **IBMDSwitcherClip::UploadFrame** method

The **UploadFrame** method transfers a clip frame to a clip in the media pool. The client must hold the clip lock for the duration of the transfer. No more than one transfer can occur at a time. Do not write to the frame's buffer during the transfer.

Syntax

```
HRESULT UploadFrame (uint32_t frameIndex, IBMDSwitcherFrame* frame);
```

Parameters

Name	Direction	Description
frameIndex	in	frameIndex
frame	in	Clip frame to upload. The frame dimensions must match the switcher video mode.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The frame parameter is invalid.
E_INVALIDARG	The frameIndex parameter is invalid.
E_OUTOFMEMORY	Unable to allocate required memory.
E_ACCESSDENIED	The client is not holding the clip lock.

4.3.12.19 **IBMDSwitcherClip::DownloadFrame** method

The **DownloadFrame** method transfers a clip frame from the media pool. The client must hold the clip lock for the duration of the transfer. No more than one transfer can occur at a time.

Syntax

```
HRESULT DownloadFrame (uint32_t frameIndex);
```

Parameters

Name	Direction	Description
frameIndex	in	Index of clip frame to download.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_INVALIDARG	The frameIndex parameter is invalid.
E_OUTOFMEMORY	Unable to allocate required memory.
E_ACCESSDENIED	The client is not holding the clip lock.

4.3.12.20 **IBMDSwitcherClip::UploadAudio** method

The **UploadAudio** method transfers audio to a clip in the media pool. The client must hold the clip lock for the duration of the transfer. No more than one transfer can occur at a time. Do not write to the audio's buffer during the transfer.

Syntax

```
HRESULT UploadAudio (IBMDSwitcherAudio* audio);
```

Parameters

Name	Direction	Description
audio	in	Clip audio to upload.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The audio parameter is invalid.
E_OUTOFMEMORY	Unable to allocate required memory.
E_ACCESSDENIED	The client is not holding the clip lock.

4.3.12.21 **IBMDSwitcherClip::DownloadAudio** method

The **Download** method transfers a clip from the media pool. The client must hold the clip lock for the duration of the transfer. No more than one transfer can occur at a time.

Syntax

```
HRESULT DownloadAudio ();
```

Parameters

none.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_OUTOFMEMORY	Unable to allocate required memory.
E_ACCESSDENIED	The client is not holding the clip lock.

4.3.12.22 **IBMDSwitcherClip::CancelTransfer** method

The **CancelTransfer** method cancels the pending transfer. If there is no pending transfer then this method has no effect.

Syntax

```
HRESULT CancelTransfer ();
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.12.23 **IBMDSwitcherClip::GetProgress** method

The **GetProgress** method gets the progress of the pending transfer. If there is no pending transfer then progress is zero.

Syntax

```
HRESULT GetProgress (double* progress);
```

Parameters

Name	Direction	Description
progress	out	Transfer progress. Range is between 0.0 and 1.0.

Return Values

Value	Description
E_POINTER	The progress parameter is invalid.
S_OK	Success.

4.3.12.24 IBMDSwitcherClip::AddCallback method

The **AddCallback** method configures a callback to be called when an event occurs for an **IBMDSwitcherClip** object. Pass an object implementing the **IBMDSwitcherClipCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

IBMDSwitcherClipCallback::Notify will be called immediately on the provided **IBMDSwitcherClipCallback** callback object with one of the following **BMDSwitcherMediaPoolEventType** eventTypes:

- **bmdSwitcherMediaPoolEventTypeLockBusy**
- **bmdSwitcherMediaPoolEventTypeLockIdle**

Syntax

```
HRESULT AddCallback (IBMDSwitcherClipCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherClipCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

4.3.12.25 IBMDSwitcherClip::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherClipCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherClipCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

4.3.13 IBMDSwitcherMediaPoolCallback Interface

The **IBMDSwitcherMediaPoolCallback** object interface is a callback class containing methods that are called when a property changes on an **IBMDSwitcherMediaPool** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMediaPool	IID_IBMDSwitcherMediaPool	An IBMDSwitcherMediaPoolCallback object interface is installed with IBMDSwitcherMediaPool::AddCallback and removed with IBMDSwitcherMediaPool::RemoveCallback

Public Member Functions	
Method	Description
ClipFrameMaxCountsChanged	Called when the maximum frame count changes for one or more clips.
FrameTotalForClipsChanged	Called when the total number of frames available to clips changes.

4.3.13.1 IBMDSwitcherMediaPoolCallback::ClipFrameMaxCountsChanged method

The **ClipFrameMaxCountsChanged** method is called when the maximum frame count changes for one or more clips. Call **IBMDSwitcherMediaPool::GetClipMaxFrameCounts** to get the maximum frame counts for clips.

Syntax

```
HRESULT ClipFrameMaxCountsChanged ();
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.13.2 IBMDSwitcherMediaPoolCallback::FrameTotalForClipsChanged method

The **FrameTotalForClipsChanged** method is called when the total number of frames available to clips changes. Call **IBMDSwitcherMediaPool::GetFrameTotalForClips** to get the the total number of frames available to clips.

Syntax

```
HRESULT FrameTotalForClipsChanged ();
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.

4.3.14 IBMDSwitcherMediaPool Interface

The **IBMDSwitcherMediaPool** object interface provides for the creation of frames and audio and for accessing and modifying stills and clips.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	An IBMDSwitcherMediaPool object interface can be obtained with IBMDSwitcher::QueryInterface .

Public Member Functions	
Method	Description
GetStills	Gets the IBMDSwitcherStills object interface.
GetClip	Gets a IBMDSwitcherClip object interface.
GetClipCount	Gets the number of clips.
CreateFrame	Creates an IBMDSwitcherFrame object.
CreateAudio	Creates an IBMDSwitcherAudio object.
GetFrameTotalForClips	Gets the total number of frames available to clips.
GetClipMaxFrameCounts	Gets the maximum frame count for all clips.
SetClipMaxFrameCounts	Sets the maximum frame count for all clips.
Clear	clears all stills, clips and clip audio
DoesVideoModeChangeClearMediaPool	Determines if changing video standard will clear the media pool.
AddCallback	Adds a media pool callback.
RemoveCallback	Removes a media pool callback.

4.3.14.1 IBMDSwitcherMediaPool::GetStills method

The **GetStills** method gets the **IBMDSwitcherStills** object interface.

Syntax

```
HRESULT GetStills (IBMDSwitcherStills* stills);
```

Parameters

Name	Direction	Description
stills	out	The stills object interface.

Return Values

Value	Description
E_POINTER	The stills parameter is invalid.
S_OK	Success.

4.3.14.2 IBMDSwitcherMediaPool::GetClip method

The `GetClip` method gets the `IBMDSwitcherClip` object interface.

Syntax

```
HRESULT GetClip (uint32_t clipIndex, IBMDSwitcherClip* clip);
```

Parameters

Name	Direction	Description
clipIndex	in	The clip index.
clip	out	The clip object interface.

Return Values

Value	Description
E_POINTER	The stills parameter is invalid.
E_INVALIDARG	The <code>clipIndex</code> parameter is invalid.
S_OK	Success.

4.3.14.3 IBMDSwitcherMediaPool::GetClipCount method

The `GetClipCount` method gets the number of clips.

Syntax

```
HRESULT GetClipCount (uint32_t* clipCount);
```

Parameters

Name	Direction	Description
clipCount	out	The number of clips.

Return Values

Value	Description
E_POINTER	The <code>clipCount</code> parameter is invalid.
S_OK	Success.

4.3.14.4 **IBMDSwitcherMediaPool::CreateFrame** method

The `CreateFrame` method creates an `IBMDSwitcherFrame` object.

Syntax

```
HRESULT CreateFrame (IBMDSwitcherPixelFormat pixelFormat, uint32_t width,
uint32_t height, IBMDSwitcherFrame* frame);
```

Parameters

Name	Direction	Description
pixelFormat	in	The pixel format. See <code>IBMDSwitcherPixelFormat</code> for a list of supported pixel formats.
width	in	The frame width in pixels.
height	in	The frame height in pixels.
frame	out	The newly created frame.

Return Values

Value	Description
<code>E_POINTER</code>	The frame parameter is invalid.
<code>E_INVALIDARG</code>	The <code>pixelFormat</code> , width or height parameter is invalid.
<code>E_OUTOFMEMORY</code>	Unable to allocate required memory.
<code>E_FAIL</code>	Failure.
<code>S_OK</code>	Success.

4.3.14.5 **IBMDSwitcherMediaPool::CreateAudio** method

The `CreateAudio` method creates an `IBMDSwitcherAudio` object.

Syntax

```
HRESULT CreateAudio (uint32_t sizeBytes, IBMDSwitcherAudio* audio);
```

Parameters

Name	Direction	Description
sizeBytes	in	The audio's buffer size in bytes.
audio	out	The newly created audio object.

Return Values

Value	Description
<code>E_POINTER</code>	The audio parameter is invalid.
<code>E_INVALIDARG</code>	The <code>sizeBytes</code> parameter is invalid.
<code>E_OUTOFMEMORY</code>	Unable to allocate required memory.
<code>E_FAIL</code>	Failure.
<code>S_OK</code>	Success.

4.3.14.6 **IBMDSwitcherMediaPool::GetFrameTotalForClips** method

The **GetFrameTotalForClips** method gets the total number of frames available to clips.

Syntax

```
HRESULT GetFrameTotalForClips (uint32_t* total);
```

Parameters

Name	Direction	Description
clipCount	out	The number of clips.

Return Values

Value	Description
E_POINTER	The total parameter is invalid.
S_OK	Success.

4.3.14.7 **IBMDSwitcherMediaPool::GetClipMaxFrameCounts** method

The **GetClipMaxFrameCounts** method gets the maximum frame count for all clips.

Syntax

```
HRESULT GetFrameTotalForClips  
(uint32_t clipCount, uint32_t* clipMaxFrameCounts);
```

Parameters

Name	Direction	Description
clipCount	in	Length of clipMaxFrameCounts array. This must match the switcher clip count.
clipMaxFrameCounts	out	A clipCount length array, where each element receives the maximum frame count for its respective clip index.

Return Values

Value	Description
E_POINTER	The clipMaxFrameCounts parameter is invalid.
E_INVALIDARG	The clipCount parameter is invalid.
S_OK	Success.

4.3.14.8 IBMDSwitcherMediaPool::Clear method

The **Clear** method invalidates all stills, clips and clip audio.

Syntax

```
HRESULT Clear ();
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

4.3.14.9 IBMDSwitcherMediaPool::SetClipMaxFrameCounts method

The **SetClipMaxFrameCounts** method sets the maximum frame count for all clips.

Syntax

```
HRESULT SetClipMaxFrameCounts (uint32_t clipCount, const uint32_t* clipMaxFrameCounts);
```

Parameters

Name	Direction	Description
clipCount	in	Length of clipMaxFrameCounts array. This must match the switcher clip count.
clipMaxFrameCounts	in	A clipCount length array, where each element sets the maximum frame count for its respective clip index.

Return Values

Value	Description
E_POINTER	The clipMaxFrameCounts parameter is invalid.
E_INVALIDARG	The clipCount parameter is invalid.
S_OK	Success.

4.3.14.10 **IBMDSwitcherMediaPool::DoesVideoModeChangeClearMediaPool** method

The **DoesVideoModeChangeClearMediaPool** method determines if changing to the specified video standard will clear the media pool.

Syntax

```
HRESULT DoesVideoModeChangeClearMediaPool(IBMDSwitcherVideoMode videoMode,  
Boolean* clear)
```

Parameters

Name	Direction	Description
videoMode	in	The video standard.
clear	out	Boolean value that is true if changing to the video standard will clear the media pool.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The videoMode is not a valid video standard.
E_POINTER	The required parameter is invalid.

4.3.14.11 **IBMDSwitcherMediaPool::AddCallback** method

The **AddCallback** method configures a callback to be called when an event occurs for an **IBMDSwitcherMediaPool** object. Pass an object implementing the **IBMDSwitcherMediaPoolCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT SetClipMaxFrameCounts  
(uint32_t clipCount, const uint32_t* clipMaxFrameCounts);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMediaPoolCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

4.3.14.12 **IBMDSwitcherMediaPool::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMediaPoolCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMediaPoolCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

Section 5 — Keyers

Any form of a keyer available in our switchers use these API components to perform keying.

5.1 Key Data Types

5.1.1 Key Type

BMDSwitcherKeyType enumerates the possible key types, used by **IBMDSwitcherKey** object interface.

- **bmdSwitcherKeyTypeLuma**
Luminance key.
- **bmdSwitcherKeyTypeChroma**
Chroma key.
- **bmdSwitcherKeyTypePattern**
Pattern key.
- **bmdSwitcherKeyTypeDVE**
DVE key.

5.1.2 Fly Key Frames

BMDSwitcherFlyKeyFrame is a bit set that enumerates possible key frames for a fly key, used by **IBMDSwitcherKeyFlyParameters** object interface.

- **bmdSwitcherFlyKeyFrameFull**
Full screen.
- **bmdSwitcherFlyKeyFrameInfinityCentreOfKey**
Infinity at centre of key.
- **bmdSwitcherFlyKeyFrameInfinityTopLeft**
Infinity at top left of screen.
- **bmdSwitcherFlyKeyFrameInfinityTop**
Infinity at top centre of screen.
- **bmdSwitcherFlyKeyFrameInfinityTopRight**
Infinity at top right of screen.
- **bmdSwitcherFlyKeyFrameInfinityLeft**
Infinity at mid left of screen.
- **bmdSwitcherFlyKeyFrameInfinityCentre**
Infinity at centre of screen.
- **bmdSwitcherFlyKeyFrameInfinityRight**
Infinity at mid right of screen.
- **bmdSwitcherFlyKeyFrameInfinityBottomLeft**
Infinity at bottom left of screen.
- **bmdSwitcherFlyKeyFrameInfinityBottom**
Infinity at bottom centre of screen.
- **bmdSwitcherFlyKeyFrameInfinityBottomRight**
Infinity at bottom right of screen.
- **bmdSwitcherFlyKeyFrameA**
User-defined key frame A.
- **bmdSwitcherFlyKeyFrameB**
User-defined key frame B.

5.1.3 Border Bevel Options

BMDSwitcherBorderBevelOption enumerates possible border bevel style options. This type is used by **IBMDSwitcherKeyDVEParameters** and **IBMDSwitcherInputSuperSource** object interfaces.

- **bmdSwitcherBorderBevelOptionNone**
No bevel.
- **bmdSwitcherBorderBevelOptionInOut**
Both inner and outer bevel.
- **bmdSwitcherBorderBevelOptionIn**
Inner bevel only.
- **bmdSwitcherBorderBevelOptionOut**
Outer bevel only.

5.1.4 Key Event Type

BMDSwitcherKeyEventType enumerates the possible event types for **IBMDSwitcherKeyCallback**.

- **bmdSwitcherKeyEventTypeTypeChanged**
The type changed.
- **bmdSwitcherKeyEventTypeInputCutChanged**
The cut input source changed.
- **bmdSwitcherKeyEventTypeInputFillChanged**
The fill input source changed.
- **bmdSwitcherKeyEventTypeOnAirChanged**
The on-air flag changed.
- **bmdSwitcherKeyEventTypeCanBeDVEKeyChanged**
The can-be-DVE flag changed.
- **bmdSwitcherKeyEventTypeMaskedChanged**
The masked flag changed.
- **bmdSwitcherKeyEventTypeMaskTopChanged**
The mask top value changed.
- **bmdSwitcherKeyEventTypeMaskBottomChanged**
The mask bottom value changed.
- **bmdSwitcherKeyEventTypeMaskLeftChanged**
The mask left value changed.
- **bmdSwitcherKeyEventTypeMaskRightChanged**
The mask right value changed.

5.1.5 Luminance Key Parameters Event Type

BMDSwitcherKeyLumaParametersEventType enumerates the possible event types for **IBMDSwitcherKeyLumaParametersCallback**.

- **bmdSwitcherKeyLumaParametersEventTypePreMultipliedChanged**
The pre-multiplied flag changed.
- **bmdSwitcherKeyLumaParametersEventTypeClipChanged**
The clip value changed.
- **bmdSwitcherKeyLumaParametersEventTypeGainChanged**
The gain value changed.
- **bmdSwitcherKeyLumaParametersEventTypeInverseChanged**
The inverse flag changed.

5.1.6 Chroma Key Parameters Event Type

BMDSwitcherKeyChromaParametersEventType enumerates the possible event types for **IBMDSwitcherKeyChromaParametersCallback**.

- **bmdSwitcherKeyChromaParametersEventTypeHueChanged**
The hue value changed.
- **bmdSwitcherKeyChromaParametersEventTypeGainChanged**
The gain value changed.
- **bmdSwitcherKeyChromaParametersEventTypeYSuppressChanged**
The y-suppress value changed.
- **bmdSwitcherKeyChromaParametersEventTypeLiftChanged**
The lift value changed.
- **bmdSwitcherKeyChromaParametersEventTypeNarrowChanged**
The narrow flag changed.

5.1.7 Pattern Key Parameters Event Type

BMDSwitcherKeyAdvancedChromaParametersEventType enumerates the possible event types for **IBMDSwitcherKeyAdvancedChromaParametersCallback**.

- **bmdSwitcherKeyAdvancedChromaParametersEventTypeForegroundLevelChanged**
The key adjustment foreground level value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeBackgroundLevelChanged**
The key adjustment background level value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeKeyEdgeChanged**
The key adjustment key edge value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeSpillSuppressChanged**
The chroma correction spill suppress value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeFlareSuppressChanged**
The chroma correction flare suppress value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeBrightnessChanged**
The color adjustment brightness value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeContrastChanged**
The color adjustment contrast value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeSaturationChanged**
The color adjustment saturation value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeRedChanged**
The color adjustment red value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeGreenChanged**
The color adjustment green value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeBlueChanged**
The color adjustment blue value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeSamplingModeEnabledChanged**
The sampling mode enabled flag changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypePreviewEnabledChanged**
The preview enabled flag changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeCursorXPositionChanged**
The cursor X position value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeCursorYPositionChanged**
The cursor Y position value changed.

- **bmdSwitcherKeyAdvancedChromaParametersEventTypeCursorSizeChanged**
The cursor size value changed.
- **bmdSwitcherKeyAdvancedChromaParametersEventTypeSampledColorChanged**
The sampled color value changed.

5.1.8 Pattern Key Parameters Event Type

BMDSwitcherKeyPatternParametersEventType enumerates the possible event types for **IBMDSwitcherKeyPatternParametersCallback**.

- **bmdSwitcherKeyPatternParametersEventTypePatternChanged**
The pattern style changed.
- **bmdSwitcherKeyPatternParametersEventTypeSizeChanged**
The size value changed.
- **bmdSwitcherKeyPatternParametersEventTypeSymmetryChanged**
The symmetry value changed.
- **bmdSwitcherKeyPatternParametersEventTypeSoftnessChanged**
The softness value changed.
- **bmdSwitcherKeyPatternParametersEventTypeHorizontalOffsetChanged**
The horizontal offset changed.
- **bmdSwitcherKeyPatternParametersEventTypeVerticalOffsetChanged**
The vertical offset changed.
- **bmdSwitcherKeyPatternParametersEventTypeInverseChanged**
The inverse flag changed.

5.1.9 DVE Key Parameters Event Type

BMDSwitcherKeyDVEParametersEventType enumerates the possible event types for **IBMDSwitcherKeyDVEParametersCallback**.

- **bmdSwitcherKeyDVEParametersEventTypeShadowChanged**
The shadow flag changed.
- **bmdSwitcherKeyDVEParametersEventTypeLightSourceDirectionChanged**
The light source direction value changed.
- **bmdSwitcherKeyDVEParametersEventTypeLightSourceAltitudeChanged**
The light source altitude value changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderEnabledChanged**
The border enabled flag changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderBevelChanged**
The border bevel option changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderWidthInChanged**
The border inner width value changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderWidthOutChanged**
The border outer width value changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderSoftnessInChanged**
The border inner softness value changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderSoftnessOutChanged**
The border outer softness value changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderBevelSoftnessChanged**
The border bevel softness value changed.

- **bmdSwitcherKeyDVEParametersEventTypeBorderBevelPositionChanged**
The border bevel position value changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderOpacityChanged**
The border opacity value changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderHueChanged**
The border hue value changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderSaturationChanged**
The border saturation value changed.
- **bmdSwitcherKeyDVEParametersEventTypeBorderLumaChanged**
The border luminance value changed.
- **bmdSwitcherKeyDVEParametersEventTypeMaskedChanged**
The masked flag changed.
- **bmdSwitcherKeyDVEParametersEventTypeMaskTopChanged**
The mask top value changed.
- **bmdSwitcherKeyDVEParametersEventTypeMaskBottomChanged**
The mask bottom value changed.
- **bmdSwitcherKeyDVEParametersEventTypeMaskLeftChanged**
The mask left value changed.
- **bmdSwitcherKeyDVEParametersEventTypeMaskRightChanged**
The mask right value changed.

5.1.10 Fly Key Parameters Event Type

BMDSwitcherKeyFlyParametersEventType enumerates the possible event types for **IBMDSwitcherKeyFlyParametersCallback**.

- **bmdSwitcherKeyFlyParametersEventTypeFlyChanged**
The fly flag changed.
- **bmdSwitcherKeyFlyParametersEventTypeCanFlyChanged**
The can-fly flag changed.
- **bmdSwitcherKeyFlyParametersEventTypeRateChanged**
The rate value changed.
- **bmdSwitcherKeyFlyParametersEventTypeSizeXChanged**
The size x value changed.
- **bmdSwitcherKeyFlyParametersEventTypeSizeYChanged**
The size y value changed.
- **bmdSwitcherKeyFlyParametersEventTypePositionXChanged**
The position x value changed.
- **bmdSwitcherKeyFlyParametersEventTypePositionYChanged**
The position y value changed.
- **bmdSwitcherKeyFlyParametersEventTypeRotationChanged**
The rotation value changed.
- **bmdSwitcherKeyFlyParametersEventTypeIsKeyFrameStoredChanged**
The is-key-frame-stored flag changed.
- **bmdSwitcherKeyFlyParametersEventTypeIsAtKeyFramesChanged**
The is-at-key-frames status changed.
- **bmdSwitcherKeyFlyParametersEventTypeIsRunningChanged**
The is-running status changed.

5.1.11 Downstream Key Event Type

BMDSwitcherDownstreamKeyEventType enumerates the possible event types for **IBMDSwitcherDownstreamKeyCallback**.

- **bmdSwitcherDownstreamKeyEventTypeInputCutChanged**
The cut input source changed.
- **bmdSwitcherDownstreamKeyEventTypeInputFillChanged**
The fill input source changed.
- **bmdSwitcherDownstreamKeyEventTypeTieChanged**
The tie flag changed.
- **bmdSwitcherDownstreamKeyEventTypeRateChanged**
The rate value changed.
- **bmdSwitcherDownstreamKeyEventTypeOnAirChanged**
The on-air flag changed.
- **bmdSwitcherDownstreamKeyEventTypesTransitioningChanged**
The is-transitioning flag changed.
- **bmdSwitcherDownstreamKeyEventTypesAutoTransitioningChanged**
The is-auto-transitioning flag changed.
- **bmdSwitcherDownstreamKeyEventTypesTransitionTowardsOnAirChanged**
The is-transitioning-towards-on-air flag changed.
- **bmdSwitcherDownstreamKeyEventTypeFramesRemainingChanged**
The frames remaining value changed.
- **bmdSwitcherDownstreamKeyEventTypePreMultipliedChanged**
The pre-multiplied flag changed.
- **bmdSwitcherDownstreamKeyEventTypeClipChanged**
The clip value changed.
- **bmdSwitcherDownstreamKeyEventTypeGainChanged**
The gain value changed.
- **bmdSwitcherDownstreamKeyEventTypeInverseChanged**
The inverse flag changed.
- **bmdSwitcherDownstreamKeyEventTypeMaskedChanged**
The masked flag changed.
- **bmdSwitcherDownstreamKeyEventTypeMaskTopChanged**
The mask top value changed.
- **bmdSwitcherDownstreamKeyEventTypeMaskBottomChanged**
The mask bottom value changed.
- **bmdSwitcherDownstreamKeyEventTypeMaskLeftChanged**
The mask left value changed.
- **bmdSwitcherDownstreamKeyEventTypeMaskRightChanged**
The mask right value changed.

5.2 Interface Reference

5.2.1 IBMDSwitcherKeylterator Interface

The **IBMDSwitcherKeylterator** is used to enumerate the available keys for each mix effect block.

A reference to an **IBMDSwitcherKeylterator** object interface may be obtained from an **IBMDSwitcherMixEffectBlock** object interface using the **Createrlterator** method. Pass **IID_IBMDSwitcherKeylterator** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMixEffectBlock	IID_IBMDSwitcherMixEffectBlock	IBMDSwitcherMixEffectBlock::Createrlterator can return an IBMDSwitcherKeylterator object interface.

Public Member Functions	
Method	Description
Next	Returns a pointer to the next IBMDSwitcherKey object interface.

5.2.1.1 IBMDSwitcherKeylterator::Next method

The **Next** method returns the next available **IBMDSwitcherKey** object interface.

Syntax

```
HRESULT Next (IBMDSwitcherKey* key);
```

Parameters

Name	Direction	Description
key	out	IBMDSwitcherKey object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No more IBMDSwitcherKey objects available.
E_POINTER	The key parameter is invalid.

5.2.2 IBMDSwitcherKey Interface

The **IBMDSwitcherKey** object interface is used for manipulating the basic settings of a key. Please note that the mask settings in this interface only apply to luminance, chroma and pattern key types; DVE type key uses its own mask settings available in the **IBMDSwitcherKeyDVEParameters** interface.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKeyIterator	IID_IBMDSwitcherKeyIterator	An IBMDSwitcherKey object will be returned after a successful call to IBMDSwitcherKeyIterator::Next method.

Public Member Functions	
Method	Description
DoesSupportAdvancedChroma	The DoesSupportAdvancedChroma method determines if advanced chroma key is supported by the switcher.
GetType	Get the current key type.
SetType	Set the key type.
GetInputCut	Get the current cut input source.
SetInputCut	Set the cut input source.
GetInputFill	Get the current fill input source.
SetInputFill	Set the fill input source.
GetFillInputAvailabilityMask	Get the availability mask for the fill of this input.
GetCutInputAvailabilityMask	Get the availability mask for the cut of this input.
GetOnAir	Get the on-air flag.
SetOnAir	Set the on-air flag.
GetCanBeDVEKey	Determine if this key can be set to DVE type.
GetMasked	Get the current masked flag.
SetMasked	Set the masked flag.
GetMaskTop	Get the current mask top value.
SetMaskTop	Set the mask top value.
GetMaskBottom	Get the current mask bottom value.
SetMaskBottom	Set the mask bottom value.
GetMaskLeft	Get the current mask left value.
SetMaskLeft	Set the mask left value.
GetMaskRight	Get the current mask right value.
SetMaskRight	Set the mask right value.
ResetMask	Reset mask to default values.
GetTransitionSelectionMask	Get the corresponding BMDSwitcherTransitionSelection bit mask for this key.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

5.2.2.1 IBMDSwitcherKey::DoesSupportAdvancedChroma method

The DoesSupportAdvancedChroma method determines if advanced chroma key is supported by the switcher.

Syntax

```
HRESULT DoesSupportAdvancedChroma (boolean* supportsAdvancedChroma)
```

Parameters

Name	Direction	Description
supportsAdvancedChroma	out	Boolean value describing whether the advanced chroma key is supported by the switcher.

5.2.2.2 IBMDSwitcherKey::GetType method

The GetType method returns the current key type.

Syntax

```
HRESULT GetType (BMDSwitcherKeyType* type);
```

Parameters

Name	Direction	Description
type	out	The current key type.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The type parameter is invalid.
E_UNEXPECTED	Unexpected error occurred.

5.2.2.3 IBMDSwitcherKey::SetType method

The SetType method sets the key to the specified type.

Syntax

```
HRESULT SetType (BMDSwitcherKeyType type);
```

Parameters

Name	Direction	Description
type	in	The desired key type.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The type parameter is invalid.

5.2.2.4 IBMDSwitcherKey::GetInputCut method

The `GetInputCut` method returns the selected cut input source.

Syntax

```
HRESULT GetInputCut (BMDSwitcherInputId* inputId);
```

Parameters

Name	Direction	Description
inputId	out	BMDSwitcherInputId of the selected cut input source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inputId parameter is invalid.

5.2.2.5 IBMDSwitcherKey::SetInputCut method

The `SetInputCut` method sets the cut input source.

Syntax

```
HRESULT SetInputCut (BMDSwitcherInputId inputId);
```

Parameters

Name	Direction	Description
inputId	in	The desired cut input source's BMDSwitcherInputId .

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The inputId parameter is invalid.

5.2.2.6 **IBMDSwitcherKey::GetInputFill** method

The `GetInputFill` method returns the selected fill input source.

Syntax

```
HRESULT GetInputFill (BMDSwitcherInputId* inputId);
```

Parameters

Name	Direction	Description
inputId	out	BMDSwitcherInputId of the selected fill input source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inputId parameter is invalid.

5.2.2.7 **IBMDSwitcherKey::SetInputFill** method

The `SetInputFill` method sets the fill input source.

Syntax

```
HRESULT SetInputFill (BMDSwitcherInputId inputId);
```

Parameters

Name	Direction	Description
inputId	in	The desired fill input source's BMDSwitcherInputId .

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The inputId parameter is invalid.

5.2.2.8 **IBMDSwitcherKey::GetFillInputAvailabilityMask** method

The **GetFillInputAvailabilityMask** method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for fill inputs available to this key. The input availability property of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a fill input for this key.

Syntax

```
HRESULT GetFillInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	BMDSwitcherInputAvailability bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

5.2.2.9 **IBMDSwitcherKey::GetCutInputAvailabilityMask** method

The **GetCutInputAvailabilityMask** method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for cut inputs available to this key. The input availability property of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a cut input for this key.

Syntax

```
HRESULT GetCutInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	BMDSwitcherInputAvailability bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

5.2.2.10 **IBMDSwitcherKey::GetOnAir** method

The **GetOnAir** method returns the on-air flag.

Syntax

```
HRESULT GetOnAir (boolean* onAir);
```

Parameters

Name	Direction	Description
onAir	out	Boolean on-air flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The onAir parameter is invalid.

5.2.2.11 **IBMDSwitcherKey::SetOnAir** method

The **SetOnAir** method sets the on-air flag.

Syntax

```
HRESULT SetOnAir (boolean onAir);
```

Parameters

Name	Direction	Description
onAir	in	The desired on-air flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.2.12 **IBMDSwitcherKey::CanBeDVEKey** method

The **CanBeDVEKey** method returns a status flag of whether this key can be set to the DVE type. The DVE hardware is a shared resource; if another component is currently using the resource, it may not be available for this key.

Syntax

```
HRESULT CanBeDVEKey (boolean* canDVE);
```

Parameters

Name	Direction	Description
canDVE	out	Boolean status of whether this key can be a DVE key.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canDVE parameter is invalid.

5.2.2.13 IBMDSwitcherKey::GetMasked method

The `GetMasked` method returns whether masking is enabled or not.

Syntax

```
HRESULT GetMasked (boolean* masked);
```

Parameters

Name	Direction	Description
masked	out	Boolean flag of whether masking is enabled.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The masked parameter is invalid.

5.2.2.14 IBMDSwitcherKey::SetMasked method

Use `SetMasked` method to enable or disable masking.

Syntax

```
HRESULT SetMasked (boolean masked);
```

Parameters

Name	Direction	Description
masked	in	The desired masked value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.2.15 IBMDSwitcherKey::GetMaskTop method

The `GetMaskTop` method returns the current mask top value.

Syntax

```
HRESULT GetMaskTop (double* maskTop);
```

Parameters

Name	Direction	Description
maskTop	out	The current mask top value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskTop parameter is invalid.

5.2.2.16 **IBMDSwitcherKey::SetMaskTop** method

The **SetMaskTop** method sets the mask top value.

Syntax

```
HRESULT SetMaskTop (double maskTop);
```

Parameters

Name	Direction	Description
maskTop	in	The desired mask top value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.2.17 **IBMDSwitcherKey::GetMaskBottom** method

The **GetMaskBottom** method returns the current mask bottom value.

Syntax

```
HRESULT GetMaskBottom (double* maskBottom);
```

Parameters

Name	Direction	Description
maskBottom	out	The current mask bottom value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskBottom parameter is invalid.

5.2.2.18 **IBMDSwitcherKey::SetMaskBottom** method

The **SetMaskBottom** method sets the mask bottom value.

Syntax

```
HRESULT SetMaskBottom (double maskBottom);
```

Parameters

Name	Direction	Description
maskBottom	in	The desired mask bottom value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.2.19 IBMDSwitcherKey::GetMaskLeft method

The `GetMaskLeft` method returns the current mask left value.

Syntax

```
HRESULT GetMaskLeft (double* maskLeft);
```

Parameters

Name	Direction	Description
maskLeft	out	The current mask left value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskLeft parameter is invalid.

5.2.2.20 IBMDSwitcherKey::SetMaskLeft method

The `SetMaskLeft` method sets the mask left value.

Syntax

```
HRESULT SetMaskLeft (double maskLeft);
```

Parameters

Name	Direction	Description
maskLeft	in	The desired mask left value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.2.21 IBMDSwitcherKey::GetMaskRight method

The `GetMaskRight` method returns the current mask right value.

Syntax

```
HRESULT GetMaskRight (double* maskRight);
```

Parameters

Name	Direction	Description
maskRight	out	The current mask right value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskRight parameter is invalid.

5.2.2.22 **IBMDSwitcherKey::SetMaskRight** method

The **SetMaskRight** method sets the mask right value.

Syntax

```
HRESULT SetMaskRight (double maskRight);
```

Parameters

Name	Direction	Description
maskRight	in	The desired mask right value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.2.23 **IBMDSwitcherKey::ResetMask** method

Use the **ResetMask** method to reset mask settings to default values.

Syntax

```
HRESULT ResetMask (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.2.24 **IBMDSwitcherKey::GetTransitionSelectionMask** method

The **GetTransitionSelectionMask** method returns the corresponding **BMDSwitcherTransitionSelection** bit mask for this key.

Syntax

```
HRESULT GetTransitionSelectionMask (BMDSwitcherTransitionSelection* selectionMask);
```

Parameters

Name	Direction	Description
selectionMask	out	BMDSwitcherTransitionSelection bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The selectionMask parameter is invalid.

5.2.2.25 **IBMDSwitcherKey::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKey** object. Pass an object implementing the **IBMDSwitcherKeyCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.2.26 **IBMDSwitcherKey::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.3 IBMDSwitcherKeyCallback Interface

The **IBMDSwitcherKeyCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKey** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKey	IID_IBMDSwitcherKey	An IBMDSwitcherKeyCallback object interface is installed with IBMDSwitcherKey::AddCallback and removed with IBMDSwitcherKey::RemoveCallback .

Public Member Functions

Method	Description
Notify	Called when an event occurs.

5.2.3.1 IBMDSwitcherKeyCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKey** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherKeyEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherKeyEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.4 IBMDSwitcherKeyLumaParameters Interface

The `IBMDSwitcherKeyLumaParameters` object interface is used for manipulating parameters specific to luminance type key.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherKey</code>	<code>IID_IBMDSwitcherKey</code>	An <code>IBMDSwitcherKeyLumaParameters</code> object interface can be obtained with <code>IBMDSwitcherKey::QueryInterface</code> .

Public Member Functions

Method	Description
<code>GetPreMultiplied</code>	Get the current pre-multiplied flag.
<code>SetPreMultiplied</code>	Set pre-multiplied flag.
<code>GetClip</code>	Get the current clip value.
<code>SetClip</code>	Set the clip value.
<code>GetGain</code>	Get the current gain value.
<code>SetGain</code>	Set gain value.
<code>GetInverse</code>	Get the current inverse flag.
<code>SetInverse</code>	Set the inverse flag.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

5.2.4.1 IBMDSwitcherKeyLumaParameters::GetPreMultiplied method

The `GetPreMultiplied` method returns the current pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

Name	Direction	Description
<code>preMultiplied</code>	out	The current pre-multiplied flag.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The <code>preMultiplied</code> parameter is invalid.

5.2.4.2 IBMDSwitcherKeyLumaParameters::SetPreMultiplied method

The `SetPreMultiplied` method sets the pre-multiplied flag.

NOTE That clip, gain and inverse controls are not used when pre-multiplied flag is set to true.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

Name	Direction	Description
preMultiplied	in	The desired pre-multiplied flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.4.3 IBMDSwitcherKeyLumaParameters::GetClip method

The `GetClip` method returns the current clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

Name	Direction	Description
clip	out	The current clip value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The clip parameter is invalid.

5.2.4.4 **IBMDSwitcherKeyLumaParameters::SetClip** method

The **SetClip** method sets the clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

Name	Direction	Description
clip	in	The desired clip value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.4.5 **IBMDSwitcherKeyLumaParameters::GetGain** method

The **GetGain** method returns the current gain value.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

5.2.4.6 **IBMDSwitcherKeyLumaParameters::SetGain** method

The **SetGain** method sets the gain value.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.4.7 IBMDSwitcherKeyLumaParameters::GetInverse method

The `GetInverse` method returns the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

Name	Direction	Description
inverse	out	The current inverse flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inverse parameter is invalid.

5.2.4.8 IBMDSwitcherKeyLumaParameters::SetInverse method

The `SetInverse` method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

Name	Direction	Description
inverse	in	The desired inverse flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.4.9 IBMDSwitcherKeyLumaParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyLumaParameters** object. Pass an object implementing the **IBMDSwitcherKeyLumaParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyLumaParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyLumaParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.4.10 IBMDSwitcherKeyLumaParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyLumaParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyLumaParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.5 IBMDSwitcherKeyLumaParametersCallback Interface

The **IBMDSwitcherKeyLumaParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyLumaParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKeyLumaParameters	IID_IBMDSwitcherKeyLumaParameters	An IBMDSwitcherKeyLumaParametersCallback object interface is installed with IBMDSwitcherKeyLumaParameters::AddCallback and removed with IBMDSwitcherKeyLumaParameters::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

5.2.5.1 IBMDSwitcherKeyLumaParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyLumaParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherKeyLumaParametersEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherKeyLumaParametersEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.6 IBMDSwitcherKeyChromaParameters Interface

The `IBMDSwitcherKeyChromaParameters` object interface is used for manipulating settings specific to the chroma type key.

If a switcher is capable of using advanced chroma key, then this interface will not be available. Only if `IBMDSwitcherKey::DoesSupportAdvancedChroma` returns false, does the switcher support this `IBMDSwitcherKeyChromaParameters` interface.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKey	IID_IBMDSwitcherKey	An <code>IBMDSwitcherKeyChromaParameters</code> object interface can be obtained with <code>IBMDSwitcherKey::QueryInterface</code> .

Public Member Functions	
Method	Description
GetHue	Get the current hue value.
SetHue	Set the hue value.
GetGain	Get the current gain value.
SetGain	Set the gain value.
GetYSuppress	Get the current y-suppress flag.
SetYSuppress	Set the y-suppress flag.
GetLift	Get the current lift value.
SetLift	Set the lift value.
GetNarrow	Get the current narrow flag.
SetNarrow	Set the narrow flag.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

5.2.6.1 IBMDSwitcherKeyChromaParameters::GetHue method

The `GetHue` method gets the current hue value.

Syntax

```
HRESULT GetHue (double* hue);
```

Parameters

Name	Direction	Description
hue	out	The current hue value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The hue parameter is invalid.

5.2.6.2 IBMDSwitcherKeyChromaParameters::SetHue method

The `SetHue` method sets the hue value.

Syntax

```
HRESULT SetHue (double hue);
```

Parameters

Name	Direction	Description
hue	in	The desired hue value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.6.3 IBMDSwitcherKeyChromaParameters::GetGain method

The `GetGain` method gets the current gain value.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

5.2.6.4 IBMDSwitcherKeyChromaParameters::SetGain method

The `SetGain` method sets the gain value.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.6.5 IBMDSwitcherKeyChromaParameters::GetYSuppress method

The `GetYSuppress` method gets the current y-suppress value.

Syntax

```
HRESULT GetYSuppress (double* ySuppress);
```

Parameters

Name	Direction	Description
ySuppress	out	The current y-suppress value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ySuppress parameter is invalid.

5.2.6.6 IBMDSwitcherKeyChromaParameters::SetYSuppress method

The `SetYSuppress` method sets the y-suppress value.

Syntax

```
HRESULT SetYSuppress (double ySuppress);
```

Parameters

Name	Direction	Description
ySuppress	in	The desired ySuppress value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.6.7 IBMDSwitcherKeyChromaParameters::GetLift method

The `GetLift` method gets the current lift value.

Syntax

```
HRESULT GetLift (double* lift);
```

Parameters

Name	Direction	Description
lift	out	The current lift value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The lift parameter is invalid.

5.2.6.8 **IBMDSwitcherKeyChromaParameters::SetLift** method

The **SetLift** method sets the lift value.

Syntax

```
HRESULT SetLift (double lift);
```

Parameters

Name	Direction	Description
lift	in	The desired lift value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.6.9 **IBMDSwitcherKeyChromaParameters::GetNarrow** method

The **GetNarrow** method gets the current narrow flag.

Syntax

```
HRESULT GetNarrow (boolean* narrow);
```

Parameters

Name	Direction	Description
narrow	out	The current narrow flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The narrow parameter is invalid.

5.2.6.10 **IBMDSwitcherKeyChromaParameters::SetNarrow** method

The **SetNarrow** method sets the narrow flag.

Syntax

```
HRESULT SetNarrow (boolean narrow);
```

Parameters

Name	Direction	Description
narrow	in	The desired narrow flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.6.11 **IBMDSwitcherKeyChromaParameters::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyChromaParameters** object. Pass an object implementing the **IBMDSwitcherKeyChromaParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyChromaParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyChromaParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.6.12 **IBMDSwitcherKeyChromaParameters::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyChromaParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyChromaParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.7 IBMDSwitcherKeyChromaParametersCallback Interface

The **IBMDSwitcherKeyChromaParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyChromaParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKeyChromaParameters	IID_IBMDSwitcherKeyChromaParameters	An IBMDSwitcherKeyChromaParametersCallback object interface is installed with IBMDSwitcherKeyChromaParameters::AddCallback and removed with IBMDSwitcherKeyChromaParameters::RemoveCallback

Public Member Functions

Method	Description
Notify	Called when an event occurs.

5.2.7.1 IBMDSwitcherKeyChromaParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyChromaParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherKeyChromaParametersEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherKeyChromaParametersEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8 IBMDSwitcherKeyAdvancedChromaParameters Interface

The **IBMDSwitcherKeyAdvancedChromaParameters** object interface is used for manipulating settings specific to the advanced chroma type key.

Advanced chroma key is an improved version of chroma key and is not available on all models of switchers. Use **IBMDSwitcherKey::DoesSupportAdvancedChroma** to determine if a switcher supports the **IBMDSwitcherKeyAdvancedChromaParameters** interface.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKey	IID_IBMDSwitcherKey	An IBMDSwitcherKeyAdvancedChromaParameters object interface can be obtained with IBMDSwitcherKey::QueryInterface .

Public Member Functions	
Method	Description
GetForegroundLevel	Get the current key adjustment foreground level value.
SetForegroundLevel	Set the key adjustment foreground level value.
GetBackgroundLevel	Get the current key adjustment background level value.
SetBackgroundLevel	Set the key adjustment background level value.
GetKeyEdge	Get the current key adjustment key edge value.
SetKeyEdge	Set the key adjustment key edge value.
GetSpillSuppress	Get the current chroma correction spill suppress value.
SetSpillSuppress	Set the chroma correction spill suppress value.
GetFlareSuppress	Get the current chroma correction flare suppress value.
SetFlareSuppress	Set the chroma correction flare suppress value.
GetBrightness	Get the current color adjustment brightness value.
SetBrightness	Set the color adjustment brightness value.
GetContrast	Get the current color adjustment contrast value.
SetContrast	Set the color adjustment contrast value.
GetSaturation	Get the current color adjustment saturation value.
SetSaturation	Set the color adjustment saturation value.
GetRed	Get the current color adjustment red value.
SetRed	Set the color adjustment red value.
GetGreen	Get the current color adjustment green value.
SetGreen	Set the color adjustment green value.
GetBlue	Get the current color adjustment blue value.
SetBlue	Set the color adjustment blue value.

Public Member Functions	
Method	Description
GetSamplingModeEnabled	Get the current sampling mode enabled flag.
SetSamplingModeEnabled	Set the sampling mode enabled flag.
GetPreviewEnabled	Get the current preview enabled flag.
SetPreviewEnabled	Set the preview enabled flag.
GetCursorXPosition	Get the current cursor x position.
SetCursorXPosition	Set the cursor x position.
GetCursorYPosition	Get the current cursor y position.
SetCursorYPosition	Set the cursor y position.
GetCursorSize	Get the current cursor size.
SetCursorSize	Set the cursor size.
GetSampledColor	Get the current sampled color.
SetSampledColor	Set the sampled color.
ResetKeyAdjustments	Reset key adjustment properties to default values.
ResetChromaCorrection	Reset chroma correction properties to default values.
ResetColorAdjustments	Reset color adjustment properties to default values.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

5.2.8.1 **IBMDSwitcherKeyAdvancedChromaParameters:: GetForegroundLevel** method

The **GetForegroundLevel** method gets the current key adjustment foreground level value.

Syntax

```
HRESULT GetForegroundLevel (double* level);
```

Parameters

Name	Direction	Description
level	out	The current key adjustment foreground level value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The level parameter is invalid.

5.2.8.2 **IBMDSwitcherKeyAdvancedChromaParameters::SetForegroundLevel** method

The **SetForegroundLevel** method sets the key adjustment foreground level value.

Syntax

```
HRESULT SetForegroundLevel (double level);
```

Parameters

Name	Direction	Description
level	in	The desired key adjustment foreground level value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.3 **IBMDSwitcherKeyAdvancedChromaParameters::GetBackgroundLevel** method

The **GetBackgroundLevel** method gets the current key adjustment background level value.

Syntax

```
HRESULT GetBackgroundLevel (double* level);
```

Parameters

Name	Direction	Description
level	out	The current key adjustment background level value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The level parameter is invalid.

5.2.8.4 **IBMDSwitcherKeyAdvancedChromaParameters::SetBackgroundLevel** method

The **SetBackgroundLevel** method sets the key adjustment background level value.

Syntax

```
HRESULT SetBackgroundLevel (double level);
```

Parameters

Name	Direction	Description
level	in	The desired key adjustment background level value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.5 **IBMDSwitcherKeyAdvancedChromaParameters::GetKeyEdge** method

The **GetKeyEdge** method gets the current key adjustment key edge value.

Syntax

```
HRESULT GetKeyEdge (double* keyEdge);
```

Parameters

Name	Direction	Description
keyEdge	out	The current key adjustment key edge value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The keyEdge parameter is invalid.

5.2.8.6 **IBMDSwitcherKeyAdvancedChromaParameters::SetKeyEdge** method

The **SetKeyEdge** method sets the key adjustment key edge value.

Syntax

```
HRESULT SetKeyEdge (double keyEdge);
```

Parameters

Name	Direction	Description
keyEdge	in	The desired key adjustment key edge value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.7 **IBMDSwitcherKeyAdvancedChromaParameters::GetSpillSuppress** method

The **GetSpillSuppress** method gets the current chroma correction spill suppress value.

Syntax

```
HRESULT GetSpillSuppress (double* spillSuppress);
```

Parameters

Name	Direction	Description
spillSuppress	out	The current chroma correction spill suppress value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The spillSuppress parameter is invalid.

5.2.8.8 **IBMDSwitcherKeyAdvancedChromaParameters::SetSpillSuppress** method

The **SetSpillSuppress** method sets the chroma correction spill suppress value.

Syntax

```
HRESULT SetSpillSuppress (double spillSuppress);
```

Parameters

Name	Direction	Description
spillSuppress	in	The desired chroma correction spill suppress value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.9 **IBMDSwitcherKeyAdvancedChromaParameters::GetFlareSuppress** method

The **GetFlareSuppress** method gets the current chroma correction flare suppress value.

Syntax

```
HRESULT GetFlareSuppress (double* flareSuppress);
```

Parameters

Name	Direction	Description
flareSuppress	out	The current chroma correction flare suppress value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The flareSuppress parameter is invalid.

5.2.8.10 **IBMDSwitcherKeyAdvancedChromaParameters::SetFlareSuppress** method

The **SetFlareSuppress** method sets the chroma correction flare suppress value.

Syntax

```
HRESULT SetFlareSuppress (double flareSuppress);
```

Parameters

Name	Direction	Description
flareSuppress	in	The desired chroma correction flare suppress value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.11 **IBMDSwitcherKeyAdvancedChromaParameters::GetBrightness** method

The **GetBrightness** method gets the current color adjustment brightness value.

Syntax

```
HRESULT GetBrightness (double* brightness);
```

Parameters

Name	Direction	Description
brightness	out	The current color adjustment brightness value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The brightness parameter is invalid.

5.2.8.12 **IBMDSwitcherKeyAdvancedChromaParameters::SetBrightness** method

The **SetBrightness** method sets the color adjustment brightness value.

Syntax

```
HRESULT SetBrightness (double brightness);
```

Parameters

Name	Direction	Description
brightness	in	The desired color adjustment brightness value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.13 **IBMDSwitcherKeyAdvancedChromaParameters::GetContrast** method

The **GetContrast** method gets the current color adjustment contrast value.

Syntax

```
HRESULT GetContrast (double* contrast);
```

Parameters

Name	Direction	Description
contrast	out	The current color adjustment contrast value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The contrast parameter is invalid.

5.2.8.14 **IBMDSwitcherKeyAdvancedChromaParameters::SetContrast** method

The **SetContrast** method sets the color adjustment contrast value.

Syntax

```
HRESULT SetContrast (double contrast);
```

Parameters

Name	Direction	Description
contrast	in	The desired color adjustment contrast value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.15 **IBMDSwitcherKeyAdvancedChromaParameters::GetSaturation** method

The **GetSaturation** method gets the current color adjustment saturation value.

Syntax

```
HRESULT GetSaturation (double* saturation);
```

Parameters

Name	Direction	Description
saturation	out	The current color adjustment saturation value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The saturation parameter is invalid.

5.2.8.16 **IBMDSwitcherKeyAdvancedChromaParameters::SetSaturation** method

The **SetSaturation** method sets the color adjustment saturation value.

Syntax

```
HRESULT SetSaturation (double saturation);
```

Parameters

Name	Direction	Description
saturation	in	The desired color adjustment saturation value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.17 **IBMDSwitcherKeyAdvancedChromaParameters::GetRed** method

The **GetRed** method gets the current color adjustment red value.

Syntax

```
HRESULT GetRed (double* red);
```

Parameters

Name	Direction	Description
red	out	The current color adjustment red value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The red parameter is invalid.

5.2.8.18 **IBMDSwitcherKeyAdvancedChromaParameters::SetRed** method

The **SetRed** method sets the color adjustment red value.

Syntax

```
HRESULT SetRed (double red);
```

Parameters

Name	Direction	Description
red	in	The desired color adjustment red value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.19 **IBMDSwitcherKeyAdvancedChromaParameters::GetGreen** method

The **GetGreen** method gets the current color adjustment green value.

Syntax

```
HRESULT GetGreen (double* green);
```

Parameters

Name	Direction	Description
green	out	The current color adjustment green value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The green parameter is invalid.

5.2.8.20 **IBMDSwitcherKeyAdvancedChromaParameters::SetGreen** method

The **SetGreen** method sets the color adjustment green value.

Syntax

```
HRESULT SetGreen (double green);
```

Parameters

Name	Direction	Description
green	in	The desired color adjustment green value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.21 **IBMDSwitcherKeyAdvancedChromaParameters::GetBlue** method

The **GetBlue** method gets the current color adjustment blue value.

Syntax

```
HRESULT GetBlue (double* blue);
```

Parameters

Name	Direction	Description
blue	out	The current color adjustment blue value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The blue parameter is invalid.

5.2.8.22 **IBMDSwitcherKeyAdvancedChromaParameters::SetBlue** method

The **SetBlue** method sets the color adjustment blue value.

Syntax

```
HRESULT SetBlue (double blue);
```

Parameters

Name	Direction	Description
blue	in	The desired color adjustment blue value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.23 **IBMDSwitcherKeyAdvancedChromaParameters::GetSamplingModeEnabled** method

The `GetSamplingModeEnabled` method gets the current sampling mode enabled flag.

Syntax

```
HRESULT GetSamplingModeEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
enabled	out	The current sampling mode enabled flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.

5.2.8.24 **IBMDSwitcherKeyAdvancedChromaParameters::SetSamplingModeEnabled** method

The `SetSamplingModeEnabled` method sets the sampling mode enabled flag.

Syntax

```
HRESULT SetSamplingModeEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	The desired sampling mode enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.25 **IBMDSwitcherKeyAdvancedChromaParameters::GetPreviewEnabled** method

The `GetPreviewEnabled` method gets the current preview enabled flag.

Syntax

```
HRESULT GetPreviewEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
enabled	out	The enabled parameter is invalid.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.

5.2.8.26 **IBMDSwitcherKeyAdvancedChromaParameters::SetPreviewEnabled** method

The `SetPreviewEnabled` method sets the preview enabled flag.

Syntax

```
HRESULT SetPreviewEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	The desired preview enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.27 **IBMDSwitcherKeyAdvancedChromaParameters::GetCursorXPosition** method

The `GetCursorXPosition` method gets the current cursor x position value.

Syntax

```
HRESULT GetCursorXPosition (double* position);
```

Parameters

Name	Direction	Description
position	out	The current cursor x position value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The position parameter is invalid.

5.2.8.28 **IBMDSwitcherKeyAdvancedChromaParameters::SetCursorXPosition** method

The `SetCursorXPosition` method sets the cursor x position value.

Syntax

```
HRESULT SetCursorXPosition (double position);
```

Parameters

Name	Direction	Description
position	in	The desired cursor x position value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.29 **IBMDSwitcherKeyAdvancedChromaParameters::GetCursorYPosition** method

The `GetCursorYPosition` method gets the current cursor y position value.

Syntax

```
HRESULT GetCursorYPosition (double* position);
```

Parameters

Name	Direction	Description
position	out	The current cursor y position value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The position parameter is invalid.

5.2.8.30 **IBMDSwitcherKeyAdvancedChromaParameters::SetCursorYPosition** method

The `SetCursorYPosition` method sets the cursor y position value.

Syntax

```
HRESULT SetCursorYPosition (double position);
```

Parameters

Name	Direction	Description
position	in	The desired cursor y position value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.31 **IBMDSwitcherKeyAdvancedChromaParameters::GetCursorSize** method

The `GetCursorSize` method gets the current cursor size value.

Syntax

```
HRESULT GetCursorSize (double* size);
```

Parameters

Name	Direction	Description
size	out	The current cursor size value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The size parameter is invalid.

5.2.8.32 **IBMDSwitcherKeyAdvancedChromaParameters::SetCursorSize** method

The `SetCursorSize` method sets the cursor size value.

Syntax

```
HRESULT SetCursorSize (double size);
```

Parameters

Name	Direction	Description
size	in	The desired cursor size value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.33 **IBMDSwitcherKeyAdvancedChromaParameters::GetSampledColor** method

The `GetSampledColor` method gets the current sampled color value. The sampled color is in YCbCr format.

Syntax

```
HRESULT GetCursorSize (double* y, double* cb, double* cr);
```

Parameters

Name	Direction	Description
y	out	The current sampled color y value.
cb	out	The current sampled color cb value.
cr	out	The current sampled color cr value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The y, cb, or cr parameter is invalid.

5.2.8.34 **IBMDSwitcherKeyAdvancedChromaParameters::SetSampledColor** method

The `SetSampledColor` method sets the sampled color value. The sampled color is in YCbCr format.

Syntax

```
HRESULT SetSampledColor (double y, double cb, double, cr);
```

Parameters

Name	Direction	Description
y	in	The desired sampled color y value.
cb	in	The desired sampled color cb value.
cr	in	The desired sampled color cr value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.35 **IBMDSwitcherKeyAdvancedChromaParameters::ResetKeyAdjustments** method

The **ResetKeyAdjustments** method resets the key adjustment properties to default values. This includes foreground level, background level, and key edge values.

Syntax

```
HRESULT ResetKeyAdjustments (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.36 **IBMDSwitcherKeyAdvancedChromaParameters::ResetChromaCorrection** method

The **ResetChromaCorrection** method resets the chroma correction properties to default values. This includes spill suppress, and flare suppress values.

Syntax

```
HRESULT ResetChromaCorrection (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.37 **IBMDSwitcherKeyAdvancedChromaParameters::ResetColorAdjustments** method

The **ResetColorAdjustments** method resets the color adjustment properties to default values. This includes brightness, contrast, saturation, red, green, and blue values.

Syntax

```
HRESULT ResetColorAdjustments (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.8.38 **IBMDSwitcherKeyAdvancedChromaParameters::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyAdvancedChromaParameters** object. Pass an object implementing the **IBMDSwitcherKeyAdvancedChromaParametersCallback** interface to receive callbacks.

Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyAdvancedChromaParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyAdvancedChromaParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.8.39 **IBMDSwitcherKeyAdvancedChromaParameters::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyAdvancedChromaParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyAdvancedChromaParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.9 IBMDSwitcherKeyAdvancedChromaParametersCallback Interface

The **IBMDSwitcherKeyAdvancedChromaParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyAdvancedChromaParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKeyAdvancedChromaParameters	IID_IBMDSwitcherKeyAdvancedChromaParameters	An IBMDSwitcherKeyAdvancedChromaParametersCallback object interface is installed with IBMDSwitcherKeyAdvancedChromaParameters::AddCallback and removed with IBMDSwitcherKeyAdvancedChromaParameters::RemoveCallback .

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

5.2.9.1 IBMDSwitcherKeyAdvancedChromaParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyAdvancedChromaParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherKeyAdvancedChromaParametersEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherKeyAdvancedChromaParametersEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.10 IBMDSwitcherKeyPatternParameters Interface

The `IBMDSwitcherKeyPatternParameters` object interface is used for manipulating settings specific to the pattern type key.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKey	IID_IBMDSwitcherKey	An <code>IBMDSwitcherKeyPatternParameters</code> object interface can be obtained with <code>IBMDSwitcherKey::QueryInterface</code> .

Public Member Functions	
Method	Description
GetPattern	Get the current pattern style.
SetPattern	Set the pattern style.
GetSize	Get the current size value.
SetSize	Set the size value.
GetSymmetry	Get the current symmetry value.
SetSymmetry	Set the symmetry value.
GetSoftness	Get the current softness value.
SetSoftness	Set the softness value.
GetHorizontalOffset	Get the current horizontal offset.
SetHorizontalOffset	Set the horizontal offset.
GetVerticalOffset	Get the current vertical offset.
SetVerticalOffset	Set the vertical offset.
GetInverse	Get the current inverse flag.
SetInverse	Set the inverse flag.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

5.2.10.1 IBMDSwitcherKeyPatternParameters::GetPattern method

The `GetPattern` method gets the current pattern style.

Syntax

```
HRESULT GetPattern (BMDSwitcherPatternStyle* pattern);
```

Parameters

Name	Direction	Description
pattern	out	The current pattern style of <code>BMDSwitcherPatternStyle</code> .

Return Values

Value	Description
S_OK	Success.
E_POINTER	The pattern parameter is invalid.

5.2.10.2 IBMDSwitcherKeyPatternParameters::SetPattern method

The `SetPattern` method sets the pattern style.

Syntax

```
HRESULT SetPattern (BMDSwitcherPatternStyle pattern);
```

Parameters

Name	Direction	Description
pattern	in	The desired <code>BMDSwitcherPatternStyle</code> pattern style.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The pattern parameter is invalid.
E_FAIL	Failure.

5.2.10.3 IBMDSwitcherKeyPatternParameters::GetSize method

The `GetSize` method gets the current size value.

Syntax

```
HRESULT GetSize (double* size);
```

Parameters

Name	Direction	Description
size	out	The current size value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The size parameter is invalid.

5.2.10.4 **IBMDSwitcherKeyPatternParameters::SetSize** method

The **SetSize** method sets the size value.

Syntax

```
HRESULT SetSize (double size);
```

Parameters

Name	Direction	Description
size	in	The desired size value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.10.5 **IBMDSwitcherKeyPatternParameters::GetSymmetry** method

The **GetSymmetry** method gets the current symmetry value.

Syntax

```
HRESULT GetSymmetry (double* symmetry);
```

Parameters

Name	Direction	Description
symmetry	out	The current symmetry value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The symmetry parameter is invalid.

5.2.10.6 **IBMDSwitcherKeyPatternParameters::SetSymmetry** method

The **SetSymmetry** method sets the symmetry value.

Syntax

```
HRESULT SetSymmetry (double symmetry);
```

Parameters

Name	Direction	Description
symmetry	in	The desired symmetry value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.10.7 IBMDSwitcherKeyPatternParameters::GetSoftness method

The `GetSoftness` method gets the current softness value.

Syntax

```
HRESULT GetSoftness (double* softness);
```

Parameters

Name	Direction	Description
softness	out	The current softness value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The softness parameter is invalid.

5.2.10.8 IBMDSwitcherKeyPatternParameters::SetSoftness method

The `SetSoftness` method sets the softness value.

Syntax

```
HRESULT SetSoftness (double softness);
```

Parameters

Name	Direction	Description
softness	in	The desired softness value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.10.9 IBMDSwitcherKeyPatternParameters::GetHorizontalOffset method

The `GetHorizontalOffset` method gets the current horizontal offset value.

Syntax

```
HRESULT GetHorizontalOffset (double* hOffset);
```

Parameters

Name	Direction	Description
hOffset	out	The current horizontal offset value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The hOffset parameter is invalid.

5.2.10.10 **IBMDSwitcherKeyPatternParameters::SetHorizontalOffset** method

The **SetHorizontalOffset** method sets the horizontal offset value.

Syntax

```
HRESULT SetHorizontalOffset (double hOffset);
```

Parameters

Name	Direction	Description
hOffset	in	The desired horizontal offset value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.10.11 **IBMDSwitcherKeyPatternParameters::GetVerticalOffset** method

The **GetVerticalOffset** method gets the current vertical offset value.

Syntax

```
HRESULT GetVerticalOffset (double* vOffset);
```

Parameters

Name	Direction	Description
vOffset	out	The current vertical offset value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The vOffset parameter is invalid.

5.2.10.12 **IBMDSwitcherKeyPatternParameters::SetVerticalOffset** method

The **SetVerticalOffset** method sets the vertical offset value.

Syntax

```
HRESULT SetVerticalOffset (double vOffset);
```

Parameters

Name	Direction	Description
vOffset	in	The desired vertical offset value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.10.13 IBMDSwitcherKeyPatternParameters::GetInverse method

The `GetInverse` method gets the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

Name	Direction	Description
inverse	out	The current inverse flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inverse parameter is invalid.

5.2.10.14 IBMDSwitcherKeyPatternParameters::SetInverse method

The `SetInverse` method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

Name	Direction	Description
inverse	in	The desired inverse flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.10.15 IBMDSwitcherKeyPatternParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyPatternParameters** object. Pass an object implementing the **IBMDSwitcherKeyPatternParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyPatternParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyPatternParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.10.16 IBMDSwitcherKeyPatternParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyPatternParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyPatternParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.11 IBMDSwitcherKeyPatternParametersCallback Interface

The **IBMDSwitcherKeyPatternParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyPatternParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKeyPatternParameters	IID_IBMDSwitcherKeyPatternParameters	An IBMDSwitcherKeyPatternParametersCallback object interface is installed with IBMDSwitcherKeyPatternParameters::AddCallback and removed with IBMDSwitcherKeyPatternParameters::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

5.2.11.1 IBMDSwitcherKeyPatternParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyPatternParameters** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherKeyPatternParametersEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherKeyPatternParametersEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12 IBMDSwitcherKeyDVEParameters Interface

The **IBMDSwitcherKeyDVEParameters** object interface is used for manipulating settings specific to the DVE-type key. Note that properties that affect a fly key also affects a DVE key; they are access through the **IBMDSwitcherKeyFlyParameters** object interface. Also note that the mask properties in this interface only affect keys with their type set to DVE.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKey	IID_IBMDSwitcherKey	An IBMDSwitcherKeyDVEParameters object interface can be obtained with IBMDSwitcherKey::QueryInterface .

Public Member Functions	
Method	Description
GetShadow	Get the current shadow flag.
SetShadow	Set the shadow flag.
GetLightSourceDirection	Get the current light source direction value.
SetLightSourceDirection	Set the light source direction value.
GetLightSourceAltitude	Get the current light source altitude value.
SetLightSourceAltitude	Set the light source altitude value.
GetBorderEnabled	Get the current border enabled flag.
SetBorderEnabled	Set the border enabled flag.
GetBorderBevel	Get the current border bevel option.
SetBorderBevel	Set the border bevel option.
GetBorderWidthIn	Get the current border inner width value.
SetBorderWidthIn	Set the border inner width value.
GetBorderWidthOut	Get the current border outer width value.
SetBorderWidthOut	Set the border outer width value.
GetBorderSoftnessIn	Get the current border inner softness value.
SetBorderSoftnessIn	Set the border inner softness value.
GetBorderSoftnessOut	Get the current border outer softness value.
SetBorderSoftnessOut	Set the border outer softness value.
GetBorderBevelSoftness	Get the current border bevel softness value.
SetBorderBevelSoftness	Set the border bevel softness value.
GetBorderBevelPosition	Get the current border bevel position value.
SetBorderBevelPosition	Set the border bevel position value.
GetBorderOpacity	Get the current border opacity value.
SetBorderOpacity	Set the border opacity value.
GetBorderHue	Get the current border hue value.

Public Member Functions	
Method	Description
SetBorderHue	Set the border hue value.
GetBorderSaturation	Get the current border saturation value.
SetBorderSaturation	Set the border saturation value.
GetBorderLuma	Get the current border luminance value.
SetBorderLuma	Set the border luminance value.
GetMasked	Get the current masked flag.
SetMasked	Set the masked flag.
GetMaskTop	Get the current mask top value.
SetMaskTop	Set the mask top value.
GetMaskBottom	Get the current mask bottom value.
SetMaskBottom	Set the mask bottom value.
GetMaskLeft	Get the current mask left value.
SetMaskLeft	Set the mask left value.
GetMaskRight	Get the current mask right value.
SetMaskRight	Set the mask right value.
ResetMask	Reset mask properties to default values.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

5.2.12.1 IBMDSwitcherKeyDVEParameters::GetShadow method

The `GetShadow` method gets the current shadow flag.

Syntax

```
HRESULT GetShadow (boolean* shadow);
```

Parameters

Name	Direction	Description
shadow	out	The current shadow flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The shadow parameter is invalid.

5.2.12.2 **IBMDSwitcherKeyDVEParameters::SetShadow** method

The `SetShadow` method sets the shadow flag.

Syntax

```
HRESULT SetShadow (boolean shadow);
```

Parameters

Name	Direction	Description
shadow	in	The desired shadow flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.3 **IBMDSwitcherKeyDVEParameters::GetLightSourceDirection** method

The `GetLightSourceDirection` method gets the current light source direction value.

Syntax

```
HRESULT GetLightSourceDirection (double* degrees);
```

Parameters

Name	Direction	Description
degrees	out	The current light source direction in degrees.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The degrees parameter is invalid.

5.2.12.4 **IBMDSwitcherKeyDVEParameters::SetLightSourceDirection** method

The `SetLightSourceDirection` method sets the light source direction value.

Syntax

```
HRESULT SetLightSourceDirection (double degrees);
```

Parameters

Name	Direction	Description
degrees	in	The desired light source direction value in degrees.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.5 **IBMDSwitcherKeyDVEParameters::GetLightSourceAltitude** method

The `GetLightSourceAltitude` method gets the current light source altitude value.

Syntax

```
HRESULT GetLightSourceAltitude (double* altitude);
```

Parameters

Name	Direction	Description
altitude	out	The current light source altitude value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The altitude parameter is invalid.

5.2.12.6 **IBMDSwitcherKeyDVEParameters::SetLightSourceAltitude** method

The `SetLightSourceAltitude` method sets the light source altitude value.

Syntax

```
HRESULT SetLightSourceAltitude (double altitude);
```

Parameters

Name	Direction	Description
altitude	in	The desired light source altitude value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.7 **IBMDSwitcherKeyDVEParameters::GetBorderEnabled** method

The `GetBorderEnabled` method gets the current border enabled flag.

Syntax

```
HRESULT GetBorderEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
enabled	out	The current border enabled flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.

5.2.12.8 **IBMDSwitcherKeyDVEParameters::SetBorderEnabled** method

The **SetBorderEnabled** method sets the border enabled flag.

Syntax

```
HRESULT SetBorderEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	The desired border enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.9 **IBMDSwitcherKeyDVEParameters::GetBorderBevel** method

The **GetBorderBevel** method gets the current border bevel option.

Syntax

```
HRESULT GetBorderBevel (BMDSwitcherBorderBevelOption* bevelOption);
```

Parameters

Name	Direction	Description
bevelOption	out	The current bevel option of BMDSwitcherBorderBevelOption .

Return Values

Value	Description
S_OK	Success.
E_POINTER	The bevelOption parameter is invalid.
E_UNEXPECTED	Unexpected error occurred.

5.2.12.10 **IBMDSwitcherKeyDVEParameters::SetBorderBevel** method

The **SetBorderBevel** method sets the border bevel option.

Syntax

```
HRESULT SetBorderBevel (IBMDSwitcherBorderBevelOption bevelOption);
```

Parameters

Name	Direction	Description
bevelOption	in	The desired bevel option of IBMDSwitcherBorderBevelOption .

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The bevelOption parameter is invalid.
E_FAIL	Failure.

5.2.12.11 **IBMDSwitcherKeyDVEParameters::GetBorderWidthIn** method

The **GetBorderWidthIn** method gets the current border inner width value.

Syntax

```
HRESULT GetBorderWidthIn (double* widthIn);
```

Parameters

Name	Direction	Description
widthIn	out	The current border inner width value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The widthIn parameter is invalid.

5.2.12.12 **IBMDSwitcherKeyDVEParameters::SetBorderWidthIn** method

The `SetBorderWidthIn` method sets the border inner width value.

Syntax

```
HRESULT SetBorderWidthIn (double widthIn);
```

Parameters

Name	Direction	Description
widthIn	in	The desired border inner width value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.13 **IBMDSwitcherKeyDVEParameters::GetBorderWidthOut** method

The `GetBorderWidthOut` method gets the current border outer width value.

Syntax

```
HRESULT GetBorderWidthOut (double* widthOut);
```

Parameters

Name	Direction	Description
widthIn	out	The current border outer width value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The widthOut parameter is invalid.

5.2.12.14 **IBMDSwitcherKeyDVEParameters::SetBorderWidthOut** method

The `SetBorderWidthOut` method sets the border outer width value.

Syntax

```
HRESULT SetBorderWidthOut (double widthOut);
```

Parameters

Name	Direction	Description
widthIn	in	The desired border outer width value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.15 **IBMDSwitcherKeyDVEParameters::GetBorderSoftnessIn** method

The **GetBorderSoftnessIn** method gets the current border inner softness value.

Syntax

```
HRESULT GetBorderSoftnessIn (double* softIn);
```

Parameters

Name	Direction	Description
softIn	out	The current border inner softness value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.16 **IBMDSwitcherKeyDVEParameters::SetBorderSoftnessIn** method

The **SetBorderSoftnessIn** method sets the border inner softness value.

Syntax

```
HRESULT SetBorderSoftnessIn (double softIn);
```

Parameters

Name	Direction	Description
softIn	in	The desired border inner softness value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.17 **IBMDSwitcherKeyDVEParameters::GetBorderSoftnessOut** method

The **GetBorderSoftnessOut** method gets the current border outer softness value.

Syntax

```
HRESULT GetBorderSoftnessOut (double* softOut);
```

Parameters

Name	Direction	Description
softOut	out	The current border outer softness value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The softOut parameter is invalid.

5.2.12.18 **IBMDSwitcherKeyDVEParameters::SetBorderSoftnessOut** method

The `SetBorderSoftnessOut` method sets the border outer softness value.

Syntax

```
HRESULT SetBorderSoftnessOut (double softOut);
```

Parameters

Name	Direction	Description
softOut	in	The desired border outer softness value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.19 **IBMDSwitcherKeyDVEParameters::GetBorderBevelSoftness** method

The `GetBorderBevelSoftness` method gets the current border bevel softness value.

Syntax

```
HRESULT GetBorderBevelSoftness (double* bevelSoft);
```

Parameters

Name	Direction	Description
bevelSoft	out	The current border bevel softness value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The bevelSoft parameter is invalid.

5.2.12.20 **IBMDSwitcherKeyDVEParameters::SetBorderBevelSoftness** method

The `SetBorderBevelSoftness` method sets the border bevel softness value.

Syntax

```
HRESULT SetBorderBevelSoftness (double bevelSoft);
```

Parameters

Name	Direction	Description
bevelSoft	in	The desired border bevel softness value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.21 IBMDSwitcherKeyDVEParameters::GetBorderBevelPosition method

The `GetBorderBevelPosition` method gets the current border bevel position value.

Syntax

```
HRESULT GetBorderBevelPosition (double* bevelPosition);
```

Parameters

Name	Direction	Description
bevelPosition	out	The current border bevel position value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The bevelPosition parameter is invalid.

5.2.12.22 IBMDSwitcherKeyDVEParameters::SetBorderBevelPosition method

The `SetBorderBevelPosition` method sets the border bevel position value.

Syntax

```
HRESULT SetBorderBevelPosition (double bevelPosition);
```

Parameters

Name	Direction	Description
bevelPosition	in	The desired border bevel position value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.23 IBMDSwitcherKeyDVEParameters::GetBorderOpacity method

The `GetBorderOpacity` method gets the current border opacity value.

Syntax

```
HRESULT GetBorderOpacity (double* opacity);
```

Parameters

Name	Direction	Description
opacity	out	The current border opacity value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The opacity parameter is invalid.

5.2.12.24 **IBMDSwitcherKeyDVEParameters::SetBorderOpacity** method

The **SetBorderOpacity** method sets the border opacity value.

Syntax

```
HRESULT SetBorderOpacity (double opacity);
```

Parameters

Name	Direction	Description
opacity	in	The desired border opacity value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.25 **IBMDSwitcherKeyDVEParameters::GetBorderHue** method

The **GetBorderHue** method gets the current border hue value.

Syntax

```
HRESULT GetBorderHue (double* hue);
```

Parameters

Name	Direction	Description
hue	out	The current border hue value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The hue parameter is invalid.

5.2.12.26 **IBMDSwitcherKeyDVEParameters::SetBorderHue** method

The **SetBorderHue** method sets the border hue value.

Syntax

```
HRESULT SetBorderHue (double hue);
```

Parameters

Name	Direction	Description
hue	in	The desired border hue value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.27 **IBMDSwitcherKeyDVEParameters::GetBorderSaturation** method

The **GetBorderSaturation** method gets the current border saturation value.

Syntax

```
HRESULT GetBorderSaturation (double* sat);
```

Parameters

Name	Direction	Description
sat	out	The current border saturation value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The sat parameter is invalid.

5.2.12.28 **IBMDSwitcherKeyDVEParameters::SetBorderSaturation** method

The **SetBorderSaturation** method sets the border saturation value.

Syntax

```
HRESULT SetBorderSaturation (double saturation);
```

Parameters

Name	Direction	Description
saturation	in	The desired border saturation value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.29 **IBMDSwitcherKeyDVEParameters::GetBorderLuma** method

The **GetBorderLuma** method gets the current border luminance value.

Syntax

```
HRESULT GetBorderLuma (double* luma);
```

Parameters

Name	Direction	Description
luma	out	The current border luminance value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The luma parameter is invalid.

5.2.12.30 IBMDSwitcherKeyDVEParameters::SetBorderLuma method

The `SetBorderLuma` method sets the border luminance value.

Syntax

```
HRESULT SetBorderLuma (double luma);
```

Parameters

Name	Direction	Description
luma	in	The desired border luminance value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.31 IBMDSwitcherKeyDVEParameters::GetMasked method

The `GetMasked` method returns whether masking is enabled or not.

Syntax

```
HRESULT GetMasked (boolean* masked);
```

Parameters

Name	Direction	Description
masked	out	Boolean flag of whether masking is enabled.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The masked parameter is invalid.

5.2.12.32 IBMDSwitcherKeyDVEParameters::SetMasked method

Use `SetMasked` method to enable or disable masking.

Syntax

```
HRESULT SetMasked (boolean masked);
```

Parameters

Name	Direction	Description
masked	in	The desired masked value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.33 IBMDSwitcherKeyDVEParameters::GetMaskTop method

The `GetMaskTop` method returns the current mask top value.

Syntax

```
HRESULT GetMaskTop (double* maskTop);
```

Parameters

Name	Direction	Description
maskTop	out	The current mask top value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskTop parameter is invalid.

5.2.12.34 IBMDSwitcherKeyDVEParameters::SetMaskTop method

The `SetMaskTop` method sets the mask top value.

Syntax

```
HRESULT SetMaskTop (double maskTop);
```

Parameters

Name	Direction	Description
maskTop	in	The desired mask top value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.35 IBMDSwitcherKeyDVEParameters::GetMaskBottom method

The `GetMaskBottom` method returns the current mask bottom value.

Syntax

```
HRESULT GetMaskBottom (double* maskBottom);
```

Parameters

Name	Direction	Description
maskBottom	out	The current mask bottom value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskBottom parameter is invalid.

5.2.12.36 IBMDSwitcherKeyDVEParameters::SetMaskBottom method

The `SetMaskBottom` method sets the mask bottom value.

Syntax

```
HRESULT SetMaskBottom (double maskBottom);
```

Parameters

Name	Direction	Description
maskBottom	in	The desired mask bottom value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.37 IBMDSwitcherKeyDVEParameters::GetMaskLeft method

The `GetMaskLeft` method returns the current mask left value.

Syntax

```
HRESULT GetMaskLeft (double* maskLeft);
```

Parameters

Name	Direction	Description
maskLeft	out	The current mask left value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskLeft parameter is invalid.

5.2.12.38 BMDSwitcherKeyDVEParameters::SetMaskLeft method

The `SetMaskLeft` method sets the mask left value.

Syntax

```
HRESULT SetMaskLeft (double maskLeft);
```

Parameters

Name	Direction	Description
maskLeft	in	The desired mask left value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.39 BMDSwitcherKeyDVEParameters::GetMaskRight method

The `GetMaskRight` method returns the current mask right value.

Syntax

```
HRESULT GetMaskRight (double* maskRight);
```

Parameters

Name	Direction	Description
maskRight	out	The current mask right value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskRight parameter is invalid.

5.2.12.40 BMDSwitcherKeyDVEParameters::SetMaskRight method

The `SetMaskRight` method sets the mask right value.

Syntax

```
HRESULT SetMaskRight (double maskRight);
```

Parameters

Name	Direction	Description
maskRight	in	The desired mask right value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.41 IBMDSwitcherKeyDVEParameters::ResetMask method

The `ResetMask` method resets the mask settings to default values.

Syntax

```
HRESULT ResetMask (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.12.42 IBMDSwitcherKeyDVEParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyDVEParameters** object. Pass an object implementing the **IBMDSwitcherKeyDVEParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyDVEParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyDVEParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.12.43 IBMDSwitcherKeyDVEParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyDVEParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyDVEParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.13 IBMDSwitcherKeyDVEParametersCallback Interface

The `IBMDSwitcherKeyDVEParametersCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherKeyDVEParameters` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKeyDVEParameters	IID_IBMDSwitcherKeyDVEParameters	An <code>IBMDSwitcherKeyDVEParametersCallback</code> object interface is installed with <code>IBMDSwitcherKeyDVEParameters::AddCallback</code> and removed with <code>IBMDSwitcherKeyDVEParameters::RemoveCallback</code>

Public Member Functions

Method	Description
Notify	Called when an event occurs.

5.2.13.1 IBMDSwitcherKeyDVEParametersCallback::Notify method

The `Notify` method is called when `IBMDSwitcherKeyDVEParameters` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherKeyDVEParametersEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	<code>BMDSwitcherKeyDVEParametersEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14 IBMDSwitcherKeyFlyParameters Interface

The **IBMDSwitcherKeyFlyParameters** object interface is used for manipulating fly settings of a key. A luminance, chroma or pattern key can be made a “fly” key, filtering its current state through the DVE hardware. Turning off the fly setting will remove the filter and return the key to its original state. Note that most properties in this interface also take effect when the key type is set to DVE.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKey	IID_IBMDSwitcherKey	An IBMDSwitcherKeyFlyParameters object interface can be obtained with IBMDSwitcherKey::QueryInterface .

Public Member Functions	
Method	Description
GetFly	Get the current fly flag.
SetFly	Set the fly flag.
GetCanFly	Get the current can-fly flag.
GetRate	Get the current fly rate.
SetRate	Set the fly rate.
GetSizeX	Get the current size x value.
SetSizeX	Set the size x value.
GetSizeY	Get the current size y value.
SetSizeY	Set the size y value.
GetCanScaleUp	Gets whether the Fly Key size x and size y values can be greater than 1.0.
GetPositionX	Get the current position x value.
SetPositionX	Set the position x value.
GetPositionY	Get the current position y value.
SetPositionY	Set the position y value.
GetRotation	Get the current rotation value.
SetRotation	Set the rotation value.
GetCanRotate	Gets whether the Fly Key supports rotation.
ResetRotation	Reset rotation to default value.
ResetDVE	Reset DVE properties (size, position and rotation) to default values.
ResetDVEFull	Reset DVE properties (size, position and rotation) to full screen.
IsKeyFrameStored	Determine if a key frame has been stored.
StoreAsKeyFrame	Store current state into a key frame.
RunToKeyFrame	Run to a key frame.
IsAtKeyFrames	Determines if the current frame matches any of the stored key frames.
IsRunning	Determines if the key is currently running.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

5.2.14.1 IBMDSwitcherKeyFlyParameters::GetFly method

The **GetFly** method returns whether fly is enabled or not.

Syntax

```
HRESULT GetFly (boolean* isFlyKey);
```

Parameters

Name	Direction	Description
isFlyKey	out	Boolean status of whether fly is enabled.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The isFlyKey parameter is invalid.

5.2.14.2 IBMDSwitcherKeyFlyParameters::SetFly method

Use the **SetFly** method to enable or disable fly.

Syntax

```
HRESULT SetFly (boolean isFlyKey);
```

Parameters

Name	Direction	Description
isFlyKey	in	The desired fly enable flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14.3 IBMDSwitcherKeyFlyParameters::GetCanFly method

The **GetCanFly** method returns whether this key can enable fly or not. The DVE hardware is a shared resource; if another component is currently using the resource, it may not be available for this key.

Syntax

```
HRESULT GetCanFly (boolean* canFly);
```

Parameters

Name	Direction	Description
canFly	out	Boolean status of the can-fly flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canFly parameter is invalid.

5.2.14.4 **IBMDSwitcherKeyFlyParameters::GetRate** method

The `GetRate` method gets the current fly rate value.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

Name	Direction	Description
frames	out	The current rate value in frames.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

5.2.14.5 **IBMDSwitcherKeyFlyParameters::SetRate** method

The `SetRate` method sets the fly rate value.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	The desired rate value in frames.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The frames parameter is invalid.
E_FAIL	Failure.

5.2.14.6 **IBMDSwitcherKeyFlyParameters::GetSizeX** method

The **GetSizeX** method gets the current size x value. The flying size is a multiple of the original key size.

Syntax

```
HRESULT GetSizeX (double* multiplierX);
```

Parameters

Name	Direction	Description
multiplierX	out	The current size x value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The multiplierX parameter is invalid.

5.2.14.7 **IBMDSwitcherKeyFlyParameters::SetSizeX** method

The **SetSizeX** method sets the size x value. The flying size is a multiple of the original key size.

Note: On some switchers the maximum size x value is 1.0. The **GetCanScaleUp** method can be used to determine whether the switcher supports Fly Key size x values greater than 1.0.

Syntax

```
HRESULT SetSizeX (double multiplierX);
```

Parameters

Name	Direction	Description
multiplierX	in	The desired size x value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14.8 IBMDSwitcherKeyFlyParameters::GetSizeY method

The `GetSizeY` method gets the current size y value. The flying size is a multiple of the original key size.

Syntax

```
HRESULT GetSizeY (double* multiplierY);
```

Parameters

Name	Direction	Description
multiplierY	out	The current size y value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The multiplierY parameter is invalid.

5.2.14.9 IBMDSwitcherKeyFlyParameters::SetSizeY method

The `SetSizeY` method sets the size y value. The flying size is a multiple of the original key size.

Note: On some switchers the maximum size y value is 1.0. The `GetCanScaleUp` method can be used to determine whether the switcher supports Fly Key size y values greater than 1.0.

Syntax

```
HRESULT SetSizeY (double multiplierY);
```

Parameters

Name	Direction	Description
multiplierY	in	The desired size y value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14.10 **IBMDSwitcherKeyFlyParameters::GetCanScaleUp** method

The **GetCanScaleUp** method is used to check whether the switcher supports Fly Key size x and size y values greater than 1.0.

Syntax

```
HRESULT GetCanScaleUp (boolean* canScaleUp);
```

Parameters

Name	Direction	Description
canScaleUp	out	A Boolean value indicating whether the switcher supports Fly Key size x and size y values greater than 1.0.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canScaleUp parameter is not a valid pointer.

5.2.14.11 **IBMDSwitcherKeyFlyParameters::GetPositionX** method

The **GetPositionX** method gets the current position x value. This is an offset from the original key position.

Syntax

```
HRESULT GetPositionX (double* offsetX);
```

Parameters

Name	Direction	Description
offsetX	out	The current offset x value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The offsetX parameter is invalid.

5.2.14.12 **IBMDSwitcherKeyFlyParameters::SetPositionX** method

The **SetPositionX** method sets the position x value. This is an offset from the original key position.

Syntax

```
HRESULT SetPositionX (double offsetX);
```

Parameters

Name	Direction	Description
offsetX	in	The desired position x value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14.13 **IBMDSwitcherKeyFlyParameters::GetPositionY** method

The **GetPositionY** method gets the current position y value. This is an offset from the original key position.

Syntax

```
HRESULT GetPositionY (double* offsetY);
```

Parameters

Name	Direction	Description
offsetY	out	The current offset y value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The offsetY parameter is invalid.

5.2.14.14 **IBMDSwitcherKeyFlyParameters::SetPositionY** method

The **SetPositionY** method sets the position y value. This is an offset from the original key position.

Syntax

```
HRESULT SetPositionY (double offsetY);
```

Parameters

Name	Direction	Description
offsetY	in	The desired position y value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14.15 **IBMDSwitcherKeyFlyParameters::GetRotation** method

The **GetRotation** method gets the current rotation value.

Syntax

```
HRESULT GetRotation (double* degrees);
```

Parameters

Name	Direction	Description
degrees	out	The current rotation value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The degrees parameter is invalid.

5.2.14.16 **IBMDSwitcherKeyFlyParameters::SetRotation** method

The **SetRotation** method sets the rotation value.

Syntax

```
HRESULT SetRotation (double degrees);
```

Parameters

Name	Direction	Description
degrees	in	The desired rotation value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14.17 **IBMDSwitcherKeyFlyParameters::GetCanRotate** method

The **GetCanRotate** method determines whether the current Fly Key supports rotation via the **SetRotation** method.

Syntax

```
HRESULT GetCanRotate (bool* canRotate);
```

Parameters

Name	Direction	Description
canRotate	out	The rotation support of the current Fly Key.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canRotate parameter is invalid.

5.2.14.18 **IBMDSwitcherKeyFlyParameters::ResetRotation** method

The **ResetRotation** method resets the rotation value to its default.

Syntax

```
HRESULT ResetRotation (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14.19 **IBMDSwitcherKeyFlyParameters::ResetDVE** method

The **ResetDVE** method resets the DVE parameters to their default values, i.e. size, position and rotation.

Syntax

```
HRESULT ResetDVE (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14.20 **IBMDSwitcherKeyFlyParameters::ResetDVEFull** method

The **ResetDVEFull** method resets the key fly parameters to full screen with no rotation.

Syntax

```
HRESULT ResetDVEFull (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.14.21 **IBMDSwitcherKeyFlyParameters::IsKeyFrameStored** method

The **IsKeyFrameStored** method returns whether the specified key frame has been stored or not. It is intended for use with user-defined key frames to determine if they have been stored.

Syntax

```
HRESULT IsKeyFrameStored (BMDSwitcherFlyKeyFrame keyFrame, boolean* stored);
```

Parameters

Name	Direction	Description
keyFrame	in	Specify a single key frame of BMDSwitcherFlyKeyFrame to query the status on.
stored	out	The current status flag of whether the specified key frame has been stored.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The keyFrame parameter is invalid.
E_POINTER	The stored parameter is invalid.

5.2.14.22 **IBMDSwitcherKeyFlyParameters::StoreAsKeyFrame** method

The **StoreAsKeyFrame** method stores the current frame into the specified key frame(s). Multiple user-defined key frames can be specified.

Syntax

```
HRESULT StoreAsKeyFrame (BMDSwitcherFlyKeyFrame keyFrames);
```

Parameters

Name	Direction	Description
keyFrames	in	Specify where to store the current frame, must be user-defined key frame(s).

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The keyFrames parameter is invalid.
E_FAIL	Failure.

5.2.14.23 **BMDSwitcherKeyFlyParameters::RunToKeyFrame** method

The **RunToKeyFrame** method commences a run from current frame to the specified key frame.

Syntax

```
HRESULT RunToKeyFrame (BMDSwitcherFlyKeyFrame destination);
```

Parameters

Name	Direction	Description
destination	in	The destination key frame.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The destination parameter is invalid.
E_FAIL	Failure.

5.2.14.24 **BMDSwitcherKeyFlyParameters::IsAtKeyFrames** method

The **IsAtKeyFrames** method returns a bit set of key frames that match the current frame. Zero is returned if the current frame does not match any built-in or user-defined frames.

Syntax

```
HRESULT IsAtKeyFrames (BMDSwitcherFlyKeyFrame* keyFrames);
```

Parameters

Name	Direction	Description
keyFrames	out	All key frames that match the current frame.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The keyFrames parameter is invalid.

5.2.14.25 IBMDSwitcherKeyFlyParameters::GetKeyFrameParameters method

The `GetKeyFrameParameters` method returns an object interface for accessing individual parameters in a key frame.

Syntax

```
HRESULT GetKeyFrameParameters (BMDSwitcherFlyKeyFrame keyFrame,  
                               IBMDSwitcherKeyFlyKeyFrameParameters** keyFrameParameters);
```

Parameters

Name	Direction	Description
keyFrame	in	The desired key frame.
keyFrameParameters	out	IBMDSwitcherKeyFlyKeyFrameParameters object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The keyFrame parameter is invalid.
E_POINTER	The keyFrameParameters parameter is invalid.

5.2.14.26 IBMDSwitcherKeyFlyParameters::IsRunning method

The `IsRunning` method returns the current run status.

Syntax

```
HRESULT IsRunning (boolean* isRunning, BMDSwitcherFlyKeyFrame* destination);
```

Parameters

Name	Direction	Description
isRunning	out	Boolean status of whether the key is running.
destination	out	If the key is running, this is the destination of the run.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The isRunning and/or destination parameter is invalid.
E_FAIL	Failure.

5.2.14.27 IBMDSwitcherKeyFlyParameters::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyFlyParameters** object. Pass an object implementing the **IBMDSwitcherKeyFlyParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherKeyFlyParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyFlyParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.14.28 IBMDSwitcherKeyFlyParameters::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyFlyParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyFlyParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.15 IBMDSwitcherKeyFlyParametersCallback Interface

The `IBMDSwitcherKeyFlyParametersCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherKeyFlyParameters` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherKeyFlyParameters</code>	<code>IID_IBMDSwitcherKeyFlyParameters</code>	An <code>IBMDSwitcherKeyFlyParametersCallback</code> object interface is installed with <code>IBMDSwitcherKeyFlyParameters::AddCallback</code> and removed with <code>IBMDSwitcherKeyFlyParameters::RemoveCallback</code>

Public Member Functions

Method	Description
<code>Notify</code>	Called when an event occurs.

5.2.15.1 IBMDSwitcherKeyFlyParametersCallback::Notify method

The `Notify` method is called when `IBMDSwitcherKeyFlyParameters` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherKeyFlyParametersEventType eventType,  
                BMDSwitcherFlyKeyFrame keyFrame);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherKeyFlyParametersEventType</code> that describes the type of event that has occurred.
<code>keyFrame</code>	in	This parameter is only valid when <code>eventType</code> is <code>bmdSwitcherKeyFlyParametersEventTypes KeyFrameStoredChanged</code> , it specifies the changed key frame.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

5.2.16 IBMDSwitcherKeyFlyKeyFrameParametersInterface

The `IBMDSwitcherKeyFlyKeyFrameParameters` object interface provides access to individual key frame parameters.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKeyFlyParameters	IID_IBMDSwitcherKeyFlyParameters	An <code>IBMDSwitcherKeyFlyKeyFrameParameters</code> object interface can be obtained from <code>IBMDSwitcherKeyFlyParameters::GetKeyFrameParameters</code> .

Public Member Functions	
Method	Description
GetSizeX	Get the size x value.
SetSizeX	Set the size x value.
GetSizeY	Get the size y value.
SetSizeY	Set the size y value.
GetCanScaleUp	Gets whether the Fly Key Key Frame size x and size y values can be greater than 1.0.
GetPositionX	Get the position x value.
SetPositionX	Set the position x value.
GetPositionY	Get the position y value.
SetPositionY	Set the position y value.
GetRotation	Get the rotation value.
SetRotation	Set the rotation value.
GetCanRotate	Gets whether the Fly Key Key Frame supports rotation.
GetBorderWidthOut	Get the border outer width value.
SetBorderWidthOut	Set the border outer width value.
GetBorderWidthIn	Get the border inner width value.
SetBorderWidthIn	Set the border inner width value.
GetBorderSoftnessOut	Get the border outer softness value.
SetBorderSoftnessOut	Set the border outer softness value.
GetBorderSoftnessIn	Get the border inner softness value.
SetBorderSoftnessIn	Set the border inner softness value.
GetBorderBevelSoftness	Get the border bevel softness value.
SetBorderBevelSoftness	Set the border bevel softness value.
GetBorderBevelPosition	Get the border bevel position value.
SetBorderBevelPosition	Set the border bevel position value.
GetBorderOpacity	Get the border opacity value.
SetBorderOpacity	Set the border opacity value.
GetBorderHue	Get the border hue value.
SetBorderHue	Set the border hue value.

Public Member Functions	
Method	Description
GetBorderSaturation	Get the border saturation value.
SetBorderSaturation	Set the border saturation value.
GetBorderLuma	Get the border luminance value.
SetBorderLuma	Set the border luminance value.
GetBorderLightSourceDirection	Get the border light source direction value.
SetBorderLightSourceDirection	Set the border light source direction value.
GetBorderLightSourceAltitude	Get the border light source altitude value.
SetBorderLightSourceAltitude	Set the border light source altitude value.
GetMaskTop	Get the mask top value.
SetMaskTop	Set the mask top value.
GetMaskBottom	Get the mask bottom value.
SetMaskBottom	Set the mask bottom value.
GetMaskLeft	Get the mask left value.
SetMaskLeft	Set the mask left value.
GetMaskRight	Get the mask right value.
SetMaskRight	Set the mask right value.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

5.2.16.1 IBMDSwitcherKeyFlyKeyFrameParameters::GetSizeX method

The `GetSizeX` method gets the size x value.

Syntax

```
HRESULT GetSizeX (double* multiplierX);
```

Parameters

Name	Direction	Description
multiplierX	out	The current size x value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The multiplierX parameter is invalid.

5.2.16.2 IBMDSwitcherKeyFlyKeyFrameParameters::SetSizeX method

The `SetSizeX` method sets the size x value.

Note: On some switchers the maximum size x value is 1.0. The `GetCanScaleUp` method can be used to determine whether the switcher supports Fly Key Key Frame size x values greater than 1.0.

Syntax

```
HRESULT SetSizeX (double multiplierX);
```

Parameters

Name	Direction	Description
multiplierX	in	The desired size x value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.3 IBMDSwitcherKeyFlyKeyFrameParameters::GetSizeY method

The `GetSizeY` method gets the size y value.

Syntax

```
HRESULT GetSizeY (double* multiplierY);
```

Parameters

Name	Direction	Description
multiplierY	out	The size y value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The multiplierY parameter is invalid.

5.2.16.4 IBMDSwitcherKeyFlyKeyFrameParameters::SetSizeY method

The **SetSizeY** method sets the size y value.

Note: On some switchers the maximum size y value is 1.0. The **GetCanScaleUp** method can be used to determine whether the switcher supports Fly Key Key Frame size y values greater than 1.0.

Syntax

```
HRESULT SetSizeY (double multiplierY);
```

Parameters

Name	Direction	Description
multiplierY	in	The desired size y value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.5 IBMDSwitcherKeyFlyKeyFrameParameters::GetCanScaleUp method

The **GetCanScaleUp** method is used to check whether the switcher supports Fly Key Key Frame size x and size y values greater than 1.0.

Syntax

```
HRESULT GetCanScaleUp (boolean* canScaleUp);
```

Parameters

Name	Direction	Description
canScaleUp	out	A Boolean value indicating whether the switcher supports Fly Key Key Frame size x and size y values greater than 1.0.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canScaleUp parameter is not a valid pointer.

5.2.16.6 **IBMDSwitcherKeyFlyKeyFrameParameters::GetPositionX** method

The `GetPositionX` method gets the position x value.

Syntax

```
HRESULT GetPositionX (double* offsetX);
```

Parameters

Name	Direction	Description
offsetX	out	The position x value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The offsetX parameter is invalid.

5.2.16.7 **IBMDSwitcherKeyFlyKeyFrameParameters::SetPositionX** method

The `SetPositionX` method sets the position x value.

Syntax

```
HRESULT SetPositionX (double offsetX);
```

Parameters

Name	Direction	Description
offsetX	in	The desired position x value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.8 **IBMDSwitcherKeyFlyKeyFrameParameters::GetPositionY** method

The `GetPositionY` method gets the position y value.

Syntax

```
HRESULT GetPositionY (double* offsetY);
```

Parameters

Name	Direction	Description
offsetY	out	The position y value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The offsetY parameter is invalid.

5.2.16.9 IBMDSwitcherKeyFlyKeyFrameParameters::SetPositionY method

The `SetPositionY` method sets the position y value.

Syntax

```
HRESULT SetPositionY (double offsetY);
```

Parameters

Name	Direction	Description
offsetY	in	The desired position y value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.10 IBMDSwitcherKeyFlyKeyFrameParameters::GetRotation method

The `GetRotation` method gets the rotation value.

Syntax

```
HRESULT GetRotation (double* degrees);
```

Parameters

Name	Direction	Description
degrees	out	The rotation value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The degrees parameter is invalid.

5.2.16.11 IBMDSwitcherKeyFlyKeyFrameParameters::SetRotation method

The `SetRotation` method sets the rotation value.

Syntax

```
HRESULT SetRotation (double degrees);
```

Parameters

Name	Direction	Description
degrees	in	The desired rotation value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.12 **IBMDSwitcherKeyFlyKeyFrameParameters::GetCanRotate** method

The `GetCanRotate` method determines whether the Fly Key Key Frame supports rotation via the `SetRotation` method.

Syntax

```
HRESULT GetCanRotate (bool* canRotate);
```

Parameters

Name	Direction	Description
canRotate	out	The rotation support of the Fly Key Key Frame.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The canRotate parameter is invalid.

5.2.16.13 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderWidthOut** method

The `GetBorderWidthOut` method gets the border outer width value.

Syntax

```
HRESULT GetBorderWidthOut (double* widthOut);
```

Parameters

Name	Direction	Description
widthOut	out	The border outer width value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The widthOut parameter is invalid.

5.2.16.14 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderWidthOut** method

The `SetBorderWidthOut` method sets the border outer width value.

Syntax

```
HRESULT SetBorderWidthOut (double widthOut);
```

Parameters

Name	Direction	Description
widthOut	in	The desired border outer width value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.15 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderWidthIn** method

The `GetBorderWidthIn` method gets the border inner width value.

Syntax

```
HRESULT GetBorderWidthIn (double* widthIn);
```

Parameters

Name	Direction	Description
widthIn	out	The border inner width value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The widthIn parameter is invalid.

5.2.16.16 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderWidthIn** method

The `SetBorderWidthIn` method sets the border inner width value.

Syntax

```
HRESULT SetBorderWidthIn (double widthIn);
```

Parameters

Name	Direction	Description
widthIn	in	The desired border inner width value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.17 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSoftnessOut** method

The `GetBorderSoftnessOut` method gets the border outer softness value.

Syntax

```
HRESULT GetBorderSoftnessOut (double* softOut);
```

Parameters

Name	Direction	Description
softOut	out	The border outer softness value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The softOut parameter is invalid.

5.2.16.18 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSoftnessOut** method

The **SetBorderSoftnessOut** method sets the border outer softness value.

Syntax

```
HRESULT SetBorderSoftnessOut (double softOut);
```

Parameters

Name	Direction	Description
softOut	in	The desired border outer softness value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.19 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSoftnessIn** method

The **GetBorderSoftnessIn** method gets the border inner softness value.

Syntax

```
HRESULT GetBorderSoftnessIn (double* softIn);
```

Parameters

Name	Direction	Description
softIn	out	The border inner softness value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The softIn parameter is invalid.

5.2.16.20 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSoftnessIn** method

The **SetBorderSoftnessIn** method sets the border inner softness value.

Syntax

```
HRESULT SetBorderSoftnessIn (double softIn);
```

Parameters

Name	Direction	Description
softIn	in	The desired border inner softness value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.21 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderBevelSoftness** method

The `GetBorderBevelSoftness` method gets the border bevel softness value.

Syntax

```
HRESULT GetBorderBevelSoftness (double* bevelSoft);
```

Parameters

Name	Direction	Description
bevelSoft	out	The border bevel softness value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The bevelSoft parameter is invalid.

5.2.16.22 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderBevelSoftness** method

The `SetBorderBevelSoftness` method sets the border bevel softness value.

Syntax

```
HRESULT SetBorderBevelSoftness (double bevelSoft);
```

Parameters

Name	Direction	Description
bevelSoft	in	The desired border bevel softness value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.23 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderBevelPosition** method

The `GetBorderBevelPosition` method gets the border bevel position value.

Syntax

```
HRESULT GetBorderBevelPosition (double* bevelPosition);
```

Parameters

Name	Direction	Description
bevelPosition	out	The border bevel position value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The bevelPosition parameter is invalid.

5.2.16.24 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderBevelPosition** method

The `SetBorderBevelPosition` method sets the border bevel position value.

Syntax

```
HRESULT SetBorderBevelPosition (double bevelPosition);
```

Parameters

Name	Direction	Description
bevelPosition	in	The desired border bevel position value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.25 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderOpacity** method

The `GetBorderOpacity` method gets the border opacity value.

Syntax

```
HRESULT GetBorderOpacity (double* opacity);
```

Parameters

Name	Direction	Description
opacity	out	The border opacity value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The opacity parameter is invalid.

5.2.16.26 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderOpacity** method

The `SetBorderOpacity` method sets the border opacity value.

Syntax

```
HRESULT SetBorderOpacity (double opacity);
```

Parameters

Name	Direction	Description
opacity	in	The desired border opacity value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.27 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderHue** method

The **GetBorderHue** method gets the border hue value.

Syntax

```
HRESULT GetBorderHue (double* hue);
```

Parameters

Name	Direction	Description
hue	out	The border hue value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The hue parameter is invalid.

5.2.16.28 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderHue** method

The **SetBorderHue** method sets the border hue value.

Syntax

```
HRESULT SetBorderHue (double hue);
```

Parameters

Name	Direction	Description
hue	in	The desired border hue value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.29 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderSaturation** method

The **GetBorderSaturation** method gets the border saturation value.

Syntax

```
HRESULT GetBorderSaturation (double* sat);
```

Parameters

Name	Direction	Description
sat	out	The border saturation value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The sat parameter is invalid.

5.2.16.30 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderSaturation** method

The **SetBorderSaturation** method sets the border saturation value.

Syntax

```
HRESULT SetBorderSaturation (double sat);
```

Parameters

Name	Direction	Description
sat	in	The desired border saturation value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.31 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLuma** method

The **GetBorderLuma** method gets the border luminance value.

Syntax

```
HRESULT GetBorderLuma (double* luma);
```

Parameters

Name	Direction	Description
luma	out	The border luminance value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The luma parameter is invalid.

5.2.16.32 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLuma** method

The **SetBorderLuma** method sets the border luminance value.

Syntax

```
HRESULT SetBorderLuma (double luma);
```

Parameters

Name	Direction	Description
luma	in	The desired border luminance value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.33 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLightSourceDirection** method

The **GetBorderLightSourceDirection** method gets the border light source direction value.

Syntax

```
HRESULT GetBorderLightSourceDirection (double* degrees);
```

Parameters

Name	Direction	Description
degrees	out	The border light source direction in degrees.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The degrees parameter is invalid.

5.2.16.34 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLightSourceDirection** method

The **SetBorderLightSourceDirection** method sets the border light source direction value.

Syntax

```
HRESULT SetBorderLightSourceDirection (double degrees);
```

Parameters

Name	Direction	Description
degrees	in	The desired border light source direction value in degrees.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.35 **IBMDSwitcherKeyFlyKeyFrameParameters::GetBorderLightSourceAltitude** method

The `GetBorderLightSourceAltitude` method gets the border light source altitude value.

Syntax

```
HRESULT GetBorderLightSourceAltitude (double* altitude);
```

Parameters

Name	Direction	Description
altitude	out	The border light source altitude value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The altitude parameter is invalid.

5.2.16.36 **IBMDSwitcherKeyFlyKeyFrameParameters::SetBorderLightSourceAltitude** method

The `SetBorderLightSourceAltitude` method sets the border light source altitude value.

Syntax

```
HRESULT SetBorderLightSourceAltitude (double altitude);
```

Parameters

Name	Direction	Description
altitude	in	The desired border light source altitude value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.37 **IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskTop** method

The **GetMaskTop** method returns the mask top value.

Syntax

```
HRESULT GetMaskTop (double* maskTop);
```

Parameters

Name	Direction	Description
maskTop	out	The mask top value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskTop parameter is invalid.

5.2.16.38 **IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskTop** method

The **SetMaskTop** method sets the mask top value.

Syntax

```
HRESULT SetMaskTop (double maskTop);
```

Parameters

Name	Direction	Description
maskTop	in	The desired mask top value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.39 **IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskBottom** method

The **GetMaskBottom** method returns the mask bottom value.

Syntax

```
HRESULT GetMaskBottom (double* maskBottom);
```

Parameters

Name	Direction	Description
maskBottom	out	The mask bottom value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskBottom parameter is invalid.

5.2.16.40 **IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskBottom** method

The **SetMaskBottom** method sets the mask bottom value.

Syntax

```
HRESULT SetMaskBottom (double maskBottom);
```

Parameters

Name	Direction	Description
maskBottom	in	The desired mask bottom value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.41 **IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskLeft** method

The **GetMaskLeft** method returns the mask left value.

Syntax

```
HRESULT GetMaskLeft (double* maskLeft);
```

Parameters

Name	Direction	Description
maskLeft	out	The mask left value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskLeft parameter is invalid.

5.2.16.42 **IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskLeft** method

The **SetMaskLeft** method sets the mask left value.

Syntax

```
HRESULT SetMaskLeft (double maskLeft);
```

Parameters

Name	Direction	Description
maskLeft	in	The desired mask left value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.43 **IBMDSwitcherKeyFlyKeyFrameParameters::GetMaskRight** method

The **GetMaskRight** method returns the mask right value.

Syntax

```
HRESULT GetMaskRight (double* maskRight);
```

Parameters

Name	Direction	Description
maskRight	out	The mask right value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskRight parameter is invalid.

5.2.16.44 **IBMDSwitcherKeyFlyKeyFrameParameters::SetMaskRight** method

The **SetMaskRight** method sets the mask right value.

Syntax

```
HRESULT SetMaskRight (double maskRight);
```

Parameters

Name	Direction	Description
maskRight	in	The desired mask right value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.16.45 **IBMDSwitcherKeyFlyKeyFrameParameters::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherKeyFlyKeyFrameParameters** object. Pass an object implementing the **IBMDSwitcherKeyFlyKeyFrameParametersCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherKeyFlyKeyFrameParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyFlyKeyFrameParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.16.46 **IBMDSwitcherKeyFlyKeyFrameParameters::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherKeyFlyKeyFrameParametersCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherKeyFlyKeyFrameParametersCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.17 IBMDSwitcherKeyFlyKeyFrameParametersCallback Interface

The **IBMDSwitcherKeyFlyKeyFrameParametersCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherKeyFlyKeyFrameParameters** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherKeyFlyKeyFrameParameters	IID_IBMDSwitcherKeyFlyKeyFrameParameters	An IBMDSwitcherKeyFlyKeyFrameParametersCallback object interface is installed with IBMDSwitcherKeyFlyKeyFrameParameters::AddCallback and removed with IBMDSwitcherKeyFlyKeyFrameParameters::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

5.2.17.1 IBMDSwitcherKeyFlyKeyFrameParametersCallback::Notify method

The **Notify** method is called when **IBMDSwitcherKeyFlyKeyFrameParameters** events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherKeyFlyKeyFrameParametersEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherKeyFlyKeyFrameParametersEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.18 IBMDSwitcherDownstreamKeylterator Interface

The **IBMDSwitcherDownstreamKeylterator** is used to enumerate the available downstream keys.

A reference to an **IBMDSwitcherDownstreamKeylterator** object interface may be obtained from an **IBMDSwitcher** object interface using the **Createliterator** method. Pass **IID_IBMDSwitcherDownstreamKeylterator** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	IBMDSwitcher::Createliterator can return an IBMDSwitcherDownstreamKeylterator object interface.

Public Member Functions

Method	Description
Next	Returns a pointer to the next IBMDSwitcherDownstreamKey object interface.

5.2.18.1 IBMDSwitcherDownstreamKeylterator::Next method

The **Next** method returns the next available **IBMDSwitcherDownstreamKey** object interface.

Syntax

```
HRESULT Next (IBMDSwitcherDownstreamKey** downstreamKey);
```

Parameters

Name	Direction	Description
downstreamKey	out	IBMDSwitcherDownstreamKey object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No more IBMDSwitcherDownstreamKey objects available.
E_POINTER	The downstreamKey parameter is invalid.

5.2.19 IBMDSwitcherDownstreamKey Interface

The `IBMDSwitcherDownstreamKey` object interface is used for managing the settings of a downstream key.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherDownstreamKeyIterator</code>	<code>IID_IBMDSwitcherDownstreamKeyIterator</code>	An <code>IBMDSwitcherDownstreamKey</code> object will be returned after a successful call to <code>IBMDSwitcherDownstreamKeyIterator::Next</code> method.

Public Member Functions	
Method	Description
<code>GetInputCut</code>	Get the current cut input source.
<code>SetInputCut</code>	Set the cut input source.
<code>GetInputFill</code>	Get the current fill input source.
<code>SetInputFill</code>	Set the fill input source.
<code>GetFillInputAvailabilityMask</code>	Get the availability mask for the fill of this input.
<code>GetCutInputAvailabilityMask</code>	Get the availability mask for the cut of this input.
<code>GetTie</code>	Get the current tie flag.
<code>SetTie</code>	Set the tie flag.
<code>GetRate</code>	Get the current rate value.
<code>SetRate</code>	Set the rate value.
<code>GetOnAir</code>	Get the current on-air flag.
<code>SetOnAir</code>	Set the on-air flag.
<code>PerformAutoTransition</code>	Perform an auto-transition.
<code>PerformAutoTransitionInDirection</code>	Perform an auto-transition in a particular direction.
<code>IsTransitioning</code>	Determines if this downstream key is transitioning.
<code>IsAutoTransitioning</code>	Determines if this downstream key is auto-transitioning.
<code>IsTransitionTowardsOnAir</code>	Determines which direction this downstream key is transitioning.
<code>GetFramesRemaining</code>	Get the number of frames remaining in the transition.
<code>GetPreMultiplied</code>	Get the current pre-multiplied flag.
<code>SetPreMultiplied</code>	Set the pre-multiplied flag.
<code>GetClip</code>	Get the current clip value.
<code>SetClip</code>	Set the clip value.
<code>GetGain</code>	Get the current gain value.
<code>SetGain</code>	Set the gain value.
<code>GetInverse</code>	Get the current inverse flag.
<code>SetInverse</code>	Set the inverse flag.
<code>GetMasked</code>	Get the current masked flag.

Public Member Functions	
Method	Description
SetMasked	Set the masked flag.
GetMaskTop	Get the current mask top value.
SetMaskTop	Set the mask top value.
GetMaskBottom	Get the current mask bottom value.
SetMaskBottom	Set the mask bottom value.
GetMaskLeft	Get the current mask left value.
SetMaskLeft	Set the mask left value.
GetMaskRight	Get the current mask right value.
SetMaskRight	Set the mask right value.
ResetMask	Reset mask properties to default.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

5.2.19.1 **BMDSwitcherDownstreamKey::GetInputCut** method

The **GetInputCut** method returns the selected cut input source.

Syntax

```
HRESULT GetInputCut (BMDSwitcherInputId* inputId);
```

Parameters

Name	Direction	Description
inputId	out	BMDSwitcherInputId of the selected cut input source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inputId parameter is invalid.

5.2.19.2 IBMDSwitcherDownstreamKey::SetInputCut method

The `SetInputCut` method sets the cut input source.

Syntax

```
HRESULT SetInputCut (BMDSwitcherInputId inputId);
```

Parameters

Name	Direction	Description
inputId	in	The desired cut input source's <code>BMDSwitcherInputId</code> .

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The inputId parameter is invalid.

5.2.19.3 IBMDSwitcherDownstreamKey::GetInputFill method

The `GetInputFill` method returns the selected fill input source.

Syntax

```
HRESULT GetInputFill (BMDSwitcherInputId* inputId);
```

Parameters

Name	Direction	Description
inputId	out	<code>BMDSwitcherInputId</code> of the selected fill input source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inputId parameter is invalid.

5.2.19.4 **IBMDSwitcherDownstreamKey::SetInputFill** method

The **SetInputFill** method sets the fill input source.

Syntax

```
HRESULT SetInputFill (IBMDSwitcherInputId inputId);
```

Parameters

Name	Direction	Description
inputId	in	The desired fill input source's IBMDSwitcherInputId .

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The inputId parameter is invalid.

5.2.19.5 **IBMDSwitcherDownstreamKey::GetFillInputAvailabilityMask** method

The **GetFillInputAvailabilityMask** method returns the corresponding **IBMDSwitcherInputAvailability** bit mask value for fill inputs available to this downstream key. The input availability property of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a fill input for this downstream key.

Syntax

```
HRESULT GetFillInputAvailabilityMask (IBMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	IBMDSwitcherInputAvailability bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

5.2.19.6 IBMDSwitcherDownstreamKey::GetCutInputAvailabilityMask method

The `GetCutInputAvailabilityMask` method returns the corresponding `BMDSwitcherInputAvailability` bit mask value for cut inputs available to this downstream key. The input availability property of an `IBMDSwitcherInput` can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a cut input for this downstream key.

Syntax

```
HRESULT GetCutInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	BMDSwitcherInputAvailability bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

5.2.19.7 IBMDSwitcherDownstreamKey::GetTie method

The `GetTie` method gets the current tie flag.

Syntax

```
HRESULT GetTie (boolean* tie);
```

Parameters

Name	Direction	Description
tie	out	Boolean tie flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The tie parameter is invalid.

5.2.19.8 IBMDSwitcherDownstreamKey::SetTie method

The `SetTie` method sets the tie flag.

Syntax

```
HRESULT SetTie (boolean tie);
```

Parameters

Name	Direction	Description
tie	in	The desired tie flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.9 IBMDSwitcherDownstreamKey::GetRate method

The `GetRate` method gets the current rate value.

Syntax

```
HRESULT GetRate (uint32_t* frames);
```

Parameters

Name	Direction	Description
frames	out	The current rate value in frames.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frames parameter is invalid.

5.2.19.10 **IBMDSwitcherDownstreamKey::SetRate** method

The **SetRate** method sets the rate value.

Syntax

```
HRESULT SetRate (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	The desired rate value in frames.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The frames parameter is invalid.
E_FAIL	Failure.

5.2.19.11 **IBMDSwitcherDownstreamKey::GetOnAir** method

The **GetOnAir** method returns the on-air flag.

Syntax

```
HRESULT GetOnAir (boolean* onAir);
```

Parameters

Name	Direction	Description
onAir	out	Boolean on-air flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The onAir parameter is invalid.

5.2.19.12 **IBMDSwitcherDownstreamKey::SetOnAir** method

The **SetOnAir** method sets the on-air flag.

Syntax

```
HRESULT SetOnAir (boolean onAir);
```

Parameters

Name	Direction	Description
onAir	in	The desired on-air flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.13 **IBMDSwitcherDownstreamKey::PerformAutoTransition** method

Use the **PerformAutoTransition** method to start an auto-transition.

Syntax

```
HRESULT PerformAutoTransition (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.14 **IBMDSwitcherDownstreamKey::PerformAutoTransitionInDirection** method

The **PerformAutoTransitionInDirection** method performs an auto-transition in the specified direction, either towards on-air or away from on-air.

Syntax

```
HRESULT PerformAutoTransitionInDirection(boolean towardsOnAir)
```

Parameters

Name	Direction	Description
towardsOnAir	in	The desired direction.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.15 **IBMDSwitcherDownstreamKey::IsTransitioning** method

The `IsTransitioning` method returns whether this downstream key is transitioning or not.

Syntax

```
HRESULT IsTransitioning (boolean* isTransitioning);
```

Parameters

Name	Direction	Description
isTransitioning	out	Boolean status of whether it is transitioning.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The isTransitioning parameter is invalid.

5.2.19.16 **IBMDSwitcherDownstreamKey::IsAutoTransitioning** method

The `IsAutoTransitioning` method returns whether this downstream key is auto-transitioning or not.

Syntax

```
HRESULT IsAutoTransitioning (boolean* isAutoTransitioning);
```

Parameters

Name	Direction	Description
isAutoTransitioning	out	Boolean status of whether it is auto-transitioning.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The isAutoTransitioning parameter is invalid.

5.2.19.17 **IBMDSwitcherDownstreamKey::IsTransitionTowardsOnAir** method

The `IsTransitionTowardsOnAir` method returns whether this downstream key is transitioning towards or away from on-air.

Syntax

```
HRESULT IsTransitionTowardsOnAir (boolean* isTransitionTowardsOnAir)
```

Parameters

Name	Direction	Description
isTransitionTowardsOnAir	out	Boolean status of whether it is transitioning towards on-air.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The isTransitionTowardsOnAir parameter is invalid.

5.2.19.18 **IBMDSwitcherDownstreamKey::GetFramesRemaining** method

The `GetFramesRemaining` method gets the number of frames remaining in the transition.

Syntax

```
HRESULT GetFramesRemaining (uint32_t* framesRemaining);
```

Parameters

Name	Direction	Description
framesRemaining	out	Number of frames remaining in the transition.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The framesRemaining parameter is invalid.

5.2.19.19 **IBMDSwitcherDownstreamKey::GetPreMultiplied** method

The `GetPreMultiplied` method returns the current pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

Name	Direction	Description
preMultiplied	out	The current pre-multiplied flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The preMultiplied parameter is invalid.

5.2.19.20 **IBMDSwitcherDownstreamKey::SetPreMultiplied** method

The `SetPreMultiplied` method sets the pre-multiplied flag. Note that clip, gain and inverse controls are not used when pre-multiplied flag is set to true.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

Name	Direction	Description
preMultiplied	in	The desired pre-multiplied flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.21 **IBMDSwitcherDownstreamKey::GetClip** method

The `GetClip` method returns the current clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

Name	Direction	Description
clip	out	The current clip value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The clip parameter is invalid.

5.2.19.22 **IBMDSwitcherDownstreamKey::SetClip** method

The `SetClip` method sets the clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

Name	Direction	Description
clip	in	The desired clip value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.23 **IBMDSwitcherDownstreamKey::GetGain** method

The `GetGain` method returns the current gain value.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

5.2.19.24 **IBMDSwitcherDownstreamKey::SetGain** method

The **SetGain** method sets the gain value.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.25 **IBMDSwitcherDownstreamKey::GetInverse** method

The **GetInverse** method returns the current inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

Name	Direction	Description
inverse	out	The current inverse flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inverse parameter is invalid.

5.2.19.26 **IBMDSwitcherDownstreamKey::SetInverse** method

The **SetInverse** method sets the inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

Name	Direction	Description
inverse	in	The desired inverse flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.27 IBMDSwitcherDownstreamKey::GetMasked method

The `GetMasked` method returns whether masking is enabled or not.

Syntax

```
HRESULT GetMasked (boolean* masked);
```

Parameters

Name	Direction	Description
masked	out	Boolean flag of whether masking is enabled.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The masked parameter is invalid.

5.2.19.28 IBMDSwitcherDownstreamKey::SetMasked method

The `SetMasked` method enables or disables masking.

Syntax

```
HRESULT SetMasked (boolean masked);
```

Parameters

Name	Direction	Description
masked	in	The desired masked value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.29 IBMDSwitcherDownstreamKey::GetMaskTop method

The `GetMaskTop` method returns the current mask top value.

Syntax

```
HRESULT GetMaskTop (double* maskTop);
```

Parameters

Name	Direction	Description
maskTop	out	The current mask top value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskTop parameter is invalid.

5.2.19.30 **IBMDSwitcherDownstreamKey::SetMaskTop** method

The **SetMaskTop** method sets the mask top value.

Syntax

```
HRESULT SetMaskTop (double maskTop);
```

Parameters

Name	Direction	Description
maskTop	in	The desired mask top value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.31 **IBMDSwitcherDownstreamKey::GetMaskBottom** method

The **GetMaskBottom** method returns the current mask bottom value.

Syntax

```
HRESULT GetMaskBottom (double* maskBottom);
```

Parameters

Name	Direction	Description
maskBottom	out	The current mask bottom value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskBottom parameter is invalid.

5.2.19.32 **IBMDSwitcherDownstreamKey::SetMaskBottom** method

The **SetMaskBottom** method sets the mask bottom value.

Syntax

```
HRESULT SetMaskBottom (double maskBottom);
```

Parameters

Name	Direction	Description
maskBottom	in	The desired mask bottom value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.33 **IBMDSwitcherDownstreamKey::GetMaskLeft** method

The **GetMaskLeft** method returns the current mask left value.

Syntax

```
HRESULT GetMaskLeft (double* maskLeft);
```

Parameters

Name	Direction	Description
maskLeft	out	The current mask left value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskLeft parameter is invalid.

5.2.19.34 **IBMDSwitcherDownstreamKey::SetMaskLeft** method

The **SetMaskLeft** method sets the mask left value.

Syntax

```
HRESULT SetMaskLeft (double maskLeft);
```

Parameters

Name	Direction	Description
maskLeft	in	The desired mask left value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.35 **IBMDSwitcherDownstreamKey::GetMaskRight** method

The **GetMaskRight** method returns the current mask right value.

Syntax

```
HRESULT GetMaskRight (double* maskRight);
```

Parameters

Name	Direction	Description
maskRight	out	The current mask right value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maskRight parameter is invalid.

5.2.19.36 IBMDSwitcherDownstreamKey::SetMaskRight method

The `SetMaskRight` method sets the mask right value.

Syntax

```
HRESULT SetMaskRight (double maskRight);
```

Parameters

Name	Direction	Description
maskRight	in	The desired mask right value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.37 IBMDSwitcherDownstreamKey::ResetMask method

The `ResetMask` method resets mask settings to the default values.

Syntax

```
HRESULT ResetMask (void);
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

5.2.19.38 IBMDSwitcherDownstreamKey::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherDownstreamKey** object. Pass an object implementing the **IBMDSwitcherDownstreamKeyCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherDownstreamKeyCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherDownstreamKeyCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.19.39 IBMDSwitcherDownstreamKey::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherDownstreamKeyCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherDownstreamKeyCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

5.2.20 IBMDSwitcherDownstreamKeyCallback Interface

The `IBMDSwitcherDownstreamKeyCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherDownstreamKey` object.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherDownstreamKey</code>	<code>IID_IBMDSwitcherDownstreamKey</code>	An <code>IBMDSwitcherDownstreamKeyCallback</code> object interface is installed with <code>IBMDSwitcherDownstreamKey::AddCallback</code> and removed with <code>IBMDSwitcherDownstreamKey::RemoveCallback</code>

Public Member Functions	
Method	Description
<code>Next</code>	Called when an event occurs.

5.2.20.1 IBMDSwitcherDownstreamKeyCallback::Notify

The `Notify` method is called when `IBMDSwitcherDownstreamKey` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherDownstreamKeyEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>BMDSwitcherDownstreamKeyEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

Section 6 — SuperSource

When available in the target switcher, the SuperSource allows multiple video sources to be displayed within boxes as part of a single video output.

6.1 SuperSource Data Types

6.1.1 SuperSource Box Event Type

BMDSwitcherSuperSourceBoxEventType enumerates the possible event types for the **IBMDSwitcherSuperSourceBox** object interface.

- **bmdSwitcherSuperSourceBoxEventTypeInputSourceChanged**
The source input changed.
- **bmdSwitcherSuperSourceBoxEventTypePositionXChanged**
The x position changed.
- **bmdSwitcherSuperSourceBoxEventTypePositionYChanged**
The y position changed.
- **bmdSwitcherSuperSourceBoxEventTypeSizeChanged**
The size changed.
- **bmdSwitcherSuperSourceBoxEventTypeCroppedChanged**
The cropped flag changed.
- **bmdSwitcherSuperSourceBoxEventTypeCropTopChanged**
The top crop value changed.
- **bmdSwitcherSuperSourceBoxEventTypeCropBottomChanged**
The bottom crop value changed.
- **bmdSwitcherSuperSourceBoxEventTypeCropLeftChanged**
The left crop value changed.
- **bmdSwitcherSuperSourceBoxEventTypeCropRightChanged**
The right crop value changed.

6.1.2 SuperSource Border Event Type

BMDSwitcherSuperSourceBorderEventType enumerates the possible event types for the **IBMDSwitcherSuperSourceBorder** object interface.

- **bmdSwitcherSuperSourceBorderEventTypeEnabledChanged**
The border enabled flag changed.
- **bmdSwitcherSuperSourceBorderEventTypeBevelChanged**
The border bevel changed.
- **bmdSwitcherSuperSourceBorderEventTypeWidthOutChanged**
The border outer width changed.
- **bmdSwitcherSuperSourceBorderEventTypeWidthInChanged**
The border inner width changed.
- **bmdSwitcherSuperSourceBorderEventTypeSoftnessOutChanged**
The border outer softness changed.
- **bmdSwitcherSuperSourceBorderEventTypeSoftnessInChanged**
The border inner softness changed.
- **bmdSwitcherSuperSourceBorderEventTypeBevelSoftnessChanged**
The border bevel softness changed.

- **bmdSwitcherSuperSourceBorderEventTypeBevelPositionChanged**
The border bevel position changed.
- **bmdSwitcherSuperSourceBorderEventTypeHueChanged**
The border hue changed.
- **bmdSwitcherSuperSourceBorderEventTypeSaturationChanged**
The border saturation changed.
- **bmdSwitcherSuperSourceBorderEventTypeLumaChanged**
The border luminescence changed.
- **bmdSwitcherSuperSourceBorderEventTypeLightSourceDirectionChanged**
The border light source direction changed.
- **bmdSwitcherSuperSourceBorderEventTypeLightSourceAltitudeChanged**
The border light source altitude changed.

6.1.3 SuperSource Input Event Type

BMDSwitcherInputSuperSourceEventType enumerates the possible event types for the **IBMDSwitcherInputSuperSource** object interface.

- **bmdSwitcherInputSuperSourceEventTypeInputFillChanged**
The fill input changed.
- **bmdSwitcherInputSuperSourceEventTypeInputCutChanged**
The cut input changed.
- **bmdSwitcherInputSuperSourceEventTypeArtOptionChanged**
The art option changed.
- **bmdSwitcherInputSuperSourceEventTypePreMultipliedChanged**
The pre-multiplied flag changed.
- **bmdSwitcherInputSuperSourceEventTypeClipChanged**
The clip value changed.
- **bmdSwitcherInputSuperSourceEventTypeGainChanged**
The gain changed.
- **bmdSwitcherInputSuperSourceEventTypeInverseChanged**
The inverse flag changed.

6.1.4 SuperSource Art Option

BMDSwitcherSuperSourceArtOption enumerates the possible supersource art options, used by the **IBMDSwitcherInputSuperSource** object interface.

- **bmdSwitcherSuperSourceArtOptionBackground**
Places art in the background.
- **bmdSwitcherSuperSourceArtOptionForeground**
Places art in the foreground.

6.2 Interface Reference

6.2.1 IBMDSwitcherInputSuperSource Interface

The `IBMDSwitcherInputSuperSource` object interface is used for manipulating settings specific to the SuperSource input.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherInput	IID_IBMDSwitcherInput	An <code>IBMDSwitcherInputSuperSource</code> object interface can be obtained with <code>IBMDSwitcherInput::QueryInterface</code> .

Public Member Functions	
Method	Description
<code>GetInputCut</code>	Get the current art cut input.
<code>SetInputCut</code>	Set the art cut input.
<code>GetInputFill</code>	Get the current art fill input.
<code>SetInputFill</code>	Set the art fill input.
<code>GetFillInputAvailabilityMask</code>	Get the availability mask for the fill of this input.
<code>GetCutInputAvailabilityMask</code>	Get the availability mask for the cut of this input.
<code>GetArtOption</code>	Get the current art option.
<code>SetArtOption</code>	Set the art option.
<code>GetPreMultiplied</code>	Get the current art pre-multiplied flag.
<code>SetPreMultiplied</code>	Set the art pre-multiplied flag.
<code>GetClip</code>	Get the current art clip value.
<code>SetClip</code>	Set the art clip value.
<code>GetGain</code>	Get the current art gain.
<code>SetGain</code>	Set the art gain.
<code>GetInverse</code>	Get the current art inverse flag.
<code>SetInverse</code>	Set the art inverse flag.
<code>SupportsBorder</code>	Determine if the SuperSource supports the display of borders.
<code>SetBorderLightSourceAltitude</code>	Set the border light source altitude.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.
<code>CreateIterator</code>	Creates an iterator.

6.2.1.1 IBMDSwitcherInputSuperSource::GetInputCut method

The `GetInputCut` method returns the current art cut input.

Syntax

```
HRESULT GetInputCut (IBMDSwitcherInputId* input);
```

Parameters

Name	Direction	Description
input	out	The current cut input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The input parameter is invalid.

6.2.1.2 IBMDSwitcherInputSuperSource::SetInputCut method

The `SetInputCut` method sets the art cut input.

Syntax

```
HRESULT SetInputCut (IBMDSwitcherInputId input);
```

Parameters

Name	Direction	Description
input	in	The desired cut input.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The input parameter is invalid.

6.2.1.3 IBMDSwitcherInputSuperSource::GetInputFill method

The `GetInputFill` method returns the current art fill input.

Syntax

```
HRESULT GetInputFill (IBMDSwitcherInputId* input);
```

Parameters

Name	Direction	Description
input	out	The current fill input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The input parameter is invalid.

6.2.1.4 IBMDSwitcherInputSuperSource::SetInputFill method

The `SetInputFill` method sets the art fill input.

Syntax

```
HRESULT SetInputFill (BMDSwitcherInputId input);
```

Parameters

Name	Direction	Description
input	in	The desired fill input.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The input parameter is invalid.

6.2.1.5 IBMDSwitcherInputSuperSource::GetFillInputAvailabilityMask method

The `GetFillInputAvailabilityMask` method returns the corresponding `BMDSwitcherInputAvailability` bit mask value for fill inputs available to this supersource input. The input availability property of an `IBMDSwitcherInput` can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a fill input for this supersource.

Syntax

```
HRESULT GetFillInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	<code>BMDSwitcherInputAvailability</code> bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

6.2.1.6 **IBMDSwitcherInputSuperSource::GetCutInputAvailabilityMask** method

The **GetCutInputAvailabilityMask** method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for cut inputs available to this supersource input. The input availability property of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a cut input for this supersource.

Syntax

```
HRESULT GetCutInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	BMDSwitcherInputAvailability bit mask.

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter.

6.2.1.7 **IBMDSwitcherInputSuperSource::GetArtOption** method

The **GetArtOption** method returns the current art option.

Syntax

```
HRESULT GetArtOption (BMDSwitcherSuperSourceArtOption* artOption);
```

Parameters

Name	Direction	Description
artOption	out	The current art option.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The artOption parameter is invalid.

6.2.1.8 IBMDSwitcherInputSuperSource::SetArtOption method

The `SetArtOption` method sets the art option.

Syntax

```
HRESULT SetArtOption (BMDSwitcherSuperSourceArtOption artOption);
```

Parameters

Name	Direction	Description
artOption	in	The desired art option.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The artOption parameter is invalid.

6.2.1.9 IBMDSwitcherInputSuperSource::GetPreMultiplied method

The `GetPreMultiplied` method returns the current art pre-multiplied flag.

Syntax

```
HRESULT GetPreMultiplied (boolean* preMultiplied);
```

Parameters

Name	Direction	Description
preMultiplied	out	The current pre-multiplied flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The preMultiplied parameter is invalid.

6.2.1.10 IBMDSwitcherInputSuperSource::SetPreMultiplied method

The `SetPreMultiplied` method sets the art pre-multiplied flag.

Syntax

```
HRESULT SetPreMultiplied (boolean preMultiplied);
```

Parameters

Name	Direction	Description
preMultiplied	in	The desired pre-multiplied flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The preMultiplied parameter is invalid.

6.2.1.11 IBMDSwitcherInputSuperSource::GetClip method

The `GetClip` method returns the current art clip value.

Syntax

```
HRESULT GetClip (double* clip);
```

Parameters

Name	Direction	Description
clip	out	The current clip value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The clip parameter is invalid.

6.2.1.12 IBMDSwitcherInputSuperSource::SetClip method

The `SetClip` method sets the art clip value.

Syntax

```
HRESULT SetClip (double clip);
```

Parameters

Name	Direction	Description
clip	in	The desired clip value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.1.13 **IBMDSwitcherInputSuperSource::GetGain** method

The **GetGain** method returns the current art gain.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

6.2.1.14 **IBMDSwitcherInputSuperSource::SetGain** method

The **SetGain** method sets the art gain.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.1.15 **IBMDSwitcherInputSuperSource::GetInverse** method

The **GetInverse** method returns the current art inverse flag.

Syntax

```
HRESULT GetInverse (boolean* inverse);
```

Parameters

Name	Direction	Description
inverse	out	The current inverse flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inverse parameter is invalid.

6.2.1.16 IBMDSwitcherInputSuperSource::SetInverse method

The `SetInverse` method sets the art inverse flag.

Syntax

```
HRESULT SetInverse (boolean inverse);
```

Parameters

Name	Direction	Description
inverse	in	The desired inverse flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.1.17 IBMDSwitcherInputSuperSource::SupportsBorder method

The `SupportsBorder` method is used to determine if the switcher supports the display of borders on the SuperSource.

Syntax

```
HRESULT SupportsBorder(Boolea* supportsBorder)
```

Parameters

Name	Direction	Description
supportsBorder	out	Boolean value indicating whether borders are supported by the SuperSource.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsBorder parameter is invalid.

6.2.1.18 IBMDSwitcherInputSuperSource::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherInputSuperSource** object. Pass an object implementing the **IBMDSwitcherInputSuperSourceCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherInputSuperSourceCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherInputSuperSourceCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

6.2.1.19 IBMDSwitcherInputSuperSource::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherInputSuperSourceCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherInputSuperSourceCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

6.2.2 IBMDSwitcherInputSuperSourceCallback Interface

The **IBMDSwitcherInputSuperSourceCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherInputSuperSource** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherInputSuperSource	IID_IBMDSwitcherInputSuperSource	An IBMDSwitcherInputSuperSourceCallback object interface is installed with IBMDSwitcherInputSuperSource::AddCallback and removed with IBMDSwitcherInputSuperSource::RemoveCallback

Public Member Functions

Method	Description
Notify	Called when an event occurs.

6.2.2.1 IBMDSwitcherInputSuperSourceCallback::Notify method

The **Notify** method is called when **IBMDSwitcherInputSuperSource** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherInputSuperSourceEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherInputSuperSourceEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.3 IBMDSwitcherSuperSourceBoxIterator Interface

The `IBMDSwitcherSuperSourceBoxIterator` is used to enumerate the available supersource boxes for a supersource input.

A reference to an `IBMDSwitcherSuperSourceBoxIterator` object interface may be obtained from an `IBMDSwitcherInputSuperSource` object interface using the `CreateIterator` method. Pass `IID_IBMDSwitcherSuperSourceBoxIterator` for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherInputSuperSource</code>	<code>IID_IBMDSwitcherInputSuperSource</code>	<code>IBMDSwitcherInputSuperSource::CreateIterator</code> can return an <code>IBMDSwitcherSuperSourceBoxIterator</code> object interface.

Public Member Functions	
Method	Description
<code>Next</code>	Returns a pointer to the next <code>IBMDSwitcherSuperSourceBox</code> object interface.

6.2.3.1 IBMDSwitcherSuperSourceBoxIterator::Next method

The `Next` method returns the next available `IBMDSwitcherSuperSourceBox` object interface.

Syntax

```
HRESULT Next (IBMDSwitcherSuperSourceBox** box);
```

Parameters

Name	Direction	Description
<code>box</code>	out	<code>IBMDSwitcherSuperSourceBox</code> object interface.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>S_FALSE</code>	No more <code>IBMDSwitcherSuperSourceBox</code> objects available.
<code>E_POINTER</code>	The box parameter is invalid.

6.2.4 IBMDSwitcherSuperSourceBox Interface

The `IBMDSwitcherSuperSourceBox` object interface is used for manipulating supersource box settings.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherSuperSourceBoxIterator</code>	<code>IID_IBMDSwitcherSuperSourceBoxIterator</code>	An <code>IBMDSwitcherSuperSourceBox</code> object will be returned after a successful call to <code>IBMDSwitcherSuperSourceBoxIterator::Next</code> method.

Public Member Functions	
Method	Description
<code>GetEnabled</code>	Get the current enabled flag.
<code>SetEnabled</code>	Set the enabled flag.
<code>GetInputSource</code>	Get the input source.
<code>SetInputSource</code>	Set the input source.
<code>GetPositionX</code>	Get the x position.
<code>SetPositionX</code>	Set the x position.
<code>GetPositionY</code>	Get the y position.
<code>SetPositionY</code>	Set the y position.
<code>GetSize</code>	Get the size.
<code>SetSize</code>	Set the size.
<code>GetCropped</code>	Get the cropped flag.
<code>SetCropped</code>	Set the cropped flag.
<code>GetCropTop</code>	Get the top crop value.
<code>SetCropTop</code>	Set the top crop value.
<code>GetCropBottom</code>	Get the bottom crop value.
<code>SetCropBottom</code>	Set the bottom crop value.
<code>GetCropLeft</code>	Get the left crop value.
<code>SetCropLeft</code>	Set the left crop value.
<code>GetCropRight</code>	Get the right crop value.
<code>SetCropRight</code>	Set the right crop value.
<code>ResetCrop</code>	Reset to default crop values.
<code>GetInputAvailabilityMask</code>	Get the input availability mask.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

6.2.4.1 **IBMDSwitcherSuperSourceBox::GetEnabled** method

The **GetEnabled** method returns the current enabled flag. Enabled supersource boxes are included in the corresponding supersource input.

Syntax

```
HRESULT GetEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
enabled	out	The current enabled flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.

6.2.4.2 **IBMDSwitcherSuperSourceBox::SetEnabled** method

The **SetEnabled** method sets the enabled flag. Enabled supersource boxes are included in the corresponding supersource input.

Syntax

```
HRESULT SetEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	The desired enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.3 **IBMDSwitcherSuperSourceBox::GetInputSource** method

The **GetInputSource** method returns the current input source.

Syntax

```
HRESULT GetInputSource (BMDSwitcherInputId* input);
```

Parameters

Name	Direction	Description
input	out	The current input source's BMDSwitcherInputId .

Return Values

Value	Description
S_OK	Success.
E_POINTER	The input parameter is invalid.

6.2.4.4 **IBMDSwitcherSuperSourceBox::SetInputSource** method

The `SetInputSource` method sets the input source.

Syntax

```
HRESULT SetInputSource (IBMDSwitcherInputId input);
```

Parameters

Name	Direction	Description
input	in	The desired input source's <code>IBMDSwitcherInputId</code> .

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The input parameter is invalid.

6.2.4.5 **IBMDSwitcherSuperSourceBox::GetPositionX** method

The `GetPositionX` method returns the current x position.

Syntax

```
HRESULT GetPositionX (double* positionX);
```

Parameters

Name	Direction	Description
positionX	out	The current x position.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The positionX parameter is invalid.

6.2.4.6 **IBMDSwitcherSuperSourceBox::SetPositionX** method

The `SetPositionX` method sets the x position.

Syntax

```
HRESULT SetPositionX (double positionX);
```

Parameters

Name	Direction	Description
positionX	in	The desired x position.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.7 IBMDSwitcherSuperSourceBox::GetPositionY method

The `GetPositionY` method returns the current y position.

Syntax

```
HRESULT GetPositionY (double* positionY);
```

Parameters

Name	Direction	Description
positionY	out	The current y position.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The positionY parameter is invalid.

6.2.4.8 IBMDSwitcherSuperSourceBox::SetPositionY method

The `SetPositionY` method sets the y position.

Syntax

```
HRESULT SetPositionY (double positionY);
```

Parameters

Name	Direction	Description
positionY	in	The desired y position.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.9 IBMDSwitcherSuperSourceBox::GetSize method

The `GetSize` method returns the current size.

Syntax

```
HRESULT GetSize (double* size);
```

Parameters

Name	Direction	Description
size	out	The current size.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The size parameter is invalid.

6.2.4.10 IBMDSwitcherSuperSourceBox::SetSize method

The `SetSize` method sets the size.

Syntax

```
HRESULT SetSize (double size);
```

Parameters

Name	Direction	Description
size	in	The desired size.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.11 IBMDSwitcherSuperSourceBox::GetCropped method

The `GetCropped` method returns the current cropped flag.

Syntax

```
HRESULT GetCropped (boolean* cropped);
```

Parameters

Name	Direction	Description
cropped	out	The current cropped flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The cropped parameter is invalid.

6.2.4.12 IBMDSwitcherSuperSourceBox::SetCropped method

The `SetCropped` method sets the cropped flag.

Syntax

```
HRESULT SetCropped (boolean cropped);
```

Parameters

Name	Direction	Description
cropped	in	The desired cropped flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.13 **IBMDSwitcherSuperSourceBox::GetCropTop** method

The **GetCropTop** method returns the current top crop value.

Syntax

```
HRESULT GetCropTop (double* top);
```

Parameters

Name	Direction	Description
top	out	The current top crop value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The top parameter is invalid.

6.2.4.14 **IBMDSwitcherSuperSourceBox::SetCropTop** method

The **SetCropTop** method sets the top crop value.

Syntax

```
HRESULT SetCropTop (double top);
```

Parameters

Name	Direction	Description
top	in	The desired top crop value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.15 **IBMDSwitcherSuperSourceBox::GetCropBottom** method

The **GetCropBottom** method returns the current bottom crop value.

Syntax

```
HRESULT GetCropBottom (double* bottom);
```

Parameters

Name	Direction	Description
bottom	out	The current bottom crop value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The bottom parameter is invalid.

6.2.4.16 IBMDSwitcherSuperSourceBox::SetCropBottom method

The `SetCropBottom` method sets the bottom crop value.

Syntax

```
HRESULT SetCropBottom (double bottom);
```

Parameters

Name	Direction	Description
bottom	in	The desired bottom crop value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.17 IBMDSwitcherSuperSourceBox::GetCropLeft method

The `GetCropLeft` method returns the current left crop value.

Syntax

```
HRESULT GetCropLeft (double* left);
```

Parameters

Name	Direction	Description
left	out	The current left crop value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The left parameter is invalid.

6.2.4.18 IBMDSwitcherSuperSourceBox::SetCropLeft method

The `SetCropLeft` method sets the left crop value.

Syntax

```
HRESULT SetCropLeft (double left);
```

Parameters

Name	Direction	Description
left	in	The desired left crop value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.19 IBMDSwitcherSuperSourceBox::GetCropRight method

The `GetCropRight` method returns the current right crop value.

Syntax

```
HRESULT GetCropRight (double* right);
```

Parameters

Name	Direction	Description
right	out	The current right crop value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The right parameter is invalid.

6.2.4.20 IBMDSwitcherSuperSourceBox::SetCropRight method

The `SetCropRight` method sets the right crop value.

Syntax

```
HRESULT SetCropRight (double right);
```

Parameters

Name	Direction	Description
right	in	The desired right crop value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.21 IBMDSwitcherSuperSourceBox::ResetCrop method

The `ResetCrop` method resets the crop to default values.

Syntax

```
HRESULT ResetCrop (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.4.22 **IBMDSwitcherSuperSourceBox::GetInputAvailabilityMask** method

The **GetInputAvailabilityMask** method returns the corresponding **BMDSwitcherInputAvailability** bit mask value for this supersource box. The input availability property of an **IBMDSwitcherInput** can be bitwise-ANDed with this mask value. If the result of the bitwise-AND is equal to the mask value then this input is available for use as a source for this supersource box.

Syntax

```
HRESULT GetInputAvailabilityMask (BMDSwitcherInputAvailability* mask);
```

Parameters

Name	Direction	Description
mask	out	BMDSwitcherInputAvailability bit mask

Return Values

Value	Description
S_OK	Success.
E_POINTER	Invalid mask parameter

6.2.4.23 **IBMDSwitcherSuperSourceBox::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherSuperSourceBox** object. Pass an object implementing the **IBMDSwitcherSuperSourceBoxCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherSuperSourceBoxCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherSuperSourceBoxCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

6.2.4.24 **IBMDSwitcherSuperSourceBox::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherSuperSourceBoxCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherSuperSourceBoxCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

6.2.5 IBMDSwitcherSuperSourceBoxCallback Interface

The **IBMDSwitcherSuperSourceBoxCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherSuperSourceBox** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherSuperSourceBox	IID_ IBMDSwitcherSuperSourceBox	An IBMDSwitcherSuperSourceBoxCallback object interface is installed with IBMDSwitcherSuperSourceBox::AddCallback and removed with IBMDSwitcherSuperSourceBox::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

6.2.5.1 IBMDSwitcherSuperSourceBoxCallback::Notify method

The **Notify** method is called when **IBMDSwitcherSuperSourceBox** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherSuperSourceBoxEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherSuperSourceBoxEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6 IBMDSwitcherSuperSourceBorder Interface

The `IBMDSwitcherSuperSourceBorder` object interface is used for manipulating supersource border settings.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherInputSuperSource</code>	<code>IID_IBMDSwitcherInputSuperSource</code>	An <code>IBMDSwitcherSuperSourceBorder</code> object interface can be obtained with <code>IBMDSwitcherInputSuperSource::QueryInterface</code> .

Public Member Functions	
Method	Description
<code>GetBorderEnabled</code>	Get the current border enabled flag.
<code>SetBorderEnabled</code>	Set the border enabled flag.
<code>GetBorderBevel</code>	Get the current border bevel.
<code>SetBorderBevel</code>	Set the border bevel.
<code>GetBorderWidthOut</code>	Get the current border outer width.
<code>SetBorderWidthOut</code>	Set the border outer width.
<code>GetBorderWidthIn</code>	Get the current border inner width.
<code>SetBorderWidthIn</code>	Set the border inner width.
<code>GetBorderSoftnessOut</code>	Get the current border outer softness.
<code>SetBorderSoftnessOut</code>	Set the border outer softness.
<code>GetBorderSoftnessIn</code>	Get the current border inner softness.
<code>SetBorderSoftnessIn</code>	Set the border inner softness.
<code>GetBorderBevelSoftness</code>	Get the current border bevel softness.
<code>SetBorderBevelSoftness</code>	Set the border bevel softness.
<code>GetBorderBevelPosition</code>	Get the current border bevel position.
<code>SetBorderBevelPosition</code>	Set the border bevel position.
<code>GetBorderHue</code>	Get the current border hue.
<code>SetBorderHue</code>	Set the border hue.
<code>GetBorderSaturation</code>	Get the current border saturation.
<code>SetBorderSaturation</code>	Set the border saturation.
<code>GetBorderLuma</code>	Get the current border luminescence.
<code>SetBorderLuma</code>	Set the border luminescence.
<code>GetBorderLightSourceDirection</code>	Get the current border light source direction.
<code>SetBorderLightSourceDirection</code>	Set the border light source direction.
<code>GetBorderLightSourceAltitude</code>	Get the current border light source altitude.
<code>SetBorderLightSourceAltitude</code>	Set the border light source altitude.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

6.2.6.1 IBMDSwitcherSuperSourceBorder::GetBorderEnabled method

The `GetBorderEnabled` method returns the current border enabled flag.

Syntax

```
HRESULT GetBorderEnabled(Boolean* enabled)
```

Parameters

Name	Direction	Description
enabled	out	The current border enabled flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.

6.2.6.2 IBMDSwitcherSuperSourceBorder::SetBorderEnabled method

The `SetBorderEnabled` method sets the border enabled flag.

Syntax

```
HRESULT SetBorderEnabled(Boolean enabled)
```

Parameters

Name	Direction	Description
enabled	in	The desired border enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.3 IBMDSwitcherSuperSourceBorder::GetBorderBevel method

The `GetBorderBevel` method returns the current border bevel option.

Syntax

```
HRESULT GetBorderBevel(BMDSwitcherBorderBevelOption* bevelOption)
```

Parameters

Name	Direction	Description
bevelOption	out	The current border bevel option.

Return Values

Value	Description
S_OK	Success.
E_UNEXPECTED	Unexpected error occurred.
E_POINTER	The bevelOption parameter is invalid.

6.2.6.4 IBMDSwitcherSuperSourceBorder::SetBorderBevel method

The `SetBorderBevel` method sets the border bevel option.

Syntax

```
HRESULT SetBorderBevel(BMDSwitcherBorderBevelOption bevelOption)
```

Parameters

Name	Direction	Description
bevelOption	in	The desired border bevel option.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The bevelOption parameter is invalid.
E_FAIL	Failure.

6.2.6.5 IBMDSwitcherSuperSourceBorder::GetBorderWidthOut method

The `GetBorderWidthOut` method returns the current border outer width.

Syntax

```
HRESULT GetBorderWidthOut(double* widthOut)
```

Parameters

Name	Direction	Description
widthOut	out	The current border outer width.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The widthOut parameter is invalid.

6.2.6.7 IBMDSwitcherSuperSourceBorder::SetBorderWidthOut method

The `SetBorderWidthOut` method sets the border outer width.

Syntax

```
HRESULT SetBorderWidthOut(double widthOut)
```

Parameters

Name	Direction	Description
widthOut	in	The desired border outer width.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.8 IBMDSwitcherSuperSourceBorder::GetBorderWidthIn method

The `GetBorderWidthIn` method returns the current border inner width.

Syntax

```
HRESULT GetBorderWidthIn(double* widthIn)
```

Parameters

Name	Direction	Description
widthIn	out	The current border inner width.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The widthIn parameter is invalid.

6.2.6.9 IBMDSwitcherSuperSourceBorder::SetBorderWidthIn method

The `SetBorderWidthIn` method sets the border inner width.

Syntax

```
HRESULT SetBorderWidthIn(double widthIn)
```

Parameters

Name	Direction	Description
widthIn	in	The desired border inner width.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.10 IBMDSwitcherSuperSourceBorder::GetBorderSoftnessOut method

The `GetBorderSoftnessOut` method returns the current border outer softness.

Syntax

```
HRESULT GetBorderSoftnessOut(double* softnessOut)
```

Parameters

Name	Direction	Description
softnessOut	out	The current border outer softness.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The softnessOut parameter is invalid.

6.2.6.11 **IBMDSwitcherSuperSourceBorder::SetBorderSoftnessOut** method

The **SetBorderSoftnessOut** method sets the border outer softness.

Syntax

```
HRESULT SetBorderSoftnessOut(double softnessOut)
```

Parameters

Name	Direction	Description
softnessOut	in	The desired border outer softness.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.12 **IBMDSwitcherSuperSourceBorder::GetBorderSoftnessIn** method

The **GetBorderSoftnessIn** method returns the current border inner softness.

Syntax

```
HRESULT GetBorderSoftnessIn(double* softnessIn)
```

Parameters

Name	Direction	Description
softnessIn	out	The current border inner softness.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The softnessIn parameter is invalid.

6.2.6.13 **IBMDSwitcherSuperSourceBorder::SetBorderSoftnessIn** method

The **SetBorderSoftnessIn** method sets the border inner softness.

Syntax

```
HRESULT SetBorderSoftnessIn(double softnessIn)
```

Parameters

Name	Direction	Description
softnessIn	in	The desired border inner softness.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.14 **IBMDSwitcherSuperSourceBorder::GetBorderBevelSoftness** method

The **GetBorderBevelSoftness** method returns the current border bevel softness.

Syntax

```
HRESULT GetBorderBevelSoftness(double* bevelSoftness)
```

Parameters

Name	Direction	Description
bevelSoftness	out	The current border bevel softness.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The bevelSoftness parameter is invalid.

6.2.6.15 **IBMDSwitcherSuperSourceBorder::SetBorderBevelSoftness** method

The **SetBorderBevelSoftness** method sets the border bevel softness.

Syntax

```
HRESULT SetBorderBevelSoftness(double bevelSoftness)
```

Parameters

Name	Direction	Description
bevelSoftness	in	The desired border bevel softness.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.16 **IBMDSwitcherSuperSourceBorder::GetBorderBevelPosition** method

The **GetBorderBevelPosition** method returns the current border bevel position.

Syntax

```
HRESULT GetBorderBevelPosition(double* bevelPosition)
```

Parameters

Name	Direction	Description
bevelPosition	out	The current border bevel position.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The bevelPosition parameter is invalid.

6.2.6.17 **IBMDSwitcherSuperSourceBorder::SetBorderBevelPosition** method

The `SetBorderBevelPosition` method sets the border bevel position.

Syntax

```
HRESULT SetBorderBevelPosition(double bevelPosition)
```

Parameters

Name	Direction	Description
bevelPosition	in	The desired border bevel position.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.18 **IBMDSwitcherSuperSourceBorder::GetBorderHue** method

The `GetBorderHue` method returns the current border hue.

Syntax

```
HRESULT GetBorderHue(double* hue)
```

Parameters

Name	Direction	Description
hue	out	The current border hue.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The hue parameter is invalid.

6.2.6.19 **IBMDSwitcherSuperSourceBorder::SetBorderHue** method

The `SetBorderHue` method sets the border hue.

Syntax

```
HRESULT SetBorderHue(double hue)
```

Parameters

Name	Direction	Description
hue	in	The desired border hue.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.20 **IBMDSwitcherSuperSourceBorder::GetBorderSaturation** method

The **GetBorderSaturation** method returns the current border saturation.

Syntax

```
HRESULT GetBorderSaturation(double* sat)
```

Parameters

Name	Direction	Description
sat	out	The current border saturation.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The sat parameter is invalid.

6.2.6.21 **IBMDSwitcherSuperSourceBorder::SetBorderSaturation** method

The **SetBorderSaturation** method sets the border saturation.

Syntax

```
HRESULT SetBorderSaturation(double sat)
```

Parameters

Name	Direction	Description
sat	in	The desired border saturation.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.22 **IBMDSwitcherSuperSourceBorder::GetBorderLuma** method

The **GetBorderLuma** method returns the current border luminescence.

Syntax

```
HRESULT GetBorderLuma(double* luma)
```

Parameters

Name	Direction	Description
luma	out	The current border luminescence.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The luma parameter is invalid.

6.2.6.23 **IBMDSwitcherSuperSourceBorder::SetBorderLuma** method

The `SetBorderLuma` method sets the border luminescence.

Syntax

```
HRESULT SetBorderLuma(double luma)
```

Parameters

Name	Direction	Description
luma	in	The desired border luminescence.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.24 **IBMDSwitcherSuperSourceBorder::GetBorderLightSourceDirection** method

The `GetBorderLightSourceDirection` method returns the current border light source direction.

Syntax

```
HRESULT GetBorderLightSourceDirection(double* degrees)
```

Parameters

Name	Direction	Description
degrees	out	The current border light source direction in degrees.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The degrees parameter is invalid.

6.2.6.25 **IBMDSwitcherSuperSourceBorder::SetBorderLightSourceDirection** method

The `SetBorderLightSourceDirection` method sets the border light source direction.

Syntax

```
HRESULT SetBorderLightSourceDirection(double degrees)
```

Parameters

Name	Direction	Description
degrees	in	The desired border light source direction in degrees.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.6.26 IBMDSwitcherSuperSourceBorder::GetBorderLightSourceAltitude method

The `GetBorderLightSourceAltitude` method returns the current border light source altitude.

Syntax

```
HRESULT GetBorderLightSourceAltitude(double* altitude)
```

Parameters

Name	Direction	Description
altitude	out	The current border light source altitude.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The altitude parameter is invalid.

6.2.6.27 IBMDSwitcherSuperSourceBorder::SetBorderLightSourceAltitude method

The `SetBorderLightSourceAltitude` method sets the border light source altitude.

Syntax

```
HRESULT SetBorderLightSourceAltitude(double altitude)
```

Parameters

Name	Direction	Description
altitude	in	The desired border light source altitude.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

6.2.7 IBMDSwitcherSuperSourceBorderCallback Interface

The **IBMDSwitcherSuperSourceBorderCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherSuperSourceBorder** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherSuperSourceBorder	IID_IBMDSwitcherSuperSourceBorder	An IBMDSwitcherSuperSourceBorderCallback object interface is installed with IBMDSwitcherSuperSourceBorder::AddCallback and removed with IBMDSwitcherSuperSourceBorder::RemoveCallback .

Public Member Functions

Method	Description
Notify	Called when an event occurs.

6.2.7.1 IBMDSwitcherSuperSourceBorderCallback::Notify method

The **Notify** method is called when **IBMDSwitcherSuperSourceBorder** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(BMDSwitcherSuperSourceBorderEventType eventType)
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherSuperSourceBorderEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

Section 7 — Audio Mixing

Every switcher allows control over how audio is to be mixed into the program output, whether it is sourced from the media players, external audio-in or embedded with the video on an input.

7.1 Original Audio Mixing Data Types

7.1.1 Original Audio Mixer Event Type

BMDSwitcherAudioMixerEventType enumerates the possible event types for the **IBMDSwitcherAudioMixerCallback** object interface.

- **bmdSwitcherAudioMixerEventTypeProgramOutGainChanged**
The program out gain changed.
- **bmdSwitcherAudioMixerEventTypeProgramOutBalanceChanged**
The program out balance changed.

7.1.2 Original Audio Mixer Audio Input Identifier

BMDSwitcherAudioInputId

BMDSwitcherAudioInputId is a signed 64 bit integer type and used as a unique identifier for each audio input.

7.1.3 Original Audio Mixer Audio Input Type

BMDSwitcherAudioInputType enumerates the possible input types for the **IBMDSwitcherAudioInput** object interface.

- **bmdSwitcherAudioInputTypeEmbeddedWithVideo**
The audio is embedded into a switcher input.
- **bmdSwitcherAudioInputTypeMediaPlayer**
The audio is from a media player.
- **bmdSwitcherAudioInputTypeAudioIn**
The audio is from an external audio-in.

7.1.4 Original Audio Mixer Mix Option

BMDSwitcherAudioMixOption enumerates the possible mix options for the **IBMDSwitcherAudioInput** object interface.

- **bmdSwitcherAudioMixOptionOff**
The audio is not to be mixed into anything.
- **bmdSwitcherAudioMixOptionOn**
The audio is always mixed into the output.
- **bmdSwitcherAudioMixOptionAudioFollowVideo**
The audio is mixed into the output when its associated video is on air.

7.1.5 Original Audio Mixer Audio Input Event Type

BMDSwitcherAudioInputEventType enumerates the possible event types for the **IBMDSwitcherAudioInputCallback** object interface.

- **bmdSwitcherAudioInputEventTypeMixOptionChanged**
The mix option changed.
- **bmdSwitcherAudioInputEventTypeGainChanged**
The gain changed.
- **bmdSwitcherAudioInputEventTypeBalanceChanged**
The balance changed.
- **bmdSwitcherAudioInputEventTypeCurrentExternalPortTypeChanged**
The audio input's external port type changed.
- **bmdSwitcherAudioInputEventTypeIsMixedInChanged**
The is-mixed-in changed.

7.1.6 Original Audio Mixer Monitor Output Event Type

BMDSwitcherAudioMonitorOutputEventType enumerates the possible event types for the **IBMDSwitcherAudioMonitorOutputCallback** object interface.

- **bmdSwitcherAudioMonitorOutputEventTypeMonitorEnableChanged**
The monitor enable flag changed.
- **bmdSwitcherAudioMonitorOutputEventTypeGainChanged**
The gain changed.
- **bmdSwitcherAudioMonitorOutputEventTypeMuteChanged**
The mute changed.
- **bmdSwitcherAudioMonitorOutputEventTypeSoloChanged**
The solo flag changed.
- **bmdSwitcherAudioMonitorOutputEventTypeSoloInputChanged**
The input that is soloed changed.
- **bmdSwitcherAudioMonitorOutputEventTypeDimChanged**
The dim flag changed.
- **bmdSwitcherAudioMonitorOutputEventTypeDimLevelChanged**
The dim level changed.

7.1.7 Original Audio Mixer Audio Headphone Output Event Type

BMDSwitcherAudioHeadphoneOutputEventType enumerates the possible event types for the **IBMDSwitcherAudioHeadphoneOutput** object interface.

- **bmdSwitcherAudioHeadphoneOutputEventTypeGainChanged**
The gain of the headphone output has changed.
- **bmdSwitcherAudioHeadphoneOutputEventTypeInputProgramOutGainChanged**
The gain of the program out input to the headphone output has changed.
- **bmdSwitcherAudioHeadphoneOutputEventTypeInputTalkbackGainChanged**
The gain of the talkback input to the headphone output has changed.
- **bmdSwitcherAudioHeadphoneOutputEventTypeInputSidetoneGainChanged**
The gain of the sidetone (microphone) input to the headphone output has changed.

7.2 Fairlight Audio Mixing Data Types

7.2.1 Fairlight Audio Mixer Event Type

BMDSwitcherFairlightAudioMixerEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioMixerCallback** object interface.

- **bmdSwitcherFairlightAudioMixerEventTypeMasterOutFaderGainChanged**
The master out fader gain changed.
- **bmdSwitcherFairlightAudioMixerEventTypeMasterOutFollowFadeToBlackChanged**
The master out follow fade to black changed.
- **bmdSwitcherFairlightAudioMixerEventTypeAudioFollowVideo CrossfadeTransitionChanged**
The audio follow video crossfade transition changed.

7.2.2 Fairlight Audio Input Type

BMDSwitcherFairlightAudioInputType enumerates the possible input types for the **IBMDSwitcherFairlightAudioInput** object interface.

- **bmdSwitcherFairlightAudioInputTypeMediaPlayer**
The audio is from a media player.
- **bmdSwitcherFairlightAudioInputTypeMediaPlayer**
The audio is from a media player
- **bmdSwitcherFairlightAudioInputTypeMADI**
The audio is from a MADI input.

7.2.3 Fairlight Audio Input Configuration

BMDSwitcherFairlightAudioInputConfiguration enumerates the possible input types for the **IBMDSwitcherFairlightAudioInput** object interface.

- **bmdSwitcherFairlightAudioInputConfigurationMono**
The input configuration is mono.
- **bmdSwitcherFairlightAudioInputConfigurationStereo**
The input configuration is stereo.
- **bmdSwitcherFairlightAudioInputConfigurationDualMono**
The input configuration is dual mono.

7.2.4 Fairlight Audio Source Identifier

BMDSwitcherFairlightAudioSourceId.

- **BMDSwitcherFairlightAudioSourceId** is a signed 64-bit integer type and used as a unique identifier for each Fairlight audio source.

7.2.5 Fairlight Audio Source Type

BMDSwitcherFairlightAudioSourceType enumerates the possible source types for the **IBMDSwitcherFairlightAudioSource** object interface.

- **bmdSwitcherFairlightAudioSourceTypeMono**
The source type is mono.
- **bmdSwitcherFairlightAudioSourceTypeStereo**
The source type is stereo.

7.2.6 Fairlight Audio Mix Option

BMDSwitcherFairlightAudioMixOption enumerates the possible mix options for the **IBMDSwitcherFairlightAudioSource** object interface.

- **bmdSwitcherFairlightAudioMixOptionOff**
The audio is not to be mixed into anything
- **bmdSwitcherFairlightAudioMixOptionOn**
The audio is always mixed into the output.
- **bmdSwitcherFairlightAudioMixOptionAudioFollowVideo**
The audio is mixed into the output when its associated video is on air.

7.2.7 Fairlight Audio Equalizer Band Shape

BMDSwitcherFairlightAudioEqualizerBandShape enumerates the possible band shapes for the **IBMDSwitcherFairlightAudioEqualizerBand** object interface.

- **bmdSwitcherFairlightAudioEqualizerBandShapeLowShelf**
The band shape is low shelf.
- **bmdSwitcherFairlightAudioEqualizerBandShapeLowPass**
The band shape is low pass.
- **bmdSwitcherFairlightAudioEqualizerBandShapeBandPass**
The band shape is band pass.
- **bmdSwitcherFairlightAudioEqualizerBandShapeNotch**
The band shape is notch.
- **bmdSwitcherFairlightAudioEqualizerBandShapeHighPass**
The band shape is high pass.
- **bmdSwitcherFairlightAudioEqualizerBandShapeHighShelf**
The band shape is high shelf.

7.2.8 Fairlight Audio Equalizer Band Frequency Range

BMDSwitcherFairlightAudioEqualizerBandFrequencyRange enumerates the possible frequency ranges for the **IBMDSwitcherFairlightAudioEqualizerBand** object interface.

- **bmdSwitcherFairlightAudioEqualizerBandFrequencyRangeLow**
The band frequency range is low.
- **bmdSwitcherFairlightAudioEqualizerBandFrequencyRangeMidLow**
The band frequency range is mid low.
- **bmdSwitcherFairlightAudioEqualizerBandFrequencyRangeMidHigh**
The band frequency range is mid high.
- **bmdSwitcherFairlightAudioEqualizerBandFrequencyRangeHigh**
The band frequency range is high.

7.2.9 Fairlight Audio Analog Input Level

BMDSwitcherFairlightAudioAnalogInputLevel enumerates the different input level settings for Fairlight analog audio inputs. This enumeration represents a bitset since an input may support multiple levels.

- **bmdSwitcherFairlightAudioAnalogInputLevelMicrophone**
Microphone input level.
- **bmdSwitcherFairlightAudioAnalogInputLevelConsumerLine**
Consumer line level (-10 dBV).
- **bmdSwitcherFairlightAudioAnalogInputLevelProLine**
Professional line level (+4 dBu).

7.2.10 Fairlight Audio Analog Input Mic Power Mode

BMDSwitcherFairlightAudioAnalogInputMicPowerMode enumerates the different microphone power mode settings for Fairlight analog audio inputs. This enumeration represents a bitset since an input may support multiple power modes.

- **bmdSwitcherFairlightAudioAnalogInputMicPowerModeNoPower**
No power supplied to microphone.
- **bmdSwitcherFairlightAudioAnalogInputMicPowerModePlugInPower**
Plug-in power is supplied to microphone

7.2.11 Fairlight Audio Input Event Type

BMDSwitcherFairlightAudioInputEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioInputCallback** object interface.

- **bmdSwitcherFairlightAudioInputEventTypeCurrentExternalPortTypeChanged**
The audio input's external port type changed.
- **bmdSwitcherFairlightAudioInputEventTypeConfigurationChanged**
The audio input's configuration changed.

7.2.12 Fairlight Audio Source Event Type

BMDSwitcherFairlightAudioSourceEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioSource** object interface.

- **bmdSwitcherFairlightAudioSourceEventTypesActiveChanged**
The is active property of the audio source has changed.
- **bmdSwitcherFairlightAudioSourceEventTypeMaxDelayFramesChanged**
The max delay frames of the audio source has changed.
- **bmdSwitcherFairlightAudioSourceEventTypeDelayFramesChanged**
The delay frames of the audio source has changed.
- **bmdSwitcherFairlightAudioSourceEventTypeInputGainChanged**
The input gain of the audio source has changed.
- **bmdSwitcherFairlightAudioSourceEventTypeStereoSimulationIntensityChanged**
The stereo simulation intensity of the audio source has changed.
- **bmdSwitcherFairlightAudioSourceEventTypePanChanged**
The pan of the audio source has changed.
- **bmdSwitcherFairlightAudioSourceEventTypeFaderGainChanged**
The fader gain of the audio source has changed.
- **bmdSwitcherFairlightAudioSourceEventTypeMixOptionChanged**
The mix option of the audio source has changed.
- **bmdSwitcherFairlightAudioSourceEventTypesMixedInChanged**
The mixed in of the audio source has changed.

7.2.13 Fairlight Audio Equalizer Event Type

BMDSwitcherFairlightAudioEqualizerEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioEqualizer** object interface.

- **bmdSwitcherFairlightAudioEqualizerEventTypeEnabledChanged**
The enable state of the equalizer has changed.
- **bmdSwitcherFairlightAudioEqualizerEventTypeGainChanged**
The gain of the equalizer has changed.

7.2.14 Fairlight Audio Equalizer Band Event Type

BMDSwitcherFairlightAudioEqualizerBandEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioEqualizerBand** object interface.

- **bmdSwitcherFairlightAudioEqualizerBandEventTypeEnabledChanged**
The enable of the equalizer band has changed.
- **bmdSwitcherFairlightAudioEqualizerBandEventTypeShapeChanged**
The shape of the equalizer band has changed.
- **bmdSwitcherFairlightAudioEqualizerBandEventTypeFrequencyRangeChanged**
The frequency range of the equalizer band has changed.
- **bmdSwitcherFairlightAudioEqualizerBandEventTypeFrequencyChanged**
The frequency of the equalizer band has changed.
- **bmdSwitcherFairlightAudioEqualizerBandEventTypeGainChanged**
The gain of the equalizer band has changed.
- **bmdSwitcherFairlightAudioEqualizerBandEventTypeQFactorChanged**
The Q factor of the equalizer band has changed.

7.2.15 Fairlight Audio Dynamics Event Type

BMDSwitcherFairlightAudioDynamicsProcessorEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioDynamicsProcessor** object interface.

- **bmdSwitcherFairlightAudioDynamicsProcessorEventTypeMakeupGainChanged**
The make up gain of the dynamics processor has changed.

7.2.16 Fairlight Audio Limiter Event Type

BMDSwitcherFairlightAudioLimiterEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioLimiter** object interface.

- **bmdSwitcherFairlightAudioLimiterEventTypeEnabledChanged**
The enable state of the limiter has changed.
- **bmdSwitcherFairlightAudioLimiterEventTypeThresholdChanged**
The threshold of the limiter has changed.
- **bmdSwitcherFairlightAudioLimiterEventTypeAttackChanged**
The attack of the limiter has changed.
- **bmdSwitcherFairlightAudioLimiterEventTypeHoldChanged**
The hold of the limiter has changed.
- **bmdSwitcherFairlightAudioLimiterEventTypeReleaseChanged**
The release of the limiter has changed.

7.2.17 Fairlight Audio Compressor Event Type

BMDSwitcherFairlightAudioCompressorEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioCompressor** object interface.

- **bmdSwitcherFairlightAudioCompressorEventTypeEnabledChanged**
The enable of the compressor has changed.
- **bmdSwitcherFairlightAudioCompressorEventTypeThresholdChanged**
The threshold of the compressor has changed.
- **bmdSwitcherFairlightAudioCompressorEventTypeRatioChanged**
The ratio of the compressor has changed.
- **bmdSwitcherFairlightAudioCompressorEventTypeAttackChanged**
The attack of the compressor has changed.
- **bmdSwitcherFairlightAudioCompressorEventTypeHoldChanged**
The hold of the compressor has changed.
- **bmdSwitcherFairlightAudioCompressorEventTypeReleaseChanged**
The release of the compressor has changed.

7.2.18 Fairlight Audio Expander Event Type

BMDSwitcherFairlightAudioExpanderEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioExpander** object interface.

- **bmdSwitcherFairlightAudioExpanderEventTypeEnabledChanged**
The enable state of the expander has changed.
- **bmdSwitcherFairlightAudioExpanderEventTypeGateModeChanged**
The gate mode of the expander has changed.
- **bmdSwitcherFairlightAudioExpanderEventTypeThresholdChanged**
The threshold of the expander has changed.
- **bmdSwitcherFairlightAudioExpanderEventTypeRangeChanged**
The range of the expander has changed.
- **bmdSwitcherFairlightAudioExpanderEventTypeRatioChanged**
The ratio of the expander has changed.
- **bmdSwitcherFairlightAudioExpanderEventTypeAttackChanged**
The attack of the expander has changed.
- **bmdSwitcherFairlightAudioExpanderEventTypeHoldChanged**
The hold of the expander has changed.
- **bmdSwitcherFairlightAudioExpanderEventTypeReleaseChanged**
The release of the expander has changed.

7.2.19 Fairlight Audio Headphone Output Event Type

BMDSwitcherFairlightAudioHeadphoneOutputEventType enumerates the possible event types for the **IBMDSwitcherFairlightAudioHeadphoneOutput** object interface.

- **bmdSwitcherFairlightAudioHeadphoneOutputEventTypeGainChanged**
The gain of the headphone output has changed.
- **bmdSwitcherFairlightAudioHeadphoneOutputEventTypeInput MasterOutGainChanged**
The gain of the master out input to the headphone output has changed.
- **bmdSwitcherFairlightAudioHeadphoneOutputEventTypeInput TalkbackGainChanged**
The gain of the talkback input to the headphone output has changed.
- **bmdSwitcherFairlightAudioHeadphoneOutputEventTypeInput SidetoneGainChanged**
The gain of the sidetone (microphone) input to the headphone output has changed.
- **bmdSwitcherFairlightAudioHeadphoneOutputEventTypeInputMasterOutMuteChanged**
The mute of the master out input to the headphone output has changed.
- **bmdSwitcherFairlightAudioHeadphoneOutputEventTypeInputTalkbackMuteChanged**
The mute of the talkback input to the headphone output has changed.

7.2.20 Fairlight Audio Solo Event Type

BMDSwitcherFairlightAudioSoloEventType enumerates the possible event types for **IBMDSwitcherFairlightAudioSoloCallback**.

- **bmdSwitcherFairlightAudioSoloEventTypeSoloChanged**
Solo state changed.
- **bmdSwitcherFairlightAudioSoloEventTypeSoloInputChanged**
Solo input changed.

7.2.21 Fairlight Analog Audio Input Event Type

BMDSwitcherFairlightAnalogAudioInputEventType enumerates the possible event types for **IBMDSwitcherFairlightAnalogAudioInputCallback**.

- **bmdSwitcherFairlightAnalogAudioInputEventTypeLevelChanged**
The analog input level setting changed.
- **bmdSwitcherFairlightAnalogAudioInputEventTypePowerModeChanged**
The analog input power mode setting changed.

7.3 Talkback Data Types

7.3.1 Switcher Talkback Event Type

BMDSwitcherTalkbackEventType enumerates the possible event types for the **IBMDSwitcherTalkbackCallback** object interface.

- **bmdSwitcherTalkbackEventTypeMuteSDIChanged**
The mute state of the talkback input SDI channels has changed.
- **bmdSwitcherTalkbackEventTypeInputMuteSDIChanged**
The mute state of a talkback input SDI channel has changed.
- **bmdSwitcherTalkbackEventTypeCurrentInputSupportsMuteSDIChanged**
The input port has changed from/to an SDI port to/from a non-SDI port. As talkback is carried via SDI, the talkback mute setting has no effect when the input is on a non-SDI port.

7.3.2 Switcher Talkback ID Type

BMDSwitcherTalkbackId enumerates the possible talkback ID types for the **IBMDSwitcherTalkback** object interface.

- **bmdSwitcherTalkbackIdProduction**
The talkback ID is a production talkback ID.
- **bmdSwitcherTalkbackIdEngineering**
The talkback ID is an engineering talkback ID.

7.4 Original Audio Mixing Interface Reference

7.4.1 IBMDSwitcherAudioMixer Interface

The **IBMDSwitcherAudioMixer** object interface is the root object for all original audio mixing control and feedback.

A reference to an **IBMDSwitcherAudioMixer** object interface may be obtained from an **IBMDSwitcher** object interface using the **QueryInterface** method. Pass **IID_IBMDSwitcherAudioMixer** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	IBMDSwitcher::QueryInterface can return an IBMDSwitcherAudioMixer object interface.

Public Member Functions	
Method	Description
GetProgramOutGain	Get the current program out gain value.
SetProgramOutGain	Set the program out gain value.
GetProgramOutBalance	Get the current program out balance value.
SetProgramOutBalance	Set the program out balance value.
GetProgramOutFollowFadeToBlack	Get the current program out follow fade to black state.
SetProgramOutFollowFadeToBlack	Set the current program out follow fade to black state.
GetAudioFollowVideoCrossfadeTransition	Get the current audio follow video crossfade transition state.
SetAudioFollowVideoCrossfadeTransition	Set the audio follow video crossfade transition state.
SetAllLevelNotificationsEnable	Opt-in to level notifications.
ResetProgramOutLevelNotificationPeaks	Reset program out peak level statistics to zero.
ResetAllLevelNotificationPeaks	Reset all switcher peak level statistics to zero.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.
CreateIterator	Create an iterator.

7.4.1.1 **IBMDSwitcherAudioMixer::GetProgramOutGain** method

The `GetProgramOutGain` method returns the current gain value.

Syntax

```
HRESULT GetProgramOutGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.4.1.2 **IBMDSwitcherAudioMixer::SetProgramOutGain** method

The `SetProgramOutGain` method sets the gain to apply to the program out.

Syntax

```
HRESULT SetProgramOutGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.1.3 **IBMDSwitcherAudioMixer::GetProgramOutBalance** method

The `GetProgramOutBalance` method returns the current balance value.

Syntax

```
HRESULT GetProgramOutBalance (double* balance);
```

Parameters

Name	Direction	Description
balance	out	The current balance value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The balance parameter is invalid.

7.4.1.4 **IBMDSwitcherAudioMixer::GetProgramOutFollowFadeToBlack** method

The **GetProgramOutFollowFadeToBlack** method returns the current follow fade to black state. When enabled the program out audio will fade in unity with a fade to black transition.

Syntax

```
HRESULT GetProgramOutFollowFadeToBlack (boolean* follow)
```

Parameters

Name	Direction	Description
follow	out	The current follow fade to black state.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The balance parameter is invalid.

7.4.1.5 **IBMDSwitcherAudioMixer::SetProgramOutFollowFadeToBlack** method

The **SetProgramOutFollowFadeToBlack** method sets the current follow fade to black state. When enabled the program out audio will fade in unity with a fade to black transition.

Syntax

```
HRESULT SetProgramOutFollowFadeToBlack (boolean follow)
```

Parameters

Name	Direction	Description
follow	in	The desired follow fade to black state.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

7.4.1.6 **IBMDSwitcherAudioMixer::SetProgramOutBalance** method

The **SetProgramOutBalance** method sets the balance to apply to the program out.

Syntax

```
HRESULT SetProgramOutBalance (double balance);
```

Parameters

Name	Direction	Description
balance	in	The desired balance value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.1.7 **IBMDSwitcherAudioMixer::GetAudioFollowVideoCrossfadeTransition**

The **GetAudioFollowVideoCrossfadeTransition** method returns the current follow video with crossfade transition state. When enabled the audio will crossfade with the video.

Syntax

```
HRESULT GetAudioFollowVideoCrossfadeTransition (Boolean* transition)
```

Parameters

Name	Direction	Description
transition	out	The current follow video with crossfade transition state.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The transition parameter is invalid.

7.4.1.8 **IBMDSwitcherAudioMixer::SetAudioFollowVideoCrossfadeTransition**

The **SetAudioFollowVideoCrossfadeTransition** method sets the current follow video with crossfade transition state. When enabled the audio will crossfade with the video.

Syntax

```
HRESULT SetAudioFollowVideoCrossfadeTransition (Boolean transition)
```

Parameters

Name	Direction	Description
transition	in	The desired follow video with crossfade transition state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.1.9 **IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable** method

The **SetAllLevelNotificationsEnable** method enables level statistics for the relevant mixer inputs and outputs. Receiving level notifications are an opt-in subscription, affecting the callbacks **IBMDSwitcherAudioMixerCallback::ProgramOutLevelNotification**, **IBMDSwitcherAudioInputCallback::LevelNotification** and **IBMDSwitcherAudioMonitorOutputCallback::LevelNotification**.

Syntax

```
HRESULT SetAllLevelNotificationsEnable (boolean enable);
```

Parameters

Name	Direction	Description
enable	in	Whether to enable notifications.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.1.10 **IBMDSwitcherAudioMixer::ResetProgramOutLevelNotificationPeaks** method

The **ResetLevelNotificationPeaks** method resets's the switcher's program out peak level statistics to zero.

Syntax

```
HRESULT ResetProgramOutLevelNotificationPeaks (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.1.11 **IBMDSwitcherAudioMixer::ResetAllLevelNotificationPeaks** method

The **ResetAllLevelNotificationPeaks** method resets peak statistics to zero for all original audio mixer inputs and outputs.

Syntax

```
HRESULT ResetAllLevelNotificationPeaks (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.1.12 **IBMDSwitcherAudioMixer::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherAudioMixer** object. Pass an object implementing the **IBMDSwitcherAudioMixerCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherAudioMixerCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioMixerCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.113 **IBMDSwitcherAudioMixer::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherAudioMixerCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioMixerCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.114 **IBMDSwitcherAudioMixer::CreateIterator** method

The **CreateIterator** method creates an iterator object interface for the specified interface ID, such as **IBMDSwitcherAudioInputIterator** and **IBMDSwitcherAudioMonitorOutputIterator**.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Iterator Interface ID to create an iterator for.
ppv	in	Pointer to return interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_OUTOFMEMORY	Insufficient memory to create interface object.
E_NOINTERFACE	Interface was not found.

7.4.2 IBMDSwitcherAudioMixerCallback Interface

The **IBMDSwitcherAudioMixerCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherAudioMixer** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherAudioMixer	IID_IBMDSwitcherAudioMixer	An IBMDSwitcherAudioMixerCallback object interface is installed with IBMDSwitcherAudioMixer::AddCallback and removed with IBMDSwitcherAudioMixer::RemoveCallback

Public Member Functions

Method	Description
Notify	Called when an event occurs.
ProgramOutLevelNotification	Reports level statistics.

7.4.2.1 IBMDSwitcherAudioMixerCallback::Notify method

The **Notify** method is called when **IBMDSwitcherAudioMixer** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherAudioMixerEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherAudioMixerEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.2.2 **IBMDSwitcherAudioMixerCallback::ProgramOutLevelNotification** method

The **ProgramOutLevelNotification** method is called periodically to report the current dB levels and the last known peak levels. These peak levels can be reset using

IBMDSwitcherAudioMixer::ResetProgramOutLevelNotificationPeaks.

Note that this is an opt-in subscription. Enable or disable receiving these calls using

IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT ProgramOutLevelNotification (double left, double right, peakRight);
```

Parameters

Name	Direction	Description
left	in	The current dB level of the left channel.
right	in	The current dB level of the right channel.
peakLeft	in	The highest encountered peak dB level of the left channel since the last reset.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.3 **IBMDSwitcherAudioInputIterator** Interface

The **IBMDSwitcherAudioInputIterator** is used to enumerate the available inputs for the original audio mixer.

A reference to an **IBMDSwitcherAudioInputIterator** object interface may be obtained from an **IBMDSwitcherAudioMixer** object interface using the **CreateIterator** method. Pass **IID_IBMDSwitcherAudioInputIterator** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherAudioMixer	IID_IBMDSwitcherAudioMixer	IBMDSwitcherAudioMixer::CreateIterator can return an IBMDSwitcherAudioInputIterator object interface.

Public Member Functions	
Method	Description
Next	Returns a pointer to the next IBMDSwitcherAudioInput object interface.
GetById	Returns a pointer to an IBMDSwitcherAudioInput object interface, given its BMDSwitcherAudioInputId .

7.4.3.1 IBMDSwitcherAudioInputIterator::Next method

The `Next` method returns the next available `IBMDSwitcherAudioInput` object interface.

Syntax

```
HRESULT Next (IBMDSwitcherAudioInput* audioInput);
```

Parameters

Name	Direction	Description
audioInput	out	IBMDSwitcherAudioInput object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No more <code>IBMDSwitcherAudioInput</code> objects available.
E_POINTER	The audioInput parameter is invalid.

7.4.3.2 IBMDSwitcherAudioInputIterator::GetById method

The `GetById` method returns a pointer to an `IBMDSwitcherAudioInput` object interface, given its `BMDSwitcherAudioInputId`.

Syntax

```
HRESULT GetById (BMDSwitcherAudioInputId audioInputId, IBMDSwitcherAudioInput* audioInput);
```

Parameters

Name	Direction	Description
audioInputId	in	<code>BMDSwitcherAudioInputId</code> identifier.
audioInput	out	IBMDSwitcherAudioInput object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The audioInputId is not a valid identifier.
E_POINTER	The audioInput parameter is invalid.

7.4.4 IBMDSwitcherAudioInput Interface

The **IBMDSwitcherAudioInput** object interface is used for manipulating the settings of an original audio mixer audio input.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherAudioInputIterator	IID_IBMDSwitcherAudioInputIterator	An IBMDSwitcherAudioInput object interface will be returned after a successful call to IBMDSwitcherAudioInputIterator::Next method.

Public Member Functions	
Method	Description
GetType	Get the audio input type.
GetCurrentExternalPortType	Get the current physical external port type of the audio input.
GetMixOption	Get the current mix option.
SetMixOption	Set the mix option.
GetGain	Get the current gain value.
SetGain	Set the gain value.
GetBalance	Get the current balance value.
SetBalance	Set the balance value.
IsMixedIn	Get the current is-mixed-in flag.
GetAudioInputId	Returns the ID of this IBMDSwitcherAudioInput interface.
ResetLevelNotificationPeaks	Reset peak level statistics to zero.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

7.4.4.1 IBMDSwitcherAudioInput::GetType method

The **GetType** method returns the type of the original audio mixer audio input.

Syntax

```
HRESULT GetType (BMDSwitcherAudioInputType* type);
```

Parameters

Name	Direction	Description
type	out	The audio input type.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The type parameter is invalid.

7.4.4.2 **IBMDSwitcherAudioInput::GetCurrentExternalPortType** method

The **GetCurrentExternalPortType** method gets the current physical external port type of the original audio mixer audio input. This may change if the physical input is switchable, generating the event **bmdSwitcherAudioInputEventTypeCurrentExternalPort TypeChanged**.

Syntax

```
HRESULT GetCurrentExternalPortType (BMDSwitcherExternalPortType* type);
```

Parameters

Name	Direction	Description
type	out	The current external port type.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The type parameter is invalid.

7.4.4.3 **IBMDSwitcherAudioInput::GetMixOption** method

The **GetMixOption** method returns the mix option of the original audio mixer audio input.

Syntax

```
HRESULT GetMixOption (BMDSwitcherAudioMixOption* mixOption);
```

Parameters

Name	Direction	Description
mixOption	out	The audio input mix option.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The mixOption parameter is invalid.

7.4.4.4 IBMDSwitcherAudioInput::SetMixOption method

The `SetMixOption` method sets the mix option of the original audio mixer audio input.

Syntax

```
HRESULT SetMixOption (BMDSwitcherAudioMixOption mixOption);
```

Parameters

Name	Direction	Description
mixOption	in	The audio input mix option.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The mixOption parameter is invalid.

7.4.4.5 IBMDSwitcherAudioInput::GetGain method

The `GetGain` method returns the gain currently applied to the original audio mixer audio input.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The gain currently applied to the audio input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.4.4.6 IBMDSwitcherAudioInput::SetGain method

The `SetGain` method sets the gain to apply to the original audio mixer audio input.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The gain to apply to the audio input.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.4.7 IBMDSwitcherAudioInput::GetBalance method

The `GetBalance` method returns the current balance for the original audio mixer audio input.

Syntax

```
HRESULT GetBalance (double* balance);
```

Parameters

Name	Direction	Description
balance	out	The current balance.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The balance parameter is invalid.

7.4.4.8 IBMDSwitcherAudioInput::SetBalance method

The **SetBalance** method sets the balance to apply to the original audio mixer audio input.

Syntax

```
HRESULT SetBalance (double balance);
```

Parameters

Name	Direction	Description
balance	in	The balance to apply.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The balance parameter is invalid.

7.4.4.9 IBMDSwitcherAudioInput::IsMixedIn method

The **IsMixedIn** method indicates whether the original audio mixer audio input is currently being mixed into the program out.

Syntax

```
HRESULT IsMixedIn (boolean* mixedIn);
```

Parameters

Name	Direction	Description
mixedIn	out	The current mixed-in flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The mixedIn parameter is invalid.

7.4.4.10 **IBMDSwitcherAudioInput::GetAudioInputId** method

The **GetAudioInputId** method returns the **BMDSwitcherAudioInputId** of the original audio mixer audio input.

Syntax

```
HRESULT GetAudioInputId (BMDSwitcherAudioInputId* audioInputId);
```

Parameters

Name	Direction	Description
audioInputId	out	The BMDSwitcherAudioInputId of the audio input.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.4.11 **IBMDSwitcherAudioInput::ResetLevelNotificationPeaks** method

The **ResetLevelNotificationPeaks** method resets the switcher's input peak level statistics for the original audio mixer audio input to zero.

Syntax

```
HRESULT ResetLevelNotificationPeaks (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.4.12 **IBMDSwitcherAudioInput::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherAudioInput** object. Pass an object implementing the **IBMDSwitcherAudioInputCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherAudioInputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioInputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.4.13 **IBMDSwitcherAudioInput::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherAudioInputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioInputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.5 IBMDSwitcherAudioInputCallback Interface

The **IBMDSwitcherAudioInputCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherAudioInput** object.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherAudioInput	IID_IBMDSwitcherAudioInput	An IBMDSwitcherAudioInputCallback object interface is installed with IBMDSwitcherAudioInput::AddCallback and removed with IBMDSwitcherAudioInput::RemoveCallback

Public Member Functions

Method	Description
Notify	Called when an event occurs.
LevelNotification	Reports level statistics.

7.4.5.1 IBMDSwitcherAudioInputCallback::Notify method

The **Notify** method is called when **IBMDSwitcherAudioInput** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherAudioInputEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherAudioInputEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.5.2 IBMDSwitcherAudioInputCallback::LevelNotification method

The **LevelNotification** method is called periodically to report the current dB levels and the last known peak levels for the original audio mixer audio input. These peak levels can be reset using **IBMDSwitcherAudioInput::ResetLevelNotificationPeaks**.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT LevelNotification (double left, double right,  
double peakLeft, double peakRight);
```

Parameters

Name	Direction	Description
left	in	The current dB level of the left channel.
right	in	The current dB level of the right channel.
peakLeft	in	The highest encountered peak dB level of the left channel since the last reset.
peakRight	in	The highest encountered peak dB level of the right channel since the last reset.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.6 IBMDSwitcherAudioInputXLR Interface

The `IBMDSwitcherAudioInputXLR` object interface is used for manipulating the original audio mixer XLR input settings.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherAudioInput</code>	<code>IID_IBMDSwitcherAudioInput</code>	<code>IBMDSwitcherAudioInput::QueryInterface</code> can return an <code>IBMDSwitcherAudioInputXLR</code> object interface.

Public Member Functions

Method	Description
<code>HasRCAToXLR</code>	Determine if the input has the capability of converting the input level from RCA to XLR.
<code>GetRCAToXLREnabled</code>	Query the RCA to XLR state of the XLR input.
<code>SetRCAToXLREnabled</code>	Set the RCA to XLR state of the XLR input.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

7.4.6.1 IBMDSwitcherAudioInputXLR::HasRCAToXLR method

The `HasRCAToXLR` method is used to check if the switcher input has the capability to convert the input level from RCA to XLR.

Syntax

```
HRESULT HasRCAToXLR (boolean* hasRcaToXlr);
```

Parameters

Name	Direction	Description
<code>hasRcaToXlr</code>	out	A Boolean value indicating whether the switcher input has the capability to convert the input level from RCA to XLR.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The <code>hasRcaToXlr</code> parameter is not a valid pointer.

7.4.6.2 IBMDSwitcherAudioInputXLR::GetRCAToXLREnabled method

The **GetRCAToXLREnabled** method returns the RCA to XLR enabled state of the original audio mixer audio input.

Syntax

```
HRESULT GetRCAToXLREnabled (boolean* rcaToXlrEnabled);
```

Parameters

Name	Direction	Description
rcaToXlrEnabled	out	The RCA to XLR state of the audio input

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The rcaToXlrEnabled parameter is invalid.

7.4.6.3 IBMDSwitcherAudioInputXLR::SetRCAToXLREnabled method

The **SetRCAToXLREnabled** method sets the RCA to XLR enabled state of the original audio mixer audio input.

Syntax

```
HRESULT SetRCAToXLREnabled (boolean rcaToXlrEnabled);
```

Parameters

Name	Direction	Description
rcaToXlrEnabled	in	The RCA to XLR state of the audio input

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.6.4 IBMDSwitcherAudioInputXLR::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherAudioInputXLR** object. Pass an object implementing the **IBMDSwitcherAudioInputXLRCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherAudioInputXLRCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioInputXLRCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.6.5 IBMDSwitcherAudioInputXLR::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherAudioInputXLRCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioInputXLRCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.7 IBMDSwitcherAudioInputXLRCallback Interface

The **IBMDSwitcherAudioInputXLRCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherAudioInputXLR** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherAudioInputXLR	IID_ IBMDSwitcherAudioInputXLR	An IBMDSwitcherAudioInputXLRCallback object interface is installed with IBMDSwitcherAudioInputXLR::AddCallback and removed with IBMDSwitcherAudioInputXLR::RemoveCallback

Public Member Functions

Method	Description
Notify	Called when an event occurs.

7.4.7.1 IBMDSwitcherAudioInputXLRCallback::Notify method

The **Notify** method is called when **IBMDSwitcherAudioInputXLR** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherAudioInputXLREventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherAudioInputXLREventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.8 IBMDSwitcherAudioMonitorOutputIterator Interface

The `IBMDSwitcherAudioMonitorOutputIterator` is used to enumerate the available monitor outputs for the original audio mixer.

A reference to an `IBMDSwitcherAudioMonitorOutputIterator` object interface may be obtained from an `IBMDSwitcherAudioMixer` object interface using the `CreateIterator` method.

Pass `IID_IBMDSwitcherAudioMonitorOutputIterator` for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherAudioMixer</code>	<code>IID_IBMDSwitcherAudioMixer</code>	<code>IBMDSwitcherAudioMixer::CreateIterator</code> can return an <code>IBMDSwitcherAudioMonitorOutputIterator</code> object interface.

Public Member Functions

Method	Description
<code>Next</code>	Returns a pointer to the next <code>IBMDSwitcherAudioMonitorOutputIterator</code> object interface.

7.4.8.1 IBMDSwitcherAudioMonitorOutputIterator::Next method

The `Next` method returns the next available `IBMDSwitcherAudioMonitorOutput` object interface.

Syntax

```
HRESULT Next(IBMDSwitcherAudioMonitorOutput* audioMonitorOutput);
```

Parameters

Name	Direction	Description
<code>audioMonitorOutput</code>	out	<code>IBMDSwitcherAudioMonitorOutput</code> object interface.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>S_FALSE</code>	No more <code>IBMDSwitcherAudioMonitorOutput</code> objects available.
<code>E_POINTER</code>	The <code>audioMonitorOutput</code> parameter is invalid.

7.4.9 IBMDSwitcherAudioMonitorOutput Interface

The `IBMDSwitcherAudioMonitorOutput` object interface is used for manipulating parameters specific to audio monitor outputs for the original audio mixer.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherAudioMonitorOutputIterator</code>	<code>IID_IBMDSwitcherAudioMonitorOutput</code>	An <code>IBMDSwitcherAudioMonitorOutput</code> interface can be obtained with <code>IBMDSwitcherAudioMonitorOutputIterator::Next</code> .

Public Member Functions	
Method	Description
<code>GetMonitorEnable</code>	Get the current monitor-enable flag.
<code>SetMonitorEnable</code>	Set the monitor-enable flag.
<code>GetMute</code>	Get the current mute flag.
<code>SetMute</code>	Set the mute flag.
<code>GetGain</code>	Get the current gain value.
<code>SetGain</code>	Set the gain value.
<code>GetSolo</code>	Get the current solo flag.
<code>SetSolo</code>	Set the solo flag.
<code>GetSoloInput</code>	Get the current soloed input.
<code>SetSoloInput</code>	Set the soloed input.
<code>GetDim</code>	Get the current dim flag.
<code>SetDim</code>	Set the dim flag.
<code>GetDimLevel</code>	Get the current dim level.
<code>SetDimLevel</code>	Set the dim level.
<code>ResetLevelNotificationPeaks</code>	Reset peak level statistics to zero.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

7.4.9.1 IBMDSwitcherAudioMonitorOutput::GetMonitorEnable method

The `GetMonitorEnable` method returns the current monitor enable flag.

Syntax

```
HRESULT GetMonitorEnable (boolean* enable);
```

Parameters

Name	Direction	Description
enable	out	The current monitor enable flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enable parameter is invalid.

7.4.9.2 IBMDSwitcherAudioMonitorOutput::SetMonitorEnable method

The `SetMonitorEnable` method sets the monitor enable flag. This output acts as a monitor when the flag is set, otherwise it mirrors the content of program out.

Syntax

```
HRESULT SetMonitorEnable (boolean enable);
```

Parameters

Name	Direction	Description
enable	in	The current monitor enable flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.9.3 IBMDSwitcherAudioMonitorOutput::GetMute method

The `GetMute` method returns the current mute flag.

Syntax

```
HRESULT GetMute (boolean* mute);
```

Parameters

Name	Direction	Description
mute	out	The current mute flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The mute parameter is invalid.

7.4.9.4 IBMDSwitcherAudioMonitorOutput::SetMute method

The `SetMute` method sets the mute flag.

Syntax

```
HRESULT SetMute (boolean mute);
```

Parameters

Name	Direction	Description
mute	in	The desired mute flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.9.5 IBMDSwitcherAudioMonitorOutput::GetGain method

The `GetGain` method returns the current gain value.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.4.9.6 IBMDSwitcherAudioMonitorOutput::SetGain method

The `SetGain` method sets the gain to apply to the audio monitor output.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.9.7 IBMDSwitcherAudioMonitorOutput::GetSolo method

The `GetSolo` method returns the current solo flag.

Syntax

```
HRESULT GetSolo (boolean* solo);
```

Parameters

Name	Direction	Description
solo	out	The current solo flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The solo parameter is invalid.

7.4.9.8 IBMDSwitcherAudioMonitorOutput::SetSolo method

The `SetSolo` method sets the solo flag.

Syntax

```
HRESULT SetSolo (boolean solo);
```

Parameters

Name	Direction	Description
solo	in	The desired solo flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.9.9 IBMDSwitcherAudioMonitorOutput::GetSoloInput method

The `GetSoloInput` method returns which audio input is selected for soloing in the monitor output.

Syntax

```
HRESULT GetSoloInput (BMDSwitcherAudioInputId* audioInput);
```

Parameters

Name	Direction	Description
audioInput	out	The audio input for soloing.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The audioInput parameter is invalid.

7.4.9.10 IBMDSwitcherAudioMonitorOutput::SetSoloInput method

The `SetSoloInput` method selects which audio input is soloed in the monitor output.

Syntax

```
HRESULT SetSoloInput (BMDSwitcherAudioInputId audioInput);
```

Parameters

Name	Direction	Description
audioInput	in	The audio input for soloing.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The audioInput parameter is invalid.

7.4.9.11 IBMDSwitcherAudioMonitorOutput::GetDim method

The `GetDim` method returns the current dim flag.

Syntax

```
HRESULT GetDim (boolean* dim);
```

Parameters

Name	Direction	Description
dim	out	The current dim flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The dim parameter is invalid.

7.4.9.12 IBMDSwitcherAudioMonitorOutput::SetDim method

The `SetDim` method sets the dim flag.

Syntax

```
HRESULT SetDim (boolean dim);
```

Parameters

Name	Direction	Description
dim	in	The desired dim flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.9.13 IBMDSwitcherAudioMonitorOutput::GetDimLevel method

The `GetDimLevel` method returns the current dim level in dB for the original audio mixer.

Syntax

```
HRESULT GetDimLevel (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current dim level.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.4.9.14 **IBMDSwitcherAudioMonitorOutput::SetDimLevel** method

The **SetDimLevel** method sets the dim level in dB.

Syntax

```
HRESULT SetDimLevel (double gain);
```

Parameters

Name	Direction	Description
dim	in	The desired dim level.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.9.15 **IBMDSwitcherAudioMonitorOutput::ResetLevelNotificationPeaks** method

The **ResetLevelNotificationPeaks** method resets the switcher's output peak level statistics to zero.

Syntax

```
HRESULT ResetLevelNotificationPeaks (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.9.16 **IBMDSwitcherAudioMonitorOutput::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherAudioMonitorOutput** object. Pass an object implementing the **IBMDSwitcherAudioMonitorOutputCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherAudioMonitorOutputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioMonitorOutputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.9.17 **IBMDSwitcherAudioMonitorOutput::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherAudioMonitorOutputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioMonitorOutputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.10 IBMDSwitcherAudioMonitorOutputCallback Interface

The **IBMDSwitcherAudioMonitorOutputCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherAudioMonitorOutput** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherAudioMonitorOutput	IID_ IBMDSwitcherAudioMonitorOutput	An IBMDSwitcherAudioMonitorOutputCallback object interface is installed with IBMDSwitcherAudioMonitorOutput::AddCallback and removed with IBMDSwitcherAudioMonitorOutput::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.
LevelNotification	Reports level statistics.

7.4.10.1 IBMDSwitcherAudioMonitorOutputCallback::Notify method

The **Notify** method is called when **IBMDSwitcherAudioMonitorOutput** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherAudioMonitorOutputEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherAudioMonitorOutputEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.10.2 IBMDSwitcherAudioMonitorOutputCallback::LevelNotification method

The **LevelNotification** method is called periodically to report the current dB levels and the last known peak levels. These peak levels can be reset using

IBMDSwitcherAudioMonitorOutput::ResetLevelNotificationPeaks.

Note that this is an opt-in subscription. Enable or disable receiving these calls using

IBMDSwitcherAudioMixer::SetAllLevelNotificationsEnable.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT LevelNotification (double left, double right, double peakLeft,  
double peakRight);
```

Parameters

Name	Direction	Description
left	in	The current dB level of the left channel.
right	in	The current dB level of the right channel.
peakLeft	in	The highest encountered peak dB level of the left channel since the last reset.
peakRight	in	The highest encountered peak dB level of the right channel since the last reset.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.11 IBMDSwitcherAudioHeadphoneOutputIterator Interface

The **IBMDSwitcherAudioHeadphoneOutputIterator** is used to enumerate the available headphone outputs for the original audio mixer.

A reference to an **IBMDSwitcherAudioHeadphoneOutputIterator** object interface may be obtained from an **IBMDSwitcherAudioMixer** object interface using the `CreateIterator` method.

Pass `IID_IBMDSwitcherAudioHeadphoneOutputIterator` for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherAudioMixer	IID_IBMDSwitcherAudioMixer	IBMDSwitcherAudioMixer::CreateIterator returns an IBMDSwitcherAudioHeadphoneOutputIterator interface when the <code>IID_IBMDSwitcherAudioHeadphoneOutputIterator</code> IID is specified.

Public Member Functions	
Method	Description
Next	Returns a pointer to the next IBMDSwitcherAudioHeadphoneOutput object interface.

7.4.11.1 IBMDSwitcherAudioHeadphoneOutputIterator::Next method

The **Next** method returns the next available **IBMDSwitcherAudioHeadphoneOutput** object interface.

The **IBMDSwitcherAudioHeadphoneOutput** object interface must be released by the caller when no longer required.

Syntax

```
HRESULT Next (IBMDSwitcherAudioHeadphoneOutput* audioHeadphoneOutput);
```

Parameters

Name	Direction	Description
audioHeadphoneOutput	out	IBMDSwitcherAudioHeadphoneOutput object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No (more) headphone outputs are available.
E_POINTER	The audioHeadphoneOutput parameter is not a valid pointer.

7.4.12 IBMDSwitcherAudioHeadphoneOutput Interface

The `IBMDSwitcherAudioHeadphoneOutput` object interface is used for manipulating parameters specific to the original audio mixer headphone outputs.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherAudioHeadphoneOutputIterator</code>	<code>IID_IBMDSwitcherAudioHeadphoneOutputIterator</code>	An <code>IBMDSwitcherAudioHeadphoneOutput</code> interface can be obtained with <code>IBMDSwitcherAudioHeadphoneOutputIterator::Next</code> .

Public Member Functions

Method	Description
<code>GetGain</code>	Get the current headphone output gain value.
<code>SetGain</code>	Set the headphone output gain value.
<code>GetInputProgramOutGain</code>	Get the current headphone program out input gain value.
<code>SetInputProgramOutGain</code>	Set the headphone program out input gain value.
<code>GetInputTalkbackGain</code>	Get the current headphone talkback input gain value.
<code>SetInputTalkbackGain</code>	Set the headphone talkback input gain value.
<code>GetInputSidetoneGain</code>	Get the current headphone sidetone (microphone) input gain value.
<code>SetInputSidetoneGain</code>	Set the headphone sidetone (microphone) input gain value.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

7.4.12.1 IBMDSwitcherAudioHeadphoneOutput::GetGain method

The `GetGain` method returns the gain currently applied to the headphone output.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
<code>gain</code>	out	The current gain value.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The gain parameter is not a valid pointer.

7.4.12.2 IBMDSwitcherAudioHeadphoneOutput::SetGain method

The `SetGain` method sets the gain to apply to the headphone output.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.12.3 IBMDSwitcherAudioHeadphoneOutput::GetInputProgramOutGain method

The `GetInputProgramOutGain` method returns the gain currently applied to the program out input of the headphone output.

Syntax

```
HRESULT GetInputProgramOutGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is not a valid pointer.

7.4.12.4 **IBMDSwitcherAudioHeadphoneOutput::SetInputProgramOutGain** method

The **SetInputProgramOutGain** method sets the gain to apply to the program out input of the headphone output.

Syntax

```
HRESULT SetInputProgramOutGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.12.5 **IBMDSwitcherAudioHeadphoneOutput::GetInputTalkbackGain** method

The **GetInputTalkbackGain** method returns the gain currently applied to the talkback input of the headphone output.

Syntax

```
HRESULT GetInputTalkbackGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is not a valid pointer.

7.4.12.6 **IBMDSwitcherAudioHeadphoneOutput::SetInputTalkbackGain** method

The **SetInputTalkbackGain** method sets the gain to apply to the talkback input of the headphone output.

Syntax

```
HRESULT SetInputTalkbackGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.12.7 **IBMDSwitcherAudioHeadphoneOutput::GetInputSidetoneGain** method

The **GetInputSidetoneGain** method returns the gain currently applied to the sidetone (microphone) input of the headphone output.

Syntax

```
HRESULT GetInputSidetoneGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is not a valid pointer.

7.4.12.8 **IBMDSwitcherAudioHeadphoneOutput::SetInputSidetoneGain** method

The **SetInputSidetoneGain** method sets the gain to apply to the sidetone (microphone) input of the headphone output.

Syntax

```
HRESULT SetInputSidetoneGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.4.12.9 IBMDSwitcherAudioHeadphoneOutput::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherAudioHeadphoneOutput** object. Pass an object implementing the **IBMDSwitcherAudioHeadphoneOutputCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherAudioHeadphoneOutputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioHeadphoneOutputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.12.10 IBMDSwitcherAudioHeadphoneOutput::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback(IBMDSwitcherAudioHeadphoneOutputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherAudioHeadphoneOutputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.4.13 IBMDSwitcherAudioHeadphoneOutputCallback Interface

The **IBMDSwitcherAudioHeadphoneOutputCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherAudioHeadphoneOutput** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherAudioHeadphoneOutput	IID_IBMDSwitcherAudioHeadphoneOutput	An IBMDSwitcherAudioHeadphoneOutputCallback object interface is installed with IBMDSwitcherAudioHeadphoneOutput::AddCallback and removed with IBMDSwitcherAudioHeadphoneOutput::RemoveCallback .

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

7.4.13.1 IBMDSwitcherAudioHeadphoneOutputCallback::Notify method

The **Notify** method is called when **IBMDSwitcherAudioHeadphoneOutput** events occur, such as gain setting changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherAudioHeadphoneOutputEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherAudioHeadphoneOutputEventType that describes the type of event that occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5 Fairlight Audio Mixing Interface Reference

7.5.1 IBMDSwitcherFairlightAudioMixer Interface

The **IBMDSwitcherFairlightAudioMixer** object interface is the root object for all Fairlight audio mixing control and feedback.

A reference to an **IBMDSwitcherFairlightAudioMixer** object interface may be obtained from an **IBMDSwitcher** object interface using the **QueryInterface** method.

Pass **IID_IBMDSwitcherFairlightAudioMixer** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	IBMDSwitcher::QueryInterface can return an IBMDSwitcherFairlightAudioMixer object interface.

Public Member Functions	
Method	Description
GetMasterOutEffect	Get a master out effect object interface.
GetMasterOutFaderGain	Get the current master out fader gain value.
SetMasterOutFaderGain	Set the master out fader gain value.
GetMasterOutFollowFadeToBlack	Get the current master out follow fade to black state.
SetMasterOutFollowFadeToBlack	Set the master out follow fade to black state.
GetAudioFollowVideoCrossfadeTransition	Get the current audio follow video crossfade transition state.
SetAudioFollowVideoCrossfadeTransition	Set the audio follow video crossfade transition state.
SetAllLevelNotificationsEnabled	Opt-in to level notifications.
ResetMasterOutPeakLevels	Reset master out peak levels.
ResetAllPeakLevels	Reset all switcher peak level statistics.
CreateIterator	Create an iterator.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

7.5.1.1

IBMDSwitcherFairlightAudioMixer::GetMasterOutEffect method

The **GetMasterOutEffect** method returns the master out effect object interface for the specified interface ID, such as **IBMDSwitcherFairlightAudioEqualizer** and **IBMDSwitcherFairlightAudioDynamicsProcessor**.

The object interface must be released by the caller when no longer required.

Syntax

```
HRESULT GetMasterOutEffect (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Interface ID for the desired interface.
ppv	out	Pointer to return interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_NOINTERFACE	Interface was not found.

7.5.1.2

IBMDSwitcherFairlightAudioMixer::GetMasterOutFaderGain method

The **GetMasterOutFaderGain** method returns the current gain value.

Syntax

```
HRESULT GetMasterOutFaderGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.5.1.3 **IBMDSwitcherFairlightAudioMixer::SetMasterOutFaderGain** method

The **SetMasterOutFaderGain** method sets the gain to apply to the master out.

Syntax

```
HRESULT SetMasterOutFaderGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.1.4 **IBMDSwitcherFairlightAudioMixer::GetMasterOutFollowFadeToBlack** method

The **GetMasterOutFollowFadeToBlack** method returns the current follow fade to black state. When enabled the master out audio will fade in unity with a fade to black transition.

Syntax

```
HRESULT GetMasterOutFollowFadeToBlack (boolean* follow);
```

Parameters

Name	Direction	Description
follow	out	The current follow fade to black state.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The follow parameter is invalid.

7.5.1.5 **IBMDSwitcherFairlightAudioMixer::SetMasterOutFollowFadeToBlack** method

The **SetMasterOutFollowFadeToBlack** method sets the current follow fade to black state. When enabled the master out audio will fade in unity with a fade to black transition.

Syntax

```
HRESULT SetMasterOutFollowFadeToBlack (boolean follow);
```

Parameters

Name	Direction	Description
follow	in	The desired follow fade to black state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.1.6 **IBMDSwitcherFairlightAudioMixer::GetAudioFollowVideoCrossfadeTransition** method

The **GetAudioFollowVideoCrossfadeTransition** method returns the current follow video with crossfade transition state. When enabled the audio will crossfade with the video.

Syntax

```
HRESULT GetAudioFollowVideoCrossfadeTransition (boolean* transition);
```

Parameters

Name	Direction	Description
transition	out	The current follow video with crossfade transition state.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The transition parameter is invalid.

7.5.1.7 **IBMDSwitcherFairlightAudioMixer::SetAudioFollowVideoCrossfadeTransition** method

The **SetAudioFollowVideoCrossfadeTransition** method sets the current follow video with crossfade transition state. When enabled the audio will crossfade with the video.

Syntax

```
HRESULT SetAudioFollowVideoCrossfadeTransition (boolean transition);
```

Parameters

Name	Direction	Description
transition	in	The desired follow video with crossfade transition state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.1.8 **IBMDSwitcherFairlightAudioMixer::SetAllLevelNotificationsEnabled** method

The **SetAllLevelNotificationsEnabled** method enables level statistics for the Fairlight mixer inputs and outputs. Receiving level notifications are an opt-in subscription, affecting the callbacks

IBMDSwitcherFairlightAudioMixerCallback::MasterOutLevelNotification,
IBMDSwitcherFairlightAudioSourceCallback::OutputLevelNotification,
IBMDSwitcherFairlightAudioDynamicsProcessorCallback::InputLevelNotification,
IBMDSwitcherFairlightAudioDynamicsProcessorCallback::OutputLevelNotification,
IBMDSwitcherFairlightAudioLimiterCallback::GainReductionLevelNotification,
IBMDSwitcherFairlightAudioCompressorCallback::GainReductionLevelNotification and
IBMDSwitcherFairlightAudioExpanderCallback::GainReductionLevelNotification

Syntax

```
HRESULT SetAllLevelNotificationsEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	Whether to enable notifications.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.1.9 **IBMDSwitcherFairlightAudioMixer::ResetMasterOutPeakLevels** method

The **ResetMasterOutPeakLevels** method resets the switcher's master out peak level statistics.

Syntax

```
HRESULT ResetMasterOutPeakLevels (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.1.10 **IBMDSwitcherFairlightAudioMixer::ResetAllPeakLevels** method

The **ResetAllPeakLevels** method resets peak level statistics for all Fairlight audio mixer inputs and outputs.

Syntax

```
HRESULT ResetAllPeakLevels (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.1.11 **IBMDSwitcherFairlightAudioMixer::CreateIterator** method

The **CreateIterator** method creates an iterator object interface for the specified interface ID, such as **IBMDSwitcherFairlightAudioInputIterator** and **IBMDSwitcherFairlightAudioHeadphoneOutputIterator**.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Iterator Interface ID to create an iterator for.
ppv	out	Pointer to return interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_OUTOFMEMORY	Insufficient memory to create interface object.
E_NOINTERFACE	Interface was not found.

7.5.1.12 **IBMDSwitcherFairlightAudioMixer::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioMixer** object. Pass an object implementing the **IBMDSwitcherFairlightAudioMixerCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherFairlightAudioMixerCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioMixerCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.1.13 **IBMDSwitcherFairlightAudioMixer::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherFairlightAudioMixerCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioMixerCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.2 IBMDSwitcherFairlightAudioMixerCallback Interface

The **IBMDSwitcherFairlightAudioMixerCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherFairlightAudioMixer** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioMixer	IID_IBMDSwitcherFairlightAudioMixer	An IBMDSwitcherFairlightAudioMixerCallback object interface is installed with IBMDSwitcherFairlightAudioMixer::AddCallback and removed with IBMDSwitcherFairlightAudioMixer::RemoveCallback .

Public Member Functions

Method	Description
Notify	Called when an event occurs.
MasterOutLevelNotification	Reports level statistics.

7.5.2.1 IBMDSwitcherFairlightAudioMixerCallback::Notify method

The **Notify** method is called when **IBMDSwitcherFairlightAudioMixer** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(IBMDSwitcherFairlightAudioMixerEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherFairlightAudioMixerEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.2.2 IBMDSwitcherFairlightAudioMixerCallback::MasterOutLevelNotification method

The **MasterOutLevelNotification** method is called periodically to report the current dB levels and the last known peak levels. These peak levels can be reset using **IBMDSwitcherFairlightAudioMixer::ResetMasterOutPeakLevels**.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMDSwitcherFairlightAudioMixer::SetAllLevelNotificationsEnabled**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT MasterOutLevelNotification (uint32_t numLevels, const double* levels,
    uint32_t numPeakLevels, const double* peakLevels);
```

Parameters

Name	Direction	Description
numLevels	in	The number of levels of the master out.
levels	in	The current dB levels of the master out.
numPeakLevels	in	The number of peak levels of the master out.
peakLevels	in	The highest encountered peak dB level of the master out since the last reset.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.3 IBMDSwitcherFairlightAudioInputIterator Interface

The **IBMDSwitcherFairlightAudioInputIterator** is used to enumerate the available audio inputs for the Fairlight audio mixer.

A reference to an **IBMDSwitcherFairlightAudioInputIterator** object interface may be obtained from an **IBMDSwitcherFairlightAudioMixer** object interface using the **CreateIterator** method.

Pass **IID_IBMDSwitcherFairlightAudioInputIterator** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioMixer	IID_IBMDSwitcherFairlightAudioMixer	IBMDSwitcherFairlightAudioMixer::CreateIterator can return an IBMDSwitcherFairlightAudioInputIterator object interface.

Public Member Functions

Method	Description
Next	Returns a pointer to the next IBMDSwitcherFairlightAudioInput object interface.
GetById	Returns a pointer to an IBMDSwitcherFairlightAudioInput object interface, given its BMDSwitcherAudioInputId .

7.5.3.1 IBMDSwitcherFairlightAudioInputIterator::Next method

The **Next** method returns the next available **IBMDSwitcherFairlightAudioInput** object interface.

Syntax

```
HRESULT Next(IBMDSwitcherFairlightAudioInput* audioInput);
```

Parameters

Name	Direction	Description
audioInput	out	IBMDSwitcherFairlightAudioInput object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No more IBMDSwitcherFairlightAudioInput objects available.
E_POINTER	The audioInput parameter is invalid.

7.5.3.2 IBMDSwitcherFairlightAudioInputIterator::GetById method

The `GetById` method returns a pointer to an `IBMDSwitcherFairlightAudioInput` object interface, given its `BMDSwitcherAudioInputId`.

Syntax

```
HRESULT GetById (BMDSwitcherAudioInputId audioInputId,  
                IBMDSwitcherFairlightAudioInput* audioInput);
```

Parameters

Name	Direction	Description
audioInputId	in	<code>BMDSwitcherAudioInputId</code> identifier.
audioInput	out	<code>IBMDSwitcherFairlightAudioInput</code> object interface.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_INVALIDARG</code>	The <code>audioInputId</code> is not a valid identifier.
<code>E_POINTER</code>	The <code>audioInput</code> parameter is invalid.

7.5.4 IBMDSwitcherFairlightAudioInput Interface

The `IBMDSwitcherFairlightAudioInput` object interface is used for managing a Fairlight audio input.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherFairlightAudioInputIterator</code>	<code>IID_IBMDSwitcherFairlightAudioInputIterator</code>	An <code>IBMDSwitcherFairlightAudioInput</code> object interface will be returned after a successful call to <code>IBMDSwitcherFairlightAudioInputIterator::Next</code> method.

Public Member Functions	
Method	Description
<code>GetType</code>	Get the audio input type.
<code>GetCurrentExternalPortType</code>	Get the current physical external port type of the Fairlight audio input.
<code>GetSupportedConfigurations</code>	Get the available input configurations.
<code>GetConfiguration</code>	Get the current input configuration.
<code>SetConfiguration</code>	Set the input configuration.
<code>GetId</code>	Returns the ID of this <code>IBMDSwitcherFairlightAudioInput</code> interface.
<code>CreateIterator</code>	Create an iterator.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

7.5.4.1 IBMDSwitcherFairlightAudioInput::GetType method

The `GetType` method returns the type of the Fairlight audio input.

Syntax

```
HRESULT GetType (BMDSwitcherFairlightAudioInputType* type);
```

Parameters

Name	Direction	Description
type	out	The Fairlight audio input type.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The type parameter is invalid.

7.5.4.2 IBMDSwitcherFairlightAudioInput::GetCurrentExternalPortType method

The `GetCurrentExternalPortType` method gets the current physical external port type of the Fairlight audio input. This may change if the physical input is switchable, generating the event `bmdSwitcherFairlightAudioInputEventTypeCurrentExternalPortTypeChanged`.

Syntax

```
HRESULT GetCurrentExternalPortType (BMDSwitcherExternalPortType* type);
```

Parameters

Name	Direction	Description
type	out	The current external port type.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The type parameter is invalid.

7.5.4.3 **IBMDSwitcherFairlightAudioInput::GetSupportedConfigurations** method

The **GetSupportedConfigurations** method returns the supported input configurations of the Fairlight audio input.

Syntax

```
HRESULT GetSupportedConfigurations (IBMDSwitcherFairlightAudioInputConfiguration* supportedConfigurations);
```

Parameters

Name	Direction	Description
supportedConfigurations	out	The supported Fairlight audio input configurations.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportedConfigurations parameter is invalid.

7.5.4.4 **IBMDSwitcherFairlightAudioInput::GetConfiguration** method

The **GetConfiguration** method returns the current Fairlight audio input configuration.

Syntax

```
HRESULT GetConfiguration (IBMDSwitcherFairlightAudioInputConfiguration* configuration);
```

Parameters

Name	Direction	Description
configuration	out	The current Fairlight audio input configuration.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The configuration parameter is invalid.

7.5.4.5 **IBMDSwitcherFairlightAudioInput::SetConfiguration** method

The **SetConfiguration** method sets the Fairlight audio input configuration.

Syntax

```
HRESULT SetConfiguration (IBMDSwitcherFairlightAudioInputConfiguration configuration);
```

Parameters

Name	Direction	Description
configuration	in	The Fairlight audio input configuration

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The configuration is not a valid identifier.

7.5.4.6 **IBMDSwitcherFairlightAudioInput::GetId** method

The **GetId** method returns the audio input's ID, used to uniquely identify an audio input within the Switcher.

Syntax

```
HRESULT GetId (IBMDSwitcherAudioInputId* audioInputId);
```

Parameters

Name	Direction	Description
audioInputId	out	IBMDSwitcherAudioInputId identifier for the current audio input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The audioInputId parameter is invalid.

7.5.4.7 **IBMDSwitcherFairlightAudioInput::CreateIterator** method

The **CreateIterator** method creates an iterator object for the interface ID **IBMDSwitcherFairlightAudioSourceIterator**.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Iterator Interface ID to create an iterator for.
ppv	out	Pointer to return interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_NOINTERFACE	Interface was not found.

7.5.4.8 **IBMDSwitcherFairlightAudioInput::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioInput** object. Pass an object implementing the **IBMDSwitcherFairlightAudioInputCallback** interface to receive callbacks.

Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherFairlightAudioInputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioInputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.4.9 IBMDSwitcherFairlightAudioInput::RemoveCallback method

The `RemoveCallback` method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherFairlightAudioInputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the <code>IBMDSwitcherFairlightAudioInputCallback</code> object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.5 IBMDSwitcherFairlightAudioInputCallback Interface

The `IBMDSwitcherFairlightAudioInputCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherFairlightAudioInput` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherFairlightAudioInput</code>	<code>IID_IBMDSwitcherFairlightAudioInput</code>	An <code>IBMDSwitcherFairlightAudioInputCallback</code> object interface is installed with <code>IBMDSwitcherFairlightAudioInput::AddCallback</code> and removed with <code>IBMDSwitcherFairlightAudioInput::RemoveCallback</code>

Public Member Functions	
Method	Description
<code>Notify</code>	Called when an event occurs.

7.5.5.1 **IBMDSwitcherFairlightAudioInputCallback::Notify** method

The **Notify** method is called when **IBMDSwitcherFairlightAudioInput** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherFairlightAudioInputEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherFairlightAudioInputEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.6 **IBMDSwitcherFairlightAudioSourceIterator** Interface

The **IBMDSwitcherFairlightAudioSourceIterator** is used to enumerate the available audio sources for a Fairlight audio mixer input.

A reference to an **IBMDSwitcherFairlightAudioSourceIterator** object interface may be obtained from an **IBMDSwitcherFairlightAudioInput** object interface using the **CreateIterator** method.

Pass **IID_IBMDSwitcherFairlightAudioSourceIterator** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioInput	IID_IBMDSwitcherFairlightAudioInput	IBMDSwitcherFairlightAudioInput::CreateIterator can return an IBMDSwitcherFairlightAudioSourceIterator object interface.

Public Member Functions	
Method	Description
Next	Returns a pointer to the next IBMDSwitcherFairlightAudioSource object interface.
GetById	Returns a pointer to an IBMDSwitcherFairlightAudioSource object interface, given its IBMDSwitcherFairlightAudioSourceId .

7.5.6.1 IBMDSwitcherFairlightAudioSourceIterator::Next method

The `Next` method returns the next available `IBMDSwitcherFairlightAudioSource` object interface.

Syntax

```
HRESULT Next(IBMDSwitcherFairlightAudioSource* audioSource);
```

Parameters

Name	Direction	Description
audioSource	out	IBMDSwitcherFairlightAudioSource object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No more <code>IBMDSwitcherFairlightAudioSource</code> objects available.
E_POINTER	The audioSource parameter is invalid.

7.5.6.2 IBMDSwitcherFairlightAudioSourceIterator::GetById method

The `GetById` method returns a pointer to an `IBMDSwitcherFairlightAudioSource` object interface, given its `BMDSwitcherFairlightAudioSourceId`.

Syntax

```
HRESULT GetById(BMDSwitcherFairlightAudioSourceId audioSourceId,  
IBMDSwitcherFairlightAudioSource* audioSource);
```

Parameters

Name	Direction	Description
audioSourceId	in	<code>BMDSwitcherFairlightAudioSourceId</code> identifier.
audioSource	out	IBMDSwitcherFairlightAudioSource object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The audioSourceId is not a valid identifier.
E_POINTER	The audioSource parameter is invalid.

7.5.7 IBMDSwitcherFairlightAudioSource Interface

The **IBMDSwitcherFairlightAudioSource** object interface is used for manipulating the settings of an audio source for the Fairlight audio mixer.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioSourceIteator	IID_IBMDSwitcherFairlightAudioSourceIteator	An IBMDSwitcherFairlightAudioSource object interface will be returned after a successful call to IBMDSwitcherFairlightAudioSourceIteator::Next method.

Public Member Functions	
Method	Description
IsActive	Get the current is-active state.
GetSourceType	Get the current source type.
GetMaxDelayFrames	Get the maximum delay frames.
GetDelayFrames	Get the current delay frames.
SetDelayFrames	Set the delay frames.
GetInputGain	Get the current input gain value.
SetInputGain	Set the input gain value.
HasStereoSimulation	Get the current has-stereo-simulation flag.
GetStereoSimulationIntensity	Get the current stereo-simulation-intensity percentage.
SetStereoSimulationIntensity	Set the stereo-simulation-intensity percentage.
GetEffect	Get the effect object interface.
GetPan	Get the current pan value.
SetPan	Set the pan value.
GetFaderGain	Get the current fader gain value.
SetFaderGain	Set the fader gain value.
GetSupportedMixOptions	Get the supported mix options.
GetMixOption	Get the current mix option.
SetMixOption	Set the mix option.
IsMixedIn	Get the is-mixed-in flag.
ResetOutputPeakLevels	Reset output peak level statistics.
GetId	Returns the ID of this IBMDSwitcherFairlightAudioSource interface.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

7.5.7.1 **IBMDSwitcherFairlightAudioSource::IsActive** method

The **IsActive** method indicates whether the Fairlight audio source is currently active.

Audio sources can become inactive when the configuration property of the **IBMDSwitcherFairlightAudioInput** is changed. When a source is not active, it can not be used to manipulate audio on the switcher.

Syntax

```
HRESULT IsActive (boolean* active);
```

Parameters

Name	Direction	Description
active	out	The current is-active state.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The active parameter is invalid.

7.5.7.2 **IBMDSwitcherFairlightAudioSource::GetSourceType** method

The **GetSourceType** method indicates the type of Fairlight audio source.

Syntax

```
HRESULT GetSourceType(BMDSwitcherFairlightAudioSourceType* type);
```

Parameters

Name	Direction	Description
type	out	The current Fairlight audio source type.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The type parameter is invalid.

7.5.7.3 IBMDSwitcherFairlightAudioSource::GetMaxDelayFrames method

The `GetMaxDelayFrames` method returns the maximum delay frames.

Syntax

```
HRESULT GetMaxDelayFrames (uint16_t* maxDelay);
```

Parameters

Name	Direction	Description
maxDelay	out	Maximum number of delay frames.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The maxDelay parameter is invalid.

7.5.7.4 IBMDSwitcherFairlightAudioSource::GetDelayFrames method

The `GetDelayFrames` method returns the current number of delay frames applied to the Fairlight audio source.

Syntax

```
HRESULT GetDelayFrames (uint16_t* delay);
```

Parameters

Name	Direction	Description
delay	out	The current number of delay frames applied to the Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The delay parameter is invalid.

7.5.7.5 IBMDSwitcherFairlightAudioSource::SetDelayFrames method

The `SetDelayFrames` method sets the number of delay frames to apply to the Fairlight audio source.

Syntax

```
HRESULT SetDelayFrames (uint16_t delay);
```

Parameters

Name	Direction	Description
delay	in	The number of delay frames to apply to the Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the source is no longer active.

7.5.7.6 **IBMDSwitcherFairlightAudioSource::GetInputGain** method

The **GetInputGain** method returns the current input gain applied to the Fairlight audio source.

Syntax

```
HRESULT GetInputGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The gain currently applied to the Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.5.7.7 **IBMDSwitcherFairlightAudioSource::SetInputGain** method

The **SetInputGain** method sets the input gain of a Fairlight audio source.

Syntax

```
HRESULT SetInputGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The gain to apply to the audio source.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the source is no longer active.

7.5.7.8 **IBMDSwitcherFairlightAudioSource::HasStereoSimulation** method

The **HasStereoSimulation** method indicates whether the Fairlight audio source has stereo simulation available.

Syntax

```
HRESULT HasStereoSimulation (boolean* hasStereoSimulation);
```

Parameters

Name	Direction	Description
hasStereoSimulation	out	The has-stereo-simulation flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The hasStereoSimulation parameter is invalid.

7.5.7.9 **IBMDSwitcherFairlightAudioSource::GetStereoSimulationIntensity** method

The **GetStereoSimulationIntensity** method returns the current intensity of the stereo simulation applied to the Fairlight audio source.

Syntax

```
HRESULT GetStereoSimulationIntensity (double* intensity);
```

Parameters

Name	Direction	Description
intensity	out	The current stereo-simulation-intensity percentage applied to the Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The intensity parameter is invalid.

7.5.7.10 **IBMDSwitcherFairlightAudioSource::SetStereoSimulationIntensity** method

The **SetStereoSimulationIntensity** method sets the intensity of the stereo simulation to apply to the Fairlight audio source.

Syntax

```
HRESULT SetStereoSimulationIntensity (double intensity);
```

Parameters

Name	Direction	Description
intensity	in	The desired stereo simulation intensity to apply to the Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the source is no longer active.

7.5.7.11 **IBMDSwitcherFairlightAudioSource::GetEffect** method

The **GetEffect** method returns the effect object interface for the specified interface ID, such as **IBMDSwitcherFairlightAudioEqualizer** and **IBMDSwitcherFairlightAudioDynamicsProcessor**.

The object interface must be released by the caller when no longer required.

Syntax

```
HRESULT GetEffect (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Interface ID for the desired interface.
ppv	out	Pointer to return interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_NOINTERFACE	Interface was not found.

7.5.7.12 **IBMDSwitcherFairlightAudioSource::GetPan** method

The **GetPan** method returns the current pan value applied to the Fairlight audio source.

Syntax

```
HRESULT GetPan (double* pan);
```

Parameters

Name	Direction	Description
pan	out	The pan currently applied to the Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The pan parameter is invalid.

7.5.7.13 **IBMDSwitcherFairlightAudioSource::SetPan** method

The **SetPan** method sets the pan value to apply to the Fairlight audio source.

Syntax

```
HRESULT SetPan (double pan);
```

Parameters

Name	Direction	Description
pan	in	The pan to apply to the Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the source is no longer active.

7.5.7.14 **IBMDSwitcherFairlightAudioSource::GetFaderGain** method

The **GetFaderGain** method returns the current fader gain value applied to the Fairlight audio source.

Syntax

```
HRESULT GetFaderGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The fader gain currently applied to the Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.5.7.15 **IBMDSwitcherFairlightAudioSource::SetFaderGain** method

The **SetFaderGain** method sets the fader gain value to apply to the Fairlight audio source.

Syntax

```
HRESULT SetFaderGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The fader gain value to apply to the Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the source is no longer active.

7.5.7.16 **IBMDSwitcherFairlightAudioSource::GetSupportedMixOptions** method

The `GetSupportedMixOptions` method returns the supported mix options.

Syntax

```
HRESULT GetSupportedMixOptions (IBMDSwitcherFairlightAudioMixOption* mixOptions);
```

Parameters

Name	Direction	Description
mixOptions	out	The available mix options.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The mixOptions parameter is invalid.

7.5.7.17 **IBMDSwitcherFairlightAudioSource::GetMixOption** method

The `GetMixOption` method returns the current mix option.

Syntax

```
HRESULT GetMixOption (IBMDSwitcherFairlightAudioMixOption* mixOption);
```

Parameters

Name	Direction	Description
mixOption	out	The current mix option.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The mixOption parameter is invalid.

7.5.7.18 **IBMDSwitcherFairlightAudioSource::SetMixOption** method

The `SetMixOption` method sets the mix option.

Syntax

```
HRESULT SetMixOption (IBMDSwitcherFairlightAudioMixOption mixOption);
```

Parameters

Name	Direction	Description
mixOption	in	The desired mix option.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the source is no longer active.
E_INVALIDARG	The mixOption is not a valid identifier.

7.5.7.19 **IBMDSwitcherFairlightAudioSource::IsMixedIn** method

The **IsMixedIn** method indicates whether the Fairlight audio source is currently being mixed into the program out.

Syntax

```
HRESULT IsMixedIn (boolean* mixedIn);
```

Parameters

Name	Direction	Description
mixedIn	out	The current mixed-in flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The mixedIn parameter is invalid.

7.5.7.20 **IBMDSwitcherFairlightAudioSource::ResetOutputPeakLevels** method

The **ResetOutputPeakLevels** method resets peak statistics for the Fairlight audio source.

Syntax

```
HRESULT ResetOutputPeakLevels (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure. This can happen if the source is no longer active.

7.5.7.21 **IBMDSwitcherFairlightAudioSource::GetId** method

The **GetId** method returns the **BMDSwitcherFairlightAudioSourceId** of the Fairlight audio source.

Syntax

```
HRESULT GetId (BMDSwitcherFairlightAudioSourceId* sourceId);
```

Parameters

Name	Direction	Description
sourceId	out	BMDSwitcherFairlightAudioSourceId identifier for the current Fairlight audio source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The sourceId parameter is invalid.

7.5.7.22 **IBMDSwitcherFairlightAudioSource::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioSource** object. Pass an object implementing the **IBMDSwitcherFairlightAudioSourceCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherFairlightAudioSourceCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioSourceCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.7.23 **IBMDSwitcherFairlightAudioSource::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherFairlightAudioSourceCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioSourceCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.8 IBMDSwitcherFairlightAudioSourceCallback Interface

The **IBMDSwitcherFairlightAudioSourceCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherFairlightAudioSource** object.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioSource	IID_IBMDSwitcherFairlightAudioSource	An IBMDSwitcherFairlightAudioSourceCallback object interface is installed with IBMDSwitcherFairlightAudioSource::AddCallback and removed with IBMDSwitcherFairlightAudioSource::RemoveCallback .

Public Member Functions	
Method	Description
Notify	Called when an event occurs.
OutputLevelNotification	Reports output level statistics.

7.5.8.1 IBMDSwitcherFairlightAudioSourceCallback::Notify method

The **Notify** method is called when **IBMDSwitcherFairlightAudioSource** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(IBMDSwitcherFairlightAudioSourceEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherFairlightAudioSourceEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.8.2 IBMDSwitcherFairlightAudioSourceCallback::OutputLevelNotification method

The **OutputLevelNotification** method is called periodically to report the current dB output levels and the last known peak levels. These peak levels can be reset using **IBMDSwitcherFairlightAudioSource::ResetOutputPeakLevels**.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMDSwitcherFairlightAudioMixer::SetAllLevelNotificationsEnabled**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT OutputLevelNotification(uint32_t numLevels, const double* levels,
                                uint32_t numPeakLevels, const double* peakLevels);
```

Parameters

Name	Direction	Description
numLevels	in	The number of output levels.
levels	in	The current output dB levels.
numPeakLevels	in	The number of output peak levels.
peakLevels	in	The highest encountered output peak level.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.9 IBMDSwitcherFairlightAudioEqualizer Interface

The `IBMDSwitcherFairlightAudioEqualizer` object interface is used for manipulating the Fairlight audio equalizer interface.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherFairlightAudioMixer</code>	<code>IBMD_SwitcherFairlightAudioMixer</code>	An <code>IBMDSwitcherFairlightAudioEqualizer</code> object interface will be returned after a successful call to <code>IBMDSwitcherFairlightAudioMixer::GetMasterOutEffect</code> method.
<code>IBMDSwitcherFairlightAudioSource</code>	<code>IID_IBMDSwitcherFairlightAudioSource</code>	An <code>IBMDSwitcherFairlightAudioEqualizer</code> object interface will be returned after a successful call to <code>IBMDSwitcherFairlightAudioSource::GetEffect</code> method.

Public Member Functions	
Method	Description
<code>GetEnabled</code>	Get the current equalizer-enabled flag.
<code>SetEnabled</code>	Set the equaliser-enabled flag.
<code>GetGain</code>	Get the current gain value.
<code>SetGain</code>	Set the gain value.
<code>Reset</code>	Reset the equalizer.
<code>CreateIterator</code>	Create an iterator.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

7.5.9.1 IBMDSwitcherFairlightAudioEqualizer::GetEnabled method

The `GetEnabled` method returns the current equalizer enabled flag.

Syntax

```
HRESULT GetEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
<code>enabled</code>	out	The current equalizer enabled flag.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The enabled parameter is invalid.

7.5.9.2 **IBMDSwitcherFairlightAudioEqualizer::SetEnabled** method

The **SetEnabled** method sets the equalizer enabled flag.

Syntax

```
HRESULT SetEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	The desired equalizer enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.9.3 **IBMDSwitcherFairlightAudioEqualizer::GetGain** method

The **GetGain** method returns the current gain value applied to the Fairlight audio source by the equalizer.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The gain currently applied to the Fairlight audio source by the equalizer.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.5.9.4 **IBMDSwitcherFairlightAudioEqualizer::SetGain** method

The **SetGain** method sets the gain value to apply to the Fairlight audio source.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The gain to apply to the Fairlight audio source by the equalizer.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.9.5 **IBMDSwitcherFairlightAudioEqualizer::Reset** method

The **Reset** method resets the equalizer to its default state.

Syntax

```
HRESULT Reset (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.9.6 **IBMDSwitcherFairlightAudioEqualizer::CreateIterator** method

The **CreateIterator** method creates an iterator object for the interface ID **IBMDSwitcherFairlightAudioEqualizerBandIterator**.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Iterator Interface ID to create an iterator for.
ppv	out	Pointer to return interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_OUTOFMEMORY	Insufficient memory to create interface object.
E_NOINTERFACE	Interface was not found.

7.5.9.7 **IBMDSwitcherFairlightAudioEqualizer::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioEqualizer** object. Pass an object implementing the **IBMDSwitcherFairlightAudioEqualizerCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherFairlightAudioEqualizerCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioEqualizerCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.9.8 **IBMDSwitcherFairlightAudioEqualizer::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherFairlightAudioEqualizerCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioEqualizerCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.10 IBMDSwitcherFairlightAudioEqualizerCallback Interface

The **IBMDSwitcherFairlightAudioEqualizerCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherFairlightAudioEqualizer** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioEqualizer	IID_ IBMDSwitcherFairlightAudioEqualizer	An IBMDSwitcherFairlightAudioEqualizerCallback object interface is installed with IBMDSwitcherFairlightAudioEqualizer::AddCallback and removed with IBMDSwitcherFairlightAudioEqualizer::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

7.5.10.1 IBMDSwitcherFairlightAudioEqualizerCallback::Notify method

The **Notify** method is called when **IBMDSwitcherFairlightAudioEqualizer** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherFairlightAudioEqualizerEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherFairlightAudioEqualizerEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.11 IBMDSwitcherFairlightAudioEqualizerBandIterator Interface

The **IBMDSwitcherFairlightAudioEqualizerBandIterator** is used to enumerate the bands of a Fairlight audio equalizer.

A reference to an **IBMDSwitcherFairlightAudioEqualizerBandIterator** object interface may be obtained from an **IBMDSwitcherFairlightAudioEqualizer** object interface using the **CreateIterator** method.

Pass **IID_IBMDSwitcherFairlightAudioEqualizerBandIterator** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioEqualizer	IID_IBMDSwitcherFairlightAudioEqualizer	IBMDSwitcherFairlightAudioEqualizer::CreateIterator can return an IBMDSwitcherFairlightAudioEqualizerBandIterator object interface.

Public Member Functions	
Method	Description
Next	Returns a pointer to the next IBMDSwitcherFairlightAudioEqualizerBand object interface.

7.5.11.1 IBMDSwitcherFairlightAudioEqualizerBandIterator::Next method

The **Next** method returns the next available **IBMDSwitcherFairlightAudioEqualizerBand** object interface.

Syntax

```
HRESULT Next(IBMDSwitcherFairlightAudioEqualizerBand* audioEqualizerBand);
```

Parameters

Name	Direction	Description
audioEqualizerBand	out	IBMDSwitcherFairlightAudioEqualizerBand object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No more IBMDSwitcherFairlightAudioEqualizerBand objects available.
E_POINTER	The audioEqualizerBand parameter is invalid.

7.5.12

IBMDSwitcherFairlightAudioEqualizerBand Interface

The `IBMDSwitcherFairlightAudioEqualizerBand` object interface is used for manipulating Fairlight audio equalizer bands.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherFairlightAudioEqualizerBandIterator</code>	<code>IID_IBMDSwitcherFairlightAudioEqualizerBandIterator</code>	An <code>IBMDSwitcherFairlightAudioEqualizerBand</code> interface can be obtained with <code>IBMDSwitcherFairlightAudioEqualizerBandIterator::Next</code> .

Public Member Functions	
Method	Description
<code>GetEnabled</code>	Get the current band-enabled flag.
<code>SetEnabled</code>	Set the band-enabled flag.
<code>GetSupportedShapes</code>	Get the supported shapes.
<code>GetShape</code>	Get the current band shape.
<code>SetShape</code>	Set the band shape.
<code>GetSupportedFrequencyRanges</code>	Get the supported frequency ranges.
<code>GetFrequencyRange</code>	Get the current frequency range.
<code>SetFrequencyRange</code>	Set the frequency range.
<code>GetFrequencyRangeMinMax</code>	Get the minimum and maximum frequencies for the specified frequency range.
<code>GetFrequency</code>	Get the current frequency value.
<code>SetFrequency</code>	Set the frequency value.
<code>GetGain</code>	Get the current gain value.
<code>SetGain</code>	Set the gain value.
<code>GetQFactor</code>	Get the current Q factor.
<code>SetQFactor</code>	Set the Q factor.
<code>Reset</code>	Reset the equalizer band.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

7.5.12.1 **IBMDSwitcherFairlightAudioEqualizerBand::GetEnabled** method

The **GetEnabled** method returns the current equalizer band enabled flag.

Syntax

```
HRESULT GetEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
enabled	out	The current band enabled flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.

7.5.12.2 **IBMDSwitcherFairlightAudioEqualizerBand::SetEnabled** method

The **SetEnabled** method sets the equalizer band enabled flag.

Syntax

```
HRESULT SetEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	The desired band enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.12.3 **IBMDSwitcherFairlightAudioEqualizerBand::GetSupportedShapes** method

The `GetSupportedShapes` method returns the supported equalizer band shapes.

Syntax

```
HRESULT GetSupportedShapes (IBMDSwitcherFairlightAudioEqualizerBandShape* shapes)
```

Parameters

Name	Direction	Description
shapes	out	The available shapes.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The shapes parameter is invalid.

7.5.12.4 **IBMDSwitcherFairlightAudioEqualizerBand::GetShape** method

The `GetShape` method returns the current equalizer band shape.

Syntax

```
HRESULT GetShape (IBMDSwitcherFairlightAudioEqualizerBandShape* shape);
```

Parameters

Name	Direction	Description
shape	out	The current shape.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The shape parameter is invalid.

7.5.12.5 **IBMDSwitcherFairlightAudioEqualizerBand::SetShape** method

The **SetShape** method sets the equalizer band shape.

Syntax

```
HRESULT SetShape (IBMDSwitcherFairlightAudioEqualizerBandShape shape);
```

Parameters

Name	Direction	Description
shape	in	The desired shape.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The shape is not a valid identifier.

7.5.12.6 **IBMDSwitcherFairlightAudioEqualizerBand::GetSupportedFrequencyRanges** method

The **GetSupportedFrequencyRanges** method returns the available frequency ranges for the equalizer band.

Syntax

```
HRESULT GetSupportedFrequencyRanges  
(IBMDSwitcherFairlightAudioEqualizerBand FrequencyRange* ranges);
```

Parameters

Name	Direction	Description
ranges	out	The available frequency ranges.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ranges parameter is invalid.

7.5.12.7 **IBMDSwitcherFairlightAudioEqualizerBand::GetFrequencyRange** method

The **GetFrequencyRange** method returns the current frequency range of the equalizer band.

Syntax

```
HRESULT GetFrequencyRange  
(IBMDSwitcherFairlightAudioEqualizerBand FrequencyRange* range);
```

Parameters

Name	Direction	Description
range	out	The current frequency range.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The range parameter is invalid.

7.5.12.8 **IBMDSwitcherFairlightAudioEqualizerBand::SetFrequencyRange** method

The **SetFrequencyRange** method sets the frequency range of the equalizer band.

Syntax

```
HRESULT SetFrequencyRange  
(IBMDSwitcherFairlightAudioEqualizerBand FrequencyRange range);
```

Parameters

Name	Direction	Description
range	in	The desired frequency range.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_INVALIDARG	The range is not a valid identifier.

7.5.12.9 **IBMDSwitcherFairlightAudioEqualizerBand::GetFrequencyRangeMinMax** method

The **GetFrequencyRangeMinMax** method gets the minimum and maximum frequencies of a specified **BMDSwitcherFairlightAudioEqualizerBandFrequencyRange**.

Syntax

```
HRESULT GetFrequencyRangeMinMax  
(BMDSwitcherFairlightAudioEqualizerBandFrequencyRange range,  
 uint32_t* minFreq, uint32_t* maxFreq);
```

Parameters

Name	Direction	Description
range	in	The desired frequency range.
minFreq	out	The current minimum frequency.
maxFreq	out	The current maximum frequency.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The minFreq or maxFreq parameters are invalid.
E_INVALIDARG	The range is not a valid identifier.

7.5.12.10 **IBMDSwitcherFairlightAudioEqualizerBand::GetFrequency** method

The **GetFrequency** method returns the current frequency of the equalizer band.

Syntax

```
HRESULT GetFrequency (uint32_t* freq);
```

Parameters

Name	Direction	Description
freq	out	The current frequency.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The freq parameter is invalid.

7.5.12.11 **IBMDSwitcherFairlightAudioEqualizerBand::SetFrequency** method

The **SetFrequency** method sets the frequency of the equalizer band.

Syntax

```
HRESULT SetFrequency (uint32_t freq);
```

Parameters

Name	Direction	Description
freq	in	The desired frequency.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.12.12 **IBMDSwitcherFairlightAudioEqualizerBand::GetGain** method

The **GetGain** method returns the current gain of the equalizer band.

Syntax

```
HRESULT GetGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current gain.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.5.12.13 **IBMDSwitcherFairlightAudioEqualizerBand::SetGain** method

The **SetGain** method sets the gain of the equalizer band.

Syntax

```
HRESULT SetGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired gain.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.12.14 **IBMDSwitcherFairlightAudioEqualizerBand::GetQFactor** method

The **GetQFactor** method returns the current Q factor of the equalizer band.

Syntax

```
HRESULT GetQFactor (double* value);
```

Parameters

Name	Direction	Description
value	out	The current Q Factor.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The value parameter is invalid.

7.5.12.15 **IBMDSwitcherFairlightAudioEqualizerBand::SetQFactor** method

The **SetQFactor** method sets the Q factor of the equalizer band.

Syntax

```
HRESULT SetQFactor (double value);
```

Parameters

Name	Direction	Description
value	in	The desired Q Factor.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.12.16 **IBMDSwitcherFairlightAudioEqualizerBand::Reset** method

The **Reset** method resets the equalizer band to its default state.

Syntax

```
HRESULT Reset (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.12.17 **IBMDSwitcherFairlightAudioEqualizerBand::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioEqualizerBand** object. Pass an object implementing the **IBMDSwitcherFairlightAudioEqualizerBandCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback lightAudioEqualizerBandCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioEqualizerBandCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.12.18 **IBMDSwitcherFairlightAudioEqualizerBand::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherFairlightAudioEqualizerBandCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioEqualizerBandCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.13 IBMDSwitcherFairlightAudioEqualizerBandCallback Interface

The `IBMDSwitcherFairlightAudioEqualizerBandCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherFairlightAudioEqualizerBand` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherFairlightAudioEqualizerBand</code>	<code>IID_IBMDSwitcherFairlightAudioEqualizerBand</code>	An <code>IBMDSwitcherFairlightAudioEqualizerBandCallback</code> object interface is installed with <code>IBMDSwitcherFairlightAudioEqualizerBand::AddCallback</code> and removed with <code>IBMDSwitcherFairlightAudioEqualizerBand::RemoveCallback</code>

Public Member Functions	
Value	Description
<code>Notify</code>	Called when an event occurs.

7.5.13.1 IBMDSwitcherFairlightAudioEqualizerBandCallback::Notify method

The `Notify` method is called when `IBMDSwitcherFairlightAudioEqualizerBand` events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherFairlightAudioEqualizerBandEventType eventType);
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	<code>IBMDSwitcherFairlightAudioEqualizerBandEventType</code> that describes the type of event that has occurred.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_FAIL</code>	Failure.

7.5.14 IBMDSwitcherFairlightAudioDynamicsProcessor Interface

The `IBMDSwitcherFairlightAudioDynamicsProcessor` object interface is the root object for all Fairlight audio dynamics processing.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioMixer	IID_IBMDSwitcherFairlightAudioMixer	<code>IBMDSwitcherFairlightAudioMixer::GetMasterOutEffect</code> can return an <code>IBMDSwitcherFairlightAudioDynamicsProcessor</code> object interface.
IBMDSwitcherFairlightAudioSource	IID_IBMDSwitcherFairlightAudioSource	<code>IBMDSwitcherFairlightAudioSource::GetEffect</code> can return an <code>IBMDSwitcherFairlightAudioDynamicsProcessor</code> object interface.

Public Member Functions	
Method	Description
GetProcessor	Get the dynamics processor object interface.
GetMakeupGain	Get the current make up gain value.
SetMakeupGain	Set the make up gain value.
Reset	Reset the dynamics.
ResetInputPeakLevels	Reset the input peak level statistics.
ResetOutputPeakLevels	Reset the output peak level statistics.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

7.5.14.1 IBMDSwitcherFairlightAudioDynamicsProcessor::GetProcessor method

The `GetProcessor` method returns the dynamics processor object interface for the specified interface ID, such as `IBMDSwitcherFairlightAudioLimiter`, `IBMDSwitcherFairlightAudioCompressor`, `IBMDSwitcherFairlightAudioExpander`.

The object interface must be released by the caller when no longer required.

Syntax

```
HRESULT GetProcessor (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Interface ID for the desired interface.
ppv	out	Pointer to return interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_NOINTERFACE	Interface was not found.

7.5.14.2 **IBMDSwitcherFairlightAudioDynamicsProcessor::GetMakeupGain** method

The **GetMakeupGain** method returns the current make up gain value.

Syntax

```
HRESULT GetMakeupGain (double* gain);
```

Parameters

Name	Direction	Description
gain	out	The current make up gain value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gain parameter is invalid.

7.5.14.3 **IBMDSwitcherFairlightAudioDynamicsProcessor::SetMakeupGain** method

The **SetMakeupGain** method sets the make up gain value.

Syntax

```
HRESULT SetMakeupGain (double gain);
```

Parameters

Name	Direction	Description
gain	in	The desired make up gain value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.14.4 **IBMDSwitcherFairlightAudioDynamicsProcessor::Reset** method

The **Reset** method resets the dynamics to its default state.

Syntax

```
HRESULT Reset (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.14.5 **IBMDSwitcherFairlightAudioDynamicsProcessor::ResetInput PeakLevels method**

The **ResetInputPeakLevels** method resets the peak input level statistics.

Syntax

```
HRESULT ResetInputPeakLevels (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.14.6 **IBMDSwitcherFairlightAudioDynamicsProcessor::ResetOutput PeakLevels method**

The **ResetOutputPeakLevels** method resets the peak output level statistics.

Syntax

```
HRESULT ResetOutputPeakLevels (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.14.7 **IBMDSwitcherFairlightAudioDynamicsProcessor::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioDynamicsProcessor** object. Pass an object implementing the **IBMDSwitcherFairlightAudioDynamicsProcessorCallback** interface to receive callbacks. Adding a new callback

will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherFairlightAudioDynamics ProcessorCallback*  
callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioDynamics ProcessorCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.14.8 **IBMDSwitcherFairlightAudioDynamicsProcessor::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback  
(IBMDSwitcherFairlightAudioDynamicsProcessorCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioDynamics ProcessorCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.15 IBMDSwitcherFairlightAudioDynamicsProcessorCallback Interface

The **IBMDSwitcherFairlightAudioDynamicsProcessorCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherFairlightAudioDynamicsProcessor** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioDynamicsProcessor	IID_IBMDSwitcherFairlightAudioDynamicsProcessor	An IBMDSwitcherFairlightAudioDynamicsProcessorCallback object interface is installed with IBMDSwitcherFairlightAudioDynamicsProcessor::AddCallback and removed with IBMDSwitcherFairlightAudioDynamicsProcessor::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.
InputLevelNotification	Reports input level statistics.
OutputLevelNotification	Reports output level statistics.

7.5.15.1 IBMDSwitcherFairlightAudioDynamicsProcessorCallback::Notify method

The **Notify** method is called when **IBMDSwitcherFairlightAudioDynamicsProcessor** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherFairlightAudioDynamics ProcessorEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherFairlightAudioDynamics ProcessorEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.15.2 IBMDSwitcherFairlightAudioDynamicsProcessorCallback::InputLevel Notification method

The **InputLevelNotification** method is called periodically to report the current dB input levels and the last known peak levels. These peak levels can be reset using **IBMSwitcherFairlightAudioDynamicsProcessor::ResetInputPeakLevels**.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMSwitcherFairlightAudioMixer::SetAllLevelNotificationsEnabled**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT InputLevelNotification (uint32_t numLevels, const double* levels,
                                uint32_t numPeakLevels, const double* peakLevels);
```

Parameters

Name	Direction	Description
numLevels	in	The number of input levels.
levels	in	The current input dB levels.
numPeakLevels	in	The number of input peak levels.
peakLevels	in	The highest encountered input peak dB level.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.15.3 **IBMDSwitcherFairlightAudioDynamicsProcessorCallback::OutputLevel Notification method**

The **OutputLevelNotification** method is called periodically to report the current dB output levels and the last known peak levels. These peak levels can be reset using

IBMDSwitcherFairlightAudioDynamicsProcessor::ResetOutputPeakLevels.

Note that this is an opt-in subscription. Enable or disable receiving these calls using

IBMDSwitcherFairlightAudioMixer::SetAllLevelNotificationsEnabled.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT OutputLevelNotification (uint32_t numLevels, const double* levels,
    uint32_t numPeakLevels, const double* peakLevels);
```

Parameters

Name	Direction	Description
numLevels	in	The number of output levels.
levels	in	The current output dB levels.
numPeakLevels	in	The number of output peak levels.
peakLevels	in	The highest encountered output peak level.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.16 **IBMDSwitcherFairlightAudioLimiter Interface**

The **IBMDSwitcherFairlightAudioLimiter** object interface is used for manipulating the Fairlight audio limiter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioDynamicsProcessor	IID_IBMDSwitcherFairlightAudioDynamicsProcessor	IBMDSwitcherFairlightAudioDynamicsProcessor::GetProcessor can return an IBMDSwitcherFairlightAudioLimiter object interface.

Public Member Functions	
Method	Description
GetEnabled	Get the current limiter-enabled flag.
SetEnabled	Set the desired limiter-enabled flag.
GetThreshold	Get the current threshold value.
SetThreshold	Set the threshold value.

Public Member Functions	
Method	Description
GetAttack	Get the current attack value.
SetAttack	Set the attack value.
GetHold	Get the current hold value.
SetHold	Set the hold value.
GetRelease	Get the current release value.
SetRelease	Set the limiter release value.
Reset	Reset the limiter.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

7.5.16.1 **IBMDSwitcherFairlightAudioLimiter::GetEnabled** method

The **GetEnabled** method returns the current limiter enabled flag.

Syntax

```
HRESULT GetEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
enabled	out	The current limiter enabled flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.

7.5.16.2 **IBMDSwitcherFairlightAudioLimiter::SetEnabled** method

The **SetEnabled** method sets the limiter enabled flag.

Syntax

```
HRESULT SetEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	The desired limiter enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.16.3 **IBMDSwitcherFairlightAudioLimiter::GetThreshold** method

The `GetThreshold` method returns the current limiter threshold value.

Syntax

```
HRESULT GetThreshold (double* decibel);
```

Parameters

Name	Direction	Description
decibel	out	The current threshold value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The decibel parameter is invalid.

7.5.16.4 **IBMDSwitcherFairlightAudioLimiter::SetThreshold** method

The `SetThreshold` method sets the limiter threshold value.

Syntax

```
HRESULT SetThreshold (double decibel);
```

Parameters

Name	Direction	Description
decibel	in	The desired threshold value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.16.5 **IBMDSwitcherFairlightAudioLimiter::GetAttack** method

The `GetAttack` method returns the current limiter attack value.

Syntax

```
HRESULT GetAttack (double* ms);
```

Parameters

Name	Direction	Description
ms	out	The current attack value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ms parameter is invalid.

7.5.16.6 **IBMDSwitcherFairlightAudioLimiter::SetAttack** method

The **SetAttack** method sets the limiter attack value.

Syntax

```
HRESULT SetAttack (double ms);
```

Parameters

Name	Direction	Description
ms	in	The desired attack value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.16.7 **IBMDSwitcherFairlightAudioLimiter::GetHold** method

The **GetHold** method returns the current limiter hold value.

Syntax

```
HRESULT GetHold (double* ms);
```

Parameters

Name	Direction	Description
ms	out	The current hold value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ms parameter is invalid.

7.5.16.8 **IBMDSwitcherFairlightAudioLimiter::SetHold** method

The **SetHold** method sets the limiter hold value.

Syntax

```
HRESULT SetHold (double ms);
```

Parameters

Name	Direction	Description
ms	in	The desired hold value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.16.9 **IBMDSwitcherFairlightAudioLimiter::GetRelease** method

The **GetRelease** method returns the current limiter release value.

Syntax

```
HRESULT GetRelease (double* ms);
```

Parameters

Name	Direction	Description
ms	out	The current release value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ms parameter is invalid.

7.5.16.10 **IBMDSwitcherFairlightAudioLimiter::SetRelease** method

The **SetRelease** method sets the limiter release value.

Syntax

```
HRESULT SetRelease (double ms);
```

Parameters

Name	Direction	Description
ms	in	The desired release value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.16.11 **IBMDSwitcherFairlightAudioLimiter::Reset** method

The **Reset** method resets the limiter to its default state.

Syntax

```
HRESULT Reset (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.16.12 **IBMDSwitcherFairlightAudioLimiter::AddCallback** method

The `AddCallback` method configures a callback to be called when events occur for an `IBMDSwitcherFairlightAudioLimiter` object. Pass an object implementing the `IBMDSwitcherFairlightAudioAudioLimiterCallback` interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherFairlightAudioLimiterCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the <code>IBMDSwitcherFairlightAudioLimiterCallback</code> object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.16.13 **IBMDSwitcherFairlightAudioLimiter::RemoveCallback** method

The `RemoveCallback` method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback(IBMDSwitcherFairlightAudioLimiterCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the <code>IBMDSwitcherFairlightAudioLimiterCallback</code> object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.17 IBMDSwitcherFairlightAudioLimiterCallback Interface

The **IBMDSwitcherFairlightAudioLimiterCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherFairlightAudioLimiter** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioLimiter	IID_IBMDSwitcherFairlightAudioLimiter	An IBMDSwitcherFairlightAudioLimiterCallback object interface is installed with IBMDSwitcherFairlightAudioLimiter::AddCallback and removed with IBMDSwitcherFairlightAudioLimiter::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.
GainReductionLevelNotification	Reports the gain reduction level statistics.

7.5.17.1 IBMDSwitcherFairlightAudioLimiterCallback::Notify method

The **Notify** method is called when **IBMDSwitcherFairlightAudioLimiter** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherFairlightAudioLimiterEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherFairlightAudioLimiterEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.17.2 **IBMDSwitcherFairlightAudioLimiterCallback::GainReductionLevelNotification** method

The **GainReductionLevelNotification** method is called periodically to report the current gain reduction dB levels.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMDSwitcherFairlightAudioMixer::SetAllLevelNotificationsEnabled**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT GainReductionLevelNotification (uint32_t numLevels,  
const double* levels);
```

Parameters

Name	Direction	Description
numLevels	in	The number of levels of the gain reduction.
levels	in	The current dB levels of the gain reduction.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.18 **IBMDSwitcherFairlightAudioCompressor** Interface

The **IBMDSwitcherFairlightAudioCompressor** object interface is used for manipulating the Fairlight audio compressor.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioDynamicsProcessor	IID_IBMDSwitcherFairlightAudioDynamicsProcessor	IBMDSwitcherFairlightAudioDynamicsProcessor::GetProcessor can return an IBMDSwitcherFairlightAudioCompressor object interface.

Public Member Functions	
Method	Description
GetEnabled	Get the current limiter-enabled flag.
SetEnabled	Set the desired limiter-enabled flag.
GetThreshold	Get the current threshold value.
SetThreshold	Set the threshold value.
GetAttack	Get the current attack value.
SetAttack	Set the attack value.

Public Member Functions	
Method	Description
GetHold	Get the current hold value.
SetHold	Set the hold value.
GetRelease	Get the current release value.
SetRelease	Set the limiter release value.
Reset	Reset the limiter.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

7.5.18.1 IBMDSwitcherFairlightAudioCompressor::GetEnabled method

The `GetEnabled` method returns the current compressor enabled flag.

Syntax

```
HRESULT GetEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
enabled	out	The current compressor enabled flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.

7.5.18.2 IBMDSwitcherFairlightAudioCompressor::SetEnabled method

The `SetEnabled` method sets the desired compressor enabled flag.

Syntax

```
HRESULT SetEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	The desired compressor enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Faiure.

7.5.18.3 **IBMDSwitcherFairlightAudioCompressor::GetThreshold** method

The **GetThreshold** method returns the current compressor threshold value.

Syntax

```
HRESULT GetThreshold (double* decibel);
```

Parameters

Name	Direction	Description
decibel	out	The current threshold value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The decibel parameter is invalid.

7.5.18.4 **IBMDSwitcherFairlightAudioCompressor::SetThreshold** method

The **SetThreshold** method sets the compressor threshold value.

Syntax

```
HRESULT SetThreshold (double decibel);
```

Parameters

Name	Direction	Description
decibel	in	The desired threshold value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.18.5 **IBMDSwitcherFairlightAudioCompressor::GetAttack** method

The **GetAttack** method returns the current compressor attack value.

Syntax

```
HRESULT GetAttack (double* ms);
```

Parameters

Name	Direction	Description
ms	out	The current attack value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ms parameter is invalid.

7.5.18.6 **IBMDSwitcherFairlightAudioCompressor::SetAttack** method

The **SetAttack** method sets the compressor attack value.

Syntax

```
HRESULT SetAttack (double ms);
```

Parameters

Name	Direction	Description
ms	in	The desired attack value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.18.7 **IBMDSwitcherFairlightAudioCompressor::GetHold** method

The **GetHold** method returns the current compressor hold value.

Syntax

```
HRESULT GetHold (double* ms);
```

Parameters

Name	Direction	Description
ms	out	The current hold value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ms parameter is invalid.

7.5.18.8 **IBMDSwitcherFairlightAudioCompressor::SetHold** method

The **SetHold** method sets the compressor hold value.

Syntax

```
HRESULT SetHold (double ms);
```

Parameters

Name	Direction	Description
ms	in	The desired hold value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.18.9 **IBMDSwitcherFairlightAudioCompressor::GetRelease** method

The **GetRelease** method returns the current compressor release value.

Syntax

```
HRESULT GetRelease (double* ms);
```

Parameters

Name	Direction	Description
ms	out	The current release value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ms parameter is invalid.

7.5.18.10 **IBMDSwitcherFairlightAudioCompressor::SetRelease** method

The **SetRelease** method sets the desired compressor release value.

Syntax

```
HRESULT SetRelease (double ms);
```

Parameters

Name	Direction	Description
ms	in	The desired release value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.18.11 **IBMDSwitcherFairlightAudioCompressor::Reset** method

The **Reset** method resets the compressor to its default state.

Syntax

```
HRESULT Reset (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.18.12 **IBMDSwitcherFairlightAudioCompressor::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioCompressor** object. Pass an object implementing the **IBMDSwitcherFairlightAudioCompressorCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherFairlightAudioCompressorCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioCompressorCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.18.13 **IBMDSwitcherFairlightAudioCompressor::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherFairlightAudioCompressorCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioCompressorCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.19 IBMDSwitcherFairlightAudioCompressorCallback Interface

The **IBMDSwitcherFairlightAudioCompressorCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherFairlightAudioCompressor** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioCompressor	IID_IBMDSwitcherFairlightAudioCompressor	An IBMDSwitcherFairlightAudioCompressorCallback object interface is installed with IBMDSwitcherFairlightAudioCompressor::AddCallback and removed with IBMDSwitcherFairlightAudioCompressor::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.
GainReductionLevelNotification	Reports the gain reduction level statistics.

7.5.19.1 IBMDSwitcherFairlightAudioCompressorCallback::Notify method

The **Notify** method is called when **IBMDSwitcherFairlightAudioCompressor** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherFairlightAudioCompressorEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherFairlightAudioCompressorEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.19.2 **IBMDSwitcherFairlightAudioCompressorCallback::GainReductionLevel Notification method**

The **GainReductionLevelNotification** method is called periodically to report the current gain reduction dB levels.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMDSwitcherFairlightAudioMixer::SetAllLevelNotificationsEnabled**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT GainReductionLevelNotification (uint32_t numLevels, const double* levels);
```

Parameters

Name	Direction	Description
numLevels	in	The number of levels of the gain reduction.
levels	in	The current dB levels of the gain reduction.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20 **IBMDSwitcherFairlightAudioExpander Interface**

The **IBMDSwitcherFairlightAudioExpander** object interface is used for manipulating the Fairlight audio expander.

A reference to an **IBMDSwitcherFairlightAudioExpander** object interface may be obtained from an **IBMDSwitcherFairlightAudioDynamicsProcessor** object interface using the **GetProcessor** method.

Pass **IID_IBMDSwitcherFairlightAudioExpander** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioDynamicsProcessor	IID_IBMDSwitcherFairlightAudioDynamicsProcessor	IBMDSwitcherFairlightAudioDynamicsProcessor::GetProcessor can return an IBMDSwitcherFairlightAudioExpander object interface.

Public Member Functions	
Method	Description
GetEnabled	Get the current expander-enabled flag.
SetEnabled	Set the desired expander-enabled flag.
GetGateMode	Get the current gate mode.
SetGateMode	Set the gate mode.
GetThreshold	Get the current threshold value.

Public Member Functions	
Method	Description
SetThreshold	Set the threshold value.
GetRange	Get the current range value.
SetRange	Set the range value.
GetRatio	Get the current ratio value.
SetRatio	Set the ratio value.
GetAttack	Get the current attack value.
SetAttack	Set the attack value.
GetHold	Get the hold value.
SetHold	Set the hold value.
GetRelease	Get the current release value.
SetRelease	Set the release value.
Reset	Reset the expander.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

7.5.20.1 **IBMDSwitcherFairlightAudioExpander::GetEnabled** method

The **GetEnabled** method returns the current expander enabled flag.

Syntax

```
HRESULT GetEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
enabled	out	The current expander enabled flag.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The enabled parameter is invalid.

7.5.20.2 **IBMDSwitcherFairlightAudioExpander::SetEnabled** method

The **SetEnabled** method sets the expander enabled flag.

Syntax

```
HRESULT SetEnabled (boolean enabled);
```

Parameters

Name	Direction	Description
enabled	in	The desired expander enabled flag.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20.3 **IBMDSwitcherFairlightAudioExpander::GetGateMode** method

The **GetGateMode** method returns the current expander gate mode.

Syntax

```
HRESULT GetGateMode (boolean* gateMode);
```

Parameters

Name	Direction	Description
gateMode	out	The current gate mode.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The gateMode parameter is invalid.

7.5.20.4 **IBMDSwitcherFairlightAudioExpander::SetGateMode** method

The **SetGateMode** method sets the expander gate mode.

Syntax

```
HRESULT SetGateMode (boolean gateMode);
```

Parameters

Name	Direction	Description
gateMode	in	The desired gate mode.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20.5 **IBMDSwitcherFairlightAudioExpander::GetThreshold** method

The `GetThreshold` method returns the current expander threshold value.

Syntax

```
HRESULT GetThreshold (double* decibel);
```

Parameters

Name	Direction	Description
decibel	out	The current threshold value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The decibel parameter is invalid.

7.5.20.6 **IBMDSwitcherFairlightAudioExpander::SetThreshold** method

The `SetThreshold` method sets the expander threshold value.

Syntax

```
HRESULT SetThreshold (double decibel);
```

Parameters

Name	Direction	Description
decibel	in	The desired threshold value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20.7 **IBMDSwitcherFairlightAudioExpander::GetRange** method

The `GetRange` method returns the current expander range value.

Syntax

```
HRESULT GetRange (double* range);
```

Parameters

Name	Direction	Description
range	out	The current range value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The range parameter is invalid.

7.5.20.8 **IBMDSwitcherFairlightAudioExpander::SetRange** method

The **SetRange** method sets the expander range value.

Syntax

```
HRESULT SetRange (double range);
```

Parameters

Name	Direction	Description
range	in	The desired range value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20.9 **IBMDSwitcherFairlightAudioExpander::GetRatio** method

The **GetRatio** method returns the current expander ratio value.

Syntax

```
HRESULT GetRatio (double* ratio);
```

Parameters

Name	Direction	Description
ratio	out	The current ratio value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ratio parameter is invalid.

7.5.20.10 **IBMDSwitcherFairlightAudioExpander::SetRatio** method

The **SetRatio** method sets the expander ratio value.

Syntax

```
HRESULT SetRatio (double ratio);
```

Parameters

Name	Direction	Description
ratio	in	The desired ratio value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20.11 **IBMDSwitcherFairlightAudioExpander::GetAttack** method

The **GetAttack** method returns the current expander attack value.

Syntax

```
HRESULT GetAttack (double* ms);
```

Parameters

Name	Direction	Description
ms	out	The current attack value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ms parameter is invalid.

7.5.20.12 **IBMDSwitcherFairlightAudioExpander::SetAttack** method

The **SetAttack** method sets the expander attack value.

Syntax

```
HRESULT SetAttack (double ms);
```

Parameters

Name	Direction	Description
ms	in	The desired attack value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20.13 **IBMDSwitcherFairlightAudioExpander::GetHold** method

The **GetHold** method returns the current expander hold value.

Syntax

```
HRESULT GetHold (double* ms);
```

Parameters

Name	Direction	Description
ms	out	The current hold value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ms parameter is invalid.

7.5.20.14 **IBMDSwitcherFairlightAudioExpander::SetHold** method

The **SetHold** method sets the expander hold value.

Syntax

```
HRESULT SetHold (double ms);
```

Parameters

Name	Direction	Description
ms	in	The desired hold value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20.15 **IBMDSwitcherFairlightAudioExpander::GetRelease** method

The **GetRelease** method returns the current expander release value.

Syntax

```
HRESULT GetRelease (double* ms);
```

Parameters

Name	Direction	Description
ms	out	The current release value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ms parameter is invalid.

7.5.20.16 **IBMDSwitcherFairlightAudioExpander::SetRelease** method

The **SetRelease** method sets the expander release value.

Syntax

```
HRESULT SetRelease (double ms);
```

Parameters

Name	Direction	Description
ms	in	The desired release value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20.17 **IBMDSwitcherFairlightAudioExpander::Reset** method

The **Reset** method resets the expander to its default state.

Syntax

```
HRESULT Reset (void);
```

Parameters

none.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.20.18 **IBMDSwitcherFairlightAudioExpander::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioExpander** object. Pass an object implementing the **IBMDSwitcherFairlightAudioExpanderCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherFairlightAudioExpanderCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioExpanderCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.20.19 IBMDSwitcherFairlightAudioExpander::RemoveCallback method

The `RemoveCallback` method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherFairlightAudioExpanderCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the <code>IBMDSwitcherFairlightAudioExpander Callback</code> object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.21 IBMDSwitcherFairlightAudioExpanderCallback Interface

The `IBMDSwitcherFairlightAudioExpanderCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherFairlightAudioExpander` object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherFairlightAudioExpander</code>	<code>IID_IBMDSwitcherFairlightAudioExpander</code>	An <code>IBMDSwitcherFairlightAudioExpanderCallback</code> object interface is installed with <code>IBMDSwitcherFairlightAudioExpander::AddCallback</code> and removed with <code>IBMDSwitcherFairlightAudioExpander::RemoveCallback</code>

Public Member Functions	
Method	Description
<code>Notify</code>	Called when an event occurs.
<code>GainReductionLevelNotification</code>	Reports the gain reduction level statistics.

7.5.21.1 **IBMDSwitcherFairlightAudioExpanderCallback::Notify** method

The **Notify** method is called when **IBMDSwitcherFairlightAudioExpander** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (IBMDSwitcherFairlightAudioExpanderEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherFairlightAudioExpander EventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.21.2 **IBMDSwitcherFairlightAudioExpanderCallback::GainReductionLevel** Notification method

The **GainReductionLevelNotification** method is called periodically to report the current gain reduction dB levels.

Note that this is an opt-in subscription. Enable or disable receiving these calls using **IBMDSwitcherFairlightAudioMixer::SetAllLevelNotificationsEnabled**.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT GainReductionLevelNotification (uint32_t numLevels, const double* levels);
```

Parameters

Name	Direction	Description
numLevels	in	The number of levels of the gain reduction.
levels	in	The current dB levels of the gain reduction.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.22 IBMDSwitcherFairlightAudioHeadphoneOutputIterator Interface

The `IBMDSwitcherFairlightAudioHeadphoneOutputIterator` is used to enumerate the available headphone outputs for the Fairlight audio mixer.

A reference to an `IBMDSwitcherFairlightAudioHeadphoneOutputIterator` object interface may be obtained from an `IBMDSwitcherFairlightAudioMixer` object interface using the `CreateIterator` method.

Pass `IID_IBMDSwitcherFairlightAudioHeadphoneOutputIterator` for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherFairlightAudioMixer</code>	<code>IID_IBMDSwitcherFairlightAudioMixer</code>	<code>IBMDSwitcherFairlightAudioMixer::CreateIterator</code> can return an <code>IBMDSwitcherFairlightAudioHeadphoneOutputIterator</code> object interface.

Public Member Functions	
Method	Description
<code>Next</code>	Returns a pointer to the next <code>IBMDSwitcherFairlightAudioHeadphoneOutput</code> object interface.

7.5.22.1 IBMDSwitcherFairlightAudioHeadphoneOutputIterator::Next method

The `Next` method returns the next available `IBMDSwitcherFairlightAudioHeadphoneOutput` object interface.

Syntax

```
HRESULT Next (IBMDSwitcherFairlightAudioHeadphoneOutput* audioHeadphoneOutput);
```

Parameters

Name	Direction	Description
<code>audioHeadphoneOutput</code>	out	<code>IBMDSwitcherFairlightAudioHeadphoneOutput</code> object interface.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>S_FALSE</code>	No more <code>IBMDSwitcherFairlightAudioHeadphoneOutput</code> objects available.
<code>E_POINTER</code>	The <code>audioHeadphoneOutput</code> parameter is invalid.

7.5.23 IBMDSwitcherFairlightAudioHeadphoneOutput Interface

The `IBMDSwitcherFairlightAudioHeadphoneOutput` object interface is used for manipulating parameters specific to Fairlight audio headphone outputs.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioHeadphoneOutputIterator	IID_IBMDSwitcherFairlightAudioHeadphoneOutputIterator	An <code>IBMDSwitcherFairlightAudioHeadphoneOutput</code> interface can be obtained with <code>IBMDSwitcherFairlightAudioHeadphoneOutputIterator::Next</code>

Public Member Functions	
Method	Description
DoesSupportSolo	Determines if solo monitoring is supported by the switcher.
DoesSupportMute	Determines if mute is supported by the switcher.
GetGain	Get the current gain value.
SetGain	Set the gain value.
GetInputMasterOutGain	Get the current master out input gain value.
SetInputMasterOutGain	Set the master out input gain value.
GetInputMasterOutMute	Get the mute state of the master output.
SetInputMasterOutMute	Set the mute state of the master output.
DoesSupportTalkback	Determines if talkback is supported by the switcher.
GetInputTalkbackGain	Get the current talkback input gain value.
SetInputTalkbackGain	Set the talkback input gain value.
GetInputTalkbackMute	Get the mute state of the talkback output.
SetInputTalkbackMute	Set the mute state of the talkback output.
DoesSupportSidetone	Determines if sidetone is supported by the switcher.
GetInputSidetoneGain	Get the current headphone sidetone (microphone) input gain value.
SetInputSidetoneGain	Set the headphone sidetone (microphone) input gain value.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

7.5.23.1 **IBMDSwitcherFairlightAudioHeadphoneOutput::DoesSupportSolo** method

The **DoesSupportSolo** method is used to determine whether solo monitoring is supported by the switcher.

Syntax

```
HRESULT DoesSupportSolo(Boolean* supportsSolo);
```

Parameters

Name	Direction	Description
supportsSolo	out	Boolean value describing whether solo monitoring is supported by the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsSolo parameter is invalid.

7.5.23.2 **IBMDSwitcherFairlightAudioHeadphoneOutput::DoesSupportMute** method

The **DoesSupportMute** method is used to determine whether mute is supported by the switcher.

Syntax

```
HRESULT DoesSupportMute(Boolean* supportsMute);
```

Parameters

Name	Direction	Description
supportsMute	out	Boolean value describing whether mute is supported by the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsMute parameter is invalid.

7.5.23.3 **IBMDSwitcherFairlightAudioHeadphoneOutput::GetGain** method

The **GetGain** method returns the current gain applied to the Fairlight audio headphone output.

Syntax

```
HRESULT GetGain (double* decibel);
```

Parameters

Name	Direction	Description
decibel	out	The current decibel value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The decibel parameter is not a valid pointer.

7.5.23.4 **IBMDSwitcherFairlightAudioHeadphoneOutput::SetGain** method

The **SetGain** method sets the gain to apply to the Fairlight headphone output.

Syntax

```
HRESULT SetGain (double decibel);
```

Parameters

Name	Direction	Description
decibel	in	The desired decibel value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.23.5 **IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputMasterOutGain** method

The **GetInputMasterOutGain** method returns the gain currently applied to the master out input of the headphone output.

Syntax

```
HRESULT GetInputMasterOutGain (double* decibel);
```

Parameters

Name	Direction	Description
decibel	out	The current decibel value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The decibel parameter is not a valid pointer.

7.5.23.6 **IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputMasterOutGain** method

The **SetInputMasterOutGain** method sets the gain to apply to the master out input of the headphone output.

Syntax

```
HRESULT SetInputMasterOutGain (double decibel);
```

Parameters

Name	Direction	Description
decibel	in	The desired decibel value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.23.7 **IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputMasterOutMute** method

The **GetInputMasterOutMute** method is used to determine the current mute state of the master output.

Syntax

```
HRESULT GetInputMasterOutMute(Boolean* muteMaster);
```

Parameters

Name	Direction	Description
muteMaster	out	The mute state of the master output.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The muteMaster parameter is invalid.

7.5.23.8 **IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputMasterOutMute** method

The **SetInputMasterOutMute** method sets the mute state of the master output.

Syntax

```
HRESULT SetInputMasterOutMute(Boolean muteMaster);
```

Parameters

Name	Direction	Description
muteMaster	in	The mute state of the master output.

Return Values

Value	Description
S_OK	Success.
E_NOTIMPL	The switcher does not support master output mute.
E_FAIL	Failure.

7.5.23.9 **IBMDSwitcherFairlightAudioHeadphoneOutput::DoesSupportTalkback** method

The **DoesSupportTalkback** method is used to determine whether talkback is supported by the switcher.

Syntax

```
HRESULT DoesSupportTalkback(Boolean* supportsTalkback);
```

Parameters

Name	Direction	Description
supportsTalkback	out	Boolean value describing whether talkback is supported by the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsTalkback parameter is invalid.

7.5.23.10 **IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputTalkbackGain** method

The **GetInputTalkbackGain** method returns the gain currently applied to the talkback input of the headphone output.

Syntax

```
HRESULT GetInputTalkbackGain (double* decibel);
```

Parameters

Name	Direction	Description
decibel	out	The current decibel value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The decibel parameter is not a valid pointer.

7.5.23.11 **IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputTalkbackGain** method

The **SetInputTalkbackGain** method sets the gain to apply to the talkback input of the headphone output.

Syntax

```
HRESULT SetInputTalkbackGain (double decibel);
```

Parameters

Name	Direction	Description
decibel	in	The desired decibel value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.23.12 **IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputTalkbackMute** method

The **GetInputTalkbackMute** method is used to determine the current mute state of the talkback output.

Syntax

```
HRESULT GetInputTalkbackMute(Boolean* muteTalkback);
```

Parameters

Name	Direction	Description
muteTalkback	out	The mute state of the talkback output.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The muteTalkback parameter is invalid.

7.5.23.13 **IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputTalkbackMute** method

The **SetInputTalkbackMute** method sets the mute state of the talkback output.

Syntax

```
HRESULT SetInputTalkbackMute(Boolean muteTalkback);
```

Parameters

Name	Direction	Description
muteTalkback	in	The mute state of the talkback output.

Return Values

Value	Description
S_OK	Success.
E_NOTIMPL	The switcher does not support talkback mute.
E_FAIL	Failure.

7.5.23.14 **IBMDSwitcherFairlightAudioHeadphoneOutput::DoesSupportSidetone** method

The **DoesSupportSidetone** method is used to determine whether sidetone is supported by the switcher..

Syntax

```
HRESULT DoesSupportSidetone(Boolean* supportsSidetone);
```

Parameters

Name	Direction	Description
supportsSidetone	out	Boolean value describing whether sidetone is supported by the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsSidetone parameter is invalid.

7.5.23.15 **IBMDSwitcherFairlightAudioHeadphoneOutput::GetInputSidetoneGain** method

The **GetInputSidetoneGain** method returns the gain currently applied to the sidetone (microphone) input of the headphone output.

Syntax

```
HRESULT GetInputSidetoneGain (double* decibel);
```

Parameters

Name	Direction	Description
decibel	out	The current decibel value.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The decibel parameter is not a valid pointer.

7.5.23.16 **IBMDSwitcherFairlightAudioHeadphoneOutput::SetInputSidetoneGain** method

The **SetInputSidetoneGain** method sets the gain to apply to the sidetone (microphone) input of the headphone output.

Syntax

```
HRESULT SetInputSidetoneGain (double decibel);
```

Parameters

Name	Direction	Description
decibel	in	The desired decibel value.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.23.17 **IBMDSwitcherFairlightAudioHeadphoneOutput::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioHeadphoneOutput** object. Pass an object implementing the **IBMDSwitcherFairlightAudioHeadphoneOutputCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherFairlightAudioHeadphoneOutputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioHeadphone OutputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.23.18 **IBMDSwitcherFairlightAudioHeadphoneOutput::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherFairlightAudioHeadphoneOutputCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioHeadphone OutputCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.24 IBMDSwitcherFairlightAudioHeadphoneOutputCallback Interface

The **IBMDSwitcherFairlightAudioHeadphoneOutputCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherFairlightAudioHeadphoneOutput** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioHeadphoneOutput	IID_IBMDSwitcherFairlightAudioHeadphoneOutput	An IBMDSwitcherFairlightAudioHeadphoneOutputCallback object interface is installed with IBMDSwitcherFairlightAudioHeadphoneOutput::AddCallback and removed with IBMDSwitcherFairlightAudioHeadphoneOutput::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

7.5.24.1 IBMDSwitcherFairlightAudioHeadphoneOutputCallback::Notify method

The **Notify** method is called when **IBMDSwitcherFairlightAudioHeadphoneOutput** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

Syntax

```
HRESULT Notify (BMDSwitcherFairlightAudioHeadphoneOutputEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherFairlightAudioHeadphoneOutputEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.25 IBMDSwitcherFairlightAnalogAudioInput Interface

The `IBMDSwitcherFairlightAnalogAudioInput` object interface is used for manipulating Fairlight audio input settings specific to analog inputs.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherFairlightAudioInput</code>	<code>IID_IBMDSwitcherFairlightAudioInput</code>	An <code>IBMDSwitcherFairlightAnalogAudioInput</code> object interface can be obtained with <code>IBMDSwitcherFairlightAudioInput::QueryInterface</code> .

Public Member Functions	
Method	Description
<code>GetSupportedInputLevels</code>	Get the supported analog input levels.
<code>GetInputLevel</code>	Get the current analog input level.
<code>SetInputLevel</code>	Set the analog input level.
<code>GetSupportedMicPowerModes</code>	Get the supported microphone power modes.
<code>GetMicPowerMode</code>	Get the current microphone power mode.
<code>SetMicPowerMode</code>	Set the microphone power mode.
<code>AddCallback</code>	Add a callback.
<code>RemoveCallback</code>	Remove a callback.

7.5.25.1 IBMDSwitcherFairlightAnalogAudioInput::GetSupportedInputLevels method

The `GetSupportedInputLevels` method gets the available analog input levels for this audio input, given as a bit mask of `BMDSwitcherFairlightAudioAnalogInputLevel`. This bit mask can be bitwise-ANDed with any value of `BMDSwitcherFairlightAudioAnalogInputLevel` (e.g. `bmdSwitcherFairlightAudioAnalogInputLevelIMicrophone`) to determine if that input level is available for this input.

Syntax

```
HRESULT GetSupportedInputLevels (BMDSwitcherFairlightAudioAnalogInputLevel* levels)
```

Parameters

Name	Direction	Description
<code>levels</code>	out	The available input levels for this audio input as a bit mask of <code>BMDSwitcherFairlightAudioAnalogInputLevel</code> .

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The <code>levels</code> parameter is invalid.

7.5.25.2 **IBMDSwitcherFairlightAnalogAudioInput::GetInputLevel** method

The **GetInputLevel** method gets the current input level setting of the audio input. This may change if the input supports multiple input levels, generating the event **bmdSwitcherFairlightAnalogAudioInputEventTypeLevelChanged**.

Syntax

```
HRESULT GetInputLevel(BMDSwitcherFairlightAudioAnalogInputLevel* level)
```

Parameters

Name	Direction	Description
level	out	The current input level.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The level parameter is invalid.

7.5.25.3 **IBMDSwitcherFairlightAnalogAudioInput::SetInputLevel** method

The **SetInputLevel** method sets the input level for this input using a **BMDSwitcherFairlightAudioAnalogInputLevel**. Not all input levels are supported for a given audio input. Call the **GetSupportedInputLevels** method to determine the available input levels for this audio input.

Syntax

```
HRESULT SetInputLevel(BMDSwitcherFairlightAudioAnalogInputLevel level)
```

Parameters

Name	Direction	Description
level	in	The desired input level.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The level parameter is not a valid input level for this input.
E_FAIL	Failure.

7.5.25.4 **IBMDSwitcherFairlightAnalogAudioInput::GetSupportedMicPowerModes** method

The **GetSupportedMicPowerModes** method gets the available microphone power modes for this analog audio input, given as a bit mask of **BMDSwitcherFairlightAudioAnalogInputMicPowerMode**. This bit mask can be bitwise-ANDed with any value of **BMDSwitcherFairlightAudioAnalogInputMicPowerMode** (e.g. **bmdSwitcherFairlightAudioAnalogInputMicPowerModePlugInPower**) to determine if that power mode is available for this input.

Syntax

```
HRESULT GetSupportedMicPowerModes  
(BMDSwitcherFairlightAudioAnalogInputMicPowerMode* powerModes);
```

Parameters

Name	Direction	Description
powerModes	out	The available microphone power modes for this analog audio input as a bit mask of BMDSwitcherFairlightAudioAnalogInputMicPowerMode .

Return Values

Value	Description
S_OK	Success.
E_POINTER	The powerModes parameter is invalid.

7.5.25.5 **IBMDSwitcherFairlightAnalogAudioInput::GetMicPowerMode** method

The **GetMicPowerMode** method gets the current microphone power mode setting of the analog audio input. This may change if the input supports multiple power modes, generating the event **bmdSwitcherFairlightAnalogAudioInputEventTypeMicrophonePowerModeChanged**.

Syntax

```
HRESULT GetMicPowerMode  
(BMDSwitcherFairlightAudioAnalogInputMicPowerMode* powerMode);
```

Parameters

Name	Direction	Description
powerMode	out	The current microphone power mode for this input.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The powerMode parameter is invalid.

7.5.25.6 **IBMDSwitcherFairlightAnalogAudioInput::SetMicPowerMode** method

The **SetMicPowerMode** method sets the microphone power mode for this input using a **BMDSwitcherFairlightAudioAnalogInputMicPowerMode**. Not all microphone power modes are supported for a given audio input. Call the **GetSupportedMicrophonePowerModes** method to determine the available power modes for this audio input. The power mode is only active if the input levels for this input are set to **bmdSwitcherFairlightAudioAnalogInputLevelMicrophone**.

Syntax

```
HRESULT SetMicPowerMode  
(BMDSwitcherFairlightAudioAnalogInputMicPowerMode powerMode);
```

Parameters

Name	Direction	Description
powerMode	in	The desired microphone power mode.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The powerMode parameter is not a valid microphone power mode for this input.
E_FAIL	Failure.

7.5.25.7 **IBMDSwitcherFairlightAnalogAudioInput::AddCallback** method

The **AddCallback** method configures a callback to be called when a Fairlight analog audio input property changes, such as a change in the input level.

Adding a new callback will not affect previously added callbacks.

Callbacks will be called on a separate thread and in the order of their addition by **AddCallback**.

Syntax

```
HRESULT AddCallback(IBMDSwitcherFairlightAnalogAudioInputCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAnalogAudioInputCallback interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.25.8 IBMDSwitcherFairlightAnalogAudioInput::RemoveCallback method

The RemoveCallback method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback(IBMDSwitcherFairlightAnalogAudioInputCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object to remove.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.26 IBMDSwitcherFairlightAnalogAudioInputCallback Interface

The **IBMDSwitcherFairlightAnalogAudioInputCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherFairlightAnalogAudioInput** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAnalogAudioInput	IID_IBMDSwitcherFairlightAnalogAudioInput	An IBMDSwitcherFairlightAnalogAudioInputCallback object interface is installed with IBMDSwitcherFairlightAnalogAudioInput::AddCallback and removed with IBMDSwitcherFairlightAnalogAudioInput::RemoveCallback .

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

7.5.26.1 **IBMDSwitcherFairlightAnalogAudioInputCallback::Notify** method

The **Notify** method is called when **IBMDSwitcherFairlightAnalogAudioInput** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(IBMDSwitcherFairlightAnalogAudioInputEventType eventType)
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherFairlightAnalogAudioInputEventType that describes the type of event that occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.27 **IBMDSwitcherFairlightAudioSolo** Interface

The **IBMDSwitcherFairlightAudioSolo** object interface is used for manipulating Fairlight audio output monitoring settings.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioHeadphoneOutput	IID_IBMDSwitcherFairlightAudioHeadphoneOutput	An IBMDSwitcherFairlightAudioSolo object interface can be obtained with IBMDSwitcherFairlightAudioHeadphoneOutput::QueryInterface .

Public Member Functions	
Method	Description
GetSolo	Get the current solo state.
SetSolo	Set the solo state.
GetSoloInput	Get the ID of the current solo input.
SetSoloInput	Set the ID of the solo input.
AddCallback	Add a callback
RemoveCallback	Remove a callback

7.5.27.1 IBMDSwitcherFairlightAudioSolo::GetSolo method

The `GetSolo` method gets the solo state of the audio output monitor.

Syntax

```
HRESULT GetSolo(Boolean* solo);
```

Parameters

Name	Direction	Description
solo	out	The current solo state of the audio monitor.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The solo parameter is invalid.

7.5.27.2 IBMDSwitcherFairlightAudioSolo::SetSolo method

The `SetSolo` method sets the solo state of the audio output monitor.

Syntax

```
HRESULT SetSolo(Boolean solo);
```

Parameters

Name	Direction	Description
solo	in	The desired solo state of the audio monitor.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.27.3 **BMDSwitcherFairlightAudioSolo::GetSoloInput** method

The **GetSoloInput** method gets the input ID and source ID of the audio source being monitored.

Syntax

```
HRESULT GetSoloInput(BMDSwitcherAudioInputId* audioInput,  
BMDSwitcherFairlightAudioSourceId* audioSource);
```

Parameters

Name	Direction	Description
audioInput	out	BMDSwitcherAudioInputId of the current solo audio input.
audioSource	out	BMDSwitcherFairlightAudioSourceId of the current solo audio source.

Return Values

Value	Description
S_OK	Success.
E_POINTER	A parameter is invalid.

7.5.27.4 **BMDSwitcherFairlightAudioSolo::SetSoloInput** method

The **SetSoloInput** method sets the input ID and source ID of the audio source to be monitored.

Syntax

```
HRESULT SetSoloInput(BMDSwitcherAudioInputId audioInput,  
BMDSwitcherFairlightAudioSourceId audioSource);
```

Parameters

Name	Direction	Description
audioInput	in	BMDSwitcherAudioInputId of the desired solo audio input.
audioSource	in	BMDSwitcherFairlightAudioSourceId of the desired solo audio source.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.5.27.5 IBMDSwitcherFairlightAudioSolo::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherFairlightAudioSolo** object. Pass an object implementing the **IBMDSwitcherFairlightAudioSoloCallback** interface to receive callbacks.

Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherFairlightAudioSoloCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioSoloCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.27.6 IBMDSwitcherFairlightAudioSolo::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback(IBMDSwitcherFairlightAudioSoloCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherFairlightAudioSoloCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.5.28 IBMDSwitcherFairlightAudioSoloCallback Interface

The **IBMDSwitcherFairlightAudioSoloCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherFairlightAudioSolo** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherFairlightAudioSolo	IID_ IBMDSwitcherFairlightAudioSolo	An IBMDSwitcherFairlightAudioSoloCallback object interface is installed with IBMDSwitcherFairlightAudioSolo::AddCallback and removed with IBMDSwitcherFairlightAudioSolo::RemoveCallback .

Public Member Functions

Method	Description
Notify	Called when an event occurs.

7.5.28.1 IBMDSwitcherFairlightAudioSoloCallback::Notify method

The **Notify** method is called when **IBMDSwitcherFairlightAudioSolo** events occur, such as solo state or solo input changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(IBMDSwitcherFairlightAudioSoloEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	IBMDSwitcherFairlightAudioSoloEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.6 Talkback Interface Reference

7.6.1 IBMDSwitcherTalkbackIterator Interface

The `IBMDSwitcherTalkbackIterator` is used to enumerate the available talkbacks.

A reference to an `IBMDSwitcherTalkbackIterator` object interface may be obtained from an `IBMDSwitcher` object interface using the `CreateIterator` method. Pass `IID_IBMDSwitcherTalkbackIterator` for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcher</code>	<code>IID_IBMDSwitcher</code>	<code>IBMDSwitcher::CreateIterator</code> can return an <code>IBMDSwitcherTalkbackIterator</code> object interface.

Public Member Functions

Method	Description
<code>Next</code>	Returns a pointer to the next <code>IBMDSwitcherTalkback</code> object interface.
<code>GetById</code>	Returns a pointer to an <code>IBMDSwitcherTalkback</code> object interface, given its <code>BMDSwitcherTalkbackId</code> .

7.6.1.1 IBMDSwitcherTalkbackIterator::Next method

The `Next` method returns the next available `IBMDSwitcherTalkback` object interface.

Syntax

```
HRESULT Next(IBMDSwitcherTalkback* talkback)
```

Parameters

Name	Direction	Description
<code>talkback</code>	out	<code>IBMDSwitcherTalkback</code> object interface.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>S_FALSE</code>	No more <code>IBMDSwitcherTalkback</code> objects available.
<code>E_POINTER</code>	The <code>talkback</code> parameter is invalid.

7.6.1.2 IBMDSwitcherTalkbackIterator::GetById method

The `GetById` method returns a pointer to an `IBMDSwitcherTalkback` object interface, given its `IBMDSwitcherTalkbackId`.

Syntax

```
HRESULT GetById(IBMDSwitcherTalkbackId talkbackId,
               IBMDSwitcherTalkback* talkback)
```

Parameters

Name	Direction	Description
talkbackId	in	IBMDSwitcherTalkbackId identifier.
talkback	out	IBMDSwitcherTalkback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The talkbackId is not a valid identifier.
E_POINTER	The talkback parameter is invalid.

7.6.2 IBMDSwitcherTalkback Interface

The `IBMDSwitcherTalkback` object interface is used for managing functionality relating to the talkback features on the switcher.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	An <code>IBMDSwitcherTalkback</code> interface can be obtained with <code>IBMDSwitcher::QueryInterface</code> .

Public Member Functions	
Method	Description
GetId	Query the talkback ID.
GetMuteSDI	Query the mute state of the talkback SDI input and output channels.
SetMuteSDI	Set the mute state of the talkback SDI input and output channels.
InputCanMuteSDI	Determine if the switcher has the capability of muting the talkback input SDI channels on a particular audio input.
CurrentInputSupportsMuteSDI	Determine if the current external port type of a particular audio input supports muting the talkback input SDI channels.
GetInputMuteSDI	Query the mute state of the talkback SDI channels on a particular audio input.
SetInputMuteSDI	Set the mute state of the talkback SDI channels on a particular audio input.
AddCallback	Add a callback.
RemoveCallback	Remove a callback.

7.6.2.1 IBMDSwitcherTalkback::GetId method

The **GetId** method is used to check the ID of the audio talkback channel. The ID will be a **BMDSwitcherTalkbackId** identifier.

Syntax

```
HRESULT GetId(BMDSwitcherTalkbackId* talkbackId)
```

Parameter

Name	Direction	Description
talkbackId	out	Identifier of the talkback object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The talkbackId parameter is invalid.

7.6.2.2 IBMDSwitcherTalkback::GetMuteSDI method

The **GetMuteSDI** method returns the mute state of the audio on the dedicated talkback input SDI channels.

Syntax

```
HRESULT GetMuteSDI (boolean* muteSDI);
```

Parameter

Name	Direction	Description
muteSDI	out	The mute state of the talkback input SDI channels.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The muteSDI parameter is not a valid pointer.

7.6.2.3 IBMDSwitcherTalkback::SetMuteSDI method

The **SetMuteSDI** method sets the mute state of the audio on the dedicated talkback input SDI channels.

Syntax

```
HRESULT SetMuteSDI (boolean muteSDI);
```

Parameters

Name	Direction	Description
muteSDI	out	The mute state of the talkback input SDI channels.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

7.6.2.4 **IBMDSwitcherTalkback::InputCanMuteSDI** method

The **InputCanMuteSDI** method is used to check if the switcher has the capability to mute the talkback input SDI channels of a particular audio input. The audio input is specified by its **BMDSwitcherAudioInputId** identifier.

Syntax

```
HRESULT InputCanMuteSDI(BMDSwitcherAudioInputId audioInputId, boolean* canMuteSDI);
```

Parameters

Name	Direction	Description
audioInputId	in	BMDSwitcherAudioInputId identifier.
canMuteSDI	out	A Boolean value indicating whether the switcher has the capability to mute the talkback input SDI channels of the specified audio input.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The audioInputId parameter is not a valid identifier.
E_POINTER	The canMuteSDI parameter is not a valid pointer.

7.6.2.5 **IBMDSwitcherTalkback::CurrentInputSupportsMuteSDI** method

The **CurrentInputSupportsMuteSDI** method is used to check if the current input port of a particular audio input supports muting the talkback input SDI channels. The audio input is identified by its **BMDSwitcherAudioInputId** identifier.

Syntax

```
HRESULT CurrentInputSupportsMuteSDI (BMDSwitcherAudioInputId audioInputId, boolean* supportsMuteSDI);
```

Parameters

Name	Direction	Description
audioInputId	in	BMDSwitcherAudioInputId identifier.
supportsMuteSDI	out	A Boolean value indicating whether the current audio input port supports muting the talkback SDI channels.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The audioInputId parameter is not a valid identifier.
E_POINTER	The supportsMuteSDI parameter is not a valid pointer.

7.6.2.6 **IBMDSwitcherTalkback::GetInputMuteSDI** method

The **GetInputMuteSDI** method is used to check the mute state of the audio on the dedicated talkback input SDI channels of a particular audio input. The input is identified by its **BMDSwitcherAudioInputId** identifier.

Syntax

```
HRESULT GetInputMuteSDI (BMDSwitcherAudioInputId audioInputId, boolean* muteSDI);
```

Parameters

Name	Direction	Description
audioInputId	in	BMDSwitcherAudioInputId identifier.
supportsMuteSDI	out	The current mute state of the audio on the talkback input SDI channels of the audio input.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The audioInputId parameter is not a valid identifier.
E_POINTER	The supportsMuteSDI parameter is not a valid pointer.
E_FAIL	Failure. This can happen if the switcher does not have the capability to mute the talkback input SDI channels of the specified audio input.

7.6.2.7 **IBMDSwitcherTalkback::SetInputMuteSDI** method

The **SetInputMuteSDI** method is used to set the mute state of the audio on the dedicated talkback input SDI channels for a particular audio input. The input is specified by its **BMDSwitcherAudioInputId** identifier.

Syntax

```
HRESULT SetInputMuteSDI (BMDSwitcherAudioInputId audioInputId, boolean muteSDI);
```

Parameters

Name	Direction	Description
audioInputId	in	BMDSwitcherAudioInputId identifier.
muteSDI	in	The desired mute state of the audio on the talkback input SDI channels of the specified audio input.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The audioInputId parameter is not a valid identifier.
E_FAIL	Failure. This can happen if the switcher does not have the capability to mute the talkback input SDI channels of the specified audio input.

7.6.2.8 **IBMDSwitcherTalkback::AddCallback** method

The **AddCallback** method configures a callback to be called when a switcher talkback property changes, such as the talkback SDI mute state.

Adding a new callback will not affect previously added callbacks.

Callbacks will be called on a separate thread and in the order of their addition by **AddCallback**.

Syntax

```
HRESULT AddCallback (IBMDSwitcherTalkbackCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherTalkbackCallback interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.6.2.9 **IBMDSwitcherTalkback::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherTalkbackCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object to remove.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

7.6.3 IBMDSwitcherTalkbackCallback Interface

The **IBMDSwitcherTalkbackCallback** object interface is a callback class which is called when a switcher talkback event occurs, such as a change in the talkback input SDI mute state.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherTalkback	IID_IBMDSwitcherTalkback	An IBMDSwitcherTalkbackCallback interface may be installed with IBMDSwitcherTalkback::AddCallback .

Public Member Functions	
Method	Description
Notify	A Switcher talkback event occurred, such as a change in the talkback input SDI mute state.

7.6.3.1 IBMDSwitcherTalkbackCallback::Notify method

The **Notify** method is called when **IBMDSwitcherTalkback** events occur.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherTalkbackEventType eventType, BMDSwitcherAudioInputId audioInputId);
```

Parameters

Name	Direction	Description
eventType	in	A BMDSwitcherTalkbackEventType that describes the type of event that has occurred.
audioInputId	in	Specifies the BMDSwitcherAudioInputId of the audio input for the eventType. This parameter is not valid when the eventType is bmdSwitcherTalkbackEventTypeMuteSDIChanged , because that event does not relate to a specific audio input.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

Section 8 — Camera Control

The Switcher Camera Control API provides programmatic access to supported Blackmagic Design cameras via ATEM switchers. Devices must support the Blackmagic Video Device Embedded Control Protocol.

Please refer to the Developer Information section of the ATEM Switchers Operation Manual for further information about the protocol.

8.1 Camera Control Data Types

8.1.1 Switcher Camera Control Event Type

BMDSwitcherCameraControlEventType enumerates the possible event types for the **IBMDSwitcherCameraControlCallback** object interface.

- **bmdSwitcherCameraControlEventTypePeriodicFlushIntervalChanged**
The periodic flush interval has changed.
- **bmdSwitcherCameraControlEventTypeParameterValueChanged**
The parameter value has changed.
- **bmdSwitcherCameraControlEventTypeParameterPeriodicFlushEnabledChanged**
The parameter period flush enabled state has changed.

8.1.2 Switcher Camera Control Parameter Type

BMDSwitcherCameraControlParameterType enumerates the possible parameter types for the **IBMDSwitcherCameraControl** object interface.

- **bmdSwitcherCameraControlParameterTypeVoidBool**
Boolean (1 or more values) or Void (0 values).
- **bmdSwitcherCameraControlParameterTypeSigned8Bit**
Signed 8-bit type. This type is the same as byte.
- **bmdSwitcherCameraControlParameterTypeSigned16Bit**
Signed 16-bit type
- **bmdSwitcherCameraControlParameterTypeSigned32Bit**
Signed 32-bit type
- **bmdSwitcherCameraControlParameterTypeSigned64Bit**
Signed 64-bit type
- **bmdSwitcherCameraControlParameterTypeFixedPoint16Bit**
Binary fixed point signed number. 5 bits integer and 11 bits fractional.

8.2 Interface Reference

8.2.1 Switcher Camera Control Parameter Iterator

The `IBMDSwitcherCameraControlParameterIterator` is used to iterate control Parameters that have been previously set. A reference to an `IBMDSwitcherCameraControlParameterIterator` object interface may be obtained from an `IBMDSwitcherCameraControl` object interface using the `CreateIterator` method.

The `IBMDSwitcherCameraControlParameterIterator` interface is used to iterate through control Parameters.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherCameraControl</code>	<code>IID_IBMDSwitcherCameraControl</code>	<code>IBMDSwitcherCameraControl::CreateIterator</code> returns an <code>IBMDSwitcherCameraControlParameterIterator</code> object interface when the <code>IID_IBMDSwitcherCameraControlParameterIterator</code> IID is specified.

Public Member Functions

Method	Description
<code>Next</code>	Returns the next control parameter.

8.2.1.1 `IBMDSwitcherCameraControlParameterIterator::Next` method

The `Next` method returns the next control parameter.

Syntax

```
HRESULT Next (uint32_t* destinationDevice, uint32_t* category, uint32_t* parameter)
```

Parameters

Name	Direction	Description
<code>destinationDevice</code>	out	The destination device address.
<code>category</code>	out	The configuration category number.
<code>parameter</code>	out	The configuration parameter number.

Return Values

Value	Description
<code>S_FALSE</code>	No more control parameters are available.
<code>S_OK</code>	Success.
<code>E_POINTER</code>	One or more of the parameters is NULL.

8.2.2 IBMDSwitcherCameraControlCallback Interface

The `IBMDSwitcherCameraControlCallback` object interface is a callback class which is called when a camera control event occurs.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherCameraControl</code>	<code>IID_IBMDSwitcherCameraControl</code>	An <code>IBMDSwitcherCameraControlCallback</code> object interface may be installed with <code>IBMDSwitcherCameraControl::AddCallback</code> .

Public Member Functions	
Method	Description
<code>Notify</code>	Called when a camera control event occurs.

8.2.2.1 IBMDSwitcherCameraControlCallback::Notify method

The `Notify` method is called when `IBMDSwitcherCameraControl` events occur. This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher. To determine the type and count of the parameter values call `IBMDSwitcherCameraControl::GetParameterInfo`.

Syntax

```
HRESULT Notify(BMDSwitcherCameraControlEventType eventType,  
              uint32_t destinationDevice, uint32_t category, uint32_t parameter)
```

Parameters

Name	Direction	Description
<code>eventType</code>	in	The <code>BMDSwitcherCameraControlEventType</code> that describes the type of event that has occurred.
<code>destinationDevice</code>	in	The destination device address.
<code>category</code>	in	The configuration category number available on the device.
<code>parameter</code>	in	The configuration parameter number available on the device.

Return Values

Value	Description
<code>E_FAIL</code>	Failure.
<code>S_OK</code>	Success.
<code>E_INVALIDARG</code>	A parameter is invalid.

8.2.3 IBMDSwitcherCameraControl Interface

The `IBMDSwitcherCameraControl` object interface is used for controlling compatible Blackmagic Design cameras.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	An <code>IBMDSwitcherCameraControl</code> object interface can be obtained with <code>IBMDSwitcher::QueryInterface</code> .

Public Member Functions	
Method	Description
<code>CreateIterator</code>	Create an iterator.
<code>GetPeriodicFlushInterval</code>	Get the periodic flush interval for parameters to be sent over SDI.
<code>SetPeriodicFlushInterval</code>	Set the periodic flush interval for parameters to be sent over SDI.
<code>GetParameterInfo</code>	Get the type and count of a parameter.
<code>GetParameterPeriodicFlushEnabled</code>	Get the status of flush enable.
<code>SetFlags</code>	Sets the current flag values.
<code>ToggleFlags</code>	Toggles the current flag values.
<code>GetFlags</code>	Gets the current flag values.
<code>SetBytes</code>	Sets the current signed 8-bit values.
<code>OffsetBytes</code>	Apply signed offsets to the signed 8-bit values.
<code>GetBytes</code>	Get the parameter values consisting of bytes.
<code>SetInt16s</code>	Sets the current signed 16-bit integer values.
<code>OffsetInt16s</code>	Apply a signed offset to the signed 16-bit integer values.
<code>GetInt16s</code>	Get the current signed 16-bit integer values.
<code>SetInt32s</code>	Sets the current signed 32-bit integer values.
<code>OffsetInt32s</code>	Apply a signed offset to the signed 32-bit integer values.
<code>GetInt32s</code>	Get the current signed 32-bit integer values.
<code>SetInt64s</code>	Sets the current signed 64-bit integer values.
<code>OffsetInt64s</code>	Apply a signed offset to the signed 64-bit integer values.
<code>GetInt64s</code>	Get the current signed 64-bit integer values.
<code>OffsetFloats</code>	Apply a signed floating point offset to the fixed point values.
<code>SetFloats</code>	Sets the current fixed point values.
<code>GetFloats</code>	Get the current fixed point values.
<code>AddCallback</code>	Add a callback to receive camera control event notifications.
<code>RemoveCallback</code>	Remove a callback.

8.2.3.1 IBMDSwitcherCameraControl::CreateIterator method

The **CreateIterator** method creates an iterator object interface for the specified interface ID.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv)
```

Parameters

Name	Direction	Description
iid	in	Iterator Interface ID to create an iterator for.
ppv	in	Pointer to return interface object.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_OUTOFMEMORY	Unable to allocate memory.
E_POINTER	The ppv parameter is NULL.
E_NOINTERFACE	Unable to locate interface matching iid parameter.

8.2.3.2 IBMDSwitcherCameraControl::GetPeriodicFlushInterval method

The **GetPeriodicFlushInterval** method returns the periodic interval set on the switcher.

The flush interval is the period where the nominated Parameters are sent periodically from the switcher over the SDI connection to the cameras.

Syntax

```
HRESULT GetPeriodicFlushInterval (uint32_t *intervalMs);
```

Parameters

Name	Direction	Description
intervalMs	out	The periodic flush interval in milliseconds.

Return Values

Value	Description
E_POINTER	The intervalMs parameter is NULL.
S_OK	Success.

8.2.3.3 IBMDSwitcherCameraControl::SetPeriodicFlushInterval method

The **SetPeriodicFlushInterval** method sets the periodic flush interval on the switcher. The flush interval is the period where the Parameters are sent periodically from the switcher over the SDI connection to the cameras.

Syntax

```
HRESULT SetPeriodicFlushInterval (uint32_t intervalMs);
```

Parameters

Name	Direction	Description
intervalMs	in	The refresh interval in milliseconds.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

8.2.3.4 IBMDSwitcherCameraControl::GetParameterInfo method

The **GetParameterInfo** method obtains the type of value (**IBMDSwitcherCameraControlParameterType**) and the number of values for a given parameter.

Syntax

```
HRESULT GetParameterInfo (uint32_t destinationDevice, uint32_t category,  
uint32_t parameter, IBMDSwitcherCameraControlParameterType* type,  
uint32_t* count);
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The configuration category number.
parameter	in	The parameter number.
type	out	The parameter type.
count	out	Number of values.

Return Values

Value	Description
S_OK	Success.
E_UNEXPECTED	An unexpected type error has occurred.
E_INVALIDARG	Unable to find parameter information for the given arguments.
E_POINTER	The type or count parameter is NULL.

8.2.3.5 IBMDSwitcherCameraControl::GetParameterPeriodicFlushEnabled method

The **GetParameterPeriodicFlushEnabled** method returns the periodic flush enabled status for the parameter values. When enabled, the parameter values will be flushed periodically from the switcher over the SDI connection to the cameras. The flush interval can be changed by calling **SetPeriodicFlushInterval**.

Syntax

```
HRESULT GetParameterPeriodicFlushEnabled (uint32_t destinationDevice, uint32_t category, uint32_t parameter, boolean* nabled)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The configuration category number.
parameter	in	The parameter number.
enabled	out	The periodic flush enabled status.

Return Values

Value	Description
E_POINTER	The enabled parameter is NULL.
S_OK	Success.
E_INVALIDARG	Unable to find an entry for the given arguments.

8.2.3.6 IBMDSwitcherCameraControl::SetParameterPeriodicFlushEnabled method

The **SetParameterPeriodicFlushEnabled** method sets the periodic flush enabled Parameters. The Parameters will not be flushed unless this option has been enabled. The flush interval is the period where the Parameters are sent periodically from the switcher over the SDI connection to the cameras.

Syntax

```
HRESULT SetParameterPeriodicFlushEnabled (uint32_t destinationDevice, uint32_t category, uint32_t parameter, boolean enabled)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
enabled	in	Enable periodic flush.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

8.2.3.7 IBMDSwitcherCameraControl::SetFlags method

The **SetFlags** method sends flags to the cameras over SDI.

Syntax

```
HRESULT SetFlags (uint32_t destinationDevice, uint32_t category,  
uint32_t parameter, uint32_t count, const boolean* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of parameter elements.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values parameter is NULL and the count is non-zero.
E_OUTOFMEMORY	There is insufficient memory to complete operation.

8.2.3.8 IBMDSwitcherCameraControl::ToggleFlags method

The **ToggleFlags** method will toggle the flags and then send the flags from the switcher to the cameras over SDI. If the parameter value is true, then the flag will be toggled otherwise it will remain the same.

Syntax

```
HRESULT ToggleFlags (uint32_t destinationDevice, uint32_t category,  
uint32_t parameter, uint32_t count, const boolean* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of parameter elements.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values parameter is NULL and the count is non-zero.
E_OUTOFMEMORY	There is insufficient memory to complete operation.

8.2.3.9 IBMDSwitcherCameraControl::GetFlags method

The **GetFlags** method returns the last flags sent to the cameras over SDI.

Syntax

```
HRESULT GetFlags (uint32_t destinationDevice, uint32_t category,  
uint32_t parameter, uint32_t* count, boolean* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	out	The element count.
values	out	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_INVALIDARG	Flags do not exist for the given arguments.
E_POINTER	The count or values parameter is NULL.

8.2.3.10 IBMDSwitcherCameraControl::SetBytes method

The **SetBytes** method sends 8-bit values to the cameras over SDI.

Syntax

```
HRESULT SetBytes (uint32_t destinationDevice, uint32_t category,  
uint32_t parameter, uint32_t count, const int8_t* bytes)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of elements.
bytes	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The bytes argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.11 IBMDSwitcherCameraControl::OffsetBytes method

The **OffsetBytes** method will add signed offsets to the current 8-bit values and then send the offset values to the cameras over SDI.

Syntax

```
HRESULT OffsetBytes (uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t count, const int8_t* bytes)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of elements.
bytes	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The bytes argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.12 IBMDSwitcherCameraControl::GetBytes method

The **GetBytes** method returns the last signed bytes sent to the cameras over SDI.

Syntax

```
HRESULT GetBytes (uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t* count, int8_t* bytes)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	out	The element count.
bytes	out	The parameter values.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	Bytes do not exist for the given arguments.
E_POINTER	The count or byte parameter is NULL.

8.2.3.13 IBMDSwitcherCameraControl::SetInt16s method

The **SetInt16s** method sends signed 16-bit values from the switcher to the cameras over SDI.

Syntax

```
HRESULT SetInt16s (uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t count, const int16_t* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of elements.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.14 IBMDSwitcherCameraControl::OffsetInt16s method

The **OffsetInt16s** method will add signed offsets to the current 16-bit values and then send the offset values to the cameras over SDI.

Syntax

```
HRESULT OffsetInt16s (uint32_t destinationDevice, uint32_t category, uint32_t parameter, uint32_t count, const int16_t* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of elements.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.15 IBMDSwitcherCameraControl::GetInt16s method

The `GetInt16s` method returns the last 16-bit signed integers sent to the cameras over SDI.

Syntax

```
HRESULT GetInt16s (uint32_t destinationDevice, uint32_t category,
                  uint32_t parameter, uint32_t* count, int16_t* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	out	The number of parameter elements.
values	out	The parameter values.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	Int16s do not exist for the given arguments.
E_POINTER	The count or values argument is NULL.

8.2.3.16 IBMDSwitcherCameraControl::SetInt32s method

The `SetInt32s` method sends signed 32-bit values to the cameras over SDI.

Syntax

```
HRESULT SetInt32s (uint32_t destinationDevice, uint32_t category, uint32_t
                  parameter, uint32_t count, const int32_t* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of parameter elements.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.17 IBMDSwitcherCameraControl::OffsetInt32s method

The **OffsetInt32s** method will add signed offsets to the current 32-bit values and then send the offset values to the cameras over SDI.

Syntax

```
HRESULT OffsetInt32s (uint32_t destinationDevice, uint32_t category,
                    uint32_t parameter, uint32_t count, const int32_t* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of elements.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.18 IBMDSwitcherCameraControl::GetInt32s method

The **GetInt32s** method returns the last 32-bit signed integers sent to the cameras over SDI.

Syntax

```
HRESULT GetInt32s (uint32_t destinationDevice, uint32_t category,
                 uint32_t parameter, uint32_t* count, int32_t* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	out	The number of elements.
values	out	The parameter values.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	Int32s do not exist for the given arguments.
E_POINTER	The count or values argument is NULL.

8.2.3.19 IBMDSwitcherCameraControl::SetInt64s method

The **SetInt64s** method sends signed 64-bit values from the switcher to the cameras over SDI.

Syntax

```
HRESULT SetInt64s (uint32_t destinationDevice, uint32_t category,
uint32_t parameter, uint32_t count, const int64_t* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of parameter elements.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.20 IBMDSwitcherCameraControl::OffsetInt64s method

The **OffsetInt64s** method will add signed offsets to the current 64-bit values and then send the offset values to the cameras over SDI.

Syntax

```
HRESULT OffsetInt64s (uint32_t destinationDevice, uint32_t category,
uint32_t parameter, uint32_t count, const int64_t* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of elements.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.21 IBMDSwitcherCameraControl::GetInt64s method

The `GetInt64s` method returns the last 64-bit signed integers sent to the cameras over SDI.

Syntax

```
HRESULT GetInt64s (uint32_t destinationDevice, uint32_t category,
uint32_t parameter, uint32_t* count, int64_t* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	out	The element count.
values	out	The parameter values.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	Int64s do not exist for the given arguments.
E_POINTER	The count or values argument is NULL.

8.2.3.22 IBMDSwitcherCameraControl::OffsetFloats method

The `OffsetFloats` method will add signed offsets to the current parameter values. The representable range is from -16.0 to 15.9995 (15 + 2047/2048). The resultant Parameters are sent from the switcher to the cameras over SDI.

Syntax

```
HRESULT OffsetFloats (uint32_t destinationDevice, uint32_t category,
uint32_t parameter, uint32_t count, const double* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The number of elements.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.23 IBMDSwitcherCameraControl::SetFloats method

The **SetFloats** method sends fixed floating point values from the switcher to the cameras over SDI. The representable range is from -16.0 to 15.9995 (15 + 2047/2048).

Syntax

```
HRESULT SetFloats (uint32_t destinationDevice, uint32_t category,
                  uint32_t parameter, uint32_t count, const double* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	in	The element count.
values	in	The parameter values.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.
E_POINTER	The values argument is NULL.
E_OUTOFMEMORY	There was insufficient memory to complete the operation.

8.2.3.24 IBMDSwitcherCameraControl::GetFloats method

The **GetFloats** method returns the last fixed point values sent to the cameras over SDI. The representable range is from -16.0 to 15.9995 (15 + 2047/2048).

Syntax

```
HRESULT GetFloats (uint32_t destinationDevice, uint32_t category,
                  uint32_t parameter, uint32_t* count, double* values)
```

Parameters

Name	Direction	Description
destinationDevice	in	The destination device address.
category	in	The category.
parameter	in	The parameter.
count	out	The element count.
values	out	The fixed point parameter values.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	Floats do not exist for the given arguments.
E_POINTER	The count or values argument is NULL.

8.2.3.25 IBMDSwitcherCameraControl::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherCameraControlCallback** object. The caller should pass an object implementing the **IBMDSwitcherCameraControlCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherCameraControlCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherCameraControlCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is NULL.

8.2.3.26 IBMDSwitcherCameraControl::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherCameraControlCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherCameraControlCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

Section 9 — Macros

The Switcher Macros API provides the functionality to record, playback, and transfer macros.

9.1 General Information

9.1.1 Macro Indexes and Identification

Each switcher is capable of storing a maximum number of macros. Each macro is uniquely identified by an index ranging from 0 to $n - 1$, where n is the maximum number of macros available on the switcher.

A macro is stored using the index specified on record or upload. If there is already a macro with the same index then it will be replaced, so it is best to check for an existing macro at the specified index before recording or uploading. If a macro exists at the specified index then the macro is considered valid, otherwise the index contains no macro.

9.1.2 Recording a Macro

Here are the basic steps for recording a macro on a switcher:

- Ensure you are connected to a switcher and have an **IBMDSwitcher** object. Please refer to the Basic Switcher Control section for how to do this.
- Get the **IBMDSwitcherMacroControl** interface from the **IBMDSwitcher** object.
- Create an **IBMDSwitcherMacroControlCallback** object and add it to the macro pool with the **IBMDSwitcherMacroControl::AddCallback** method.
- Call **IBMDSwitcherMacroControl::Record** to begin recording a new macro.
- Perform the switcher operations that you wish to record to the macro.
- Call **IBMDSwitcherMacroControl::StopRecording** to end the macro recording.

9.1.3 Downloading a Macro

Here are the basic steps for downloading a macro from a switcher:

- Ensure you are connected to a switcher and have an **IBMDSwitcher** object. Please refer to the Basic Switcher Control section for how to do this.
- Get the **IBMDSwitcherMacroPool** interface from the **IBMDSwitcher** object.
- Create an **IBMDSwitcherMacroPoolCallback** object and add it to the macro pool with the **IBMDSwitcherMacroPool::AddCallback** method.
- Call **IBMDSwitcherMacroPool::Download** to begin the transfer of a macro from the switcher. This method will return an **IBMDSwitcherTransferMacro** object which can be used to track the progress of the download. You will also be notified of the download outcome via the **IBMDSwitcherMacroPoolCallback** interface.
- Using the **IBMDSwitcherTransferMacro** object obtained from either **IBMDSwitcherMacroPool::Download** or **IBMDSwitcherMacroPoolCallback::Notify** call **IBMDSwitcherTransferMacro::GetMacro** to get the macro object.

9.1.4 Uploading a Macro

The steps for uploading a macro to a switcher are very similar to downloading:

- Ensure you are connected to a switcher and have an **IBMDSwitcher** object. Please refer to the Basic Switcher Control section for how to do this.
- Get the **IBMDSwitcherMacroPool** interface from the **IBMDSwitcher** object.
- Create an **IBMDSwitcherMacroPoolCallback** object and add it to the macro pool with the **IBMDSwitcherMacroPool::AddCallback** method.
- Use **IBMDSwitcherMediaPool::CreateMacro** to create a macro object. Populate this with your macro binary data by filling in the macro object's data buffer, which is available via the **IBMDSwitcherMacro::GetBytes** method. Alternatively, you can use an **IBMDSwitcherMacro** object obtained from a previous macro download.
- Call **IBMDSwitcherMacroPool::Upload** to begin the transfer of the macro to the switcher. This method will return an **IBMDSwitcherTransferMacro** object which can be used to track the progress of the upload. You will also be notified of the upload outcome via the **IBMDSwitcherMacroPoolCallback** interface.

9.1.5 Unsupported Operations

As the capabilities of Blackmagic Design Switcher products evolve, new functionality will be added. A macro that is created on a newer version switcher and transferred to an older version switcher may contain operations that the older switcher does not support. A macro containing unsupported operations is flagged as such and can still be played, but the unsupported operations will be ignored.

9.2 Macro Data Types

9.2.1 Macro Pool Event Type

IBMDSwitcherMacroPoolEventType enumerates the possible event types for the **IBMDSwitcherMacroPoolCallback** object interface.

- **bmdSwitcherMacroPoolEventTypeValidChanged**
A macro has been created (becomes valid), or deleted (becomes invalid).
- **bmdSwitcherMacroPoolEventTypeHasUnsupportedOpsChanged**
A macro's unsupported operations flag has changed.
- **bmdSwitcherMacroPoolEventTypeNameChanged**
A macro's name has changed.
- **bmdSwitcherMacroPoolEventTypeDescriptionChanged**
A macro's description has changed.
- **bmdSwitcherMacroPoolEventTypeTransferCompleted**
A macro transfer has completed.
- **bmdSwitcherMacroPoolEventTypeTransferCancelled**
A macro transfer has cancelled.
- **bmdSwitcherMacroPoolEventTypeTransferFailed**
A macro transfer has failed.

9.2.2 Macro Control Event Type

BMDSwitcherMacroControlEventType enumerates the possible event types for the **IBMDSwitcherMacroControlCallback** object interface.

- **bmdSwitcherMacroControlEventTypeRunStatusChanged**
The switcher's macro playback state has changed.
- **bmdSwitcherMacroControlEventTypeRecordStatusChanged**
The switcher's macro record state has changed.

9.2.3 Macro Run Status

BMDSwitcherMacroRunStatus enumerates the possible macro playback states.

- **bmdSwitcherMacroRunStatusIdle**
No macro is playing.
- **bmdSwitcherMacroRunStatusRunning**
A macro is playing.
- **bmdSwitcherMacroRunStatusWaitingForUser**
A macro is waiting for the user to continue playing.

9.2.4 Macro Record Status

BMDSwitcherMacroRecordStatus enumerates the possible macro record states.

- **bmdSwitcherMacroRecordStatusIdle**
No macro is being recorded.
- **bmdSwitcherMacroRecordStatusRecording**
A macro is being recorded.

9.3 Interface Reference

9.3.1 IBMDSwitcherMacroPool Interface

The **IBMDSwitcherMacroPool** object interface provides functionality for the transfer and deletion of macros and for accessing and modifying macro properties.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	An IBMDSwitcherMacroPool object interface can be obtained with the IBMDSwitcher:QueryInterface method.

Public Member Functions	
Method	Description
GetMaxCount	Gets the number of macros that can be stored.
Delete	Deletes a macro.
IsValid	Checks if a macro exists.
HasUnsupportedOps	Checks if a macro has unsupported operations.
GetName	Gets a macro's name.
SetName	Sets a macro's name.

Public Member Functions	
Method	Description
GetDescription	Gets a macro's description.
SetDescription	Sets a macro's description.
CreateMacro	Creates an IBMDSwitcherMacro object.
Upload	Uploads a macro.
Download	Downloads a macro.
AddCallback	Adds a macro pool callback.
RemoveCallback	Removes a macro pool callback.

9.3.1.1 IBMDSwitcherMacroPool::GetMaxCount method

The **GetMaxCount** method returns the number of macros that can be stored on the switcher.

Syntax

```
HRESULT GetMaxCount (uint32_t* maxCount);
```

Parameters

Name	Direction	Description
maxCount	out	The maximum number of macros for the switcher.

Return Values

Value	Description
E_POINTER	The maxCount parameter is invalid.
S_OK	Success.

9.3.1.2 IBMDSwitcherMacroPool::Delete method

The **Delete** method will delete (set invalid) an existing macro. If the macro is already invalid then this method has no effect.

Syntax

```
HRESULT Delete (uint32_t index);
```

Parameters

Name	Direction	Description
index	in	Macro index.

Return Values

Value	Description
E_INVALIDARG	The index parameter is out of range.
S_OK	Success.

9.3.1.3 IBMDSwitcherMacroPool::IsValid method

The `IsValid` method checks if a macro with the specified index exists.

Syntax

```
HRESULT IsValid (uint32_t index, boolean* valid);
```

Parameters

Name	Direction	Description
index	in	Macro index.
valid	out	Boolean value which is true if the macro is valid.

Return Values

Value	Description
E_POINTER	The valid parameter is invalid.
E_INVALIDARG	The index parameter is out of range.
S_OK	Success.

9.3.1.4 IBMDSwitcherMacroPool::HasUnsupportedOps method

The `HasUnsupportedOps` method indicates whether a macro contains unsupported operations. A macro with unsupported operations can still be played but the unsupported operations will be ignored.

Syntax

```
HRESULT HasUnsupportedOps (uint32_t index, boolean* hasUnsupportedOps);
```

Parameters

Name	Direction	Description
index	in	Macro index.
hasUnsupportedOps	out	Boolean value which is true if the macro contains unsupported operations.

Return Values

Value	Description
E_POINTER	The hasUnsupportedOps parameter is invalid.
E_INVALIDARG	The index parameter is out of range.
S_OK	Success.

9.3.1.5 IBMDSwitcherMacroPool::GetName method

The `GetName` method gets the name of a macro.

Syntax

```
HRESULT GetName (uint32_t index, string* name);
```

Parameters

Name	Direction	Description
index	in	Macro index.
name	out	Macro name.

Return Values

Value	Description
E_POINTER	The name parameter is invalid.
E_INVALIDARG	The index parameter is out of range.
E_OUTOFMEMORY	Insufficient memory to get the name.
S_OK	Success.

9.3.1.6 IBMDSwitcherMacroPool::SetName method

The `SetName` method sets the name of a macro.

Syntax

```
HRESULT SetName (uint32_t index, string name);
```

Parameters

Name	Direction	Description
index	in	Macro index.
name	in	Macro name.

Return Values

Value	Description
E_POINTER	The name parameter is invalid.
E_INVALIDARG	The index parameter is out of range.
E_OUTOFMEMORY	Insufficient memory to set the name.
S_OK	Success.

9.3.1.7 **IBMDSwitcherMacroPool::GetDescription** method

The **GetDescription** method gets the description of a macro.

Syntax

```
HRESULT GetDescription (uint32_t index, string* description);
```

Parameters

Name	Direction	Description
index	in	Macro index.
description	out	Macro description.

Return Values

Value	Description
E_POINTER	The description parameter is invalid.
E_INVALIDARG	The index parameter is out of range.
E_OUTOFMEMORY	Insufficient memory to get the description.
S_OK	Success.

9.3.1.8 **IBMDSwitcherMacroPool::SetDescription** method

The **SetDescription** method sets the description of a macro.

Syntax

```
HRESULT SetDescription (uint32_t index, string description);
```

Parameters

Name	Direction	Description
index	in	Macro index.
description	out	Macro description.

Return Values

Value	Description
E_POINTER	The description parameter is invalid.
E_INVALIDARG	The index parameter is out of range.
E_OUTOFMEMORY	Insufficient memory to set the description.
S_OK	Success.

9.3.1.9 IBMDSwitcherMacroPool::CreateMacro method

The `CreateMacro` method creates an `IBMDSwitcherMacro` object. `IBMDSwitcherMacro` objects are only used for transfers.

Syntax

```
HRESULT CreateMacro (uint32_t sizeBytes, IBMDSwitcherMacro** macro);
```

Parameters

Name	Direction	Description
sizeBytes	in	The size of the macro, in bytes.
macro	out	The <code>IBMDSwitcherMacro</code> object.

Return Values

Value	Description
E_OUTOFMEMORY	Insufficient memory to create a macro.
S_OK	Success.

9.3.1.10 IBMDSwitcherMacroPool::Upload method

The `Upload` method transfers a macro to the switcher. No more than one transfer can occur at a time.

Syntax

```
HRESULT Upload (uint32_t index, string name, string description,  
IBMDSwitcherMacro* macro, IBMDSwitcherTransferMacro** macroTransfer);
```

Parameters

Name	Direction	Description
index	in	Destination macro index.
name	in	Destination macro name.
description	in	Destination macro description.
macro	in	<code>IBMDSwitcherMacro</code> object containing the macro binary data for the transfer.
macroTransfer	out	<code>IBMDSwitcherMacroTransfer</code> object for monitoring the progress of the transfer.

Return Values

Value	Description
E_POINTER	The name, description, or macro parameter is invalid.
E_INVALIDARG	The index parameter is out of range.
E_OUTOFMEMORY	Insufficient memory to perform a transfer.
S_OK	Success.

9.3.1.11 **IBMDSwitcherMacroPool::Download** method

The **Download** method transfers a macro from the switcher. No more than one transfer can occur at a time.

Syntax

```
HRESULT Download (uint32_t index, IBMDSwitcherTransferMacro** macroTransfer);
```

Parameters

Name	Direction	Description
index	in	Destination macro index.
macroTransfer	out	IBMDSwitcherMacroTransfer object for monitoring the progress of the transfer and retrieving the macro binary data.

Return Values

Value	Description
E_INVALIDARG	The index parameter is out of range.
E_OUTOFMEMORY	Insufficient memory to perform a transfer.
S_OK	Success.

9.3.1.12 **IBMDSwitcherMacroPool::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherMacroPool** object. Pass an object implementing the **IBMDSwitcherMacroPoolCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMacroPoolCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMacroPoolCallback object interface.

Return Values

Value	Description
E_INVALIDARG	The callback parameter is invalid.
S_OK	Success.

9.3.1.13 IBMDSwitcherMacroPool::RemoveCallback method

The `RemoveCallback` method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMacroPoolCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMacroPoolCallback object interface.

Return Values

Value	Description
E_INVALIDARG	The callback parameter is invalid.
S_OK	Success.

9.3.2 IBMDSwitcherTransferMacro Interface

The **IBMDSwitcherTransferMacro** object interface provides methods to cancel a macro transfer, monitor transfer progress, and retrieve transferred macro binary data.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMacroPool	IID_IBMDSwitcherMacroPool	IBMDSwitcherMacroPool::Upload and IBMDSwitcherMacroPool::Download return an IBMDSwitcherTransferMacro object.
IBMDSwitcherMacroPoolCallback	IID_IBMDSwitcherMacroPool	IBMDSwitcherMacroPoolCallback::Notify passes in an IBMDSwitcherTransferMacro object.

Public Member Functions	
Method	Description
Cancel	Cancel the pending transfer.
GetProgress	Get the pending transfer's progress.
GetMacro	Get an IBMDSwitcherMacro object from a completed transfer.

9.3.2.1 IBMDSwitcherTransferMacro::Cancel method

The `Cancel` method cancels the pending transfer. If there is no pending macro transfer then this method has no effect.

Syntax

```
HRESULT Cancel (void);
```

Parameters

none

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

9.3.2.2 IBMDSwitcherTransferMacro::GetProgress method

The `GetProgress` method gets the progress of the pending transfer.

Syntax

```
HRESULT GetProgress (double* progress);
```

Parameters

Name	Direction	Description
progress	out	Transfer progress. Range is between 0.0 to 1.0.

Return Values

Value	Description
E_POINTER	The progress parameter is invalid.
S_OK	Success.

9.3.2.3 IBMDSwitcherTransferMacro::GetMacro method

The `GetMacro` method gets the transferred `IBMDSwitcherMacro` object.

Syntax

```
HRESULT GetMacro (IBMDSwitcherMacro** macro);
```

Parameters

Name	Direction	Description
macro	out	Pointer to an <code>IBMDSwitcherMacro</code> object.

Return Values

Value	Description
E_POINTER	The macro parameter is invalid.
E_UNEXPECTED	No transfer has been initiated.
S_OK	Success.

9.3.3 IBMDSwitcherMacro Interface

The **IBMDSwitcherMacro** object interface provides access to macro binary data used for transferring macros.

This interface does not provide access to macro properties or control to record or playback a macro. To access properties use the **IBMDSwitcherMacroPool** interface. To record or playback a macro use the **IBMDSwitcherMacroControl** interface.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMacroPool	IID_IBMDSwitcherMacroPool	IBMDSwitcherMacroPool::CreateMacro returns an IBMDSwitcherMacro object.
IBMDSwitcherTransferMacro	IID_IBMDSwitcherMacroTransfer	IBMDSwitcherMacroTransfer::GetMacro returns an IBMDSwitcherMacro object.

Public Member Functions	
Method	Description
GetSize	Gets the size (in bytes) of the macro binary data.
GetBytes	Gets a pointer to the macro binary data buffer.

9.3.3.1 IBMDSwitcherMacro::GetSize method

The **GetSize** method returns the size (in bytes) of the macro binary data.

Syntax

```
HRESULT    uint32_t GetSize (void);
```

Parameters

none

Return Values

Value	Description
Size	Size (in bytes) of the macro binary data.

9.3.3.2 IBMDSwitcherMacro::GetBytes method

The **GetBytes** method returns a pointer to the macro binary data buffer.

Syntax

```
HRESULT    GetBytes (void** buffer);
```

Parameters

Name	Direction	Description
buffer	out	Pointer to the macro binary data.

Return Values

Value	Description
E_POINTER	The buffer parameter is invalid.
S_OK	Success.

9.3.4 IBMDSwitcherMacroPoolCallback Interface

The **IBMDSwitcherMacroPoolCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherMacroPool** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMacroPool	IID_IBMDSwitcherMacroPool	An IBMDSwitcherMacroPoolCallback object interface is installed with IBMDSwitcherMacroPool::AddCallback and removed with IBMDSwitcherMacroPool::RemoveCallback

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

9.3.4.1 IBMDSwitcherMacroPoolCallback::Notify method

The **Notify** method is called when an **IBMDSwitcherMacroPool** event occurs, such as macro property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherMacroPoolEventType eventType, uint32_t index,
                IBMDSwitcherTransferMacro* macroTransfer);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherMacroPoolEventType that describes the type of event that has occurred.
index	in	Index of the macro that has changed.
macroTransfer	in	If the event type is one of bmdSwitcherMacroPoolEventTypeTransferCompleted , bmdSwitcherMacroPoolEventTypeTransferCancelled , or bmdSwitcherMacroPoolEventTypeTransferFailed then this parameter is a pointer to the affected IBMDSwitcherTransferMacro interface object.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

9.3.5 IBMDSwitcherMacroControl Interface

The **IBMDSwitcherMacroControl** object interface provides macro recording state, playback state, and control.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	An IBMDSwitcherMacroControl object interface can be obtained with the IBMDSwitcher::QueryInterface .

Public Member Functions	
Method	Description
Run	Begins playback of a macro.
GetLoop	Gets the playback loop setting.
SetLoop	Sets the playback loop setting.
ResumeRunning	Resumes playback of a waiting macro.
StopRunning	Stops a playing or waiting macro.
Record	Begins recording of a new macro.
RecordUserWait	Inserts a user wait into the currently recording macro.
RecordPause	Inserts a time delay into the currently recording macro.
StopRecording	Ends recording.
GetRunStatus	Gets the current playback state.
GetRecordStatus	Gets the current record state.
AddCallback	Adds a macro control callback.
RemoveCallback	Removes a macro control callback.

9.3.5.1 IBMDSwitcherMacroControl::Run method

The **Run** method begins playback of a macro.

Syntax

```
HRESULT Run (uint32_t index);
```

Parameters

Name	Direction	Description
index	in	Macro index.

Return Values

Value	Description
E_INVALIDARG	The index parameter is out of range or invalid.
E_FAIL	Failure.
S_OK	Success.

9.3.5.2 IBMDSwitcherMacroControl::GetLoop method

The **GetLoop** method gets the current loop setting. When true, a running macro will loop back to the start when the last operation completes.

Syntax

```
HRESULT GetLoop (boolean* loop);
```

Parameters

Name	Direction	Description
loop	out	Boolean value which is true if playback will loop.

Return Values

Value	Description
E_POINTER	The loop parameter is invalid.
E_FAIL	Failure.
S_OK	Success.

9.3.5.3 IBMDSwitcherMacroControl::SetLoop method

The **SetLoop** method sets the current loop setting. When true, a running macro will loop back to the start when the last operation completes.

Syntax

```
HRESULT SetLoop (boolean loop);
```

Parameters

Name	Direction	Description
loop	in	Desired setting for loop, which is true if playback will loop.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

9.3.5.4 **IBMDSwitcherMacroControl::ResumeRunning** method

The **ResumeRunning** method continues playback of a macro that is waiting for the user. If there is no macro currently waiting then this method has no effect.

Syntax

```
HRESULT ResumeRunning (void);
```

Parameters

none

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

9.3.5.5 **IBMDSwitcherMacroControl::StopRunning** method

The **StopRunning** method stops the currently playing macro. If there is no macro currently playing then this method has no effect.

Syntax

```
HRESULT StopRunning (void);
```

Parameters

none

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

9.3.5.6 IBMDSwitcherMacroControl::Record method

The **Record** method begins recording of a new macro.

Syntax

```
HRESULT Record (uint32_t index, string name, string description);
```

Parameters

Name	Direction	Description
index	in	Macro index.
name	in	Name of the macro.
description	in	Description of the macro.

Return Values

Value	Description
E_POINTER	The name or description parameter is invalid.
E_INVALIDARG	The index parameter is out of range.
E_OUTOFMEMORY	Insufficient memory to record a new macro.
E_FAIL	Failure.
S_OK	Success.

9.3.5.7 IBMDSwitcherMacroControl::RecordUserWait method

The **RecordUserWait** method inserts a user wait into the currently recording macro. If there is no macro currently recording then this method has no effect.

Syntax

```
HRESULT RecordUserWait (void);
```

Parameters

None

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

9.3.5.8 **IBMDSwitcherMacroControl::RecordPause** method

The **RecordPause** method inserts a timed pause into the currently recording macro. If there is no macro currently recording then this method has no effect.

Syntax

```
HRESULT RecordPause (uint32_t frames);
```

Parameters

Name	Direction	Description
frames	in	Number of frames to pause for.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

9.3.5.9 **IBMDSwitcherMacroControl::StopRecording** method

The **StopRecording** method stops the currently recording macro. If there is no macro currently recording then this method has no effect.

Syntax

```
HRESULT StopRecording (void);
```

Parameters

none

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

9.3.5.10 **IBMDSwitcherMacroControl::GetRunStatus** method

The **GetRunStatus** method gets the current playback state of the switcher.

Syntax

```
HRESULT GetRunStatus (BMDSwitcherMacroRunStatus* status,  
                    boolean* loop, uint32_t* index);
```

Parameters

Name	Direction	Description
status	out	BMDSwitcherMacroRunStatus value indicating the macro playback state.
loop	out	Boolean value which is true if playback is set to loop.
index	out	Index of the macro that is playing/waiting.

Return Values

Value	Description
E_POINTER	The status, loop, or index parameter is invalid.
S_OK	Success.

9.3.5.11 **IBMDSwitcherMacroControl::GetRecordStatus** method

The **GetRecordStatus** method gets the current record state of the switcher.

Syntax

```
HRESULT GetRecordStatus(BMDSwitcherMacroRecordStatus* status, uint32_t* index);
```

Parameters

Name	Direction	Description
status	out	BMDSwitcherMacroRecordStatus value indicating the macro recording state.
index	out	Index of the macro that is recording.

Return Values

Value	Description
E_POINTER	The status, or index parameter is invalid.
S_OK	Success.

9.3.5.12 **IBMDSwitcherMacroControl::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherMacroControl** object. Pass an object implementing the **IBMDSwitcherMacroControlCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherMacroControlCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMacroControlCallback object interface.

Return Values

Value	Description
E_INVALIDARG	The callback parameter is invalid.
S_OK	Success.

9.3.5.13 **IBMDSwitcherMacroControl::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherMacroControlCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherMacroControlCallback object interface.

Return Values

Value	Description
E_INVALIDARG	The callback parameter is invalid.
S_OK	Success.

9.3.6 IBMDSwitcherMacroControlCallback Interface

The **IBMDSwitcherMacroControlCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherMacroControl** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherMacroControl	IID_ IBMDSwitcherMacroControl	An IBMDSwitcherMacroControlCallback object interface is installed with IBMDSwitcherMacroControl::AddCallback and removed with IBMDSwitcherMacroControl::RemoveCallback .

Public Member Functions	
Method	Description
Notify	Called when an event occurs.

9.3.6.1 IBMDSwitcherMacroControlCallback::Notify method

The **Notify** method is called when an **IBMDSwitcherMacroControl** event occurs, such as a macro playback and recording states.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherMacroControlEventType eventType);
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherMacroControlEventType that describes the type of event that has occurred.

Return Values

Value	Description
E_FAIL	Failure.
S_OK	Success.

Section 10 — HyperDeck

The Switcher HyperDeck API provides the functionality to remotely control one or more Blackmagic Design HyperDeck devices remotely, to record and playback clips.

10.1 General Information

10.1.1 HyperDeck Interfaces

Different switcher models may support different number of remote HyperDecks. Each HyperDeck interface in the device may connect to a single remote HyperDeck unit, accessible on the same local network.

Commands are issued in an asynchronous manner; they are internally queued and issued to the HyperDeck. As a result, many operations will not cause an immediate change of state until the command has been acknowledged by the HyperDeck.

10.1.2 HyperDeck Remote Control

If a HyperDeck is connected but the remote access mode (set on the HyperDeck itself) is disabled, the interface will effectively be read-only. Commands issued to change the HyperDeck state while remote access is disabled will be rejected.

10.1.3 HyperDeck Clip Cache

To speed up processing, the list of clips located on the active storage media of the HyperDeck is cached locally by the switcher. This cache is automatically invalidated when a recording session ends, or when the active storage media changes, and is signaled by a change in clip count on the HyperDeck's interface. Clients should listen for this change and discard any held clip entry references, re-fetching the new entries from the clip cache when the change occurs. Previously invalidated clip cache entries will remain invalid indefinitely.

The clip cache is filled asynchronously to free up bandwidth for user-initiated actions. This means that cache entries may exist (be valid) but may not have their clip information properties populated until a later point in time.

10.1.4 HyperDeck Configuration

An application for controlling a HyperDeck from the switcher may perform the following steps:

- Use `IBMDSwitcherDiscovery::ConnectTo` to connect to a switcher device and obtain an `IBMDSwitcher` object interface
- Use `IBMDSwitcher::CreateIterator` to get an `IBMDSwitcherHyperDeckIterator` object interface
- Obtain an `IBMDSwitcherHyperDeck` object interface using `IBMDSwitcherHyperDeckIterator::Next`
- Use `IBMDSwitcherHyperDeck::SetNetworkAddress` to configure the remote network IPv4 address of a HyperDeck
- Poll `IBMDSwitcherHyperDeck::GetConnectionStatus` to determine when the switcher has a successful connection to a HyperDeck (or listen for changes by installing a callback via `IBMDSwitcherHyperDeck::AddCallback`)

10.1.5 HyperDeck Clip Cache Configuration

An application for reading out the clips in a connected HyperDeck from the switcher may perform the following steps:

- Use `IBMDSwitcherHyperDeck::CreateIterator` to get an `IBMDSwitcherHyperDeckClipIterator` object interface
- Obtain an `IBMDSwitcherHyperDeckClip` object interface using `IBMDSwitcherHyperDeckClipIterator::Next`
- Install a callback via `IBMDSwitcherHyperDeckClip::AddCallback` to listen for information available and invalidation events

10.2 Hyperdeck Types

10.2.1 BMDSwitcherHyperDeckClipEventType

`BMDSwitcherHyperDeckClipEventType` enumerates the possible event types for the `IBMDSwitcherHyperDeckClipCallback` object interface.

- `bmdSwitcherHyperDeckClipEventTypeValidChanged`
A HyperDeck clip has been created (becomes valid) or is no longer available (becomes invalid)
- `bmdSwitcherHyperDeckClipEventTypeInfoAvailableChanged`
A HyperDeck clip's information properties (e.g. name) have become (in-)validated

10.2.2 BMDSwitcherHyperDeckEventType

`BMDSwitcherHyperDeckEventType` enumerates the possible event types for the `IBMDSwitcherHyperDeckCallback` object interface.

- `bmdSwitcherHyperDeckEventTypeConnectionStatusChanged`
The connection status of a HyperDeck to the switcher has changed
- `bmdSwitcherHyperDeckEventTypeRemoteAccessEnabledChanged`
The Remote Access function of a HyperDeck has changed
- `bmdSwitcherHyperDeckEventTypeStorageMediaStateChanged`
The state of a storage media of a HyperDeck has changed
- `bmdSwitcherHyperDeckEventTypeEstimatedRecordTimeRemainingChanged`
The estimated record time available of a HyperDeck has changed
- `bmdSwitcherHyperDeckEventTypeActiveStorageMediaChanged`
The active storage media slot of a HyperDeck has changed
- `bmdSwitcherHyperDeckEventTypeClipCountChanged`
The number of clips available on a HyperDeck has changed
- `bmdSwitcherHyperDeckEventTypeSwitcherInputChanged`
The switcher input associated with a HyperDeck has changed
- `bmdSwitcherHyperDeckEventTypeFrameRateChanged`
The video frame rate configuration of a HyperDeck has changed
- `bmdSwitcherHyperDeckEventTypeInterlacedVideoChanged`
The video interlaced configuration of a HyperDeck has changed
- `bmdSwitcherHyperDeckEventTypeDropFrameTimeCodeChanged`
The video drop frame configuration of a HyperDeck has changed
- `bmdSwitcherHyperDeckEventTypePlayerStateChanged`
The player state of a HyperDeck has changed

- **bmdSwitcherHyperDeckEventTypeCurrentClipChanged**
The currently selected clip of a HyperDeck has changed
- **bmdSwitcherHyperDeckEventTypeCurrentClipTimeChanged**
The timecode for the currently selected clip in a HyperDeck has changed
- **bmdSwitcherHyperDeckEventTypeCurrentTimelineTimeChanged**
The timecode for the overall timeline in a HyperDeck has changed
- **bmdSwitcherHyperDeckEventTypeShuttleSpeedChanged**
The playback speed of a HyperDeck has changed
- **bmdSwitcherHyperDeckEventTypeLoopedPlaybackChanged**
The playback loop state of a HyperDeck has changed
- **bmdSwitcherHyperDeckEventTypeSingleClipPlaybackChanged**
The single clip playback mode of a HyperDeck has changed
- **bmdSwitcherHyperDeckEventTypeAutoRollOnTakeChanged**
The automatic playback of a HyperDeck on Switcher input tally has changed
- **bmdSwitcherHyperDeckEventTypeAutoRollOnTakeFrameDelayChanged**
The frame delay of the automatic playback of a HyperDeck on Switcher input tally has changed
- **bmdSwitcherHyperDeckEventTypeNetworkAddressChanged**
The network address of a HyperDeck has changed

10.2.3 **BMDSwitcherHyperDeckClipId**

BMDSwitcherHyperDeckClipId is a signed 64 bit integer type and used as a unique identifier for each clip stored on a media accessible to a HyperDeck.

10.2.4 **BMDSwitcherHyperDeckId**

BMDSwitcherHyperDeckId is a signed 64 bit integer type and used as a unique identifier for each HyperDeck controllable via the attached device.

10.2.5 **BMDSwitcherHyperDeckPlayerState**

BMDSwitcherHyperDeckPlayerState enumerates the possible HyperDeck player states for a HyperDeck.

- **bmdSwitcherHyperDeckStateUnknown**
The state of the attached HyperDeck is not currently known.
- **bmdSwitcherHyperDeckStateIdle**
The HyperDeck is currently idle (stopped).
- **bmdSwitcherHyperDeckStatePlay**
The HyperDeck is currently playing a clip.
- **bmdSwitcherHyperDeckStateRecord**
The HyperDeck is currently recording a clip.
- **bmdSwitcherHyperDeckStateShuttle**
The HyperDeck is currently shuttling.

10.2.6 **BMDSwitcherHyperDeckConnectionStatus**

BMDSwitcherHyperDeckConnectionStatus enumerates the possible HyperDeck connection status states for a **IBMDSwitcherHyperDeck** interface.

- **bmdSwitcherHyperDeckConnectionStatusNotConnected**
A HyperDeck is currently not connected to this interface.
- **bmdSwitcherHyperDeckConnectionStatusConnecting**
This interface is currently attempting to connect to to a HyperDeck.
- **bmdSwitcherHyperDeckConnectionStatusConnected**
A HyperDeck is currently connected to this interface.
- **bmdSwitcherHyperDeckConnectionStatusIncompatible**
A HyperDeck with an incompatible firmware version is currently connected to this interface.

10.2.7 **BMDSwitcherHyperDeckStorageMediaState**

BMDSwitcherHyperDeckStorageMediaState enumerates the possible states of a media slot on an attached HyperDeck.

- **bmdSwitcherHyperDeckStorageMediaStateReady**
This media slot is currently populated and ready for use.
- **bmdSwitcherHyperDeckStorageMediaStateUnavailable**
This media slot is currently empty or cannot be accessed.

10.2.8 **BMDSwitcherHyperDeckErrorType**

BMDSwitcherHyperDeckErrorType enumerates the possible transient errors that may occurs on attached HyperDeck.

- **bmdSwitcherHyperDeckErrorTypeUnknown**
An unknown error has occurred on the HyperDeck.
- **bmdSwitcherHyperDeckErrorTypeAlreadyInUse**
Another client is currently remotely accessing the HyperDeck.
- **bmdSwitcherHyperDeckErrorTypeRemoteDisabled**
A request was rejected by the Hyperdeck (remote access is disabled).
- **bmdSwitcherHyperDeckErrorTypeMediaFull**
The storage media of the HyperDeck is full and new clips could not be added.
- **bmdSwitcherHyperDeckErrorTypeMediaError**
An error occurred while attempting to access the storage media of the HyperDeck.
- **bmdSwitcherHyperDeckErrorTypeNoInput**
There is no video signal detected on the HyperDeck input.
- **bmdSwitcherHyperDeckErrorTypeDuplicateAddress**
Two or more HyperDeck interfaces have been configured with the same IP address.

10.3 Interface Reference

10.3.1 IBMDSwitcherHyperDeckIterator Interface

The `IBMDSwitcherHyperDeckIterator` is used to enumerate the available HyperDecks.

Related Interfaces

Interface	Interface ID	Description
BMDSwitcher	IID_IBMDSwitcher	<code>IBMDSwitcher::CreateIterator</code> can return an <code>IBMDSwitcherHyperDeckIterator</code> object interface.

Public Member Functions

Method	Description
Next	Returns a pointer to the next <code>IBMDSwitcherHyperDeck</code> object interface.
GetById	Returns a specific <code>IBMDSwitcherHyperDeck</code> object by its ID.

10.3.1.1 IBMDSwitcherHyperDeckIterator::Next method

The Next method returns the next available `IBMDSwitcherHyperDeck` object interface.

Syntax

```
HRESULT Next (IBMDSwitcherHyperDeck* hyperDeck);
```

Parameters

Name	Direction	Description
hyperDeck	out	<code>IBMDSwitcherHyperDeck</code> object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No more <code>IBMDSwitcherHyperDeck</code> objects available.
E_POINTER	The hyperDeck parameter is invalid.

10.3.1.2 IBMDSwitcherHyperDeckIterator::GetById method

The `GetById` method returns the `IBMDSwitcherHyperDeck` object interface that matches the given ID.

Syntax

```
HRESULT GetById (IBMDSwitcherHyperDeckId hyperDeckId, IBMDSwitcherHyperDeck* hyperDeck);
```

Parameters

Name	Direction	Description
hyperDeckId	in	IBMDSwitcherHyperDeckId to retrieve.
hyperDeck	out	IBMDSwitcherHyperDeck object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The requested HyperDeck was not found.
E_POINTER	The hyperDeck parameter is invalid.

10.3.2 IBMDSwitcherHyperDeck Interface

The `IBMDSwitcherHyperDeck` object interface provides functionality for the remote control of a Blackmagic Design HyperDeck device.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherHyperDeckIterator	IID_IBMDSwitcherHyperDeckIterator	An <code>IBMDSwitcherHyperDeck</code> object will be returned after a successful call to <code>IBMDSwitcherHyperDeckIterator::Next</code> method.

Public Member Functions	
Method	Description
GetId	Returns the ID of this <code>IBMDSwitcherHyperDeck</code> interface.
GetConnectionStatus	Returns the current connection status of the interface to a remote HyperDeck device.
IsRemoteAccessEnabled	Returns whether remote access is enabled.
GetStorageMediaCount	Returns the number of media slots supported by the remote HyperDeck.
GetStorageMediaState	Returns the state of a media slot in a remote HyperDeck.
GetActiveStorageMedia	Returns the index of the currently active media slot in the remote HyperDeck.
SetActiveStorageMedia	Selects the currently active media slot in the remote HyperDeck.
GetClipCount	Returns the number of clips in the active media in the remote HyperDeck.
CreateIterator	Create an iterator.
GetSwitcherInput	Returns the currently associated Switcher input.
SetSwitcherInput	Sets the associated Switcher input.

Public Member Functions	
Method	Description
GetFrameRate	Returns the configured video frame rate of the HyperDeck.
IsInterlacedVideo	Returns whether the configured video mode is an interlaced mode.
IsDropFrameTimeCode	Returns whether the configured video mode supports drop frames.
GetPlayerState	Returns the current player state.
GetCurrentClip	Returns the currently selected clip ID in the active storage slot.
SetCurrentClip	Sets the currently selected clip ID in the active storage slot.
GetCurrentClipTime	Returns the current timecode time within the currently selected clip.
SetCurrentClipTime	Sets the current timecode within the currently selected clip.
GetCurrentTimelineTime	Returns the current timeline timecode.
SetCurrentTimelineTime	Sets the current timeline timecode.
GetEstimatedRecordTimeRemaining	Returns the current estimated recording time across all slots.
Play	Starts playback with the current settings.
Record	Starts a new clip recording session.
Stop	Stops playback.
Shuttle	Shuttles at the given playback speed.
GetShuttleSpeed	Returns the current shuttle speed.
Jog	Jogs one or more frames in the timeline.
GetLoopedPlayback	Returns whether playback requests will loop when the clip(s) have finished playing.
SetLoopedPlayback	Sets whether playback requests will loop when the clip(s) have finished playing.
GetSingleClipPlayback	Returns whether playback requests will be bound to the currently selected clip, or the entire timeline.
SetSingleClipPlayback	Sets whether playback requests will be bound to the currently selected clip, or the entire timeline.
GetAutoRollOnTake	Sets whether the HyperDeck automatically rolls when the HyperDeck is tallied to program output.
SetAutoRollOnTake	Returns whether the HyperDeck automatically rolls when the HyperDeck is tallied to program output.
GetAutoRollOnTakeFrameDelay	Returns the automatic roll-on-take frame delay when the HyperDeck is tallied.
SetAutoRollOnTakeFrameDelay	Sets the automatic roll-on-take frame delay when the HyperDeck is tallied.
GetNetworkAddress	Returns the currently set network address of a HyperDeck interface.
SetNetworkAddress	Sets the network address of a HyperDeck interface.
AddCallback	Add a HyperDeck callback to receive property changes.
RemoveCallback	Remove a HyperDeck callback.

10.3.2.1 IBMDSwitcherHyperDeck::GetId method

The **GetId** method returns the HyperDeck's ID, used to uniquely identify a HyperDeck control interface within the Switcher.

Syntax

```
HRESULT GetId (BMDSwitcherHyperDeckId* hyperDeckId);
```

Parameters

Name	Direction	Description
hyperDeckId	out	BMDSwitcherHyperDeckId identifier for the current interface.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The hyperDeckId parameter is invalid.

10.3.2.2 IBMDSwitcherHyperDeck::GetConnectionStatus method

The **GetConnectionStatus** method returns the HyperDeck's connection status, used to determine the connection state of a HyperDeck control interface within the Switcher.

Syntax

```
HRESULT GetConnectionStatus (BMDSwitcherHyperDeckConnectionStatus* status);
```

Parameters

Name	Direction	Description
status	out	BMDSwitcherHyperDeckConnectionStatus connection state for the interface.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The status parameter is invalid.

10.3.2.3 IBMDSwitcherHyperDeck::IsRemoteAccessEnabled method

The **IsRemoteAccessEnabled** method returns the HyperDeck's remote access status. A connected HyperDeck is only remotely controllable if the remote access function of the HyperDeck is enabled.

A connected HyperDeck with remote access disabled is effectively read-only; set requests will be rejected by the HyperDeck and will generate a **NotifyError** callback (if a handler is installed).

Syntax

```
HRESULT IsRemoteAccessEnabled (boolean* enabled);
```

Parameters

Name	Direction	Description
enabled	out	Boolean remote access enable state of the remote HyperDeck.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The status parameter is invalid.

10.3.2.4 IBMDSwitcherHyperDeck::GetStorageMediaCount method

The **GetStorageMediaCount** method returns the number of physical media storage slots on the connected HyperDeck device.

Syntax

```
HRESULT GetStorageMediaCount (uint32_t* count);
```

Parameters

Name	Direction	Description
count	out	Number of media slots on the connected HyperDeck.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The count parameter is invalid.

10.3.2.5 IBMDSwitcherHyperDeck::GetStorageMediaState method

The **GetStorageMediaState** method returns the state of a given storage media slot on a connected HyperDeck.

Syntax

```
HRESULT GetStorageMediaState (uint32_t storageMediaId,  
                              BMDSwitcherHyperDeckStorageMediaState* state);
```

Parameters

Name	Direction	Description
storageMediaId	in	Storage media slot to examine.
state	out	Current state of the storage media slot.

Return Values

Value	Description
S_OK	Success.
S_FALSE	Given slot index was out of bounds.
E_FAIL	Failure.
E_POINTER	The state parameter is invalid.

10.3.2.6 IBMDSwitcherHyperDeck::GetActiveStorageMedia method

The **GetActiveStorageMedia** method returns the index of the active storage media slot on a connected HyperDeck.

If no storage media is active, this will return a -1 slot index.

Syntax

```
HRESULT GetActiveStorageMedia (uint32_t* index);
```

Parameters

Name	Direction	Description
index	out	Active slot index of the connected HyperDeck.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The index parameter is invalid.

10.3.2.7 IBMDSwitcherHyperDeck::SetActiveStorageMedia method

The `SetActiveStorageMedia` method sets the active storage media slot on a connected HyperDeck.

Syntax

```
HRESULT SetActiveStorageMedia (uint32_t index);
```

Parameters

Name	Direction	Description
index	in	Active slot index to select in the connected HyperDeck.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.8 IBMDSwitcherHyperDeck::GetClipCount method

The `GetClipCount` method returns the total number of clips in the active storage media slot on a connected HyperDeck.

Syntax

```
HRESULT GetClipCount (uint32_t* count);
```

Parameters

Name	Direction	Description
count	out	Number of clips in the active slot of the connected HyperDeck.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The count parameter is invalid.

10.3.2.9 IBMDSwitcherHyperDeck::CreateIterator method

The **CreateIterator** method creates an iterator object interface for the specified interface ID.

Syntax

```
HRESULT CreateIterator (REFIID iid, LPVOID* ppv);
```

Parameters

Name	Direction	Description
iid	in	Iterator Interface ID to create an iterator for.
ppv	out	Pointer to return interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_OUTOFMEMORY	Insufficient memory to create interface object.
E_NOINTERFACE	Interface was not found.

10.3.2.10 IBMDSwitcherHyperDeck::GetSwitcherInput method

The **GetSwitcherInput** method returns the associated Switcher input source of the HyperDeck interface. This is used to detect when a HyperDeck has tally, in particular for the roll-on-take feature.

An associated input of zero is used as a sentinel for no associated input.

Syntax

```
HRESULT GetSwitcherInput (BMDSwitcherInputId* inputId);
```

Parameters

Name	Direction	Description
inputId	out	Associated Switcher input ID of the HyperDeck interface.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The inputId parameter is invalid.

10.3.2.11 **IBMDSwitcherHyperDeck::SetSwitcherInput** method

The **SetSwitcherInput** method sets the associated Switcher input source of the HyperDeck interface. This is used to detect when a HyperDeck has tally, in particular for the roll-on-take feature.

An associated input of zero is used as a sentinel for no associated input. Only external input sources are valid source inputs; an internal source will be converted to zero.

Syntax

```
HRESULT SetSwitcherInput (BMDSwitcherInputId inputId);
```

Parameters

Name	Direction	Description
inputId	in	Switcher input ID to be associated with the HyperDeck interface.

Return Values

Value	Description
S_OK	Success.

10.3.2.12 **IBMDSwitcherHyperDeck::GetFrameRate** method

The **GetFrameRate** method retrieves the configured video frame rate of the connected HyperDeck.

The framerate is expressed as a number of frames per timescale units, i.e. frames per second is frameRate divided by timescale.

Syntax

```
HRESULT GetFrameRate (uint32_t* frameRate, uint32_t* timeScale);
```

Parameters

Name	Direction	Description
frameRate	out	Video frame rate (numerator) of the configured HyperDeck.
timeScale	out	Timescale (denominator) of the video frame rate.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The frameRate or timeScale parameter(s) are invalid.

10.3.2.13 **IBMDSwitcherHyperDeck::IsInterlacedVideo** method

The **IsInterlacedVideo** returns whether the configured video mode is an interlaced mode.

Syntax

```
HRESULT IsInterlacedVideo (boolean* isInterlaced);
```

Parameters

Name	Direction	Description
isInterlaced	out	Boolean value of the interlaced video setting of the configured HyperDeck.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The isInterlaced parameter is invalid.

10.3.2.14 **IBMDSwitcherHyperDeck::IsDropFrameTimeCode** method

The **IsDropFrameTimeCode** method retrieves the configured video drop frame timecode setting of the connected HyperDeck.

Syntax

```
HRESULT IsDropFrameTimeCode (boolean* isDropFrame);
```

Parameters

Name	Direction	Description
isDropFrame	out	Boolean value of the drop frame timecode video setting of the configured HyperDeck.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The isDropFrame parameter is invalid.

10.3.2.15 IBMDSwitcherHyperDeck::GetPlayerState method

The `GetPlayerState` method retrieves the current player state of the connected HyperDeck.

Syntax

```
HRESULT GetPlayerState (BMDSwitcherHyperDeckPlayerState* playerState);
```

Parameters

Name	Direction	Description
playerState	out	Current player state of the connected HyperDeck.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The playerState parameter is invalid.

10.3.2.16 IBMDSwitcherHyperDeck::GetCurrentClip method

The `GetCurrentClip` method retrieves the currently selected clip in the active storage media of the connected HyperDeck.

If no clip is selected, this will return a -1 clip ID.

Syntax

```
HRESULT GetCurrentClip (BMDSwitcherHyperDeckClipId* clipId);
```

Parameters

Name	Direction	Description
clipId	out	Currently selected clip ID of the connected HyperDeck.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The clipId parameter is invalid.

10.3.2.17 **IBMDSwitcherHyperDeck::SetCurrentClip** method

The **SetCurrentClip** method sets the currently selected clip in the active storage media of the connected HyperDeck.

Syntax

```
HRESULT SetCurrentClip (BMDSwitcherHyperDeckClipId clipId);
```

Parameters

Name	Direction	Description
clipId	in	Clip ID to select in the connected HyperDeck.

Return Values

Value	Description
S_OK	Success.

10.3.2.18 **IBMDSwitcherHyperDeck::GetCurrentClipTime** method

The **GetCurrentClipTime** method gets the currently selected clip's elapsed time.

Syntax

```
HRESULT GetCurrentClipTime (uint16_t* hours, uint8_t* minutes,  
uint8_t* seconds, uint8_t* frames);
```

Parameters

Name	Direction	Description
hours	out	Elapsed clip time, hours component.
minutes	out	Elapsed clip time, minutes component.
seconds	out	Elapsed clip time, seconds component.
frames	out	Elapsed clip time, frames component.

Return Values

Value	Description
S_OK	Success.
S_FALSE	A clip is not currently selected.
E_POINTER	The hours, minutes, seconds and/or frames parameter is invalid.

10.3.2.19 IBMDSwitcherHyperDeck::SetCurrentClipTime method

The `SetCurrentClipTime` method seeks the currently selected clip to the specified elapsed time.

Syntax

```
HRESULT SetCurrentClipTime (uint16_t hours, uint8_t minutes,  
uint8_t seconds, uint8_t frames);
```

Parameters

Name	Direction	Description
hours	in	Elapsed clip time, hours component.
minutes	in	Elapsed clip time, minutes component.
seconds	in	Elapsed clip time, seconds component.
frames	in	Elapsed clip time, frames component.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The given position does not exist within the currently selected clip.
E_FAIL	Could not compute a valid timecode for the specified position.

10.3.2.20 IBMDSwitcherHyperDeck::GetCurrentTimelineTime method

The `GetCurrentTimelineTime` method retrieves the current elapsed time within the Hyperdeck's entire timeline.

Syntax

```
HRESULT GetCurrentTimelineTime (uint16_t* hours,  
uint8_t* minutes, uint8_t* seconds, uint8_t* frames);
```

Parameters

Name	Direction	Description
hours	out	Elapsed timeline time, hours component.
minutes	out	Elapsed timeline time, minutes component.
seconds	out	Elapsed timeline time, seconds component.
frames	out	Elapsed timeline time, frames component.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The hours, minutes, seconds and/or frames parameter is invalid.

10.3.2.21 IBMDSwitcherHyperDeck::SetCurrentTimelineTime method

The **SetCurrentTimelineTime** method sets the current elapsed time within the Hyperdeck's entire timeline.

Syntax

```
HRESULT SetCurrentTimelineTime (uint16_t hours, uint8_t minutes,
                                uint8_t seconds, uint8_t frames);
```

Parameters

Name	Direction	Description
hours	in	Elapsed timeline time, hours component.
minutes	in	Elapsed timeline time, minutes component.
seconds	in	Elapsed timeline time, seconds component.
frames	in	Elapsed timeline time, frames component.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Could not compute a valid timecode for the specified position.

10.3.2.22 IBMDSwitcherHyperDeck::GetEstimatedRecordTimeRemaining method

The **GetEstimatedRecordTimeRemaining** method gets the estimated recording time remaining across the available media slots, based on the currently configured video mode settings. Note that due to compression, this value may change in a non-linear fashion.

Syntax

```
HRESULT GetEstimatedRecordTimeRemaining (uint16_t* hours, uint8_t* minutes,
                                           uint8_t* seconds, uint8_t* frames);
```

Parameters

Name	Direction	Description
hours	out	Estimated remaining record time, hours component.
minutes	out	Estimated remaining record time, minutes component.
seconds	out	Estimated remaining record time, seconds component.
frames	out	Estimated remaining record time, frames component.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The hours, minutes, seconds and/or frames parameter is invalid.

10.3.2.23 IBMDSwitcherHyperDeck::Play method

The **Play** method starts playing the currently selected clip on the connected HyperDeck at the current timeline position.

Syntax

```
HRESULT Play (void);
```

Parameters

None.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.24 IBMDSwitcherHyperDeck::Record method

The **Record** method starts recording on the connected HyperDeck at the current timeline position.

Syntax

```
HRESULT Record (void);
```

Parameters

None.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.25 IBMDSwitcherHyperDeck::Stop method

The **Stop** method stops playback on the connected HyperDeck.

Syntax

```
HRESULT Stop (void);
```

Parameters

None.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.26 IBMDSwitcherHyperDeck::Shuttle method

The **Shuttle** method starts playback on the connected HyperDeck at the requested speed.

Syntax

```
HRESULT Shuttle (int32_t speedPercent);
```

Parameters

Name	Direction	Description
speedPercent	in	Shuttle speed, expressed as a percentage.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.27 IBMDSwitcherHyperDeck::GetShuttleSpeed method

The **GetShuttleSpeed** method retrieves the current shuttle playback speed on the connected HyperDeck.

Syntax

```
HRESULT GetShuttleSpeed (int32_t* speedPercent);
```

Parameters

Name	Direction	Description
speedPercent	out	Shuttle speed, expressed as a percentage.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The speedPercent parameter is invalid.

10.3.2.28 IBMDSwitcherHyperDeck::Jog method

The **Jog** method moves the timeline position forwards or backwards by the specified number of frames.

Syntax

```
HRESULT Jog (int32_t frameDelta);
```

Parameters

Name	Direction	Description
frameDelta	in	Number of frames to jog.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.29 IBMDSwitcherHyperDeck::GetLoopedPlayback method

The `GetLoopedPlayback` method retrieves the current loop state of the connected HyperDeck.

Syntax

```
HRESULT GetLoopedPlayback (boolean* loop);
```

Parameters

Name	Direction	Description
loop	out	Current loop state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The loop parameter is invalid.

10.3.2.30 IBMDSwitcherHyperDeck::SetLoopedPlayback method

The `SetLoopedPlayback` method sets the current loop state of the connected HyperDeck.

Syntax

```
HRESULT SetLoopedPlayback (boolean loop);
```

Parameters

Name	Direction	Description
loop	in	New loop state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.31 IBMDSwitcherHyperDeck::GetSingleClipPlayback method

The `GetSingleClipPlayback` method retrieves the current single clip playback state of the connected HyperDeck.

Syntax

```
HRESULT GetSingleClipPlayback (boolean* single);
```

Parameters

Name	Direction	Description
single	out	Current single clip playback state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The single parameter is invalid.

10.3.2.32 IBMDSwitcherHyperDeck::SetSingleClipPlayback method

The `SetSingleClipPlayback` method sets the single clip playback state of the connected HyperDeck.

Syntax

```
HRESULT SetSingleClipPlayback (boolean single);
```

Parameters

Name	Direction	Description
single	in	New single clip state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.33 **IBMDSwitcherHyperDeck::GetAutoRollOnTake** method

The **GetAutoRollOnTake** method retrieves the current roll-on-take (automatic playback on tally) state of the HyperDeck interface.

Syntax

```
HRESULT GetAutoRollOnTake (boolean* autoRollOnTake);
```

Parameters

Name	Direction	Description
autoRollOnTake	out	Current automatic roll on take state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The autoRollOnTake parameter is invalid.

10.3.2.34 **IBMDSwitcherHyperDeck::SetAutoRollOnTake** method

The **SetAutoRollOnTake** method sets the current roll-on-take (automatic playback on tally) state of the HyperDeck interface.

If this feature is enabled, and the input associated with this HyperDeck interface (set by **SetSwitcherInput**) is tallied to the program output, the HyperDeck will automatically begin playing at the current timeline position after the frame delay set by **SetAutoRollOnTakeFrameDelay**.

Syntax

```
HRESULT SetAutoRollOnTake (boolean autoRollOnTake);
```

Parameters

Name	Direction	Description
autoRollOnTake	in	New automatic roll on take state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.35 IBMDSwitcherHyperDeck::GetAutoRollOnTakeFrameDelay method

The `GetAutoRollOnTakeFrameDelay` method retrieves the current automatic playback on tally state frame delay of the HyperDeck interface.

Syntax

```
HRESULT GetAutoRollOnTakeFrameDelay (uint16_t* frameDelay);
```

Parameters

Name	Direction	Description
frameDelay	out	Current automatic roll on take frame delay.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The frameDelay parameter is invalid.

10.3.2.36 IBMDSwitcherHyperDeck::SetAutoRollOnTakeFrameDelay method

The `SetAutoRollOnTakeFrameDelay` method sets the automatic playback on tally state frame delay of the HyperDeck interface.

Syntax

```
HRESULT SetAutoRollOnTakeFrameDelay (uint16_t frameDelay);
```

Parameters

Name	Direction	Description
autoRollOnTake	in	New automatic roll on take frame delay.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.37 IBMDSwitcherHyperDeck::GetNetworkAddress method

The **GetNetworkAddress** method retrieves the current remote device network address of the HyperDeck interface. This is expressed as a packed IPv4 address, least significant byte first.

Syntax

```
HRESULT GetNetworkAddress (uint32_t* networkAddress);
```

Parameters

Name	Direction	Description
networkAddress	out	Currently set remote network IP address of the device.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The networkAddress parameter is invalid.

10.3.2.38 IBMDSwitcherHyperDeck::SetNetworkAddress method

The **SetNetworkAddress** method sets the remote device network address of the HyperDeck interface. This is expressed as a packed IPv4 address, least significant byte first.

The switcher will continuously attempt to connect to the device at the configured network address. To disable the HyperDeck interface and suppress connection attempts from the switcher, set this to an address of zero.

Syntax

```
HRESULT SetNetworkAddress (uint32_t networkAddress);
```

Parameters

Name	Direction	Description
networkAddress	in	New remote network IP address of the device.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.2.39 IBMDSwitcherHyperDeck::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherHyperDeck** object.

Pass an object implementing the **IBMDSwitcherHyperDeckCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherHyperDeckCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the in IBMDSwitcherHyperDeckCallback object interface.

Return Values

Value	Description
E_INVALIDARG	The callback parameter is invalid.
S_OK	Success.

10.3.2.40 IBMDSwitcherHyperDeck::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherHyperDeckCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherHyperDeckCallback object interface.

Return Values

Value	Description
E_INVALIDARG	The callback parameter is invalid.
S_OK	Success.

10.3.3 IBMDSwitcherHyperDeckCallback Interface

The **IBMDSwitcherHyperDeckCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherHyperDeck** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
BMDSwitcherHyperDeck	IID_IBMDSwitcherHyperDeck	An IBMDSwitcherHyperDeckCallback object interface is installed with IBMDSwitcherHyperDeck::AddCallback and removed with IBMDSwitcherHyperDeck::RemoveCallback

Public Member Functions

Method	Description
Notify	Called when an event occurs.
NotifyError	Called when an error occurs.

10.3.3.1 IBMDSwitcherHyperDeckCallback::Notify method

The **Notify** method is called when **IBMDSwitcherHyperDeck** events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherHyperDeckCallback* callback);
```

Parameters

Name	Direction	Description
eventType	out	BMDSwitcherHyperDeckEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.3.2 IBMDSwitcherHyperDeckCallback::NotifyError method

The NotifyError method is called when **IBMDSwitcherHyperDeck** error events occur.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT NotifyError (BMDSwitcherHyperDeckErrorType errorType);
```

Parameters

Name	Direction	Description
errorType	out	BMDSwitcherHyperDeckErrorType that describes the type of error that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

10.3.4 IBMDSwitcherHyperDeckClipIterator Interface

The **IBMDSwitcherHyperDeckClipIterator** is used to enumerate the available clips in a connected HyperDeck.

Related Interfaces

Interface	Interface ID	Description
BMDSwitcherHyperDeck	IID_IBMDSwitcherHyperDeck	IBMDSwitcherHyperDeck::CreateIterator can return an IBMDSwitcherHyperDeckClipIterator object interface.

Public Member Functions	
Method	Description
Next	Returns a pointer to the next IBMDSwitcherHyperDeckClip object interface.
GetById	Returns a specific IBMDSwitcherHyperDeckClip object by its clip ID.

10.3.4.1 IBMDSwitcherHyperDeckClipIterator::Next method

The `Next` method returns the next available `IBMDSwitcherHyperDeckClip` object interface.

Syntax

```
HRESULT Next (IBMDSwitcherHyperDeckClip** clip);
```

Parameters

Name	Direction	Description
clip	out	IBMDSwitcherHyperDeckClip object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No more <code>IBMDSwitcherHyperDeckClip</code> objects available.
E_POINTER	The clip parameter is invalid.

10.3.4.2 IBMDSwitcherHyperDeckClipIterator::GetById method

The `GetById` method returns the `IBMDSwitcherHyperDeckClip` object interface that matches the given clip ID.

Syntax

```
HRESULT GetById (BMDSwitcherHyperDeckClipId clipId, IBMDSwitcherHyperDeckClip** clip);
```

Parameters

Name	Direction	Description
clipId	in	BMDSwitcherHyperDeckClipId clip to retrieve.
clip	out	IBMDSwitcherHyperDeckClip object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The requested clip was not found.
E_POINTER	The clip parameter is invalid.

10.3.5 IBMDSwitcherHyperDeckClip Interface

The **IBMDSwitcherHyperDeckClip** object interface provides information about a single clip in a Blackmagic Design HyperDeck device.

Related Interfaces

Interface	Interface ID	Description
BMDSwitcherHyperDeckClipIterator	IID_IBMDSwitcherHyperDeckClipIterator	An IBMDSwitcherHyperDeckClip object will be returned after a successful call to IBMDSwitcherHyperDeckClipIterator::Next method.

Public Member Functions	
Method	Description
IsValid	Returns whether this clip entry is still valid, or has been permanently invalidated.
IsInfoAvailable	Returns whether the clip data has been successfully retrieved at this stage.
GetId	Get the ID of the clip.
GetName	Get the name of the clip.
GetDuration	Get the duration timecode of the clip.
GetTimelineStart	Get the start of the clip timecode within the Hyperdeck's timeline.
GetTimelineEnd	Get the end of the clip timecode within the Hyperdeck's timeline.
AddCallback	Add a HyperDeck clip callback to receive property changes.
RemoveCallback	Remove a HyperDeck clip callback.

10.3.5.1 IBMDSwitcherHyperDeckClip::IsValid method

The **IsValid** method returns whether the clip entry has been permanently invalidated. Under certain circumstances (such as a media slot state change) the clip cache becomes invalidated, and all entries are recreated and repopulated from the HyperDeck.

Once a clip has become invalid it should be released and discarded, and a fresh version requested from the **IBMDSwitcherHyperDeckClipIterator** object.

Syntax

```
HRESULT IsValid (boolean* isValid);
```

Parameters

Name	Direction	Description
isValid	out	Boolean value indicating if the clip's information is currently available.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The isValid parameter is invalid.

10.3.5.2 IBMDSwitcherHyperDeckClip::IsInfoAvailable method

The **IsInfoAvailable** method returns whether the information for this is currently populated. Clip information is retrieved asynchronously, thus clip entries may be created before their associated data becomes available.

Clips whose information is not currently populated may still have user callbacks registered via **AddCallback**.

Syntax

```
HRESULT IsInfoAvailable (boolean* infoAvailable);
```

Parameters

Name	Direction	Description
infoAvailable	out	Boolean value indicating if the clip's information is current available.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The infoAvailable parameter is invalid.
E_FAIL	The clip is invalid.

10.3.5.3 IBMDSwitcherHyperDeckClip::GetId method

The **GetId** method returns the clip's ID, used to uniquely identify a clip in the clip cache.

Syntax

```
HRESULT GetId (BMDSwitcherHyperDeckClipId* clipId);
```

Parameters

Name	Direction	Description
clipId	out	BMDSwitcherHyperDeckClipId clip identifier in the cache.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.
E_POINTER	The clipId parameter is invalid.

10.3.5.4 IBMDSwitcherHyperDeckClip::GetName method

The `GetName` method returns the clip's name, as returned by the HyperDeck.

Syntax

```
HRESULT GetName (string* name);
```

Parameters

Name	Direction	Description
name	out	Clip name in the cache.

Return Values

Value	Description
S_OK	Success.
S_FALSE	The clip name is not yet available.
E_FAIL	The clip is invalid.
E_POINTER	The name parameter is invalid.

10.3.5.5 IBMDSwitcherHyperDeckClip::GetDuration method

The `GetDuration` method returns the clip's duration, as returned by the HyperDeck.

Syntax

```
HRESULT GetDuration (uint16_t* hours, uint8_t* minutes, uint8_t* seconds,  
uint8_t* frames);
```

Parameters

Name	Direction	Description
hours	out	Clip duration, hours component.
minutes	out	Clip duration, minutes component.
seconds	out	Clip duration, seconds component.
frames	out	Clip duration, frames component.

Return Values

Value	Description
S_OK	Success.
S_FALSE	The clip duration is not yet available.
E_FAIL	The clip is invalid.
E_POINTER	The hours, minutes, seconds and/or frames parameter(s) are invalid.

10.3.5.6 IBMDSwitcherHyperDeckClip::GetTimelineStart method

The `GetTimelineStart` method returns the clip's start position within the entire timeline, as returned by the HyperDeck.

Syntax

```
HRESULT GetTimelineStart (uint16_t* hours, uint8_t* minutes,  
                          uint8_t* seconds, uint8_t* frames);
```

Parameters

Name	Direction	Description
hours	out	Clip timeline start, hours component.
minutes	out	Clip timeline start, minutes component.
seconds	out	Clip timeline start, seconds component.
frames	out	Clip timeline start, frames component.

Return Values

Value	Description
S_OK	Success.
S_FALSE	The clip timeline start is not yet available.
E_FAIL	The clip is invalid.
E_POINTER	The hours, minutes, seconds and/or frames parameter(s) are invalid.

10.3.5.7 IBMDSwitcherHyperDeckClip::GetTimelineEnd method

The `GetTimelineEnd` method returns the clip's end position within the entire timeline, as returned by the HyperDeck.

Syntax

```
HRESULT GetTimelineEnd (uint16_t* hours, uint8_t* minutes,  
                       uint8_t* seconds, uint8_t* frames);
```

Parameters

Name	Direction	Description
hours	out	Clip timeline end, hours component.
minutes	out	Clip timeline end, minutes component.
seconds	out	Clip timeline end, seconds component.
frames	out	Clip timeline end, frames component.

Return Values

Value	Description
S_OK	Success.
S_FALSE	The clip timeline start is not yet available.
E_FAIL	The clip is invalid.
E_POINTER	The hours, minutes, seconds and/or frames parameter(s) are invalid.

10.3.5.8 IBMDSwitcherHyperDeckClip::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherHyperDeckClip** object.

Pass an object implementing the **IBMDSwitcherHyperDeckClipCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback (IBMDSwitcherHyperDeckClipCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherHyperDeckClipCallback object interface.

Return Values

Value	Description
E_INVALIDARG	The callback parameter is invalid.
S_OK	Success.

10.3.5.9 IBMDSwitcherHyperDeckClip::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback (IBMDSwitcherHyperDeckClipCallback* callback);
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherHyperDeckClipCallback object interface.

Return Values

Value	Description
E_INVALIDARG	The callback parameter is invalid.
S_OK	Success.

10.3.6 IBMDSwitcherHyperDeckClipCallback Interface

The **IBMDSwitcherHyperDeckClipCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherHyperDeckClip** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
BMDSwitcherHyperDeckClip	IID_IBMDSwitcherHyperDeckClip	An IBMDSwitcherHyperDeckClipCallback object interface is installed with IBMDSwitcherHyperDeckClip::AddCallback and removed with IBMDSwitcherHyperDeckClip::RemoveCallback

Public Member Functions

Method	Description
Notify	Called when an event occurs.

10.3.6.1 IBMDSwitcherHyperDeckClipCallback::Notify method

The **Notify** method is called when **IBMDSwitcherHyperDeckClip** events occur, events such as a property change.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads.

Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify (BMDSwitcherHyperDeckClipEventType eventType,  
                BMDSwitcherHyperDeckClipId clipId);
```

Parameters

Name	Direction	Description
eventType	out	BMDSwitcherHyperDeckEventType that describes the type of event that has occurred.
clipId	out	BMDSwitcherHyperDeckClipId identifier of the clip generating the notification.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

Section 11 — Streaming

The Switcher Streaming API provides functionality to stream video over the internet to a streaming service such as YouTube, Twitch, or Facebook.

11.1 General Information

11.1.1 Video and Audio Encoding

The switcher will stream H.264 encoded video and AAC encoded audio via the RTMP streaming protocol to a selected streaming server. This requires that the switcher has access to an internet connection from its ethernet port.

11.2 Streaming Data Types

11.2.1 Streaming State

BMDSwitcherStreamRTMPState enumerates the possible streaming states.

- **bmdSwitcherStreamRTMPStateIdle**
Not streaming.
- **bmdSwitcherStreamRTMPStateConnecting**
Connecting to the streaming server.
- **bmdSwitcherStreamRTMPStateStreaming**
Streaming is in progress.
- **bmdSwitcherStreamRTMPStateStopping**
Streaming is stopping.

11.2.2 Streaming Error

BMDSwitcherStreamRTMPErrors enumerates the possible errors that can occur when streaming.

- **bmdSwitcherStreamRTMPErrorsNone**
No error.
- **bmdSwitcherStreamRTMPErrorsInvalidState**
Invalid state for requested command.
- **bmdSwitcherStreamRTMPErrorsUnknown**
Unknown error.

11.2.3 Streaming Event Type

BMDSwitcherStreamRTMPEventType enumerates the possible event types for the **BMDSwitcherStreamRTMPCallback** object interface.

- **bmdSwitcherStreamRTMPEventTypeServiceNameChanged**
The service name has changed.
- **bmdSwitcherStreamRTMPEventTypeUriChanged**
The server url has changed.
- **bmdSwitcherStreamRTMPEventTypeKeyChanged**
The stream key has changed.
- **bmdSwitcherStreamRTMPEventTypeVideoBitratesChanged**
The maximum video bitrates have changed.
- **bmdSwitcherStreamRTMPEventTypeAudioBitratesChanged**
The maximum audio bitrates have changed.
- **bmdSwitcherStreamRTMPEventTypeEncodingBitrateChanged**
The current encoding bitrate has changed.
- **bmdSwitcherStreamRTMPEventTypeCacheUsedChanged**
The current usage level of the streaming cache has changed.
- **bmdSwitcherStreamRTMPEventTypeTimecodeChanged**
The current streaming timecode has changed.
- **bmdSwitcherStreamRTMPEventTypeDurationChanged**
The current streaming duration has changed.
- **bmdSwitcherStreamRTMPEventTypeAuthenticationChanged**
The service authentication credentials have changed.
- **bmdSwitcherStreamRTMPEventTypeLowLatencyChanged**
The low latency setting has changed.

11.3 Interface Reference

11.3.1 IBMDSwitcherStreamRTMP Interface

The **IBMDSwitcherStreamRTMP** object interface provides functionality to start and stop streaming of video and audio to a streaming server.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	An IBMDSwitcherStreamRTMP object interface can be obtained with IBMDSwitcher::QueryInterface .

Public Member Functions	
Method	Description
StartStreaming	Start streaming.
StopStreaming	Stop streaming.
IsStreaming	Determine whether the switcher is currently streaming.
GetStatus	Get the current streaming status.
SetServiceName	Set the streaming service name.

Public Member Functions	
Method	Description
GetServiceName	Get the streaming service name.
SetUrl	Set the streaming URL.
GetUrl	Get the streaming URL.
SetKey	Set the streaming key.
GetKey	Get the streaming key.
SetVideoBitrates	Set the maximum video streaming bitrates.
GetVideoBitrates	Get the maximum video streaming bitrates.
SetAudioBitrates	Set the maximum audio streaming bitrates.
GetAudioBitrates	Get the maximum audio streaming bitrates.
RequestDuration	Request the current streaming duration and timecode from the switcher.
GetDuration	Get the cached streaming duration (in frames).
GetTimecode	Get the cached streaming timecode.
GetEncodingBitrate	Get the current encoding bitrate.
GetCacheUsed	Get the current usage level of the streaming cache.
SetAuthentication	Set the streaming authentication credentials.
GetAuthentication	Get the streaming authentication credentials.
SetLowLatency	Set the low latency flag.
GetLowLatency	Get the low latency flag.
AddCallback	Add a streaming callback.
RemoveCallback	Remove a streaming callback.

11.3.1.1 **IBMDSwitcherStreamRTMP::StartStreaming** method

The **StartStreaming** method starts video and audio streaming to the configured streaming server.

Syntax

```
HRESULT StartStreaming()
```

Return Values

Value	Description
S_OK	Success.
S_FALSE	Already streaming.
E_FAIL	Failure.

11.3.1.2 **IBMDSwitcherStreamRTMP::StopStreaming** method

The **StopStreaming** method stops video and audio streaming to the configured streaming server.

Syntax

```
HRESULT StopStreaming()
```

Return Values

Value	Description
S_OK	Success.
S_FALSE	Not currently streaming.
E_FAIL	Failure.

11.3.1.3 **IBMDSwitcherStreamRTMP::IsStreaming** method

The **IsStreaming** method is used to determine if the switcher is currently streaming.

Syntax

```
HRESULT IsStreaming(Boolean* streaming)
```

Parameters

Name	Direction	Description
streaming	out	Boolean value indicating whether the switcher is currently streaming.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The streaming parameter is invalid.

11.3.1.4 **IBMDSwitcherStreamRTMP::GetStatus** method

The **GetStatus** method returns the current streaming status.

Syntax

```
HRESULT GetStatus(BMDSwitcherStreamRTMPState* state,  
BMDSwitcherStreamRTMPError* error)
```

Parameters

Name	Direction	Description
state	out	BMDSwitcherRecordAVState value indicating the current streaming status.
error	out	BMDSwitcherStreamRTMPError value indicating the error associated with current streaming status.

Return Values

Value	Description
S_OK	Success.
E_POINTER	A parameter is invalid.

11.3.15 **IBMDSwitcherStreamRTMP::SetServiceName** method

The **SetServiceName** method sets the streaming service name. The name is only used for display purposes.

Syntax

```
HRESULT SetServiceName(string serviceName)
```

Parameters

Name	Direction	Description
serviceName	in	Name of the streaming service.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

11.3.16 **IBMDSwitcherStreamRTMP::GetServiceName** method

The **GetServiceName** method gets the name of the streaming service.

Syntax

```
HRESULT GetServiceName(string* serviceName)
```

Parameters

Name	Direction	Description
serviceName	out	Name of the streaming service.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The serviceName parameter is invalid.

11.3.1.7 **IBMDSwitcherStreamRTMP::SetUrl** method

The **SetUrl** method sets the streaming server URL.

Syntax

```
HRESULT SetUrl(string url)
```

Parameters

Name	Direction	Description
url	in	Streaming server URL.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

11.3.1.8 **IBMDSwitcherStreamRTMP::GetUrl** method

The **GetUrl** method gets the streaming server URL.

Syntax

```
HRESULT GetUrl(string* url)
```

Parameters

Name	Direction	Description
url	out	Streaming server URL.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The url parameter is invalid.

11.3.1.9 **IBMDSwitcherStreamRTMP::SetKey** method

The **SetKey** method sets the streaming server key.

Syntax

```
HRESULT SetKey(string url)
```

Parameters

Name	Direction	Description
url	in	Streaming server key.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

11.3.1.10 **IBMDSwitcherStreamRTMP::GetKey** method

The **GetKey** method gets the streaming server key.

Syntax

```
HRESULT GetKey(string* key)
```

Parameters

Name	Direction	Description
key	out	Streaming server key.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The key parameter is invalid.

11.3.1.11 **IBMDSwitcherStreamRTMP::SetVideoBitrates**

The **SetVideoBitrate** method sets the maximum video streaming bitrates, in bits per second. The low bitrate is used for framerates of 30p and lower. The high bitrate is used for framerates of p50 and higher.

Syntax

```
HRESULT SetVideoBitrates(uint32_t lowBitrate, uint32_t highBitrate)
```

Parameters

Name	Direction	Description
lowBitrate	in	Maximum video streaming bitrate for low framerates, in bits per second.
highBitrate	in	Maximum video streaming bitrate for high framerates, in bits per second.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

11.3.1.12 **IBMDSwitcherStreamRTMP::GetVideoBitrates**

The **GetVideoBitrate** method gets the current maximum video streaming bitrates, in bits per second. The low bitrate is used for framerates of 30p and lower. The high bitrate is used for framerates of p50 and higher.

Syntax

```
HRESULT GetVideoBitrates(uint32_t* lowBitRate, uint32_t* highBitRate)
```

Parameters

Name	Direction	Description
lowBitRate	out	Maximum video streaming bitrate for low framerates, in bits per second.
highBitRate	out	Maximum video streaming bitrate for high framerates, in bits per second.

Return Values

Value	Description
S_OK	Success.
E_POINTER	A parameter is invalid.

11.3.1.13 **IBMDSwitcherStreamRTMP::SetAudioBitrates method**

The **SetAudioBitrate** method sets the maximum audio streaming bitrates, in bits per second. The low bitrate is used for framerates of 30p and lower. The high bitrate is used for framerates of p50 and higher.

Syntax

```
HRESULT SetAudioBitrates(uint32_t lowBitrate, uint32_t highBitrate)
```

Parameters

Name	Direction	Description
lowBitrate	in	Maximum audio streaming bitrate for low framerates, in bits per second.
highBitrate	in	Maximum audio streaming bitrate for high framerates, in bits per second.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

11.3.1.14 **IBMDSwitcherStreamRTMP::GetAudioBitrates** method

The **GetAudioBitrate** method gets the current maximum audio streaming bitrates, in bits per second. The low bitrate is used for framerates of 30p and lower. The high bitrate is used for framerates of p50 and higher.

Syntax

```
HRESULT GetAudioBitrates(uint32_t* lowBitRate, uint32_t* highBitRate)
```

Parameters

Name	Direction	Description
lowBitRate	out	Maximum audio streaming bitrate for low framerates, in bits per second.
highBitRate	out	Maximum audio streaming bitrate for high framerates, in bits per second.

Return Values

Value	Description
S_OK	Success.
E_POINTER	A parameter is invalid.

11.3.1.15 **IBMDSwitcherStreamRTMP::RequestDuration** method

The **RequestDuration** method requests the current streaming duration and timecode from the switcher which will be cached when received. Use the **GetDuration** and **GetTimecode** methods to get the cached duration and cached timecode, respectively.

Syntax

```
HRESULT RequestDuration()
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

11.3.1.16 **IBMDSwitcherStreamRTMP::GetDuration** method

The **GetDuration** method returns the streaming duration (in frames) that was last received from the switcher.

Syntax

```
HRESULT GetDuration(uint64_t* duration);
```

Parameters

Name	Direction	Description
duration	out	Recording duration (in frames).

Return Values

Value	Description
S_OK	Success.
E_POINTER	The duration parameter is invalid.

11.3.1.17 **IBMDSwitcherStreamRTMP::GetTimecode** method

The **GetTimecode** method returns the streaming timecode that was last received from the switcher.

Syntax

```
HRESULT GetTimecode(uint8_t* hours, uint8_t* minutes, uint8_t* seconds, uint8_t* frames, Boolean* dropFrame);
```

Parameters

Name	Direction	Description
hours	out	The hours value of the timecode.
minutes	out	The minutes value of the timecode.
seconds	out	The seconds value of the timecode.
frames	out	The frames value of the timecode.
dropFrame	out	Whether the timecode is drop frame.

Return Values

Value	Description
S_OK	Success.
E_POINTER	A parameter is invalid.

11.3.1.18 **IBMDSwitcherStreamRTMP::GetTimecode** method

The **GetEncodingBitrate** method returns the current encoding bitrate, in bits per second.

Syntax

```
HRESULT GetEncodingBitrate(uint32_t* encodingBitrate)
```

Parameters

Name	Direction	Description
encodingBitrate	out	The current encoding bitrate.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The encodingBitrate parameter is invalid.

11.3.1.19 **IBMDSwitcherStreamRTMP::GetCacheUsed** method

The **GetCacheUsed** method returns the current usage level of the streaming cache, as a percentage.

Syntax

```
HRESULT GetCacheUsed(double* cacheUsed)
```

Parameters

Name	Direction	Description
cacheUsed	out	Percentage of the current usage level of the streaming cache.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The cacheUsed parameter is invalid.

11.3.1.20 **IBMDSwitcherStreamRTMP::SetAuthentication** method

The **SetAuthentication** method sets the streaming server authentication credentials.

Syntax

```
HRESULT SetAuthentication(string username, string password)
```

Parameters

Name	Direction	Description
username	in	Streaming server authentication username.
password	in	Streaming server authentication password.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

11.3.1.21 **IBMDSwitcherStreamRTMP::GetAuthentication** method

The **GetAuthentication** method gets the streaming server authentication credentials.

Syntax

```
HRESULT GetAuthentication(string* username, string* password)
```

Parameters

Name	Direction	Description
username	out	Streaming server authentication username.
password	out	Streaming server authentication password.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The username and/or password parameters are invalid.

11.3.1.22 **IBMDSwitcherStreamRTMP::SetLowLatency** method

The **SetLowLatency** method changes the low latency mode. If low latency is enabled, frames will be dropped during times of poor network performance to prevent the stream from lagging too far behind the live output of the switcher. This flag can only be changed when the switcher is not recording.

Syntax

```
HRESULT SetLowLatency(Boolean lowLatency)
```

Parameters

Name	Direction	Description
lowLatency	in	Boolean value indicating whether low latency is active.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

11.3.1.23 **IBMDSwitcherStreamRTMP::GetLowLatency** method

The **GetLowLatency** method returns the low latency mode.

Syntax

```
HRESULT GetLowLatency(Boolean* lowLatency)
```

Parameters

Name	Direction	Description
lowLatency	out	Boolean value indicating whether low latency is active.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The lowLatency parameter is invalid.

11.3.1.24 **IBMDSwitcherStreamRTMP::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherStreamRTMP** object. Pass an object implementing the **IBMDSwitcherStreamRTMPCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherStreamRTMPCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherStreamRTMPCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

11.3.1.25 IBMDSwitcherStreamRTMP::RemoveCallback method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback(IBMDSwitcherStreamRTMPCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherStreamRTMPCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

11.3.2 IBMDSwitcherStreamRTMPCallback Interface

The **IBMDSwitcherStreamRTMPCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherStreamRTMP** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherStreamRTMP	IID_IBMDSwitcherStreamRTMP	An IBMDSwitcherStreamRTMPCallback object interface is installed with IBMDSwitcherStreamRTMP::AddCallback and removed with IBMDSwitcherStreamRTMP::RemoveCallback .

Public Member Functions	
Method	Description
Notify	Called when an event occurs.
NotifyStatus	Called when the streaming status changes.

11.3.2.1 **IBMDSwitcherStreamRTMPCallback::Notify** method

The **Notify** method is called when **IBMDSwitcherStreamRTMP** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(BMDSwitcherStreamRTMPEventType eventType)
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherStreamRTMPEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

11.3.2.2 **IBMDSwitcherStreamRTMPCallback::NotifyStatus** method Interface

The **NotifyStatus** method is called when the streaming status has changed.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT NotifyStatus(BMDSwitcherStreamRTMPState stateType,  
BMDSwitcherStreamRTMPError error)
```

Parameters

Name	Direction	Description
stateType	in	BMDSwitcherStreamRTMPState that describes the current streaming state.
error	in	BMDSwitcherStreamRTMPError of the error associated with the current streaming state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

Section 12 — Recording

The Recording API provides functionality to record video and audio from the switcher.

12.1 General Information

12.1.1 Video and Audio Encoding

Recordings from the switcher are stored as H.264 video and AAC audio in MP4 file format onto any externally connected disk (USB disk, flash drive, or Blackmagic Design MultiDock).

12.1.2 Working Set of Disks

The switcher maintains a working set of two disks. By default, this will be the two connected disks (USB disks or flash drives) with the largest available capacity. One of these will be designated as the **active** disk. The active disk is the one that will be, or is currently being, used for recording. The other disk (non active disk) will be a spill disk, which will be used for recording when the active disk is filled, or if **IBMDSwitcherRecordAV::SwitchDisk** is called. The working set can be changed by calling **IBMDSwitcherRecordAV::SetWorkingSetDisk**.

12.2 Recording Data Types

12.2.1 Recording State

BMDSwitcherRecordAVState enumerates the possible recording states.

- **bmdSwitcherRecordAVStateIdle**
Not recording.
- **bmdSwitcherRecordAVStateRecording**
Recording is in progress.
- **bmdSwitcherRecordAVStateStopping**
Recording is stopping.

12.2.2 Recording Error

BMDSwitcherRecordAVErrors enumerates the possible errors that can occur when recording.

- **bmdSwitcherRecordAVErrorsNone**
No error
- **bmdSwitcherRecordAVErrorsNoMedia**
Invalid disk or no disk.
- **bmdSwitcherRecordAVErrorsMediaFull**
No space available on any disk.
- **bmdSwitcherRecordAVErrorsMediaError**
Disk error.
- **bmdSwitcherRecordAVErrorsMediaUnformatted**
Disk is not formatted.
- **bmdSwitcherRecordAVErrorsDroppingFrames**
Frames dropped while recording.
- **bmdSwitcherRecordAVErrorsUnknown**
Unknown error.

12.2.3 Recording Disk Status

BMDSwitcherRecordDiskStatus enumerates the possible recording disk statuses.

- **bmdSwitcherRecordDiskIdle**
Disk is currently not in use.
- **bmdSwitcherRecordDiskUnformatted**
Disk is not formatted.
- **bmdSwitcherRecordDiskActive**
Disk is part of the working set.
- **bmdSwitcherRecordDiskRecording**
Disk is currently being recorded to.

12.2.4 Recording Event Type

BMDSwitcherRecordAVEventType enumerates the possible event types for the **IBMDSwitcherRecordAVCallback** object interface.

- **bmdSwitcherRecordAVEventTypeFilenameChanged**
The recording filename has changed.
- **bmdSwitcherRecordAVEventTypeRecordInAllCamerasChanged**
The Record in all Cameras state has changed.
- **bmdSwitcherRecordAVEventTypeTimecodeChanged**
Current recording timecode has changed.
- **bmdSwitcherRecordAVEventTypeDurationChanged**
Current recording duration has changed.
- **bmdSwitcherRecordAVEventTypeActiveDiskIndexChanged**
The currently active disk index has changed.
- **bmdSwitcherRecordAVEventTypeTotalRecordingTimeAvailableChanged**
The combined recording time available on all connected disks has changed.
- **bmdSwitcherRecordAVEventTypeRecordAllISOInputsChanged**
The Record all ISO Inputs state has changed.

12.2.5 Recording Disk Availability Event Type

BMDSwitcherRecordDiskAvailabilityEventType enumerates the possible disk availability event types for the **IBMDSwitcherRecordAVCallback** object interface.

- **bmdSwitcherRecordDiskAvailabilityEventTypeAvailable**
A disk has become available.
- **bmdSwitcherRecordDiskAvailabilityEventTypeRemoved**
A disk is no longer available.

12.2.6 Recording Disk Event Type

BMDSwitcherRecordDiskEventType enumerates the possible event types for the **IBMDSwitcherRecordDiskCallback** object interface.

- **bmdSwitcherRecordDiskEventTypeStatusChanged**
The disk status has changed.
- **bmdSwitcherRecordDiskEventTypeRecordingTimeAvailableChanged**
The remaining recording time on the disk has changed.
- **bmdSwitcherRecordDiskEventTypeVolumeNameChanged**
The disk volume name has changed.

12.3 Interface Reference

12.3.1 IBMDSwitcherRecordAV Interface

The **IBMDSwitcherRecordAV** object interface provides functionality to start and stop recording of video and audio to externally connected disks.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcher	IID_IBMDSwitcher	An IBMDSwitcherRecordAV object interface can be obtained with IBMDSwitcher::QueryInterface .

Public Member Functions	
Method	Description
StartRecording	Start recording.
StopRecording	Stop recording.
SwitchDisk	Switch recording to the next disk.
IsRecording	Determine whether the switcher is currently recording.
GetStatus	Get the current recording status.
SetFilename	Set the recording file name.
GetFilename	Get the recording file name.
SetRecordInAllCameras	Set the record in all cameras flag.
GetRecordInAllCameras	Get the record in all cameras flag.
DoesSupportISORecording	Determine if recording ISO inputs is supported by the switcher.
SetRecordAllISOInputs	Set the record all ISO inputs flag.
GetRecordAllISOInputs	Get the record all ISO inputs flag.
GetWorkingSetLimit	Get the maximum number of disks that can be in the working set.
SetWorkingSetDisk	Set a disk in the the working set.
GetWorkingSetDisk	Get the ID of a disk in the working set.
GetActiveDiskIndex	Get the index of the active disk.
RequestDuration	Request the current recording duration and timecode from the switcher.
GetDuration	Get the cached recording duration (in frames).
GetTimecode	Get the cached recording timecode.
GetTotalRecordingTimeAvailable	Get the total available recording time.
CreateIterator	Create an iterator.
AddCallback	Add a recording callback.
RemoveCallback	Remove a recording callback.

12.3.1.1 **IBMDSwitcherRecordAV::StartRecording** method

The **StartRecording** method starts recording video and audio to disk.

Syntax

HRESULT StartRecording()

Return Values

Value	Description
S_OK	Success.
S_FALSE	Already recording.
E_FAIL	Failure.

12.3.1.2 **IBMDSwitcherRecordAV::StopRecording** method

The **StopRecording** method stops the current recording.

Syntax

HRESULT StopRecording()

Return Values

Value	Description
S_OK	Success.
S_FALSE	Not currently recording.
E_FAIL	Failure.

12.3.1.3 **IBMDSwitcherRecordAV::SwitchDisk** method

The **SwitchDisk** method stops recording to the current disk and continues recording to the next disk, if there is one available.

Syntax

HRESULT SwitchDisk()

Return Values

Value	Description
S_OK	Success.
S_FALSE	Not currently recording.
E_FAIL	Failure.

12.3.1.4 **IBMDSwitcherRecordAV::IsRecording** method

The **IsRecording** method determines if the switcher is currently recording.

Syntax

```
HRESULT IsRecording(Boolean* recording)
```

Parameters

Name	Direction	Description
recording	out	Boolean value indicating whether the switcher is currently recording.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The recording parameter is invalid.

12.3.1.5 **IBMDSwitcherRecordAV::GetStatus** method

The **GetStatus** method returns the current recording status

Syntax

```
HRESULT GetStatus(BMDSwitcherRecordAVState* state,  
BMDSwitcherRecordAVError* error)
```

Parameters

Name	Direction	Description
state	out	BMDSwitcherRecordAVState value indicating the current recording status.
error	out	BMDSwitcherRecordAVError value indicating the error associated with current recording status.

Return Values

Value	Description
S_OK	Success.
E_POINTER	A parameter is invalid.

12.3.1.6 **IBMDSwitcherRecordAV::SetFilename method**

The **SetFilename** method sets the base file name for recording. Any file extension will be ignored.

Syntax

```
HRESULT SetFilename(string filename)
```

Parameters

Name	Direction	Description
filename	in	Base name of the recording file.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

12.3.1.7 **IBMDSwitcherRecordAV::GetFilename method**

The **GetFilename** method gets the base file name for recording.

Syntax

```
HRESULT GetFilename(string* filename)
```

Parameters

Name	Direction	Description
filename	out	Base name of recording file.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure
E_POINTER	The filename parameter is invalid.

12.3.1.8 **IBMDSwitcherRecordAV::SetRecordInAllCameras** method

The **SetRecordInAllCameras** method changes the record in all cameras flag. If the switcher is currently recording, any connected Blackmagic Design cameras will immediately start or stop recording based on the **recordInAllCameras** flag. If the switcher is not recording, the **recordInAllCameras** flag will be used next time recording is started.

Syntax

```
HRESULT SetRecordInAllCameras(Boolean recordInAllCameras)
```

Parameters

Name	Direction	Description
recordInAllCameras	in	Boolean value indicating whether record in all cameras flag is active.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

12.3.1.9 **IBMDSwitcherRecordAV::GetRecordInAllCameras** method

The **GetRecordInAllCameras** method returns the record in all cameras flag.

Syntax

```
HRESULT GetRecordInAllCameras(Boolean* recordInAllCameras)
```

Parameters

Name	Direction	Description
recordInAllCameras	out	Boolean value indicating whether record in all cameras flag is active.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The recordInAllCameras parameter is invalid.

12.3.1.10 **IBMDSwitcherRecordAV::DoesSupportISORecording** method

The **DoesSupportISORecording** method determines if ISO recording is supported by the switcher.

Syntax

```
HRESULT DoesSupportISORecording(Boolean* supportsISORecording)
```

Parameters

Name	Direction	Description
supportsISORecording	out	Boolean value describing whether ISO recording is supported by the switcher.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The supportsISORecording parameter is invalid.

12.3.1.11 **IBMDSwitcherRecordAV::SetRecordAllISOInputs** method

The **SetRecordAllISOInputs** method changes the record all ISO inputs flag. This flag can only be changed when the switcher is not recording and will be used next time recording is started.

Syntax

```
HRESULT SetRecordAllISOInputs(Boolean recordAllISOInputs)
```

Parameters

Name	Direction	Description
recordAllISOInputs	in	Boolean value indicating whether record all ISO inputs flag is active.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Feature not supported on this model, or media currently recording.

12.3.1.12 **IBMDSwitcherRecordAV::GetRecordAllISOInputs** method

The `GetRecordAllISOInputs` method returns the record all ISO inputs flag.

Syntax

```
HRESULT GetRecordAllISOInputs(Boolean* recordAllISOInputs)
```

Parameters

Name	Direction	Description
recordAllISOInputs	out	Boolean value indicating whether record all ISO inputs flag is active.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Feature not supported on this model.
E_POINTER	The recordAllISOInputs parameter is invalid.

12.3.1.13 **IBMDSwitcherRecordAV::GetWorkingSetLimit** method

The `GetWorkingSetLimit` method returns the maximum number of disks that can be added to the working set.

Syntax

```
HRESULT GetWorkingSetLimit(uint32_t* workingSetLimit)
```

Parameters

Name	Direction	Description
workingSetLimit	out	Number of disks in the working set.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The workingSetLimit parameter is invalid.

12.3.1.14 **BMDSwitcherRecordAV::SetWorkingSetDisk** method

The **SetWorkingDisk** method adds the specified disk to the working set at the specified index.

Syntax

```
HRESULT SetWorkingSetDisk(uint32_t workingSetIndex,  
                          BMDSwitcherRecordDiskId diskId)
```

Parameters

Name	Direction	Description
workingSetIndex	in	Zero based index into the working set.
diskId	in	BMDSwitcherRecordDiskId of the disk.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The workingSetIndex parameter is out of range.
E_FAIL	Failure.

12.3.1.15 **BMDSwitcherRecordAV::GetWorkingSetDisk** method

The **GetWorkingDisk** method gets the ID of the disk at the specified index in the working set.

Syntax

```
HRESULT GetWorkingSetDisk(uint32_t workingSetIndex,  
                          BMDSwitcherRecordDiskId* diskId)
```

Parameters

Name	Direction	Description
workingSetIndex	in	Zero based index into the working set
diskId	out	BMDSwitcherRecordDiskId of the disk.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The workingSetIndex parameter is out of range.
E_POINTER	The diskId parameter is invalid.
E_FAIL	Failure.

12.3.1.16 **IBMDSwitcherRecordAV::GetActiveDiskIndex** method

The **GetActiveDisk** method returns the index of the currently active disk in the working set.

Syntax

```
HRESULT GetActiveDiskIndex(uint32_t* workingSetIndex)
```

Parameters

Name	Direction	Description
workingSetIndex	out	Zero based index into the working set.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The workingSetIndex parameter is invalid.

12.3.1.17 **IBMDSwitcherRecordAV::RequestDuration** method

The **RequestDuration** method requests the current recording duration and timecode from the switcher which will be cached when received. Use the **GetDuration** and **GetTimeCode** methods to get the cached duration and cached timecode, respectively.

Syntax

```
HRESULT RequestDuration()
```

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

12.3.1.18 **IBMDSwitcherRecordAV::GetDuration** method

The **GetDuration** method returns the recording duration (in frames) that was last received from the switcher.

Syntax

```
HRESULT GetDuration(uint64_t* duration);
```

Parameters

Name	Direction	Description
duration	out	Recording duration (in frames).

Return Values

Value	Description
S_OK	Success.
E_POINTER	The duration parameter is invalid.

12.3.1.19 **IBMDSwitcherRecordAV::GetTimecode** method

The **GetTimecode** method returns the recording timecode that was last received from the switcher.

Syntax

```
HRESULT GetTimecode(uint8_t* hours, uint8_t* minutes, uint8_t* seconds, uint8_t* frames, Boolean* dropFrame);
```

Parameters

Name	Direction	Description
hours	out	The hours value of the timecode.
minutes	out	The minutes value of the timecode.
seconds	out	The seconds value of the timecode.
frames	out	The frames value of the timecode.
dropFrame	out	Whether the timecode is drop frame.

Return Values

Value	Description
S_OK	Success.
E_POINTER	A parameter is invalid.

12.3.1.20 **IBMDSwitcherRecordAV::GetTotalRecordingTimeAvailable** method

The **GetTotalRecordingTimeAvailable** method returns the total recording time available across all externally connected disks..

Syntax

```
HRESULT GetTotalRecordingTimeAvailable(uint32_t* totalRecordingTimeAvailable)
```

Parameters

Name	Direction	Description
totalRecordingTimeAvailable	out	Total recording time available across all disks.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The totalRecordingTimeAvailable parameter is invalid.

12.3.1.21 **IBMDSwitcherRecordAV::CreateIterator** method

The **CreateIterator** method creates an iterator object interface for the specified interface ID.

Syntax

```
HRESULT CreateIterator(REFIID iid, LPVOID* ppv)
```

Parameters

Name	Direction	Description
iid	in	Iterator Interface ID to create an iterator for.
ppv	out	Pointer to returned interface object.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The ppv parameter is invalid.
E_OUTOFMEMORY	Insufficient memory to create interface object.
E_NOINTERFACE	Interface was not found.
E_FAIL	Failure.

12.3.1.22 **IBMDSwitcherRecordAV::AddCallback** method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherRecordAV** object. Pass an object implementing the **IBMDSwitcherRecordAVCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherRecordAVCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherRecordAVCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

12.3.1.23 **IBMDSwitcherRecordAV::RemoveCallback** method

The **RemoveCallback** method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback(IBMDSwitcherRecordAVCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherRecordAVCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

12.3.2 IBMDSwitcherRecordAVCallback Interface

The **IBMDSwitcherRecordAVCallback** object interface is a callback class containing methods that are called when an event occurs on an **IBMDSwitcherRecordAV** object. Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherRecordAV	IID_IBMDSwitcherRecordAV	An IBMDSwitcherRecordAVCallback object interface is installed with IBMDSwitcherRecordAV::AddCallback and removed with IBMDSwitcherRecordAV::RemoveCallback .

Public Member Functions

Method	Description
Notify	Called when an event occurs.
NotifyWorkingSetChange	Called when the working set changes.
NotifyDiskAvailability	Called when disk availability changes.
NotifyStatus	Called when the recording status changes.

12.3.2.1 IBMDSwitcherRecordAVCallback::Notify method

The **Notify** method is called when **IBMDSwitcherRecordAV** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(BMDSwitcherRecordAVEventType eventType)
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherRecordAVEventType that describes the type of event that has occurred.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

12.3.2.2 **BMDSwitcherRecordAVCallback::NotifyWorkingSetChange** method

The **NotifyWorkingSetChange** method is called when a disk in the working set has changed.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT NotifyWorkingSetChange(uint32_t workingSetIndex,  
                                BMDSwitcherRecordDiskId diskId)
```

Parameters

Name	Direction	Description
workingSetIndex	in	Working set index that has changed.
diskId	in	BMDSwitcherRecordDiskId of the disk associated with the working set change. A value of 0xFFFFFFFF means that no valid disk is present.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

12.3.2.3 **BMDSwitcherRecordAVCallback::NotifyDiskAvailability** method

The **NotifyDiskAvailability** method is called when the availability of a disk has changed.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT NotifyDiskAvailability(BMDSwitcherRecordDiskAvailabilityEventType eventType,  
                                BMDSwitcherRecordDiskId diskId)
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherRecordDiskAvailabilityEventType that describes the type of event that has occurred.
diskId	in	BMDSwitcherRecordDiskId of the disk associated with the availability change.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

12.3.2.4 **IBMDSwitcherRecordAVCallback::NotifyStatus** method

The **NotifyStatus** method is called when the recording status has changed.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT NotifyStatus(BMDSwitcherRecordAVState stateType,  
                    BMDSwitcherRecordAVERror error)
```

Parameters

Name	Direction	Description
stateType	in	BMDSwitcherRecordAVState that describes the current recording state.
error	in	BMDSwitcherRecordAVERror of the error associated with the current recording state.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.

12.3.3 **IBMDSwitcherRecordDiskIterator** Interface

The **IBMDSwitcherRecordDiskIterator** is used to enumerate the disks connected to the Switcher.

A reference to an **IBMDSwitcherRecordDiskIterator** object interface may be obtained from an **IBMDSwitcherRecordAV** object interface using the **CreateIterator** method.

Pass **IID_IBMDSwitcherRecordDiskIterator** for the IID parameter.

Related Interfaces

Interface	Interface ID	Description
IBMDSwitcherRecordAV	IID_IBMDSwitcherRecordAV	IBMDSwitcherRecordAV::CreateIterator can return an IBMDSwitcherRecordDiskIterator object interface.

Public Member Functions	
Method	Description
Next	Returns a pointer to the next IBMDSwitcherRecordDisk object interface.
GetById	Returns a pointer to an IBMDSwitcherRecorder object interface, given its BMDSwitcherRecordDiskId .

12.3.3.1 IBMDSwitcherRecordDiskIterator::Next method

The `Next` method returns the next available `IBMDSwitcherRecordDisk` object interface.

Syntax

```
HRESULT Next(IBMDSwitcherRecordDisk** recordDisk)
```

Parameters

Name	Direction	Description
recordDisk	out	IBMDSwitcherRecordDisk object interface.

Return Values

Value	Description
S_OK	Success.
S_FALSE	No more <code>IBMDSwitcherRecordDisk</code> objects available.
E_POINTER	The recordDisk parameter is invalid.

12.3.3.2 IBMDSwitcherRecordDiskIterator::GetById method

The `GetById` method returns a pointer to an `IBMDSwitcherRecordDisk` object interface, given its `BMDSwitcherRecordDiskId`.

Syntax

```
HRESULT GetById(BMDSwitcherRecordDiskId diskId, IBMDSwitcherRecordDisk** disk)
```

Parameters

Name	Direction	Description
diskId	in	<code>BMDSwitcherRecordDiskId</code> identifier.
disk	out	IBMDSwitcherRecordDisk object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The diskId is not a valid identifier.
E_POINTER	The disk parameter is invalid.

12.3.4 IBMDSwitcherRecordDisk Interface

The `IBMDSwitcherRecordDisk` object interface provides access to information about externally connected disks.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherRecordDiskIterator</code>	<code>IID_IBMDSwitcherRecordDiskIterator</code>	An <code>IBMDSwitcherRecordDisk</code> object interface will be returned after a successful call to <code>IBMDSwitcherRecordDiskIterator::Next</code> and <code>IBMDSwitcherRecordDiskIterator::GetById</code> methods.

Public Member Functions	
Method	Description
<code>GetId</code>	Get the ID of this <code>IBMDSwitcherRecordDisk</code> interface.
<code>GetVolumeName</code>	Get the volume name.
<code>GetRecordingTimeAvailable</code>	Get the available recording time.
<code>GetStatus</code>	Get the current status.
<code>AddCallback</code>	Add a record disk callback.
<code>RemoveCallback</code>	Remove a record disk callback.

12.3.4.1 IBMDSwitcherRecordDisk::GetId method

The `GetId` method returns the disk's ID, used to uniquely identify a disk within the switcher.

Syntax

```
HRESULT GetId(IBMDSwitcherRecordDiskId* diskId)
```

Parameters

Name	Direction	Description
<code>diskId</code>	out	<code>IBMDSwitcherRecordDiskId</code> identifier for the current disk.

Return Values

Value	Description
<code>S_OK</code>	Success.
<code>E_POINTER</code>	The <code>diskId</code> parameter is invalid.

12.3.4.2 **IBMDSwitcherRecordDisk::GetVolumeName** method

The **GetVolumeName** method returns the volume name of the disk.

Syntax

```
HRESULT GetVolumeName(string* volumeName)
```

Parameters

Name	Direction	Description
volumeName	out	The volume name of the disk.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The volumeName parameter is invalid.
E_FAIL	Failure.

12.3.4.3 **IBMDSwitcherRecordDisk::GetRecordingTimeAvailable** method

The **GetRecordingTimeAvailable** method returns the available recording time for the disk. The available recording time is calculated from the configured bitrate properties.

Syntax

```
HRESULT GetRecordingTimeAvailable(uint32_t* recordingTimeAvailable)
```

Parameters

Name	Direction	Description
recordingTimeAvailable	out	The available recording time of the disk.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The recordingTimeAvailable parameter is invalid.

12.3.4.4 IBMDSwitcherRecordDisk::GetStatus method

The **GetStatus** method returns the current status of the disk.

Syntax

```
HRESULT GetStatus(IBMDSwitcherRecordDiskStatus* diskStatus)
```

Parameters

Name	Direction	Description
diskStatus	out	The current status of the disk.

Return Values

Value	Description
S_OK	Success.
E_POINTER	The diskStatus parameter is invalid.

12.3.4.5 IBMDSwitcherRecordDisk::AddCallback method

The **AddCallback** method configures a callback to be called when events occur for an **IBMDSwitcherRecordDisk** object. Pass an object implementing the **IBMDSwitcherRecordDiskCallback** interface to receive callbacks. Adding a new callback will not affect previously added callbacks.

Syntax

```
HRESULT AddCallback(IBMDSwitcherRecordDiskCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the IBMDSwitcherRecordDiskCallback object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

12.3.4.6 IBMDSwitcherRecordDisk::RemoveCallback method

The `RemoveCallback` method removes a previously installed callback.

Syntax

```
HRESULT RemoveCallback(IBMDSwitcherRecordDiskCallback* callback)
```

Parameters

Name	Direction	Description
callback	in	Callback object implementing the <code>IBMDSwitcherRecordDiskCallback</code> object interface.

Return Values

Value	Description
S_OK	Success.
E_INVALIDARG	The callback parameter is invalid.

12.3.5 IBMDSwitcherRecordDiskCallback Interface

The `IBMDSwitcherRecordDiskCallback` object interface is a callback class containing methods that are called when an event occurs on an `IBMDSwitcherRecordDisk` object.

Like all callback methods, these callback methods may be called from another thread.

Related Interfaces

Interface	Interface ID	Description
<code>IBMDSwitcherRecordDisk</code>	<code>IID_IBMDSwitcherRecordDisk</code>	An <code>IBMDSwitcherRecordDiskCallback</code> object interface is installed with <code>IBMDSwitcherRecordDisk::AddCallback</code> and removed with <code>IBMDSwitcherRecordDisk::RemoveCallback</code> .

Public Member Functions

Method	Description
<code>Notify</code>	Called when an event occurs.

12.3.5.1 IBMDSwitcherRecordDiskCallback::Notify method

The **Notify** method is called when **IBMDSwitcherRecordDisk** events occur, such as property changes.

This method is called from a separate thread created by the switcher SDK so care should be exercised when interacting with other threads. Callbacks should be processed as quickly as possible to avoid delaying other callbacks or affecting the connection to the switcher.

The return value (required by COM) is ignored by the caller.

Syntax

```
HRESULT Notify(BMDSwitcherRecordDiskEventType eventType,  
               BMDSwitcherRecordDiskId diskId)
```

Parameters

Name	Direction	Description
eventType	in	BMDSwitcherRecordDiskEventType that describes the type of event that has occurred.
diskId	in	BMDSwitcherRecordDiskId of the disk that has changed.

Return Values

Value	Description
S_OK	Success.
E_FAIL	Failure.