

When run, the program will initialize, display its saved temperatures, and then around every 1s will update the current temp along with the max/min temperatures. On reset, the previously saved temperatures appear. If the button is held for a second, the values reset.

On repeated test runs, the program performs correctly.

There are no print-outs from serial monitor, as the program doesn't interface with UART.