

- M6
- M5
- M4
- M3
- M2
- M1
- CURR
- +5V
- LED

Turn on the ESC LED function, you need to connect 5V IN and LED IN from the FC to work

