

CADENZA

KIA Navigation System
QUICK REFERENCE GUIDE

UVO



LOOKING FOR MORE INFORMATION?

This Quick Reference Guide does not replace your System Owner's Manual.

If you require additional information or are unsure of a specific issue, refer to the System Owner's Manual for additional information.

iPod®

iPod® is a registered trademark of Apple Inc.

***Bluetooth®* Wireless Technology**

The *Bluetooth®* Wireless Technology word mark and logos are registered trademarks owned by *Bluetooth®* Wireless Technology SIG, Inc. and any use of such marks by KIA is under license.

A *Bluetooth®* Wireless Technology enabled cell phone is required to use *Bluetooth®* Wireless Technology.

HD Radio™ Technology

HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents.

HD Radio™ and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.



All Map Database cannot be copied without permission.

This is protected by U.S. copyright laws. All rights not expressly granted are reserved. You may not otherwise reproduce, modify, and distribute the content without M&Soft, Inc's prior written consent.

Table of Contents

Controls and Functions.....	2
Sound Settings.....	5
Display Settings.....	7
FM/AM Mode.....	8
HD Radio™ Mode.....	11
SIRIUS Mode.....	13
CD Mode.....	16
MP3 CD Mode.....	18
USB Mode.....	21
iPod Mode.....	25
AUX Mode.....	27
Bluetooth® Audio.....	28
My Music Mode.....	29
Navigation.....	32
Bluetooth® Handsfree.....	48
Voice Recognition.....	58

Controls and Functions

Control Panel

1 ● PWR key ● VOL Knob

- When power is off, press to turn power on.
- When power is on, press and hold (over 0.8 seconds) to turn power off.
- When power is on, press shortly (under 0.8 seconds) to turn Audio off.
- Turn left/right to control volume.

2 FM/AM

- Converts to FM/AM mode.
- Each time the key is pressed, the mode is changed in order of FM1 → FM2 → AM → FM1.

3 PHONE

Takes user to home phone screen.

4 SAT

Converts to SIRIUS mode

Each time the key is pressed, the mode is changed in order of SIRIUS1 → SIRIUS2 → SIRIUS3 → SIRIUS1.

5 MEDIA

- Displays CD, MP3, USB, iPod, AUX, Bluetooth® Audio Streaming, My Music modes.
- If the media is not connected or a disc is not inserted, corresponding modes will be disabled.

6 ▼ SEEK, TRACK ▲

Pressed shortly. (under 0.8 seconds)

- In FM/AM mode, plays previous/next frequency.
- In SIRIUS mode, plays the previous/next channel.
- In CD/MP3/USB/iPod/My Music modes, changes the track, file or chapter.

Pressed and held. (over 0.8 seconds)

- In FM/AM mode, continuously changes the frequency until the key is released and plays the current frequency.
- In SIRIUS mode, continuously changes the channel until the key is released and plays the current channel.
- In CD/MP3/USB/iPod/My Music modes, rewinds or fast-forwards the track or file.



Controls and Functions



Press to insert or eject disc.



Displays the map for the current position.



Displays Route menu screen.



Displays the Destination setup menu.



Displays the Setup mode.



- In FM/AM mode, changes the frequency.
- In SIRIUS mode, changes the channel.
- In CD, MP3, USB, iPod, My Music modes, changes the track, file or chapter.




Resets and restarts the system.



SD Card insert slot.



Turns off the screen or displays the default image.



CAUTION

- Always give your full attention to driving. Avoid operating your system in such a way that you may be distracted from driving your vehicle.

Controls and Functions

Steering Wheel Remote Controller

1 VOL+ VOL-

Controls the volume.

2 MUTE

Mutes the sound.

3 ▲ ▼

Pressed shortly. (under 0.8 seconds)

- In FM/AM mode, searches broadcast frequencies saved to Presets.
- In SIRIUS modes, searches broadcast channels saved to Presets.
- In CD/MP3/USB/iPod/My Music modes, changes the track, file or chapter.

Pressed and held. (over 0.8 seconds)

- In FM/AM mode, automatically searches broadcast frequencies and channels.
- In SIRIUS modes, automatically searches broadcast channels.
- In CD/MP3/USB/iPod/My Music modes: rewinds or fast forwards the track of file.


4 MODE

- Each time this key is pressed, the mode is changed in order of FM1 → FM2 → AM → SIRIUS1 → SIRIUS2 → SIRIUS3 → USB or iPod → AUX → Bluetooth® Audio → My Music.
- If the media is not connected or a disc is not inserted, corresponding modes will be disabled.
- Press and hold the key (over 0.8 seconds) to turn the Audio system on/off.
- When power is off, press the key to turn power back on.

5 ⏮

When pressed shortly. (under 0.8 seconds)

4



- Activates voice recognition.

When pressed and held. (over 0.8 seconds)

- Ends voice recognition.

6 ⏭

Pressed shortly. (under 1.2 seconds)

- When pressed in the phone screen, displays call history screen.
- When pressed in the dial screen, makes a call.
- When pressed in the incoming call screen, answers the call.
- When pressed during call waiting, switches to waiting call (Call Waiting)

Pressed and held. (over 1.2 seconds)

- When pressed in the Bluetooth® Handsfree wait mode, redials the last call.
- When pressed during a Bluetooth® Handsfree call, switches call back to mobile phone (Private).
- When pressed while calling on the mobile phone, switches call back to Bluetooth® Handsfree (Operates only when Bluetooth® Handsfree is connected).

7 ⏭

- When pressed during a call, ends the phone call.
- When pressed in the incoming call screen, rejects the call.

Sound Settings



Press the **Sound** button to display the sound setting screen.

Information

- UVO eServices are an optional feature equipped in select vehicles



Setting Balance/Fader

Press the **Sound** button ▶

Press **Fader/Balance** ▶ Set and press **Done**.

Use the **▲**, **▼**, **◀**, **▶** buttons to move the cursor on the control screen to the desired position.

Press **CENTER** to restore sound to the center position.




Setting Bass/Mid/Treble

Press the **Sound** button ▶

Press **Bass/Mid/Treble** ▶ Set and press **Done**.

Use the **◀** or **▶** buttons to adjust the Bass/Mid/Treble settings.



Setting Volume Ratio


Press the **Sound** button ▶

Press **Volume Ratio** ▶ Set and press **Done**.


These options are used to set the volume ratio by selecting from Navigation Priority/ Audio Priority/Same Ratio.

Sound Settings

Advanced

Press the  **Sound** button
▶ Press **Advanced** ▶ Press
Variable-EQ ▶ Set and press
Done .


This is used to set the Surround and Speed Dependent Volume Control features.



Surround

When turned on, sound with vivid, three dimensional effects can be enjoyed.

Speed Dependent Volume Control


Press the  **Sound** button ▶
Press **Advanced** ▶ Turn the
feature **On** ▶ Set and press
Done .

The volume level is controlled automatically according to the vehicle speed.

Setting Beep

Press the  **Sound** button ▶
Press **Beep** ▶ Set and press
Done .

Each press of this button turns the BEEP tone on/off.



Display Settings



Press the **i** key ▶ Press **Setup** ▶ Press **Display** .

i Information

- UVO eServices are an optional feature equipped in select vehicles




Adjusting Brightness

Press the **Display** button ▶

Press **Brightness** ▶ Set and press **Done** .

Use the **◀** or **▶** buttons to adjust the display brightness.



Setting Display Mode

Press the **Display** button ▶

Press **Display Mode** ▶ Set and press **Done** .

Press the button for the desired display mode from **• Automatic** , **• Daylight** , and **• Light** modes.

FM/AM Mode

Starting Mode

Press the **FM/AM** key to change the mode in order of FM1 → FM2 → AM.

When the power is OFF, pressing the **FM/AM** key will turn the power on and play a radio broadcast



Using Seek

Press the **SEEK** key to automatically search for frequencies.

- Shortly press the key (under 0.8 seconds) : Plays previous/next frequency
- Press and hold the key (over 0.8 seconds) : Changes the frequency while pressed and receives the next frequency upon release.

Using TUNE

Press the **TUNE** key to manually select the frequency.

- FM1/FM2 : Increases/decreases by 200kHz
- AM : Increases/decreases by 10kHz



Selecting Presets

From the 6 presets, select the frequency you want to listen to.



Saving Radio Frequency



Saving Manually

After selecting frequency ► Press and hold (over 0.8 seconds) the preset button.

- A 'beep' will sound and the frequency is saved to the selected preset button.

Saving Automatically

Press the **Auto Store** to automatically save receivable frequencies to Preset buttons.

A total of 18 frequencies with six preset frequencies each for FM1/FM2/AM modes can be saved.

Scanning Radio Frequency



Press the **Scan** button to scan all radio frequencies.

Starting from the current frequency, frequencies with superior reception are scanned for 5 seconds and the previous frequency is restored.

FM/AM Mode

Using the Menu Buttons

Press the **Menu** button to use the Preset Scan menu.

Preset Scan

Press the **Menu** button ► Press **Preset Scan**.

- Frequencies saved to the 6 preset buttons are each played for 5 seconds and the previous frequency is restored.

Text On/Text Off

Press the **Menu** button ► Press **Text On**.

The Text feature is turned on/off.

- If the **Text On** button is displayed (Text off state), information will not be displayed even if there is information being transmitted from the broadcast station.
- If the **Text Off** button is displayed (Text on state), then broadcast information will be displayed. Information may not be displayed if there is no information being transmitted from the broadcast station.



Starting Mode



Press the **FM/AM** key to turn on Radio mode.

If an HD Radio™ broadcast is received, the radio mode will switch from analog broadcast to HD Radio™ broadcast.

Operating HD Radio™ Mode

Selecting a Frequency

As HD Radio™ reception is included within Radio mode, the methods of moving between channels, saving presets, searching, or methods of searching frequencies are identical. However, while the HD Radio™ related icon display will become active when within regions where an HD Radio™ signal can be received.

Using TUNE

Press the **TUNE** key to manually select the frequency.

Selecting through Preset

From the 6 presets, select the HD Radio™ broadcast you want to listen to.



HD Radio Mode

Song-Tagging

The song tagging feature provides a way to capture broadcasted song information from the radio for future purchase in iTunes.

Upon connection of an Apple audio playback device , the "tagged songs" will be transferred to your iTunes account in your Tagged songs folder.

HD Radio™ Digital Broadcast On/Off

Press the **SETUP** key ▶ Press the **HD Radio** ▶ Press **On** / **Off** .

HD Radio™ Broadcasts can be turned On and Off for HD Radio™ FM and AM mode.



Starting Mode



Press the **SAT** key to change the mode in order of SIRIUS1 → SIRIUS2 → SIRIUS3.

When the power is OFF, pressing the **SAT** key will turn the power on and play an SIRIUS Radio broadcast.

Using SEEK

Press the **SEEK**, **TRACK** key on the control panel for under 0.8 seconds.

The previous or next channel will be selected.



Using TUNE

Press the **TUNE** key to display the previous or next channel information. After a brief moment, the selected channel will be displayed.




Selecting Presets

From the 6 presets, select the channel you want to listen to.

SIRIUS Mode

Selecting through Channel/Category List

Press the **List** button ► Select the desired category and channel. Select the desired category and the channel. Once selected, the previous screen will be restored and the selected channel will begin playing.



Saving SIRIUS Channels

Saving Manually

After selecting channel ► Press and hold (over 0.8 seconds) the preset button.

- A confirmation 'beep' will be heard and the channel will be saved to the selected preset button.



Using the Menu Buttons



Press the **Menu** button to use the Search, Preset Scan, and Scan menus.

Search

Press the **Menu** button ► Press **Search** ► Enter numbers and press **Done**.

Enter the number of the channel you want to receive.

Preset Scan

Press the **Menu** button ► Press **Preset Scan**.

Channels saved to the 6 preset buttons are each played for 10 seconds and then the previous channel is restored.

Scan

Press the **Scan** button to scan all channels.

Starting from the current channel, channels with superior reception are scanned for 10 seconds and the previous channel is restored once scanning is complete.

CD Mode

Starting Mode

Press the **MEDIA** key ▶ Press



Playing a CD

- Press the **▶** button to play the track.
- Press the **||** button to pause the track.



Fast-forwarding or Rewinding CD Tracks

While playing ▶ Press and hold the **▽SEEK**, **TRACK▲** key. (over 0.8 seconds)

This will rewind or fast-forward the track.


While the **▽SEEK**, **TRACK▲** key is being pressed, the track will rewind or fast-forward at 20x speed.

Once released, the track will begin playing at normal speed.

Searching CD Tracks

Turn the **●** key ▶ TUNE knob ▶ Search tracks ▶ Once the desired track name is displayed, press the **●** TUNE knob.

When searching tracks, the track number is displayed in orange. Pressing the **●** TUNE knob will play the corresponding track.



Using the Menu Buttons



Press the **Menu** button to set the repeat, shuffle, scan and Info On/Info Off menus.

Repeat

Press the **Menu** button ► Press **Repeat** .

The current track is repeated.

Shuffle

Press the **Menu** button ► Press **Shuffle** .

Tracks within the disc are played in random order.

Scan

Press the **Menu** button ► Press **Scan** .

The beginning (approx. 10 seconds) of all tracks within the CD are scanned.

Info On/Info Off

Press the **Menu** button ► Press **Info On** .

The amount of information displayed on the screen can be selected. When the title, artist, and album info are displayed, the button will automatically change to **Info Off** .

Press **Info Off** to restore the previous information display setting.

MP3 CD Mode

Starting Mode

Press the **MEDIA** key ▶ Press **MP3**.




Playing MP3

- Press the **▶** button to play the file.
- Press the **||** button to pause the file.

Selecting MP3 files

Selecting from the Mode Screen

- Press the **▼SEEK**, **TRACK▲** key to select the previous or next file.
- Pressing and holding the **▼SEEK**, **TRACK▲** key will rewind or fast-forward the current file.



Using Menus within List Screen

Press the **List** button ▶ Select the file from the list.

Fast-forwarding or Rewinding MP3 Files

While playing ▶ Press and hold the **▼SEEK**, **TRACK▲** key (over 0.8 seconds).


This will rewind or fast-forward the file.

While the **▼SEEK**, **TRACK▲** key is being pressed, the file will rewind or fast-forward at 20x speed.


Once released, the file will begin playing at normal speed.

Searching MP3 Files

Turn the **TUNE** knob ▶ Search files ▶ Once the desired file name is displayed, press the **TUNE** knob.



Using the Menu Buttons



Press the **Menu** button to set the copy, repeat, shuffle, scan, and Info On/Off options.

Copy

Press the **Menu** button ► Press **Copy**.

The currently playing file is copied and saved in My Music.

Repeat

Press the **Menu** button ► Press **Repeat**.

Each time the button is pressed, the option is changed from Repeat Once → Repeat Folder → Off(Repeat All).

Shuffle

Press the **Menu** button ► Press **Shuffle**.

Each time the button is pressed, the option is changed from Shuffle Folder → Shuffle All → Off(Repeat All).

Scan

Press the **Menu** button ► Press **Scan**.

Each time the button is pressed, the option is changed from Folder Scan → Scan All → Off.

MP3 CD Mode

Info On/Info Off

Press the **Menu** button ► Press **Info On** .

The amount of information displayed on the screen can be changed.

When the title, artist, and album info are displayed, the button will automatically change to **Info Off** . Press **Info Off** to restore the previous information display setting.


Using Menus within the List Screen

Moving between Lists

Press the **List** button ► Press the **▲** , **▼** buttons.

If five (5) or more files or folders exist in the same folder, the list will be displayed across two or more pages.

Press the **▲** , **▼** cursor buttons to quickly find the desired page.




Moving between Folders

Press the **Home** button ► Select folder from the folder list.

Pressing the **Home** button will move to the folder one level above the current folder.

Pressing the **Home** button folder will move to the root folder.




Returning to Current Location

While searching files within other folders, press the **Now Playing** button to return to the currently playing file screen.



Starting USB Music Mode

Press the **MEDIA** key ► Press **USB Music** . If the USB is not connected, then the **USB Music** button will be disabled.



Playing USB Music

- Press the **▶** button to play the USB Music.
- Press the **||** button to pause USB Music.

Searching USB Music Files

While Playing ► Press the **<** , **>** buttons or the **▼SEEK** , **TRACK^** key to play the previous/next file.

- Pressing and holding the **▼SEEK** , **TRACK^** key (over 0.8 seconds) will rewind or fast-forward the current file.
- While the **▼SEEK** , **TRACK^** key is being pressed, the track will rewind or fast-forward at high speeds. Once the key is released, the USB Music will begin playing at normal speed.

USB Mode

Using the Menu Buttons

Press the **Menu** button to set the Copy, Repeat, Shuffle, Scan, Info On (Info Off) menus.

Copy

Press the **Menu** button ► Press **Copy**.

The currently playing file is copied and saved in My Music.

Repeat

Press the **Menu** button ► Press **Repeat**.

Each time the button is pressed, the option is changed from Repeat Once → Repeat Folder → Off(Repeat All).

Shuffle


Press the **Menu** button ► Press **Shuffle**.

Each time the button is pressed, the option is changed from Shuffle Folder → Shuffle All → Off(Repeat All).

Scan

Press the **Menu** button ► Press **Scan**.

Each time the button is pressed, the option is changed from Folder Scan → Scan All → Off(Repeat All).



Info On/Info Off

Press the **Menu** button ► Press **Info On** .

The screen display can be set differently depending on user selection.

When the title, artist, and album info are displayed, the button is changed to **Info Off** .

Press **Info Off** to restore the previous information display setting.



Starting USB Image Mode

Press the **MEDIA** key ► Press **USB Image** .

Searching USB Image Files

While playing ► Press the **<** , **>** buttons to view the previous/next image.

Using the Menu Buttons

Press the **Menu** button to set the Slideshow, Rotate Image, Adjust Image Size, Save Image and Info menus.

USB Mode

Slideshow Interval

Press the **Menu** button ► Press **Slideshow** .

Image Slideshow intervals can be set at **5sec** , **10sec** , **20sec** , or **30sec** intervals.



Rotating Image

Press the **Menu** button ► Press **Rotate Image** ► Press **Done** .

Each time the **Rotate** button is pressed, the image is rotated from 0° → 90° → 180° → 270° degrees.



Adjusting Image Size

Press the **Menu** button ► Press **Adjust Image Size** ► Press **Done** .

Press the **-** , **+** buttons to enlarge or reduce the image size. The scale can be changed to x1/4, x1/2, x1, x2, x4.



Saving Image

Press the **Menu** button ► Press **Save Image** .

Viewing Info

Press the **Menu** button ► Press **Info** .

This menu is used to check image information, such as the image resolution and file type.

Starting Mode

Press the **MEDIA** key ▶ Press


iPod.

If the iPod is not connected, then the **iPod** button will be disabled.



Playing iPod


- Press the **▶** button to play the iPod.
- Press the **||** button to pause the iPod.



Searching iPod

Press the **List** button to display the initial iPod list screen.

When searching an iPod, it is possible to search by Playlists, Artists, Albums, Songs, Genres, Composers, Audiobooks, and Podcasts.



iPod Mode

Selecting iPod File

While playing ▶ Press the **◀**, **▶** buttons or the **▼ SEEK**, **TRACK ▲** key to play the previous/next file.

Pressing and holding the **▼ SEEK**, **TRACK ▲** key (over 0.8 seconds) will rewind or fast-forward the current song.

Searching iPod Files

Turn the **● TUNE** knob to search files. Once the desired file name is displayed, press the **● TUNE** knob. When searching files, the file number is displayed in gray. Pressing the **● TUNE** knob will play the corresponding file.

Using the Menu Buttons

Press the **Menu** button to set the Repeat, Shuffle, and Info On (Info Off) menus.

Repeat

Press the **Menu** button ▶ Press **Repeat**.

Shuffle

Press the **Menu** button ▶ Press **Shuffle**.

Info On/Info Off


Press the **Menu** button ▶ Press **Info On**.

The screen display can be set differently depending on user selection. When the title, artist, and album info are displayed, the button **Info Off**.



Press **Info Off** to restore the previous display setting.

Starting Mode



Press the **MEDIA** key ► Press **AUX**.

External Device

External AUDIO players can be played through a dedicated cable. The position of the AUX jack is at the top of the gear box located between the driver and passenger seats.

Starting Mode

Press the **MEDIA** key ▶ Press **Bluetooth Audio** .

Playing Bluetooth® Audio

- Press the **▶** button to play files saved within the Bluetooth® phone.
- Press the **||** button to pause the file.



Selecting Bluetooth® Audio Files

While playing ▶ Press the **SEEK** , **TRACK^** key ▶ Selects the previous/next file.

Setting Connection

Press the **Connections** button to add a new Bluetooth® phone, connect/disconnect, delete, delete all, or view the Help section.



Starting Mode



Press the **MEDIA** key ► Press **My Music**.



Playing My Music

- Press the **▶** button to play the file.
- Press the **⏸** button to pause the file.

Selecting My Music

While playing ► Press the **<**, **>** buttons or the **▼SEEK**, **TRACK▲** key to play the previous/next file.

- Pressing and holding the **▼SEEK**, **TRACK▲** key (over 0.8 seconds) will rewind or fast-forward the current file.
- While the **▼SEEK**, **TRACK▲** key is being pressed, the track will rewind or fast-forward at high speeds. Once the key is released, the Music will begin playing at normal speed.

My Music Mode

Using the Menu Buttons

Press the **Menu** button to set the Repeat, Shuffle, Scan, Info On (Info Off) menus.

Repeat

Press the **Menu** button ► Press **Repeat** .

The currently playing file is repeated.

Shuffle

Press the **Menu** button ► Press **Shuffle** .

When turned on, files are played in random order.

Scan

Press the **Menu** button ► Press **Scan** .

The beginning (approx 10 seconds) of all files are scanned.

Info On/Info Off


Press the **Menu** button ► Press **Info On** .

The screen display can be set differently depending on user selection.

When the title, artist, and album info are displayed, the button is changed to

Info Off .

Press **Info Off** to restore the previous information display setting.







Using Menus within the List Screen

Moving between Lists

Press the **List** button ► Press **▲** , **▼** .

If six (6) or more files or folders exist in the same folder, the list will be displayed across two or more pages.

Press the **▲** , **▼** cursor buttons to quickly find the desired page.



Retuning to Current Location

While searching files within other folders, press the **Now Playing** button to return to the currently playing file screen.

Deleting Files

Press the **List** button ► Select the files to delete ► Press **Delete Items** .

Navigation

Starting Navigation

Current Position

Press the **MAP VOICE** key or the **Ⓐ** button displayed at the upper right side in some map conditions to display the map of the current position and the neighboring area.



Map Display Settings

Press the **MAP VOICE** key ▶ Press the **ⓘ**.

This button is used to set map screen related options, such as Split screen, Heading-Up/North Up, and Left/Right screen display.



Changing Map Scale

Press the **MAP VOICE** key ▶ Press **0.75mi** ▶ Set the desired map scale. Press the **0.75mi** button to display the map scale menu and change the map to the desired scale.



Map Menu

Press the **>** button ▶ Press **Menu** button.

Features frequently used within the map screen, such as **Set as Destination**, **Add Waypoint**, **View Destination**, **Cancel Route**, **Call**, and **Details** are displayed.





Adjusting Navigation Volume

Press the **>** button ► Press

Speaker ► Adjust volume.

Press the **Speaker** button. The volume menu is displayed and allows you to adjust the navigation voice guidance volume.

The volume can be adjusted from

0~45 through the **+** / **-** button.

Press the **Mute** button to turn off the sound.




POI Display

Press the **>** button ► Press

POI .

When POI menus are displayed, pressing one of the 6 POI icon buttons will display the corresponding POI icons.



Editing POI Icons

Press **POI** ► Press the **Edit POI Icon** button ► Press **Done** .

Press the **Edit POI Icon** button to select the desired facility from the various facility types.

Up to six favorite facilities can be set.

Press the **Default** button to reset the displayed POI icons. Initially, Gas Station, Parking, Fast Food, Hospital, Auto Service, and Bank are set as default.

Navigation


Searching POIs

Press the **Search by local POI** button

► Press the search criteria.

(**Near current position** ,
Near scroll mark, or **Near destination** ,
Near route)

Name	Description
1 Near Current Position	Within the 'Search by POI' menu, searches facilities based on the current vehicle position
2 Near Scroll Mark	Within the 'Search by POI' menu, searches facilities based on the current scrolled position
3 Near Destination	Within the 'Search by POI' menu, searches facilities based on the location of the destination
4 Near route	Searches facilities nearby the current route



The POI mark is displayed according to the selected criteria.

Adding a My Place

Press the **My Place** button ► Press the desired group.

This feature is used to save the current position or the scrolled position as a My Place or Speed Alert, Quick Menu.



Destination Search



Quick Menu

Press the **★** button on the left side of the map screen to display the Quick Menu.

Name	Description
1 Quick Menu (★)	Display/hide Quick Menus
2 Quick Menu Bar	Menus added to the Quick Menu (possible to set up to 6 menus)
3 Edit	Add/Delete Quick Menus
4 Current Quick Menus	Shows list of current Quick Menus
5 Add/Remove	Add or remove Quick Menus
6 Quick Menu Categories	List of categories that can be added to Quick Menus


Point of Interest (POI) Search

Press the **DEST** key ► Press **Point of Interest**.

POI Search is a feature that allows you to search for POIs that are near your current position, near a scroll mark, near the destination, or near the city center.


Navigation

Categories are sub-categorized and the selected area and category are displayed at the top of the screen for user convenience.



Previous Destinations

Press the **DEST** key ► Press **Previous Destination** .






Address

Press the **DEST** key ► Press

Address.

This search feature is used to search destinations by addresses through state, city, and street.

Enter the name of the Street, City and State corresponding to the desired destination. Once search is complete, press the **Search** button to select the desired location from the list.



My Places

Press the **DEST** key ► Press

My Places.

This search feature is used to search destinations by selecting previously saved My Places to set as destinations. My Places can be placed in groups, and group names can be edited within Setup.

Navigation

Intersection Search

Press the **DEST** key ► Press **Intersection Search** .

This search feature is used to search destinations by street intersections throughout the map.

Enter the name of the Street, City and State corresponding to the desired destination. Once search is complete, press the **Search** button to select the desired location from the list.



Emergency

Press the **DEST** key ► Press **Emergency** .

This search feature is used to search for police stations, hospitals, and dealerships in emergency situations.





Coordinates

Press the **DEST** key ► Press

Coordinates .

This search feature is used to search destinations by entering coordinates. Two coordinate entry formats are supported. Select the desired format upon starting search.



Phone Number Search

Press the **DEST** key ► Press

Phone Number .

This search feature is used to search the locations of POIs by entering the phone number of the desired POI destination.

- Area codes must be entered to complete the search.



Exit/Entrance

Press the **DEST** key ► Press

EXIT .

This search feature is used to search destinations by entering the Exits and Entrances of corresponding expressways.


Enter the name of the Freeway corresponding to the desired destination. Once search is complete, press the **Search** button to select the desired location from the list.

Navigation

Setting a Destination

Press the **DEST** key ► Search for the Destination ► Press **Set as Destination** .

- To conduct a destination search through the desired search method, select the desired destination from the list. (For more information on destination search methods, refer to the ‘Destination Search’ section.)
- After verifying the location of the searched destination, press the **Set as Destination** button to calculate the route. The Route Overview or Alternative Route screen will be displayed.



(Alternative Route)



(Route Overview)

One Touch Scroll Setting

The destination can be set to the current map display.

- While in the map screen, touching a position on the map will move the map to the center of the selected position and display the scroll mark.
- Press the **Menu** button to set the selected position as a waypoint or destination.



Route Calculation

- Once you have set a destination, calculate the route. The route overview and route option menus will be displayed.
- After checking the Route Overview, press the **MAP VOICE** key or the **Start Guidance** button or just drive for over 3 mph or for approximately 5 seconds to start guidance.



Add Waypoint

After searching for waypoints, press the **Add Waypoint** button to add the waypoint to the current route.

Navigation

Route Recalculation

Once a route has been set, the **Recalculate** button is displayed at the top of the menus.

Pressing the **Recalculate** button will display a pop-up that allows you to change route options. Once the settings are changed, the route is recalculated by reflecting the changes.



Cancel Route

In the Map menu screen, press the **Cancel Route** button.



Route Guidance



Preliminary guidance, highway mode, turn list guidance, and other guidance screens are displayed according to the current road condition.

Within the guidance map screen, if the current position is on route, then intersection guidance will be provided once you are nearby an intersection. Also, the intersection zoom screen is displayed when nearby an intersection.



Preliminary Guidance Mode

At the top right side of the screen, the next/ after next turn info, remaining distance, direction, and other information are displayed.



Intersection Zoom Mode

This mode provides detailed guidance nearby intersections before the next turn.

This mode is displayed starting from 300m before the intersection.

Navigation

Highway Mode

Upon entering a highway during route guidance, the highway mode will automatically be displayed. This mode is displayed when driving on a highway and mainly displays highway related POIs.



Turn List Mode

Turn List Mode shows turn information on the current route.



Route Menu

Press the **ROUTE** key to use, edit, or optimize various route options.

Cancel Route

Press the **ROUTE** key ► Press **Cancel Route**.

Route Overview

Press the **ROUTE** key ► Press **Route Overview**.

Within the Route Overview screen, press the **Alternative Route** button to display other potential routes to the set destination.

From the alternative route options, select the desired route.

Route Info

Press the **ROUTE** key ► Press **Route Info**.

The turn points and distance information by key roads within the set route are played. Press the **MAP** button next to each road name to display the map position for the corresponding location.



Navigation

Route Option


Press the **ROUTE** key ▶ Press **Route Option** ▶ Set and press **Done** . Route Options refer to conditions used to calculate the route to the destination. The route is automatically re-calculated if the route options and detailed route settings are changed.



Detour

Press the **ROUTE** key ▶ Press **Detour** .

The Detour menu is used to redefine the route by setting a detour to a certain distance from the current position.



Avoid Streets

Press the **ROUTE** key ▶ Press **Avoid Streets** ▶ Select the streets you want to avoid and press **Done** .


This feature is used to select specific streets to avoid within the current route. Select **Avoid** to avoid the particular streets in the route overview that are desired to be avoided.



Edit Route

Press the **ROUTE** key ▶ Press **Edit Route** ▶ Set and press **Done** .

The Edit Route menu displays the start point, waypoints, and the destination in list format and is used to edit corresponding positions or the order of destinations within the route.





Avoid Area

Press the **ROUTE** key ► Press **Avoid Area** ► Set and press **Done** .

This feature is used by creating a rectangle over the area to avoid.


An area set as an avoid area is excluded from the calculated route. If a route had been calculated prior to creating an avoid area, the route will automatically be recalculated.

The screen will prompt to select the first corner of the square of the avoid area, followed by the second corner.

Bluetooth® Handsfree


Using Bluetooth® Handsfree

Pairing from the Bluetooth® Device

Press the  key on the steering wheel remote controller or press the **PHONE** ► Press **Yes** .

In the Search from Device screen
► Search for the car name and pair the device ► Enter the Passkey ► Bluetooth® becomes connected.

- When searching from the Bluetooth® device, the car name is Santa Fe Sport and the default passkey is '0000'.
- To learn more about searching from Bluetooth® devices and pairing, refer to the user's manual for your Bluetooth® device.
- The Bluetooth® Audio screen is displayed once audio streaming is connected.
- For more information on mobile phone compatibility, visit the Kia Motor website (<http://www.kia.com/bluetooth>).



Making/Answering Calls

Calling by Dialing a Number

Enter number on the dial pad ▶
Press the **Send** or the **Call** key on the steering wheel remote controller.

If you press the **Send** button without entering a number, the Call History screen is displayed. Press and hold the dial pad **0 +** (over 0.8 seconds) to enter a "+".



Name	Description
1 Send	Calls the entered phone number
2 End	Deletes all entered numbers

Bluetooth® Handsfree

Answering a Call

Incoming call notice ▶ Press the **Accept** button or the **Accept** key on the steering wheel remote controller.

When there is an incoming on within the connected phone, the bell will sound and the phone number of the other party will be displayed on the incoming call pop-up, as shown here.



Operating Menus during a Call

Ending a Call


While on a call ▶ Press the **End** button or the **End** key on the steering wheel remote controller.

The Bluetooth® handsfree call will end.






Switching Call to Bluetooth® Phone

During handsfree call ► Press the **Private** button or press and hold the  key (over 0.8 seconds) on the steering wheel remote controller.

The call will be switched from the handsfree to the Bluetooth® mobile phone.

Switching Call to the Handsfree

During call on mobile phone ► Press the **Use Handsfree** button or press and hold the  key (over 0.8 seconds) on the steering wheel remote controller.

The call will be switched from the Bluetooth® mobile phone to the car handsfree.

Contacts

Downloading Mobile Phone
Contacts

- Press the **Contacts** button ▶
- Press the **Download** button ▶
- Press **Yes** .



Setting Bluetooth® Connection

Connecting a Device

Press the **Connect** button on the Phone screen.

The Phone screen is displayed once Bluetooth® Handsfree is connected, and the Bluetooth® Audio screen is displayed once audio streaming is connected.



Disconnecting a Device

Select the device you wish to disconnect ► Press **Disconnect**
► Press **Yes** .





Setting Auto Connection

Press the **Auto Connection** button
► Select the desired phone ► Set
and press **Done** .

The Bluetooth® device will automatically be connected according to the option set when the car ignition is turned on. When the user selected phone cannot be connected, the system automatically attempts to connect the most recently connected phone. When the most recently connected phone cannot be connected, the system attempts to connect all paired phones continuously. If you do not want to connect automatically, turn off Bluetooth within your mobile phone.

Bluetooth® Handsfree

Device Information



Press **i** **gear** ► Press

Bluetooth ► Press

Advanced Settings ► Press

Device Information .

- This feature allows you to check device information.



Adjusting the Ring/Call Volume

While on a call ► Use the **VOL** knob on the head unit or the **VOL +** , **VOL -** keys on the steering wheel remote controller to adjust the ring/call volume.






Setting Mic Volume


While on a call ▶ Press the **Outgoing Vol.** ▶ Set Outgoing Volume ▶ Press **OK**.

If you press the **Mute** button, the outgoing volume is muted and blocked to the other party.



Restore Factory Settings


Press the **i** key ▶ Press **Setup** ▶ Press **Bluetooth** ▶ Press **Advanced Settings** ▶ Press **Restore Factory Settings**.



Voice Recognition


Starting Voice Recognition

Starting Voice Recognition


Shortly press the  key on the steering wheel remote controller (under 0.8 seconds) ▶ Say a command.

Once voice recognition starts, the voice command entry window and the six representative commands are displayed.

- If voice recognition is in [Normal Mode], then the system will say “Please say a command after the beep,” followed by a beep tone.
- If voice recognition is in [Expert Mode], then you will only hear a beep a “Beep~”.




Skipping Prompt Messages

While prompt message is being stated ▶ Shortly press the  key on the steering wheel remote controller. (under 0.8 seconds)

The prompt message is immediately ended and the beep tone will sound. After the “beep”, say the voice command.


Re-starting Voice Recognition

While system waits ▶ Shortly press the  key on the steering wheel remote controller. (under 0.8 seconds)

The command wait state will end and the beep tone will sound. After the “beep”, say the voice command.


Ending Voice Recognition

While Voice Recognition is operating

- ▶ Press and hold the  key on the steering wheel remote controller. (over 0.8 seconds)

While using voice recognition, pressing a steering wheel remote control or a different key will end voice recognition.

Illustration on Using Voice Recognition (Setting Home as the Destination)

Press the  key. (under 0.8 seconds)


The system awaits for your command and display a list of accessible commands on the screen.



Please say a command after the beep

BEEP

Destination



Destination
Please say a command after the beep

BEEP

Go Home



Voice Recognition

Voice Command List

Voice commands within this system are categorized into “Common Commands” and “Mode Commands.”

- Common Commands (●) : commands that can be used in all situations.
- Mode Commands (○) : commands that can be used in specific multimedia/navigation/Bluetooth® mode states.

Command		Operation
●	Help	Displays the main Help screen
●	Destination Help	Displays the Destination related command list
●	Map Help	Displays the Map related command list
●	Radio Help	Displays the FM/AM radio related command list
●	SIRIUS Help	Displays the SIRIUS radio related command list
●	Disc Help	Displays the DISC mode related command list for the disc inserted in the CD Player
●	iPod Help	Displays the iPod related command list
●	USB Help	Displays the USB related command list
●	Phone Help	Displays the Phone related comand list
●	My Music Help	Displays the My Music related comand list
●	UVO eServices Help(Optional)	Display the UVO eServices releated command list

Audio System Command List

FM/AM Radio

Command		Operation
●	Radio	Plays the most recent frequency for the most recently operated band
●	(Radio) AM	Plays the most recent frequency for the corresponding band
●	(Radio) FM	Plays the most recent frequency for the corresponding band. In the case of FM, The most recent frequency within the most recently played FM1 or FM2 band is played
●	FM1/FM2	Plays the most recent frequency for the corresponding band
●	AM <530~1710>	Plays the desired AM band frequency (e.g. AM "Five-Hundred Thirty")
●	FM <87.5~107.9>	Plays the desired FM band frequency (e.g. FM "Eighty-Seven point Five")
●	AM Preset <1~6>	Plays the desired AM band preset frequency
●	FM1 Preset <1~6>	Plays the desired FM1 band preset frequency
●	FM2 Preset <1~6>	Plays the desired FM2 band preset frequency
○	Preset <1~6>	Plays the desired preset frequency for the current band
○	Seek Up	Searches and plays the next frequency of the current band
○	Seek Down	Searches and plays the previous frequency of the current band
○	Preset Up	Plays the next preset frequency of the current band
○	Preset Down	Plays the previous preset frequency of the current band
○	Auto Store	Searches all frequencies within the current band and stores the 6 frequencies with the most superior reception as preset buttons
○	Scan On	Scans receivable frequencies from the current broadcast and plays for 10 seconds each
○	Scan Off	Ends the currently operating Scan or Preset Scan feature
○	Preset Scan	Plays through all presets for 10 seconds each, beginning with the current preset

Voice Recognition

SIRIUS Radio

Command		Operation
●	SIRIUS	Plays the last channel within the last band from SIRIUS1, SIRIUS2, and SIRIUS3
●	SIRIUS1/ SIRIUS2/ SIRIUS3	Plays the most recent channel for the corresponding band
●	SIRIUS Channel <1~255>	Plays the desired SIRIUS band channel (e.g. SIRIUS channel "Eleven")
●	SIRIUS1 Preset <1~6>	Plays the desired preset channel for SIRIUS1 band
●	SIRIUS2 Preset <1~6>	Plays the desired preset channel for SIRIUS2 band
●	SIRIUS3 Preset <1~6>	Plays the desired preset channel for SIRIUS3 band
○	Channel <1~255>	Plays the desired channel of the current band
○	Preset <1~6>	Plays the desired preset channel of the current band
○	Channel Up	Plays the next channel of the current band
○	Channel Down	Plays the previous channel of the current band
○	Preset Up	Plays the next preset channel of the current band
○	Preset Down	Plays the previous preset channel of the current band
○	Scan On	Scans receivable channels from the current broadcast and plays for 10 seconds each
○	Scan Off	Ends the currently operating Scan or Preset Scan feature
○	Preset Scan	Plays through all presets for 10 seconds each, beginning with the current preset

CD(Audio Type)

Command		Operation
●	CD	If the DISC inserted in the CD Player is either a CD or MP3 DISC, then the CD or MP3 will be played
●	CD Track <1~99>	If the DISC inserted in the CD Player is a CD, then CD Mode will start and plays the desired track
○	Play	Plays the currently paused song
○	Pause	Pauses the current song
○	Next Track	Plays the next track
○	Previous Track	Plays the previous track
○	Repeat On	Repeats the current track
○	Repeat Off	Cancels repeat play to play tracks in sequential order
○	Shuffle On	Randomly plays the tracks within the CD
○	Shuffle Off	Cancels random Play to play tracks in sequential order
○	Scan On	Plays each file for 10 seconds beginning with the current file
○	Scan Off	Ends the currently operating Scan feature
○	Track <1~99>	Plays the desired track number

Voice Recognition

CD(MP3 Type)

Command		Operation
●	CD	If the DISC inserted in the CD Player is either a CD or MP3 DISC, then the CD or MP3 will be played
○	Play	Plays the currently paused song
○	Pause	Pauses the current song
○	Next File	Plays the next track
○	Previous File	Plays the previous track
○	Next Folder	Plays the first file in the next folder
○	Previous Folder	Plays the first file in the previous folder
○	Repeat On	Repeats the current file
○	Repeat Off	Cancels repeat play to play files in sequential order
○	Repeat Folder	Repeats all files in the current folder
○	Shuffle On	Plays all files within the CD in random order
○	Shuffle Off	Cancels random play to play files in sequential order
○	Shuffle Folder	Randomly plays the files within the current folder
○	Scan On	Plays each file in the folder for 10 seconds beginning with the current file
○	Scan Off	Ends the currently operating Scan or Folder Scan feature
○	Folder Scan	Plays each file in the folder for 10 seconds beginning with the current file

USB Music

Command		Operation
●	USB	If the USB has been connected to the device, play the MP3 or image files within the USB
●	USB Music	If the USB has been connected to the device, plays the MP3 files within the USB
○	Play	Plays the currently paused song
○	Pause	Pauses the current song
○	Next File	Plays the next track
○	Previous File	Plays the previous track
○	Next Folder	Plays the first file in the next folder
○	Previous Folder	Plays the first file in the previous folder
○	Repeat On	Repeats the current file
○	Repeat Off	Cancels repeat play to play files in sequential order
○	Repeat Folder	Repeats all files in the current folder
○	Shuffle On	Plays all files within the USB in random order
○	Shuffle Off	Cancels random play to play files in sequential order
○	Shuffle Folder	Randomly plays the files within the current folder
○	Scan On	Plays each file in the folder for 10 seconds beginning with the current file
○	Scan Off	Ends the currently operating Scan or Folder Scan feature
○	Folder Scan	Plays each file in the folder for 10 seconds beginning with the current file

USB Image

Command		Operation
●	USB	If the USB has been connected to the device, play the MP3 or image files within the USB
●	USB Image	If the USB has been connected to the device, displays the image files within the USB
○	Next File	Displays the next image file
○	Previous File	Displays the previous image file
○	Next Folder	Displays the first image file within the next folder
○	Previous Folder	Displays the first image file within the previous folder

Voice Recognition

iPod

Command		Operation
●	iPod	Plays the songs within the iPod if the iPod has been connected to the device
○	Play	Plays the currently paused song
○	Pause	Pauses the current song
○	Next Song	Plays the next song
○	Previous Song	Plays the previous song
○	Repeat On	Repeats the current file
○	Repeat Off	Cancels repeat play to play files in sequential order
○	Shuffle On	Plays all files within the current category in random order
○	Shuffle Off	Cancels random play to play files in sequential order

My Music

Command		Operation
●	My Music	Plays the songs within the My Music
○	Play	Plays the currently paused song
○	Pause	Pauses the current song
○	Next File	Plays the next file
○	Previous File	Plays the previous file
○	Repeat On	Repeats the current file
○	Repeat Off	Cancels repeat play to play files in sequential order
○	Shuffle On	Plays all files within the current category in random order
○	Shuffle Off	Cancels random play to play files in sequential order
○	Scan On	Plays each file in the folder for 10 seconds beginning with the current file
○	Scan Off	Ends the currently operating Scan or Folder Scan feature

Others

Command		Operation
●	Audio On	Turns on the Audio
●	Audio Off	Turns off the Audio
●	Bluetooth Audio	Plays Bluetooth® Audio
●	Auxiliary	Plays the connected auxiliary device

Phone Command List

Name		Description
●	Call Name	Makes the call to the name
●	Call <Name>	Call <Name> saved in Contacts (e.g. Call "John")
●	Dial Number	Makes the call to the number
●	Dial <Number>	Call can be made by dialing the spoken numbers (e.g. Dial "123")
●	Contacts	Displays list of saved contacts. Say the name to connect the call to the corresponding contact.
●	Recent Calls	The user can select a number from the outgoing, incoming, and missed calls
●	Redial	Connects the most recently called number

UVO eServices Command List(Optional)

Name		Description
●	UVO eServices	Display the UVO eServices related command list
●	Roadside Assist	Connect with a Roadside Assist agent.
●	eService Guide	Provides guidance on how to use UVO eServices
●	Vehicle Diagnostics	Informs you if a diagnostic issue is found in your vehicle
●	My POIs	Show Points of Interest list which downloaded from Google Maps and MyUVO

Navigation Command List

Destination

Name		Description
●	Find Address	Sets the destination through address search for route guidance
●	Previous Destinations	Sets the previous destination as the current destination
●	Find Nearest POI	Sets a POI near the current position as the destination for route guidance through the POI category search
●	Find the Nearest <POI Category>	Sets a POI near the current position as the destination by directly inputting the POI name for route guidance (e.g. Find the Nearest "Restaurants"), For more information on <POI Category>, refer to Page 3-30.
●	Destination POI by Phone Number	Sets the destination by searching the phone number of the facility
●	Find Emergency Policestation	Searches for a police station near the current position and sets it as the destination for route guidance
●	Find Emergency Hospital	Searches for a hospital near the current position and sets it as the destination for route guidance
●	Find Emergency Dealership	Searches for a dealership near the current position and sets it as the destination for route guidance
●	My Places	Sets one of the list of previously registered addresses in the My Places as the destination
●	Go Home	Sets the previously registered home address as the destination for route guidance
●	Go to Office	Sets the previously registered office address as the destination for route guidance
●	Favorite Place <1 ~ 4>	Sets a previously registered favorite place as the destination for route guidance

Map

	Name	Description
●	Map Current Location	Displays the current position of the vehicle.
●	Voice Guidance On	Turns the Voice Guidance On
●	Voice Guidance Off	Turns the Voice Guidance Off
●	Voice Guidance Louder	Increases the Voice Guidance volume by 1 level
●	Voice Guidance Softer	Decreases the Voice Guidance volume by 1 level
●	Repeat Voice Guidance	Repeats the route guidance
●	Cancel Route	Deletes the designated destination and terminates the route guidance
○	Detour <1, 2, 5, 10> mile(s)	Searches detour routes within a <1, 2, 5, 10> mile(s) radius
○	Detour <1, 2, 5, 10> kilometer(s)	Searches detour routes within a <1, 2, 5, 10> kilometer(s) radius
●	Distance to Destination	Reports the remaining distance until destination by voice
●	Time to Destination	Reports the remaining time until destination by voice
○	Store Marked Location to <Text Tag> (ex: Store Marked Location to "User I")	Registers the selected location into the selected Address book
●	Replan Faster Time Route	Recalculates the route with faster time route
●	Replan Shorter Distance Route	Recalculates the route with shorter distance route
○	Zoom In / Zoom Out	Decreases/Increases the map zoom by one level
○	Zoom <Scale>	Displays the map in the corresponding zoom <scale> : 150, 300, 700 feet/0.25, 0.5 miles/1 mile/2, 4, 8, 16, 32, 64, 130, 250 miles/50, 100, 200, 400, 800 meters/1.6, 3.2, 6.4, 12, 25, 50, 100, 200, 400 kilometers
○	Zoom Maximum	Displays the map screen in the maximum zoom level
○	Zoom Minimum	Displays the map screen in the minimum zoom level
○	View Route	If the destination has been set, displays the entire route on the screen until the destination
○	Auto Zoom On	Turns the Auto Zoom feature on
○	Auto Zoom Off	Turns the Auto Zoom feature off
○	Auto Mode	Automatically converts the map display between daylight and night mode
○	Daylight Mode	Converts the map display into daylight mode
○	Night Mode	Converts the map display into night mode
○	North Up	Displays the map in North Up mode
○	Heading Up	Displays the map in Heading Up mode

Voice Recognition

POI Category List

Restaurants	Motorcycle Dealership	Recreation	Waste & Sanitary
African Restaurants	Parking	Amusement Park	Services
American Restaurants	Rest Area	Cinema	Attorney
Asian Restaurants	Road Assistance	Golf Course	Cleaning & Laundry
Chinese Restaurants	Travel	Museum	Communication Services
Coffee Shop	Airport	Recreation Area	Dentist
Continental Restaurants	Bus Station	Ski Resort	Funeral Home
Fast Food	Campground	Sports Activities	Hair & Beauty
French Restaurants	City Center	Sports Complex	Hospital
Italian Restaurants	Ferry Terminal	Video & Game Rental	Medical Service
Japanese Restaurants	Hotel	Winery	Mover Services
Korean Restaurants	Local Transit	Other Recreation	Photography
Latin American Restaurants	Rental Car Agency	Financial Services	Physician
Mexican Restaurants	Tourist Attraction	ATM	Social Service
Seafood Restaurants	Tourist Information	Bank	Tailor & Alteration
Vegetarian Restaurants	Train Station	Business Facility	Tax Service
Other Restaurants	Travel Agent	Check Cashing Service	Physician
Automotive	Shopping	Money Transfer	Social Service
Auto Parts	Bookstore	Community	Tailor & Alteration
Auto Service	Clothing Shop	City Hall	Tax Service
Automobile Dealership	Convenience Store	Civic Center	
Car Wash	Department Store	Convention Center	
Gas Station	Electronics Store	Court House	
KIA Dealership	Gift Shop	Fire Department	
	Grocery Store	Government Offices	
	Home Specialty Store	Library	
	Music Store	Police Station	
	Pharmacy	Post Office	
	Shoe Store	School	
	Shopping Center	Utilities	
	Sporting Goods Store		

3REND02



3RMS7-S0001