

Table of Contents

Part I. Control Panel.....	4
I.1. Boot up System.....	4
I.2. Shutdown.....	4
I.3. Arm System (Stay → Away).....	5
I.4. Disarm System (Away → Stay)	6
I.5. Reset Alarm	7
Part II. Web Interface.....	9
II.1. Login	9
II.2. Second Password.....	9
II.3. Floorplan	10
II.4. Menubar	11
II.4.1. Menu - Turn off.....	12
II.4.2. Surveillance - View Thumbnails	12
II.4.3. Help - About	13
II.5. Zone Mode	13
II.5.1. Change Current Zone Number	14
II.5.2. Add New Zone	14
II.5.3. Add a Device to Current Zone	15
II.5.4. Remove a Device from Current Zone	15
II.5.5. Delete Zone.....	16
II.5.6. Finish Zone Mode.....	17
II.7. Set Use Status of Sensors.....	17
II.8. Stay (Disarmed)	18
II.9. Away (Arm).....	19
II.9.1. Arm/Disarm Devices.....	20
II.9.2. Alarm Blinking.....	21
II.10. Camera View	22