

# SRM100A Test Manual

---

SEONG JI

AUG 29, 2019

## Contents


---

|              |       |   |
|--------------|-------|---|
| Hardware     | ..... | 3 |
| Test Program | ..... | 4 |

| Model   | F/W |
|---------|-----|
| SRM100A | V01 |

## Hardware

### SRM100A EVB




[ Fig. SRM100A\_EVB ]

- SRM100A module
  - SIGFOX Quad-mode module
- Antenna SAM connector
  - SIGFOX antenna
  - BLE antenna : 2.4GHz antenna
- SIGFOX download Micro USB receptacle
  - USB connector of SIGFOX and BLE for firmware writing
- Module reset switch
  - push to reset module
- Micro USB receptacle
  - Micro USB receptacle for power supply into the EVB and command interface between windows PC and Module
- Power on/off switch
  - EVB power on or off switch

## Test Program

### Test SRM100A\_EVB Connection


1. Connect EVBSRM100A board to windows OS PC via micro USB cable



[ Fig. SRM100A\_EVB connection ]

### Program execution


1. Connect SRM100A\_EVB to Windows PC via USB cable.
  - SRM100A\_EVB support USB COM & LPT driver which will be already installed in most OS.



[ Fig. Device manager ]

2. Run test program "Monarch\_CMD\_Tool\_v04.exe"

## Test program Description



[ Fig. Test program SRM200A\_APP ]

1. Connect / Close button
  - Connect : Connect test program and EVB.
  - Close : Disconnect test program from EVB.
2. Command window : Display response message for command
3. Log : Display log message

## Test program start

1. Run test program
2. Connect Windows PC to EVB board via USB cable
3. Click Connect button
4. Run the test by entering the command

Example)

**Command:** switch\_public\_key 1<CR><LF> (1:publickey 0: private key)

## Sigfox CLI commands

| Name                          | Arg  | Arguments description  | Description  |
|-------------------------------|------|--|--|
| node_close                    |      | None   | Closes the Sigfox library, resetting its state   |
| node_open                     | u    | <b>rc</b> : pointer to sfx_rc_t type representing the RC number (RC1=1, RC2=2, RC3C=3, RC4=4, RC5=5 or RC6=6).   |  |
| Node_open_with_zone           | u    |  |  |
| node_get_info                 |      | None   |  |
| node_get_version              | u    | <b>type</b> : The type of version (0=Sigfox, 1=MCU, 2=RF, 5=Monarch, 6=Device)   |  |
| node_send_bit                 | uuu  | <b>bit_value</b> : bit value to send ( 0 or 1 )<br><b>tx_repeat</b> : tx repeat value ( default : 2 )<br><b>initiate_downlink_flag</b> : wait for a response after transmitting. ( 0 or 1 )  | This function is used to send a single bit. It is mainly used when the node seeks downlink data (and not to transmit). |
| node_send_frame               | buu  | <b>cust_data</b> : pointer to the data to transmit<br>ex) ASCII : "12345678"<br>Hexa : {0102030405060708}<br><b>tx_repeat</b> : tx repeat value ( default : 2 )<br><b>initiate_downlink_flag</b> : wait for a response after transmitting. ( 0 or 1 )  | <a href="#">DM00365435.pdf</a><br>Please refer to page 9 of the "DM00365435.pdf" file                                  |
| Node_execute_monarch_scan     | uuu  | <b>rc_capability</b> : rc 6 5 4 3 2 1<br>bit 5 4 3 2 1 0<br><b>time</b> : scan time<br><b>time_unit</b> : 0: ms, 1:sec, 2:min, 3:hour  | Execute Monarch scan. rc_capability, time, unit  |
| Node_stop_monarch_scan        |      | None   | This function stops any ongoing RC scan  |
| node_set_std_config           | wwwv | <b>config_word1</b> : ch1 ~ 32 for RC2,4<br><b>config_word2</b> : ch33~64 for RC2,4<br><b>config_word3</b> : ch65~86 for RC2,4<br><b>timer_enable</b> : (0,1) for RC2,4  | <a href="#">DM00365435.pdf</a><br>Please refer to page 10 of the "DM00365435.pdf" file                                 |
| Node_get_std_config           |      | none   | Get std_config value.  |
| start_continuous_transmission | wu   | <b>frequency</b> : Frequency at which the signal has to be generated<br><b>type</b> : Type of modulation to use in continuous mode<br>(SFX_NO_MODULATION=0<br>SFX_DBPSK_100BPS=1<br>SFX_DBPSK_600BPS=2)  | Executes a continuous wave or modulation depending on the parameter type   |
| stop_continuous_transmission  |      | None   | Stop the current continuous transmission   |
| node_test_mode                | uu   | <b>rc</b> : pointer to sfx_rc_t type representing the RC number (0, 1, 2, 3, 4, 5 or 6).<br><b>test_mode</b> :<br>(SFX_TEST_MODE_TX_BPSK=0<br>SFX_TEST_MODE_TX_PROTOCOL=1<br>SFX_TEST_MODE_RX_PROTOCOL=2<br>SFX_TEST_MODE_RX_GFSK=3<br>SFX_TEST_MODE_RX_SENSI=4<br>SFX_TEST_MODE_TX_SYNTH=5<br>SFX_TEST_MODE_TX_FREQ_DISTRIBUTION=6<br>SFX_TEST_MODE_TX_BIT=11<br>SFX_TEST_MODE_PUBLIC_KEY=12<br>SFX_TEST_MODE_NVM=13) | Sigfox test mode<br>rc :<br>0 : RC1<br>1 : RC2<br>2 : RC3A<br>3 : RC3C<br>4 : RC4<br>5 : RC5<br>6 : RC6                |
| node_monarch_test_mode        | uuu  | <b>rc</b> : pointer to sfx_rc_t type representing the RC number (0, 1, 2, 3, 4, 5 or 6).<br><b>test_mode</b> :<br>(<br>SFX_TEST_MODE_RX_MONARCH_PAT<br>TERN_LISTENING_SWEEP=7<br>SFX_TEST_MODE_RX_MONARCH_PAT<br>TERN_LISTENING_WINDOW=8<br>SFX_TEST_MODE_RX_MONARCH_BE<br>ACON=9<br>SFX_TEST_MODE_RX_MONARCH_SE<br>NSI=10)<br><b>rc_capability</b> : rc 6 5 4 3 2 1<br>bit 5 4 3 2 1 0                                | Sigfox monarch test mode<br>rc :<br>0 : RC1<br>1 : RC2<br>2 : RC3A<br>3 : RC3C<br>4 : RC4<br>5 : RC5<br>6 : RC6        |

|                           |   |  |  |
|---------------------------|---|--|--|
| switch_public_key         | u | <b>key</b> : private=0, public=1   | Switch device on public or private key.  |
| Switch_test_credentials   | u | <b>credentials</b> : 1 : test ID,PAC<br>0 : module ID, PAC   | Set test credentials 1=On, 0=Off   |
| set_payload_encryption    | u | <b>enc</b> : encryption enable : 1<br>disable : 0  | Payload encryption   |
| switch_pa                 | u | <b>pa</b> : set external power amplifiler<br>(1 if a PA, 0 if not.).   | Instructs the library to configure the S2-LP for a external PA (Power Amplifier).                                |
| set_smpps_voltage         | u | <b>smpps</b> : smpps voltage of the device<br>(1.2V=1.... 1.8V=7)<br>The default is to use the S2-LP at 1.8V   | Instructs the library to configure the S2-LP with a user defined smpps frequency                                 |
| get_smpps_voltage         |   | None   | Get SMPS voltage   |
| set_rssi_offset           | u | <b>rssi_value</b> : Rssi offset value in dB  | Set an RSSI offset for the RSSI. Very useful if the RF frontend has an LNA or to calibrate the RSSI measurement. |
| get_rssi_offset           |   | None   | Get the RSSI offset for the RSSI   |
| set_xtal_frequency        | w | <b>xtal</b> : xtal value in Hz   | Sets the XTAL frequency of the S2-LP in Hertz (default is 50MHz).  |
| get_xtal_frequency        |   | None   | Get xtal frequency   |
| set_xtal_frequency_offset | w | <b>freq_offset</b> : RF offset value in Hz   | Sets the RF frequency offset in Hertz (default is 0 Hz).   |
| get_xtal_frequency_offset |   | None   | Get xtal frequency offset  |
| reduce_output_power       | v | <b>o_pwr</b> : power reduction in half dB  | Reduces the output power of the transmitted signal by a facor (reduction*0.5dB against the actual value)         |
| get_reduce_output_power   |   | None   | Get reduce output power  |
| set_lbt_thr_offset        | u | <b>lbt</b> : LBT threshold offset  | Set LBT threshold offset   |
| get_lbt_thr_offset        |   | None   | Get LBT threshold offset   |
| get_id                    |   | None   | ID stored in the current node  |
| get_pac                   |   | None   | PAC stored in the current node   |
| get_rcz                   |   | None   | RCZ stored in the current node   |
| get_lib_version           | u | <b>lib_ver</b> : 0 : Sigfox, 1 : MCU_API<br>2 : RF_API, 5 : MONARCH_API<br>6 : DEVICE_CONFIG_API               | Get version of specified module  |
| _set_rcz                  | u | <b>rc</b> : pointer to sfx_rc_t type representing the RC number (RC1=1, RC2=2, RC3C=3, RC4=4, RC5=5 or RC6=6). | Set rc   |